

Copy of DTO Component Capability 2022

Manuf. PN	Description	ATA
1850	VALVE, HYDRAULIC RELIEF	29
2406	STRIKE FLIGHT COMPARTMENT DOOR ELECTRICA	52
2758	BATTERY, MAIN AIRCRAFT, A319/A	24
4579	NICKEL CADMIUM BATTERY	24
4910	RADOME	34
5565	FIRE AND OVERHEAT DETECTION SYSTEM	26
5570	FIRE AND OVERHEAT DETECTION SYSTEM	26
5816	DETECTOR	26
6489	DETECTOR	26
6491	DETECTOR	26
7350	FIRE DETECTOR ASSEMBLIES	26
7351	FIRE DETECTOR ASSEMBLIES	26
7352	FIRE DETECTOR ASSEMBLIES	26
7353	FIRE DETECTOR ASSEMBLIES	26
7882	FIRE DETECTOR ASSEMBLIES	26
8243	FIRE DETECTOR ASSEMBLIES	26
8244	FIRE DETECTOR ASSEMBLIES	26
9810	MECHANICALLY TIMED FAUCET ASSY	38
20288	TRANSFORMER-RECTIFIER	24
27412	FILTER FUEL,IN LINE, CENTER PIPING	28
28823	POTABLE WATER SYSTEM COMPRESSOR ASSEMBLY	38
30210	ACCUMULATOR-HYDRAULIC ASSEMBLY	32
30230	ACCUMULATOR HYDRAULIC ASSEMBLY	32
30490	ACTUATOR ASSEMBLY, INBOARD GROUND SPOILER	27
44933	IGNITION EXCITER	74
45080	HYDRAULIC SOLENOID VALVE ASSEMBLY	27
45851	HARNESS, W5 CORE	73
45853	HARNESS, W5 CORE	73
45865	AIR TURBINE DRIVEN PUMP SYSTEM	73

45991	HARNESS, W5 CORE	73
46224	W6 EEC HARNESS - PW4000	73
46231	W3, W4, AND W5 EEC HARNESS - PW4000	73
46244	W6 EEC HARNESS - PW4000	73
46333	HARNESS, W5 CORE	73
46383	W3, W4, AND W5 EEC HARNESS - PW4000	73
46385	W3, W4, AND W5 EEC HARNESS - PW4000	73
46452	HARNESS, W5 CORE	73
46456	HARNESS, W5 CORE	73
46458	HARNESS, W5 CORE	73
46459	HARNESS, W5 CORE	73
46460	W6 EEC HARNESS - PW4000	73
46464	W3, W4, AND W5 EEC HARNESS - PW4000	73
46465	W3, W4, AND W5 EEC HARNESS - PW4000	77
46466	W3, W4, AND W5 EEC HARNESS - PW4000	73
46467	W3, W4, AND W5 EEC HARNESS - PW4000	73
46475	W6 EEC HARNESS - PW4000	73
46476	W3, W4, AND W5 EEC HARNESS - PW4000	73
46477	W3, W4, AND W5 EEC HARNESS - PW4000	73
46478	W3, W4, AND W5 EEC HARNESS - PW4000	73
46902	HARNESS, W5 CORE	72
46964	W6 EEC HARNESS - PW4000	73
46965	W6 EEC HARNESS - PW4000	73
46966	HARNESS, W5 CORE	73
47649	IGNITION EXCITER	74
49965	EXCITER ENG IGNITION ALT 49988	74
49988	EXCITER ENG IGNITION ALT 49988	74
50459	OVEN SINGLE, HOT FOOD SHIP IN ATA SPEC 3	25
50648	WATER QUANTITY TRANSMITTER	38
58120	ACTUATOR, THRUST REVERSER DOOR LH AND RH	78
63240	ACTUATOR THRUST REVERSER DOOR	78
64040	REGULATR FLOW, THRUST REVERSER SHIP IN A	78

65400	VALVE ASSY, SOLENOID PACKAGE 1EA PER PAC	27
66087	PRESSURE SENSITIVE FLOW LIMITER VALVE ASSEMBLY	29
66940	3-WAY NORMALLY CLOSED SOLENOID VALVE	25
66950	RESERVOIR PRESSURIZATION SHUTOFF VALVE	29
70205	MOTOR OPERATED 4 WAY VALVE	32
70267	VALVE TAIL-SKID USED ON B767 A/C 116 THR	32
70269	TAIL SKID CONTROL MODULE	32
71234	HYDRAULIC HAND PUMP	29
71404	DUAL BRAKE METERING VALVE	32
120806	AIR/OIL HEAT EXCHANGER SWITCH - PW4000	75
120837	AIR/OIL HEAT EXCHANGER SWITCH - PW4000	75
2263-01-1	COMPARTMENT TEMPERATURE INDICATOR	21
140355	VALVE DRAIN, TOILET	38
182936	OXYGEN PRESSURE INDICATOR	35
190115	EGT THERMOCOUPLE PROBE	77
213779	BOX,ENGINE CONTROL,SYNCHRONIZER CONTROL	76
233145	MOTOR ACTUATED GATE SHUTOFF VALVE	29
248697	FREQUENCY INDICATOR	24
253884	INDICATR SURFACE POSITION	22
2610-07-1	DIGITAL ELECTRONIC CHRONOMETER IPL	31
2610-08-1	PILOT AND CO-PILOT ELECTRONIC CLOCK	31
316565	HYDRAULIC RELIEF VALVE	29
340275	2-WAY 2-POSITION SHUTOFF BALL VALVE	29
340545	MOTOR ACTUATED ROTARY SELECTOR VALVE	29
340565	2-WAY 2-POSITION SHUTOFF BALL VALVE	29
341525	2-WAY 2-POSITION SHUTOFF BALL VALVE	29
371380	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	29
384300	PUMP FUEL.ENGINE.DRIVEN.EO 49-73700-3.	73
420054	W1 AND W2 EEC HARNESS - PW4000	73
420060	W1 AND W2 EEC HARNESS - PW4000	73
420061	W1 AND W2 EEC HARNESS - PW4000	73
420062	EEC WIRING HARNESS	72

420075	W1 AND W2 EEC HARNESS - PW4000	73
420076	W1 AND W2 EEC HARNESS - PW4000	73
420077	W3, W4, AND W5 EEC HARNESS - PW4000	73
420078	W3, W4, AND W5 EEC HARNESS - PW4000	73
420079	W3, W4, AND W5 EEC HARNESS - PW4000	73
420080	W3, W4, AND W5 EEC HARNESS - PW4000	73
420082	W6 EEC HARNESS - PW4000	73
420083	W6 EEC HARNESS - PW4000	73
420084	W3, W4, AND W5 EEC HARNESS - PW4000	73
420085	W1 AND W2 EEC HARNESS - PW4000	73
420086	W1 AND W2 EEC HARNESS - PW4000	73
420087	W1 AND W2 EEC HARNESS - PW4000	77
420088	W1 AND W2 EEC HARNESS - PW4000	73
420090	W3, W4, AND W5 EEC HARNESS - PW4000	73
420091	W3, W4, AND W5 EEC HARNESS - PW4000	77
420092	W3, W4, AND W5 EEC HARNESS - PW4000	73
420094	W3, W4, AND W5 EEC HARNESS - PW4000	73
420095	W6 EEC HARNESS - PW4000	73
420096	HARNESS, W5 CORE	73
420097	HARNESS, W5 CORE	73
420098	HARNESS, W5 CORE	73
420099	HARNESS, W5 CORE	73
420100	HARNESS, W5 CORE	73
420135	W6 EEC HARNESS - PW4000	73
420206	EEC WIRING HARNESS	72
420207	EEC WIRING HARNESS	72
420208	EEC WIRING HARNESS	73
420437	W1 AND W2 EEC HARNESS - PW4000	71
420438	W1 AND W2 EEC HARNESS - PW4000	71
420442	HARNESS, W5 CORE	73
420443	W3, W4, AND W5 EEC HARNESS - PW4000	73
420467	W6 EEC HARNESS - PW4000	73

420560	EEC WIRING HARNESS	73
420561	EEC WIRING HARNESS	73
420562	EEC WIRING HARNESS	73
420563	EEC WIRING HARNESS	73
420578	W6 EEC HARNESS - PW4000	73
420611	W3, W4, AND W5 EEC HARNESS - PW4000	77
420612	W1 AND W2 EEC HARNESS - PW4000	73
420613	W3, W4, AND W5 EEC HARNESS - PW4000	73
420630	W3, W4, AND W5 EEC HARNESS - PW4000	73
420745	W3, W4, AND W5 EEC HARNESS - PW4000	73
420746	HARNESS, W5 CORE	73
420748	W3, W4, AND W5 EEC HARNESS - PW4000	73
420749	W3, W4, AND W5 EEC HARNESS - PW4000	73
420750	W3, W4, AND W5 EEC HARNESS - PW4000	73
420751	HARNESS, W5 CORE	73
420752	W3, W4, AND W5 EEC HARNESS - PW4000	73
420788	W3, W4, AND W5 EEC HARNESS - PW4000	77
420789	W3, W4, AND W5 EEC HARNESS - PW4000	73
420790	W3, W4, AND W5 EEC HARNESS - PW4000	73
421101	W6 EEC HARNESS - PW4000	73
421273	W6 EEC HARNESS - PW4000	73
421660	W1 AND W2 EEC HARNESS - PW4000	73
442098	HYDROMECHANICAL UNIT	73
442124	HYDROMECHANICAL UNIT	73
442238	HYDROMECHANICAL UNIT	73
442317	HYDROMECHANICAL UNIT	73
442326	HYDROMECHANICAL UNIT	73
442355	HYDROMECHANICAL UNIT	73
442369	HYDROMECHANICAL UNIT	73
442597	HYDROMECHANICAL UNIT	73
442598	HYDROMECHANICAL UNIT	73
442653	HYDROMECHANICAL UNIT	73

472565	ENGINE FIRE AND OVERHEAT LOWER DETECTOR	26
472566	ENGINE FIRE AND OVERHEAT LOWER DETECTOR	26
472567	ENGINE FIRE AND OVERHEAT LOWER DETECTOR	26
472569	ENGINE FIRE AND OVERHEAT LOWER DETECTOR	26
472570	ENGINE FIRE AND OVERHEAT LOWER DETECTOR	26
472571	ENGINE FIRE AND OVERHEAT LOWER DETECTOR	26
472572	ENGINE FIRE AND OVERHEAT LOWER DETECTOR	26
472573	ENGINE FIRE AND OVERHEAT LOWER DETECTOR	26
472574	ENGINE FIRE AND OVERHEAT LOWER DETECTOR	26
472575	ENGINE FIRE AND OVERHEAT LOWER DETECTOR	26
472576	ENGINE FIRE AND OVERHEAT LOWER DETECTOR	26
472582	ENGINE FIRE AND OVERHEAT LOWER DETECTOR	26
472583	ENGINE FIRE AND OVERHEAT LOWER DETECTOR	26
472584	ENGINE FIRE AND OVERHEAT LOWER DETECTOR	26
472585	ENGINE FIRE AND OVERHEAT LOWER DETECTOR	26
472586	ENGINE FIRE AND OVERHEAT LOWER DETECTOR	26
473636	ENGINE FIRE AND OVERHEAT LOWER DETECTOR	26
473637	ENGINE FIRE AND OVERHEAT LOWER DETECTOR	26
473957	FIRE EXTINGUISHER CONTAINERS	26
522270	METER DC LOAD	24
522714	WATER QUANTITY INDICATOR	38
522719	WATER QUANTITY INDICATOR	38
523557	WASTE WATER QUANTITY INDICATOR	38
569668	CONSTANT DISPLACEMENT HYD MOTOR	27
569670	MOTOR ASSEMBLY	27
569672	CONSTANT DISPLACEMENT HYDRAULIC MOTOR	27
600727	CABLE ENGINE IGNITION AND POWER MANAGEME	74
601322	LOWER EGT THERMOCOUPLE HARNESS	
601323	LOWER EGT THERMOCOUPLE HARNESS	
622532	POWER TRANSFER HYDRAULIC MOTORPUMP	29
622634	CONSTANT DISPLACEMENT HYD MOTOR	27
623337	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	29

623339	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	29
624372	TURBINE, RAM AIR, LEG & PUMP ASSY	29
626447	VALVE OIL PRESSURE RELIEF FURNISHED WITH	79
651918	TIMER LAVATORY FLUSH PUMP	38
664236	THERMCPL ASSY, BOX AND CABLE	77
693335	PUMP, HYD, ELEC; A319/A320/A330	29
697836	SHIELD LPT STTR SHRD STG 4	24
699739	TRNSMSSN CSD BUILT INTO CONVENIENCE	24
701363	LIGHT, WING TIP, STROBE;AFT	33
701364	LIGHT, WING TIP, STROBE;AFT	33
702084	LIGHT, WING TIP, STROBE;AFT	33
702242	LIGHT, WING TIP, STROBE;AFT	33
702495	LIGHT, WING TIP, STROBE;AFT	33
702496	LIGHT, WING TIP, STROBE;AFT	33
702536	LIGHT STROBE WING FWD	33
713442	SWITCH ASSY, PRESSURE	24
724857	WOBBLER, VARIABLE, TIN COATED	24
725941	WOBBLER, VARIABLE, TIN COATED	24
727802	TRNSFRMR CURRENT,APU AND IDG PWR SHIP IN	24
728819	TRNSMSSN IDG-BUILT INTO CONV ASSY BY SHO	24
728825	TRNSMSSN IDG-BUILT INTO CONV ASSY BY SHO	24
729205	TRNSMSSN IDG-BUILT INTO CONV ASSY BY SHO	24
729206	TRNSMSSN IDG-BUILT INTO CONV ASSY BY SHO	24
729347	HOUSING ASSY, STATOR EXCITER ASSY	24
729349	COVER, GENERATR A	24
729552	TACHOMETER INDICATOR	29
729825	TRNSMSSN IDG-BUILT INTO CONV ASSY BY SHO	24
731376	AXIAL FLOW FAN ASSEMBLY	21
731378	AXIAL FLOW FAN	21
731510	AXIAL FLOW FAN	21
731522	AXIAL FLOW FAN	21
731530	ROTOR, ASSY	21

731534	ROTOR, ASSY	21
731764	WOBBLER, VARIABLE, TIN COATED	24
731765	WOBBLER, VARIABLE, TIN COATED	24
731966	PUMP HYD, MOTOR DRIVEN BUILT INTO CONVEN	29
733756	WOBBLER, VARIABLE, TIN COATED	24
733758	WOBBLER, VARIABLE, TIN COATED	24
733759	WOBBLER, VARIABLE, TIN COATED	24
734285	BUS POWER CONTROL UNIT	24
734933	GROUND CHECKOUT MODULE	29
735244	WOBBLER, VARIABLE, TIN COATED	24
735245	WOBBLER, VARIABLE, TIN COATED	24
735609	WOBBLER, VARIABLE, TIN COATED	24
735834	AXIAL FLOW FAN	21
735835	ROTOR, ASSY	21
738024	TRNSMSSN IDG-BUILT INTO CONV ASSY BY SHO	24
739515	INTEGRATED DRIVE GENERATOR	24
740120	CONTROL UNIT, GEN, A319/A320;	24
740121	CONTROL UNIT, GROUND POWER	24
744041	INTEGRATED DRIVE GENERATOR	24
745329	INTEGRATED DRIVE GENERATOR	24
747763	SWITCH ASSY, PRESSURE	24
749732	PANEL, LIGHT	28
749865	QUICK ATTACH-DETACH ADAPTER	24
749895	HOUSING ASSY, STATOR EXCITER ASSY	24
750696	HOUSING ASSY, STATOR EXCITER ASSY	24
750697	HOUSING ASSY, STATOR EXCITER ASSY	24
752497	HOUSING, END CAP, GENERATOR ASSY.	24
753575	TRNSMSSN IDG-BUILT INTO CONV ASSY BY SHO	24
753576	TRNSMSSN IDG-BUILT INTO CONV ASSY BY SHO	24
754257	ROTOR, IDG TRANSMISSION, FOR TRACKING PUR	24
755359	INTEGRATED DRIVE GENERATOR	24
756293	SHAFT, WORM (TRACKING ONLY)	24

756627	TRNSMSSN IDG-BUILT INTO CONV ASSY BY SHO	24
756692	ROTOR,IDG TRANSMISSION, FOR TRACKING PUR	24
756955	QUICK ATTACH-DETACH ADAPTER	24
757179	HOUSING, SUPPORT-MATCHED SET SETUP FOR	24
757483	WOBBLER, VARIABLE, TIN COATED	24
758640	WOBBLER, VARIABLE, TIN COATED	24
762246	QUICK ATTACH-DETACH ADAPTER	24
764037	SUPPORT, BEARING - GOVERNOR	24
764224	LUBRICATION AND SCAVENGE OIL PUMP ASSY	79
764635	BLOCK, TRANSMISSION - IDG	24
764855	WOBBLER, VARIABLE, TIN COATED	24
765241	TRNSMSSN IDG-BUILT INTO CONV ASSY BY SHO	24
765412	THERMOCOUPLE, 17 EGT	77
766088	INTEGRATED DRIVE GENERATOR	24
766342	VALVE FUEL PRESSURIZING AND DUMP RESTRIC	73
768504	TRNSMSSN IDG-BUILT INTO CONV ASSY BY SHO	24
771095	THERMOCOUPLE, 17 EGT	77
773547	THERMOCOUPLE, 17 EGT	77
776443	THERMCPL ASSY, BOX AND CABLE	77
789642	VALVE,COMPRESSOR,AIR.BLEED 13TH STAGE	75
789643	VALVE,COMPRESSOR,AIR.BLEED 13TH STAGE	75
790312	CONTROL, 6TH STAGE PRESSURE RATIO	75
801673	VALVE,COMPRESSOR,AIR.BLEED 13TH STAGE	75
805373	CONTROL, 6TH STAGE PRESSURE RATIO	75
811131	VALVE OIL PRESSURE RELIEF FURNISHED WITH	79
825500	PW4000 FUEL PUMP	73
849589	VARIABLE DISPLACEMENT HYDRAULIC PUMP	29
861555	TURBINE, RAM AIR, LEG & PUMP ASSY	29
887087	CONSTANT DISPLACEMENT HYDRAULIC MOTOR	27
887477	AC DRIVEN MOTORPUMP ASSEMBLY	29
887673	VARIABLE DISPLACEMENT HYDRAULIC PUMP	29
892480	AIRCRAFT FIRE EXTINGUISHERS, LIQUID TYPE	26

898150	CONTAINR, FIRE EXTNGSHR,S/L 60 MOS BUILT	26
898737	FIRE DECTECTOR ASSEMBLY	26
898738	FIRE DECTECTOR ASSEMBLY	26
898870	FIRE EXTINGUISHER CONTAINER	26
901541	DETECTOR	26
901542	DETECTOR	26
901560	ENGINE FIRE AND OVERHEAT UPPER DETECTOR	26
901561	ENGINE FIRE AND OVERHEAT UPPER DETECTOR	71
901905	MODEL 801RDS FIRE/OVERHEAT DETECTOR ASSEMBLY	71
901906	MODEL 801RDS FIRE/OVERHEAT DETECTOR ASSEMBLY	26
901907	MODEL 801RDS FIRE/OVERHEAT DETECTOR ASSEMBLY	26
901908	MODEL 801RDS FIRE/OVERHEAT DETECTOR ASSEMBLY	71
902013	MODEL 801-DRSS FIRE/OVERHEAT DETECTOR ASSEMBL	26
902014	MODEL 801-DRSS FIRE/OVERHEAT DETECTOR ASSEMBL	26
902020	MODEL 801-DRSS FIRE/OVERHEAT DETECTOR ASSEMBL	26
902862	FIRE/OVERHEAT DETECTOR ASSEMBLY	26
902864	FIRE/OVERHEAT DETECTOR ASSEMBLY	26
973600	CONSTANT DISPLACEMENT HYDRAULIC MOTOR	27
974540	PUMP, HYD, ELEC; A319/A320/A330	29
1122797	THERMCPL SCAVENGE OIL TEMPERATURE MUST B	79
1702457	HOUSING ASSY, STATOR EXCITER ASSY	24
9010-1-2	PILOT AND CO-PILOT CLOCK	31
9010-1-3	PILOT AND CO-PILOT CLOCK	31
2670296	GEAR OPERATED DOOR SEQUENCE VALVE ASSEMBLY	32
9693-1-1	SPIGOT ASSEMBLY	38
9693-1-3	SPIGOT ASSEMBLY	38
3311586	SHELL, ACCUMULATOR	27
4037230	LIGHT PANEL PACKAGE 1EA PER RIGID PACK	34
4039935	SWITCH EPR SYNCHRONIZER DRIVER	77
4100937	AXIAL FLOW FAN	21
4101054	HOUSING, INSOURCE NWA PART TRKING ONLY	21
4101140	ROTOR, HOUSING, ELECTRONIC FWD COMPT..	21

4101192	ROTOR, ASSY	21
4101193	ROTOR, ASSY	21
4205401	VARIABLE DELIVERY HYDRAULIC PUMP	29
4322268	LIGHT, ASSY, LOGO; INBD LH SIDE	33
4322275	LIGHT, ASSY, LOGO; INBD LH SIDE	31
4333302	LOGO LIGHT	31
4333318	LOGO LIGHT	31
4333325	LOGO LIGHT	33
4333332	LOGO LIGHT	31
5007436	LUBRICATION AND SCAVENGE OIL PUMP	79
5008437	LUBRICATION AND SCAVENGE OIL PUMP ASSY	79
5008798	LUBRICATION AND SCAVENGE OIL PUMP ASSY	79
5010224	FUEL PUMP	73
5262100	DOOR OPENING/SNUBBING ACTUATOR	25
6005305	TRANSDCR MLG WHEEL SPEED	32
6006090	VALVE, BRAKE ASSY	32
7579078	HYDRAULIC OIL FILTER	29
7700198	VALVE VACUUM WASTE SYSTEM RINSE	38
7820646	SCREW, BALL SCREW ASSY	27
7820647	SCREW, BALL SCREW ASSY	27
7820648	SCREW, BALL SCREW ASSY	27
7820649	SCREW, BALL SCREW ASSY	27
7820665	SCREW, BALL SCREW ASSY	27
7820679	SCREW, BALL SCREW ASSY	27
7820686	SCREW, BALL SCREW ASSY	27
7820922	SCREW BALL, T/E FLAP, PRE SB 757-27A0139	27
7820923	SCREW BALL, T/E FLAP, PRE SB 757-27A0139	27
7820924	SCREW BALL, T/E FLAP, PRE SB 757-27A0139	27
7821199	SCREW, BALL SCREW ASSY	27
7821200	SCREW, BALL SCREW ASSY	27
7821201	SCREW, BALL SCREW ASSY	27
7821341	SCREW BALL, T/E FLAP, PRE SB 757-27A0139	27

7821342	SCREW BALL, T/E FLAP, PRE SB 757-27A0139	27
7900013	VALVE, LAV WASTE DRAIN,A/C 629 -699 AND	38
7900063	TOILET, LAV (REPLD BY 381001993)	38
7900064	TOILET, LAV (REPLD BY 381001993)	38
7900067	SCREW BALL, T/E FLAP, PRE SB 757-27A0139	27
7900073	TOILET VACUUM, FWD LAV MUST BE USABLE ON	38
7900074	TOILET VACUUM, FWD LAV MUST BE USABLE ON	38
7900101	VACUUM TOILET ASSEMBLY	38
7900102	VACUUM TOILET ASSEMBLY	38
7900103	TOILET LAVATORY, VACUUM FLUSH, A/C POSIT	38
7900104	TOILET LAVATORY, VACUUM FLUSH, A/C POSIT	38
9048466	EXCITER IGNITION MUST BE USABLE ON	74
9048467	EXCITER IGNITION MUST BE USABLE ON	74
9350021	VALVE, DRAIN, LAVATORY- A320.	38
9350022	VALVE, DRAIN, LAVATORY- A320.	38
9350024	VALVE AUTO DRAIN, LAVATORY WATER SYSTEM	38
33700002	FIRE EXTINGUISHERS	26
33900004	378 CUBIC INCH FIRE EXTINGUISHER	26
34600010	BOTTLE FIRE, FWD CARGO FWD BOTTLE 800 CU	26
34600012	630 CUBIC INCH FIRE EXTINGUISHERS	26
34600013	630 CUBIC INCH FIRE EXTINGUISHERS	26
72077500	STEAM OVEN DS7000 LH	25
89794015	CYLINDER, ASSY, OXYGEN	35
89799015	CYLINDER, ASSY, OXYGEN	35
104652001	THRUST REVERSER COWL OPENING ACTUATOR	78
201134006	HARNESS, 2M,AXEL;RH;MLG 201375XXX	32
201134008	HARNESS, 2M,AXEL;RH;MLG 201375XXX	32
201134016	HARNESS, 2M,AXEL;RH;MLG 201375XXX	32
201158008	HARNESS, 2M,AXEL;RH;MLG 201375XXX	32
201159008	HARNESS, 2M,AXEL;RH;MLG 201375XXX	32
201400005	HARNESS, 2M,RH;MLG 201375XXX;	32
201400006	HARNESS, 2M,RH;MLG 201375XXX;	32

201401005	HARNESS, 1M, AXEL; L/R; MLG 20158XXX	32
201520006	HARNESS, 2M, AXEL; RH; MLG 201375XXX	32
201520008	HARNESS, 2M, AXEL; RH; MLG 201375XXX	32
201590003	ACTUATOR, MLG, RETRACT; WITH ATTACH PINS	32
272010026	CONTROL CONV ASSY, HORIZONTAL STABILIZER	27
499001513	PANEL APU CONTROL STATIC SENSITIVE	49
499701491	PANEL APU CONTROL STATIC SENSITIVE	49
638003001	COWL OPENING HYDRAULIC POWER UNIT ASSEMBLY	78
716101174	AFT ENGINE MOUNT - PW2000	71
166321430	COMPUTER, PROBE HEAT, A319/A32...	30
390613030	FCD 66 FULL COLOR DISPLAY UNIT	31
390613040	FCD 66 FULL COLOR DISPLAY UNIT	31
390713030	FCD 66 FULL COLOR DISPLAY UNIT	31
390713040	FCD 66 FULL COLOR DISPLAY UNIT	31
394512350	COMPUTER, ELEV, ELAC	27
394512810	COMPUTER, ELEV, ELAC	27
394512820	COMPUTER, ELEV, ELAC	27
394512821	COMPUTER, ELAC, ELEVATOR AILERON	27
394512910	COMPUTER, ELAC, ELEVATOR AILERON	27
395798511	UNIT, ENGINE INTERFACE, EIU	73
961532505	COMPUTER, DISPLAY MGT; USED ON PREMOD 3166	31
961532506	COMPUTER, DISPLAY MGT; USED ON PREMOD 3166	31
001048-101	UNIT AIR DATA SWITCHING "RVSM CRITICAL"	34
0016-0015-	CAP RINSE FTG, WASTE TANK PACKAGE 1 EA P	38
0016-0015-	CAP RINSE FTG, WASTE TANK PACKAGE 1 EA P	38
002A0003-1	FORWARD ENTRY DOOR ASSEMBLY	52
002A0016-3	ELEVATOR ASSEMBLY AND TAB ASSEMBLY	55
002A0016-3	ELEVATOR ASSEMBLY AND TAB ASSEMBLY	55
003-005-00	PROBE FUEL, FAULT ISOLATION JUNCTION CEN	28
003-005-00	PROBE FUEL, FAULT ISOLATION JUNCTION CEN	28
007LG027D	UNIT, CONTROL INTERFACE, LG; A330	32
007LG037E	UNIT, CONTROL INTERFACE, LG; A330	32

007LG038G	UNIT, CONTROL INTERFACE, LG; A330	32
007LG049G	UNIT, CONTROL INTERFACE, LG; A330	32
0104244-00	LOGO LIGHT ASSEMBLY	33
0104244-00	LOGO LIGHT ASSEMBLY	33
0104244-00	LOGO LIGHT ASSEMBLY	33
0104244-00	LOGO LIGHT ASSEMBLY	33
0111-0005-	SENSOR WASTE TANK LEVEL DETECTOR USED ON	38
011100-1	LIGHT, WING TIP, STROBE;AFT	33
011100-2	LIGHT, WING TIP, STROBE;AFT	33
0111153-00	MANIFOLD ASSEMBLY	78
0111153-01	MANIFOLD ASSEMBLY	78
0111153-01	MANIFOLD ASSEMBLY	78
012N8461-1	PW2000 ENGINE CORE COWL ASSEMBLY	71
012N8461-1	PW2000 ENGINE CORE COWL ASSEMBLY	71
012N8461-1	PW2000 ENGINE CORE COWL ASSEMBLY	71
012N8461-2	PW2000 ENGINE CORE COWL ASSEMBLY	71
012N8461-2	PW2000 ENGINE CORE COWL ASSEMBLY	71
012N8461-2	PW2000 ENGINE CORE COWL ASSEMBLY	71
012N8461-2	PW2000 ENGINE CORE COWL ASSEMBLY	71
012N8706-1	OUTBOARD INBOARD FLAPS TEE GEARBOX ASSEMBLY	27
012N8706-1	OUTBOARD INBOARD FLAPS TEE GEARBOX ASSEMBLY	27
012N8706-1	OUTBOARD INBOARD FLAPS TEE GEARBOX ASSEMBLY	27
012N8706-1	OUTBOARD INBOARD FLAPS TEE GEARBOX ASSEMBLY	27
012N8706-1	OUTBOARD INBOARD FLAPS TEE GEARBOX ASSEMBLY	27
012N8706-1	OUTBOARD INBOARD FLAPS TEE GEARBOX ASSEMBLY	27
012N8706-7	OUTBOARD INBOARD FLAPS TEE GEARBOX ASSEMBLY	27
012N8706-8	OUTBOARD INBOARD FLAPS TEE GEARBOX ASSEMBLY	27
012N8706-9	OUTBOARD INBOARD FLAPS TEE GEARBOX ASSEMBLY	27
012N8771-5	NO. 2 OPENABLE WINDOW ASSEMBLY	56
012N8771-6	NO. 2 OPENABLE WINDOW ASSEMBLY	56
012N8892-1	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	57
012N8892-1	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	57

012N8892-1	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	57
012N8892-1	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	57
012N8892-1	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	57
012N8892-1	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	57
012N8892-1	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	57
012N8892-2	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	57
012N8892-2	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	57
012N8892-2	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	57
012N8892-2	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	57
012N8892-5	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	57
012N8892-5	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	57
012N8892-5	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	57
012N8892-5	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	57
012N8892-6	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	57
012N8892-6	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	57
012N8892-7	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	57
012N8892-7	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	57
012N8892-7	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	57
012N8892-9	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	57
015T0094-8	ENGINE THROTTLE CONTROL BOX - CF6-80A, CF6-80C2	76
015T0376-1	ENGINE THROTTLE CONTROL BOX - CF6-80A, CF6-80C2	76
015T0376-1	ENGINE THROTTLE CONTROL BOX - CF6-80A, CF6-80C2	76
015T0376-9	ENGINE THROTTLE CONTROL BOX - CF6-80A, CF6-80C2	76
015T0449-6	INTEGRTR ASSY RH POST OFF WING ESCAPE SY	25
015T0449-7	INTEGRTR ASSY RH POST OFF WING ESCAPE SY	25
015T0540-2	CORE COWL ASSEMBLY, LH OR RH, CF6-80A	71
015T0540-3	CORE COWL ASSEMBLY, LH OR RH, CF6-80A	71
015T0540-3	CORE COWL ASSEMBLY, LH OR RH, CF6-80A	71
015T0540-3	CORE COWL ASSEMBLY, LH OR RH, CF6-80A	71
015T0540-3	CORE COWL ASSEMBLY, LH OR RH, CF6-80A	71
015T0540-3	CORE COWL ASSEMBLY, LH OR RH, CF6-80A	71
015T0540-X	CORE COWL ASSEMBLY, LH OR RH, CF6-80A	71
015T1415-1	INBOARD TRAILING EDGE FLAP AFT FLAP ASSEMBLY	27

015T1507-7	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
015T1507-7	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
015T1507-7	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
015T1507-7	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
015T1507-7	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
015T1507-7	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
015T1507-7	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
015T1507-7	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
015T1507-7	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
015T1507-7	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
015T1507-7	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
015T1507-7	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
015T1507-7	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
015T1507-X	LEADING EDGE OUTBOARD SLAT NO.3,10 STRUCTURE ASSEM	
018550-000	NICKEL CADMIUM BATTERY	24
01930-005	TANK VACUUM WASTE,	38
01930-007	TANK VACUUM WASTE,	38
01N65920	TRNSMTTR, ELT-ADT.SURVIVAL BEACONONT ISS	25
0200330-00	LIGHT GALLEY, FWD, WORK SHIP IN ATA SPEC	33
020-070-00	TRNSMTTR FUEL QTY PROBE NBR 9.	28
020-070-00	TRNSMTTR FUEL QTY PROBE NBR 9.	28
020-070-00	TRNSMTTR FUEL QTY PROBE NBR 9.	28
020-070-00	TRNSMTTR FUEL QTY PROBE NBR 9.	28
020-070-00	TRNSMTTR FUEL QTY PROBE NBR 9.	28
020-070-00	TRNSMTTR FUEL QTY PROBE NBR 9.	28
020-070-00	TRNSMTTR FUEL QTY PROBE NBR 9.	28
020-070-00	TRNSMTTR FUEL QTY PROBE NBR 9.	28
020-070-00	TRNSMTTR FUEL QTY PROBE NBR 9.	28
020-070-01	TRNSMTTR FUEL QTY PROBE NBR 9.	28
020-070-01	TRNSMTTR FUEL QTY PROBE NBR 9.	28
020-070-01	TRNSMTTR FUEL QTY PROBE NBR 9.	28
020-070-10	TRNSMTTR FUEL QTY PROBE NBR 9.	28
0218-0032-	VALVE DRAIN, LAVATORY AFT USED ON A/C 67	38

024147-000	BATTERY MODEL NO. 539CH-1	24
03-170-000	DOOR, DETAIL; GALLEY COMPT 5-3/4 & 5-8/9	25
04P23-1	DUAL 3-WAY PNEUMATIC SOLENOID AIR VALVE	75
04P23-10	DUAL 3-WAY PNEUMATIC SOLENOID AIR VALVE	75
04P23-11	DUAL 3-WAY PNEUMATIC SOLENOID AIR VALVE	75
04P23-12	DUAL 3-WAY PNEUMATIC SOLENOID AIR VALVE	75
04P23-4	DUAL 3-WAY PNEUMATIC SOLENOID AIR VALVE	75
04P23-5	DUAL 3-WAY PNEUMATIC SOLENOID AIR VALVE	75
04P23-7	DUAL 3-WAY PNEUMATIC SOLENOID AIR VALVE	75
04P23-8	DUAL 3-WAY PNEUMATIC SOLENOID AIR VALVE	75
050-014-00	COMPNSTR FUEL QTY, TOTAL	28
050-014-00	COMPNSTR FUEL QTY, TOTAL	28
050-014-00	COMPNSTR FUEL QTY, TOTAL	28
065-50000-	COMPUTER, SLAT/FLAP CONTROL, SFCC; A330	27
066-01127-	TRA-67A ATC TRANSPONDER	34
066-01127-	TRA-67A ATC TRANSPONDER	34
066-01127-	TRA-67A ATC TRANSPONDER	34
066-01127-	TRA-67A ATC TRANSPONDER	34
066-50001-	IVA-81A TRAFFIC ADVISORY/VERTICAL SPEED INDICATOR	34
066-50008-	RTA-4B RECEIVER-TRANSMITTER	34
066-50008-	RTA-4B RECEIVER-TRANSMITTER	34
066-50008-	RTA-4B RECEIVER-TRANSMITTER	34
066-50008-	RTA-4B RECEIVER-TRANSMITTER	34
071-01477-	CTA-81A CONTROL UNIT	34
071-01477-	CTA-81A CONTROL UNIT	34
071-01477-	CTA-81A CONTROL UNIT	34
071-01477-	CTA-81A CONTROL UNIT	34
071-01477-	CTA-81A CONTROL UNIT	34
071-01477-	CTA-81A CONTROL UNIT	34
071-01503-	CTA-81A CONTROL UNIT	34
071-01503-	CTA-81A CONTROL UNIT	34
071-01503-	CTA-81A CONTROL UNIT	34

0711346-00	VALVE THRUST REVERSER HYD CONTROL FUSELA	78
0711480-00	VALVE KIT ASSY-SHUTOFF T/R	78
07P95-4	PNEUMATIC RELAY VALVE - PW4000	75
07P95-7	PNEUMATIC RELAY VALVE - PW4000	75
07P95-8	PNEUMATIC RELAY VALVE - PW4000	75
07P95-9	PNEUMATIC RELAY VALVE - PW4000	75
0801801-10	OBSERVER SEAT	25
0801801-12	OBSERVER SEAT	25
0801801-4	OBSERVER SEAT	25
0801801-7	OBSERVER SEAT	25
0801801-9	OBSERVER SEAT	25
080-20288-	TRANSFORMER-RECTIFIER	24
080-20325-	TRNSFRMR RECTIFIER 50AMP UNREGULATED DC	24
080-20705-	TRANSFORMER-RECTIFIER POWER SUPPLY	24
085878-046	ACCUMULATOR, BRAKE, A319/A320/A330	32
0861EW1	ANGLE OF ATTACK SENSOR	34
0861FL	ANGLE OF ATTACK SENSOR	34
0861FL1	ANGLE OF ATTACK SENSOR	34
0871BN3-1	ICE DETECTOR	30
0871BN3-2	ICE DETECTOR	30
0871BN3-4	ICE DETECTOR	30
0871DL	ICE DETECTOR	30
0871DL1	ICE DETECTOR	30
0871DL5	ICE DETECTOR	30
0871DL6	ICE DETECTOR	30
088256-046	ACCUMULATOR, BRAKE, A319/A320/A330	32
088259-046	ACCUMULATOR, POWER, A330	29
08T2245-10	VALVE LAV DRAIN USED ON AC 9015 AND SUB	38
09033070-1	LIGHT ASSY, WING POSITION, RH	33
09033070-2	LIGHT ASSY, WING POSITION, RH	33
098C00160	MLG DOWNLOCK OPERATED DOOR SEQUENCE VALVE A	32
098C00210	MLG UPLOCK OPERATED SEQUENCE VALVE ASSEMBLY	32

0A220-0271	HEADREST CAPTAIN AND FIRST OFFICER	25
0FL1000A1	LIGHT LAV 1A2L, 2F1L, 4F1R	33
0FV0050A0	LATCH, DOOR COCKPIT	52
0YX1100A0	ENHANCED SECURITY FLIGHT DECK DOOR SYSTEM	52
0YX1500A0	ENHANCED SECURITY FLIGHT DECK DOOR SYSTEM	52
10000165-1	TRANSDCR, ANGLE OF ATTACK	34
100-0202-0	BATTERY IRU, USED ON A/C 901-985 MOD PER	34
10-0067-7	EMERGENCY EXIT LIGHT	33
10-0067-9	EMERGENCY EXIT LIGHT	33
1001002-2	WEATHERMASTER RADOME	34
1001002-7	WEATHERMASTER RADOME	53
1-002-0102	STATIC INVERTER	24
1-002-0102	STATIC INVERTER	24
1-002-0102	STATIC INVERTER	24
1-002-0102	STATIC INVERTER	24
1-002-0102	STATIC INVERTER	24
1-002-0102	STATIC INVERTER	24
1-002-0102	INVERTER.STATIC SENSITIVE	24
10037-0750	FUEL QUANTITY INDICATOR	28
1005080-12	VALVE, FLIGHT SPOILER,PRESSURE REDUCER,W	27
1007571-1	WEATHERMASTER RADOME	34
10078-0101	LOAD SELECT INDICATOR	28
10079-01	LOAD SELECT CONTROL UNIT	28
10079-02	LOAD SELECT CONTROL UNIT	28
10080-0101	INDICATOR MODULE	28
10080-0201	INDICATOR MODULE	28
1009100-3	RADOME FUSELAGE NOSE, WHITE, USD ON A/C..	53
1009100-5	RADOME FUSELAGE NOSE, WHITE, USD ON A/C..	53
100T0300-5	ELEVATOR, HAIL DAMAGE UPPER SURFACE	27
100T0300-6	ELEVATOR, HAIL DAMAGE UPPER SURFACE	27
10-1005-27	SIGN LAVATORY OCCUPIED	33
10101000B	VALVE LAV DRAIN USED ON AC 9015 AND SUB	38

10101000B	VALVE LAV DRAIN USED ON AC 9015 AND SUB	38
10101000C	VALVE, LAV WASTE DRAIN,A/C 629 AND SUBS	38
10101000C	VALVE, LAV WASTE DRAIN,A/C 629 AND SUBS	38
10101000C	VALVE, LAV WASTE DRAIN,A/C 629 AND SUBS	38
10-1073-1	SIGN EXIT HSG EMERGENCY LIGHT DR	33
10-1076-3B	SIGN, EXIT	33
10-1076-53	SIGN, EXIT	33
10-1076-55	SIGN, EXIT	33
10-1076-5B	SIGN, EXIT	33
10-1076-5C	SIGN, EXIT	33
10166N01N	RUDDER TRIM INDICATOR ASSEMBLY	27
101E1013P	CARD ASSEMBLY, CIRCUIT - EEC (ESD)	73
101E9001G	ELECTRONIC CONTROL UNIT (ECU) - CF6-80C2	73
1026V0700	No.4 BEARING SCAVENGE VALVE	79
1026V0800	No.4 BEARING SCAVENGE VALVE	79
1026V0600-	No.4 BEARING SCAVENGE VALVE	79
10285N01R	INDICATR TACHOMETER	49
10290N01Y	WATER QUANTITY INDICATOR	38
102ADP6-2	PANEL ANNUNCIATOR, (USED ON IRS AC ONLY)	33
103087-02	DOOR, DETAIL; GALLEY COMPT 5-3/4 & 5-8/9	25
103087-04	DOOR, DETAIL; GALLEY COMPT 5-3/4 & 5-8/9	25
10-3200-6	VALVE,GATE SHUTOFF,See Basic Data Text	29
10-353875-	EXCITER, IGNITION, ENGINE, BENDIX	74
10-353875-	EXCITER, IGNITION, ENGINE, BENDIX	74
10-353875-	EXCITER, IGNITION, ENGINE, BENDIX	74
10-353875-	EXCITER, IGNITION, ENGINE, BENDIX	74
10-383900-	EXCITER, ENG IGNITION	74
10-383900-	EXCITER, ENG IGNITION	74
10-383900-	EXCITER, ENG IGNITION	74
10-383900-	EXCITER, ENG IGNITION	74
10-383900-	EXCITER, ENG IGNITION	74
10-383900-	EXCITER, ENG IGNITION	74

10-383900-	EXCITER, ENG IGNITION	74
1045L14A00	PARTITION,	25
1045L23A00	PARTITION,	25
1045L43A00	PARTITION,	25
1045L49A00	PARTITION,	25
10486N01Y	WATER QUANTITY INDICATOR	38
105090-67	SEAT ATTENDANT, AFT GALLEY SHIP IN ATA S	25
1051T100-1	ACTUATOR, APU INLET DOOR	49
1051T100-1	ACTUATOR, APU INLET DOOR	49
1051T100-1	ACTUATOR, APU INLET DOOR	49
1051T100-2	ACTUATOR, APU INLET DOOR	49
1051T100-2	ACTUATOR, APU INLET DOOR	49
1051T100-2	ACTUATOR, APU INLET DOOR	49
1051T100-9	ACTUATOR, APU INLET DOOR	49
10534G01C	INDICATOR, OXYGEN PRESSURE	31
1058V0400	VALVE START BLEED CONTROL THREE VALVE BL	75
1058V0400-	VALVE START BLEED CONTROL THREE VALVE BL	75
1058V0400-	VALVE START BLEED CONTROL THREE VALVE BL	75
1058V0600	VALVE START BLEED CONTROL THREE VALVE BL	75
105984-2	VALVE, ANTI-ICING, SHUT-OFF,3-1/2 IN DIA	30
105E7206G	THRUST MANAGEMENT COMPUTER	22
10-60508-1	3 1/2 INCH DIAMETER CHECK VALVE	36
10-60508-3	3 1/2 INCH DIAMETER CHECK VALVE	36
10-60554-1	HYDRAULIC OIL QUANTITY TRANSMITTER	29
10-60554-2	HYDRAULIC OIL QUANTITY TRANSMITTER	29
10-60554-2	HYDRAULIC OIL QUANTITY TRANSMITTER	29
10-60554-3	HYDRAULIC OIL QUANTITY TRANSMITTER	29
10-60554-3	SWITCH, HYD PRESSURE	29
10-60554-3	HYDRAULIC OIL QUANTITY TRANSMITTER	29
10-60554-3	HYDRAULIC OIL QUANTITY TRANSMITTER	29
10-60554-4	HYDRAULIC OIL QUANTITY TRANSMITTER	29
10-60554-4	HYDRAULIC OIL QUANTITY TRANSMITTER	29

10-60556-2	PUMP MOTOR PACKAGE	29
10-60556-3	PUMP MOTOR PACKAGE	29
10-60556-3	PUMP MOTOR PACKAGE	29
10-60561-1	VALVE HYD, RESERVOIR DRAIN	29
10-60783-1	VALVE WASTE WATER TANK DRAIN ALT 10-6078	38
10-60783-1	VALVE WASTE WATER TANK DRAIN ALT 10-6078	38
10-60783-2	VALVE WASTE WATER TANK DRAIN ALT 10-6078	38
10-60783-4	VALVE WASTE WATER TANK DRAIN ALT 10-6078	38
10-60783-6	VALVE WASTE WATER TANK DRAIN ALT 10-6078	38
10-60811-3	RUDDER TRIM INDICATOR	27
10-60811-8	HYDRAULIC SOLENOID VALVE ASSEMBLY	27
10-609482-	HARNESS EEC WIRING SHIP IN CATEGORY 2 CO	72
10-609482-	HARNESS EEC WIRING SHIP IN CATEGORY 2 CO	72
10-609482-	HARNESS EEC WIRING SHIP IN CATEGORY 2 CO	72
10-609482-	HARNESS EEC WIRING SHIP IN CATEGORY 2 CO	72
10-609482-	HARNESS EEC WIRING SHIP IN CATEGORY 2 CO	72
10-61093-2	CONTROL VALVE	32
106-1-1100	ACTUATOR, APU, AIR INLET	49
10-617075-	EXCITER, IGNITION	49
10-617075-	EXCITER, IGNITION	49
10-617980-	IGNITION EXCITERS	74
10-61800-1	SEAT, INSOURCE CUSTOMER NWA FOR TRACKING	30
10-61800-6	SEAT, INSOURCE CUSTOMER NWA FOR TRACKING	76
10-61985-3	HYDRAULIC AUTOPILOT ACTUATOR ASSEMBLY	22
10-61985-5	HYDRAULIC AUTOPILOT ACTUATOR ASSEMBLY	27
10-62009-1	CABIN AIR RECIRCULATION FAN	21
10-62009-2	FAN, AIR, RECIRCULATION; CARGO COMPARTME	21
10-62009-3	FAN, AIR, RECIRCULATION; CARGO COMPARTME	21
10-62018-6	MODULE CONTROL VALVE, THRUST REVERSER	29
10-62018-8	MODULE CONTROL VALVE, THRUST REVERSER	29
10-621630-	IGNITION EXCITERS	74
10-62167-3	VARIABLE DISPLACEMENT HYDRAULIC PUMP	29

10-62187-2	CONTINUOUS FIRE & OVERHEAT DET CONTROL UNIT	26
10-62204-1	ANTISKID VOLUMETRIC FUSE ASSEMBLY	32
10-631045-	IGNITION EXCITERS	74
10-631045-	IGNITION EXCITERS	74
10-631045-	IGNITION EXCITERS	74
106788A13	ACTUATOR, APU FUEL, SHUTOFF VALVE, MOTOR	27
106792A10	ACTUATOR ASSY, FUEL FILL SHIP IN ATA SPE	28
107226B	VALVE CROSSFEED, MECHANICAL PLUG-IN TYPE	28
107474-1	PRESSURE REGULATOR AND SHUTOFF PILOT	36
107484-3	HIGH STAGE REGULATOR	36
107484-5	HIGH STAGE REGULATOR	36
107484-6	HIGH STAGE REGULATOR	36
107484-7	HIGH STAGE REGULATOR	36
107492-1	BLEED AIR REGULATOR	36
107492-2	BLEED AIR REGULATOR	36
107492-3	BLEED AIR REGULATOR	36
107492-5	BLEED AIR REGULATOR	36
107492-6	BLEED AIR REGULATOR	36
107494-2	REVERSE FLOW CHECK CONTROL VALVE	
107494-3	REVERSE FLOW CHECK CONTROL VALVE	36
107494-4	REVERSE FLOW CHECK CONTROL VALVE	36
1082000-2	DIRECTIONAL CONTROL VALVE ASSEMBLY	78
1082000-3	DIRECTIONAL CONTROL VALVE ASSEMBLY	78
1082000-4	DIRECTIONAL CONTROL VALVE ASSEMBLY	78
1082000-5	DIRECTIONAL CONTROL VALVE ASSEMBLY	78
109486-5-1	VALVE PNEUMATIC SHUT-OFF APU BLEED AIR.	49
109486-6-1	VALVE PNEUMATIC SHUT-OFF APU BLEED AIR.	49
1097-1AA	SEAT SECOND OBSERVER SHIP IN ATA SPEC 30	25
10P22-2	NO. 3 BEARING OIL SHUTOFF VALVE	79
10P22-3	NO. 3 BEARING OIL SHUTOFF VALVE	79
10P22-4	NO. 3 BEARING OIL SHUTOFF VALVE	79
10P22-5	NO. 3 BEARING OIL SHUTOFF VALVE	79

11-0049	CHARGER ASSY, BATTERY	25
11050-11	COFFEE MAKER	25
1106-3AB	FIRST OBSERVER SEAT	25
1108V0100	DUAL 3-WAY PNEUMATIC SOLENOID AIR VALVE - PW4000	75
1108V0100	DUAL 3-WAY PNEUMATIC SOLENOID AIR VALVE - PW4000	75
1108V0100	DUAL 3-WAY PNEUMATIC SOLENOID AIR VALVE - PW4000	75
1108V0100	DUAL 3-WAY PNEUMATIC SOLENOID AIR VALVE - PW4000	75
1109V0300	DUAL 3-WAY PNEUMATIC SOLENOID AIR VALVE - PW4000	75
1109V0300	DUAL 3-WAY PNEUMATIC SOLENOID AIR VALVE - PW4000	75
1109V0300	DUAL 3-WAY PNEUMATIC SOLENOID AIR VALVE - PW4000	75
1109V0300	DUAL 3-WAY PNEUMATIC SOLENOID AIR VALVE - PW4000	75
11-10579	FILTER STARTER VALVE, IN-LINE, CASO SPEC	80
1110V0500	TURBINE BLADE/VANE COOLING VALVE	75
1110V0500	TURBINE BLADE/VANE COOLING VALVE	75
1110V0500	TURBINE BLADE/VANE COOLING VALVE	75
1110V0500	TURBINE BLADE/VANE COOLING VALVE	75
1110V0500	TURBINE BLADE/VANE COOLING VALVE	75
1110V0500	TURBINE BLADE/VANE COOLING VALVE	75
1110V0500	TURBINE BLADE/VANE COOLING VALVE	75
1111-0001	WASTE TANK OVERFILL DETECTOR	38
1111-0006	WASTE TANK OVERFILL DETECTOR	38
1-111-0102	STATIC INVERTER	24
1115V0700	BLEED AIR VALVE	75
1115V0700	BLEED AIR VALVE	75
1115V0700	BLEED AIR VALVE	75
1115V0700	BLEED AIR VALVE	75
1116-3AA	FIRST OBSERVER SEAT	25
1116-4AA	FIRST OBSERVER SEAT	25
1121SD2-10	REGULATR HYD FLOW	29
11225-3	COFFEE MAKER	25
112E9436P	CARD ASSEMBLY, CIRCUIT - EEC	73
112E9437P	CARD ASSEMBLY, CIRCUIT - SDU	73
112E9492G	CARD ASSEMBLY, CIRCUIT; EEC	73

113A2100-4	INBOARD FLAP MAIN FLAP FINAL ASSEMBLY	27
113A2100-4	INBOARD FLAP MAIN FLAP FINAL ASSEMBLY	27
113A2100-4	INBOARD FLAP MAIN FLAP FINAL ASSEMBLY	27
113A2100-4	INBOARD FLAP MAIN FLAP FINAL ASSEMBLY	27
113A2100-5	INBOARD FLAP MAIN FLAP FINAL ASSEMBLY	27
113A2100-5	INBOARD FLAP MAIN FLAP FINAL ASSEMBLY	27
113A2100-5	INBOARD FLAP MAIN FLAP FINAL ASSEMBLY	27
113A2100-6	INBOARD FLAP MAIN FLAP FINAL ASSEMBLY	27
113A2100-6	INBOARD FLAP MAIN FLAP FINAL ASSEMBLY	27
113A2100-6	INBOARD FLAP MAIN FLAP FINAL ASSEMBLY	27
113A2100-6	INBOARD FLAP MAIN FLAP FINAL ASSEMBLY	27
113A2100-6	INBOARD FLAP MAIN FLAP FINAL ASSEMBLY	27
113A2100-6	INBOARD FLAP MAIN FLAP FINAL ASSEMBLY	27
113A2100-6	INBOARD FLAP MAIN FLAP FINAL ASSEMBLY	27
113A2100-6	INBOARD FLAP MAIN FLAP FINAL ASSEMBLY	27
113A2700-1	AFT INBOARD FLAP ASSEMBLY	27
113A2700-1	AFT INBOARD FLAP ASSEMBLY	27
113A2700-1	AFT INBOARD FLAP ASSEMBLY	27
113A2700-1	AFT INBOARD FLAP ASSEMBLY	27
113A2700-2	AFT INBOARD FLAP ASSEMBLY	27
113A3700-1	AFT OUTBOARD TRAILING EDGE FLAP ASSEMBLY	27
113A3700-1	AFT OUTBOARD TRAILING EDGE FLAP ASSEMBLY	27
113A3700-1	AFT OUTBOARD TRAILING EDGE FLAP ASSEMBLY	27
113A3700-1	AFT OUTBOARD TRAILING EDGE FLAP ASSEMBLY	27
113A3700-1	AFT OUTBOARD TRAILING EDGE FLAP ASSEMBLY	27
113A3700-2	AFT OUTBOARD TRAILING EDGE FLAP ASSEMBLY	27
113A3700-2	AFT OUTBOARD TRAILING EDGE FLAP ASSEMBLY	27
113A3700-2	AFT OUTBOARD TRAILING EDGE FLAP ASSEMBLY	27
113A3700-2	AFT OUTBOARD TRAILING EDGE FLAP ASSEMBLY	27
113A3700-2	AFT OUTBOARD TRAILING EDGE FLAP ASSEMBLY	27
113A3700-2	AFT OUTBOARD TRAILING EDGE FLAP ASSEMBLY	27
113A3700-6	AFT OUTBOARD TRAILING EDGE FLAP ASSEMBLY	27
113A3700-7	AFT OUTBOARD TRAILING EDGE FLAP ASSEMBLY	27

113A3700-8	AFT OUTBOARD TRAILING EDGE FLAP ASSEMBLY	27
113A4100-1	SPOILER ASSY; #12 GND, RH WING; 737-7/-8	27
113A4100-2	SPOILER ASSY; #12 GND, RH WING; 737-7/-8	27
113A4100-1	SPOILER ASSY; #12 GND, RH WING; 737-7/-8	27
113A4100-4	SPOILER ASSY; #12 GND, RH WING; 737-7/-8	27
113A4200-1	SPOILER ASSY; #2 FLT, LH WING	27
113A4600-1	NO 6 AND 7 INBOARD GROUND SPOILER ASSEMBLY	27
113A4600-2	NO 6 AND 7 INBOARD GROUND SPOILER ASSEMBLY	27
113A4600-3	NO 6 AND 7 INBOARD GROUND SPOILER ASSEMBLY	27
113A4600-4	NO 6 AND 7 INBOARD GROUND SPOILER ASSEMBLY	27
113A4600-5	NO 6 AND 7 INBOARD GROUND SPOILER ASSEMBLY	27
113A4600-6	NO 6 AND 7 INBOARD GROUND SPOILER ASSEMBLY	27
113A4600-7	NO 6 AND 7 INBOARD GROUND SPOILER ASSEMBLY	27
113A7100-1	AILERON ASSY., LH SIDE	27
113A7100-2	AILERON ASSY., LH SIDE	27
113A7200-3	TAB ASSY, AILERON, R/H	57
113A7200-4	TAB ASSY, AILERON, R/H	57
113A7400-1	AILERON ASSY., LH SIDE	27
113A7400-3	AILERON ASSY, RH: 3601-9999	57
113A7400-4	AILERON ASSY, RH: 3601-9999	57
113A8200-3	DOOR, RH, MLG, INNER	32
113A8200-4	DOOR, RH, MLG, INNER	32
113A8200-5	DOOR, RH, MLG, INNER	32
113A8200-6	DOOR, RH, MLG, INNER	32
113A8200-7	DOOR, RH, MLG, INNER	32
113A8331-1	DOOR, RH, MLG, INNER	52
113A8331-2	DOOR, RH, MLG, INNER	52
113A8335-1	DOOR, RH, MLG, INNER	52
113A8335-3	DOOR, RH, MLG, INNER	52
113A9305-5	FLAP SUPPORT LINK	27
113N1711-2	FAIRING, FLAP, FIXED OUTBD; 674AB;	57
113N1711-3	FAIRING, FLAP, FIXED OUTBD; 674AB;	27

113N1711-3	FAIRING, FLAP, FIXED OUTBD; 674AB;	57
113N1711-3	FAIRING, FLAP, FIXED OUTBD; 674AB;	57
113N1711-4	FAIRING, FLAP, FIXED OUTBD; 674AB;	57
113N1711-5	FAIRING, FLAP, FIXED OUTBD; 674AB;	57
113N1712-2	OUTBOARD TRAILING EDGE FLAP OUTBOARD TRACK AF	27
113N1712-2	OUTBOARD TRAILING EDGE FLAP OUTBOARD TRACK AF	27
113N1712-3	OUTBOARD TRAILING EDGE FLAP OUTBOARD TRACK AF	27
113N1712-3	OUTBOARD TRAILING EDGE FLAP OUTBOARD TRACK AF	27
113N1712-3	OUTBOARD TRAILING EDGE FLAP OUTBOARD TRACK AF	27
113N1712-3	OUTBOARD TRAILING EDGE FLAP OUTBOARD TRACK AF	27
113N1712-3	OUTBOARD TRAILING EDGE FLAP OUTBOARD TRACK AF	27
113N1712-4	OUTBOARD TRAILING EDGE FLAP OUTBOARD TRACK AF	27
113N1712-4	OUTBOARD TRAILING EDGE FLAP OUTBOARD TRACK AF	27
113N1712-5	OUTBOARD TRAILING EDGE FLAP OUTBOARD TRACK AF	27
113N1712-5	OUTBOARD TRAILING EDGE FLAP OUTBOARD TRACK AF	27
113N1712-5	OUTBOARD TRAILING EDGE FLAP OUTBOARD TRACK AF	27
113N1712-5	OUTBOARD TRAILING EDGE FLAP OUTBOARD TRACK AF	27
113N1712-5	OUTBOARD TRAILING EDGE FLAP OUTBOARD TRACK AF	27
113N1712-6	OUTBOARD TRAILING EDGE FLAP OUTBOARD TRACK AF	27
113N1712-6	OUTBOARD TRAILING EDGE FLAP OUTBOARD TRACK AF	27
113N1712-6	OUTBOARD TRAILING EDGE FLAP OUTBOARD TRACK AF	27
113N1712-7	OUTBOARD TRAILING EDGE FLAP OUTBOARD TRACK AFT FAIF	
113N1731-2	FAIRING OB TE FLAP INBD TRACK RH USED ON	27
113N1731-2	FAIRING OB TE FLAP INBD TRACK RH USED ON	27
113N1731-3	FAIRING OB TE FLAP INBD TRACK RH USED ON	27
113N1731-4	FAIRING OB TE FLAP INBD TRACK RH USED ON	27
113N1732-3	FAIRING,OB TE FLAP,IB TRACK RH AFT	27
113N1732-4	FAIRING,OB TE FLAP,IB TRACK RH AFT	27
113N1732-4	FAIRING,OB TE FLAP,IB TRACK RH AFT	27
113N1732-4	FAIRING,OB TE FLAP,IB TRACK RH AFT	27
113N1732-4	FAIRING,OB TE FLAP,IB TRACK RH AFT	27
113N1732-5	FAIRING,OB TE FLAP,IB TRACK RH AFT	27
113N1732-5	FAIRING,OB TE FLAP,IB TRACK RH AFT	27

113N1732-6	FAIRING,OB TE FLAP,IB TRACK RH AFT	27
113N1732-7	FAIRING,OB TE FLAP,IB TRACK RH AFT	27
113N1751-2	FAIRING, ASSY; RH; 672AB; A/C 5501-5642;	27
113N1751-4	FAIRING, ASSY; RH; 672AB; A/C 5501-5642;	27
113N1751-4	FAIRING, ASSY; RH; 672AB; A/C 5501-5642;	27
113N1751-5	FAIRING, ASSY; RH; 672AB; A/C 5501-5642;	27
113N1751-5	FAIRING, ASSY; RH; 672AB; A/C 5501-5642;	27
113N1751-5	FAIRING, ASSY; RH; 672AB; A/C 5501-5642;	27
113N1752-1	INBOARD TRAILING EDGE FLAP OUTBOARD TRACK AFT FAIRING	
113N1752-2	INBOARD TRAILING EDGE FLAP OUTBOARD TRACK AFT FAIRING	
113N1752-4	INBOARD TRAILING EDGE FLAP OUTBOARD TRACK AFT FAIRING	
113N1752-4	INBOARD TRAILING EDGE FLAP OUTBOARD TRACK AFT	27
113N1752-5	INBOARD TRAILING EDGE FLAP OUTBOARD TRACK AFT FAIRING	
113N1752-5	INBOARD TRAILING EDGE FLAP OUTBOARD TRACK AFT	27
113N1752-6	INBOARD TRAILING EDGE FLAP OUTBOARD TRACK AFT FAIRING	
113N1752-6	INBOARD TRAILING EDGE FLAP OUTBOARD TRACK AFT	27
113N1752-7	INBOARD TRAILING EDGE FLAP OUTBOARD TRACK AFT FAIRING	
113N1752-8	INBOARD TRAILING EDGE FLAP OUTBOARD TRACK AFT FAIRING	
113N1752-8	INBOARD TRAILING EDGE FLAP OUTBOARD TRACK AFT FAIRING	
113N1752-8	INBOARD TRAILING EDGE FLAP OUTBOARD TRACK AFT FAIRING	
113N1752-8	INBOARD TRAILING EDGE FLAP OUTBOARD TRACK AFT FAIRING	
113N1752-8	INBOARD TRAILING EDGE FLAP OUTBOARD TRACK AFT	27
113N1752-8	INBOARD TRAILING EDGE FLAP OUTBOARD TRACK AFT	27
113N1752-8	INBOARD TRAILING EDGE FLAP OUTBOARD TRACK AFT	27
113N1752-9	INBOARD TRAILING EDGE FLAP OUTBOARD TRACK AFT FAIRING	
113N1752-9	INBOARD TRAILING EDGE FLAP OUTBOARD TRACK AFT FAIRING	
113N1753-1	FAIRING, ASSY; RH; 672AB; A/C 5501-5642;	27
113N1849-1	FAIRING, RIGHT MLG AFT,TRUNNION	32
113N1849-1	FAIRING, RIGHT MLG AFT,TRUNNION	32
113N1849-2	FAIRING, RIGHT MLG AFT,TRUNNION	32
113N1849-2	FAIRING, RIGHT MLG AFT,TRUNNION	32
113N1849-3	FAIRING, RIGHT MLG AFT,TRUNNION	32

113N4501-7	SPOILER ASSEMBLIES	27
113N4501-8	SPOILER ASSEMBLIES	57
113N4501-9	SPOILER ASSEMBLIES	
113N4601-1	SPOILER ASSEMBLIES	27
113N4601-1	SPOILER ASSEMBLIES	27
113N4601-1	SPOILER ASSEMBLIES	27
113N4601-1	SPOILER ASSEMBLIES	27
113N4601-1	SPOILER ASSEMBLIES	27
113N4601-2	SPOILER ASSEMBLIES	27
113N4601-2	SPOILER ASSEMBLIES	27
113N4601-2	SPOILER ASSEMBLIES	27
113N4601-2	SPOILER ASSEMBLIES	27
113N4601-3	SPOILER ASSEMBLIES	27
113N4601-3	SPOILER ASSEMBLIES	27
113N4601-3	SPOILER ASSEMBLIES	27
113N4601-3	SPOILER ASSEMBLIES	27
113N4601-3	SPOILER ASSEMBLIES	27
113N4601-3	SPOILER ASSEMBLIES	27
113N4601-3	SPOILER ASSEMBLIES	27
113N4601-3	SPOILER ASSEMBLIES	27
113N4601-3	SPOILER ASSEMBLIES	27
113N4601-3	SPOILER ASSEMBLIES	27
113N4601-3	SPOILER ASSEMBLIES	27
113N4601-3	SPOILER ASSEMBLIES	27
113N4601-3	SPOILER ASSEMBLIES	27
113N4601-3	SPOILER ASSEMBLIES	27
113N4601-3	SPOILER ASSEMBLIES	27
113N4601-3	SPOILER ASSEMBLIES	27
113N4601-3	SPOILER ASSEMBLIES	27
113N4601-3	SPOILER ASSEMBLIES	27
113N4601-4	SPOILER ASSEMBLIES	27
113N4601-5	SPOILER ASSEMBLIES	27
113N4601-6	SPOILER ASSEMBLIES	27
113N4601-7	SPOILER ASSEMBLIES	27
113N4601-8	SPOILER ASSEMBLIES	27
113N4601-9	SPOILER ASSEMBLIES	27

113N4601-7	SPOILER ASSEMBLIES	
113N5501-1	SPOILER ASSEMBLIES	57
113N5501-2	SPOILER ASSEMBLIES	57
113N5501-2	SPOILER ASSEMBLIES	57
113N5501-3	SPOILER ASSEMBLIES	
113N5501-3	SPOILER ASSEMBLIES	57
113N5501-3	SPOILER ASSEMBLIES	57
113N5501-3	SPOILER ASSEMBLIES	57
113N5501-4	SPOILER ASSEMBLIES	57
113N5501-4	SPOILER ASSEMBLIES	57
113N5501-4	SPOILER ASSEMBLIES	57
113N5501-4	SPOILER ASSEMBLIES	57
113N5501-4	SPOILER ASSEMBLIES	57
113N5501-4	SPOILER ASSEMBLIES	57
113N5501-4	SPOILER ASSEMBLIES	57
113N5501-4	SPOILER ASSEMBLIES	57
113N5501-4	SPOILER ASSEMBLIES	57
113N5501-5	SPOILER ASSEMBLIES	57
113N5501-6	SPOILER ASSEMBLIES	57
113N5501-9	SPOILER ASSEMBLIES	57
113N5501-7	SPOILER ASSEMBLIES	
113N5601-3	SPOILER ASSEMBLIES	57
113N5601-3	SPOILER ASSEMBLIES	57
113N5601-4	SPOILER ASSEMBLIES	57
113N5601-4	SPOILER ASSEMBLIES	57
113N5601-4	SPOILER ASSEMBLIES	57
113N5601-4	SPOILER ASSEMBLIES	57
113N5601-4	SPOILER ASSEMBLIES	57
113N5601-4	SPOILER ASSEMBLIES	57
113N5601-9	SPOILER ASSEMBLIES	57
113N5601-7	SPOILER ASSEMBLIES	
113N7100-2	AILERON ASSEMBLY	57
113N7100-2	AILERON ASSEMBLY	57
113N7100-3	AILERON ASSEMBLY	57
113N7100-3	AILERON ASSEMBLY	57
113N7100-3	AILERON ASSEMBLY	57

113N7100-7	AILERON ASSEMBLY	
113N7208-1	AILERON ASSEMBLY	57
113N7208-1	AILERON ASSEMBLY	57
113N7208-1	AILERON ASSEMBLY	57
113N7208-1	AILERON ASSEMBLY	57
113N7208-1	AILERON ASSEMBLY	57
113N7208-1	AILERON ASSEMBLY	57
113N7208-1	AILERON ASSEMBLY	57
113N7208-1	AILERON ASSEMBLY	57
113N7208-1	AILERON ASSEMBLY	57
113N7208-7	AILERON ASSEMBLY	57
113N7208-8	AILERON ASSEMBLY	57
113N7208-7	AILERON ASSEMBLY	
113N8107-1	DOOR, ASSY, MLG STRUT; LH	32
113N8107-1	DOOR, ASSY, MLG STRUT; LH	32
113N8107-1	DOOR, ASSY, MLG STRUT; LH	32
113N8107-2	DOOR, ASSY, MLG STRUT; LH	32
113N8107-2	DOOR, ASSY, MLG STRUT; LH	32
113N8107-2	DOOR, ASSY, MLG STRUT; LH	32
113N8107-2	DOOR, ASSY, MLG STRUT; LH	32
113N8107-2	DOOR, ASSY, MLG STRUT; LH	32
113N8107-2	DOOR, ASSY, MLG STRUT; LH	32
113N8107-4	DOOR, ASSY, MLG STRUT; LH	32
113N8107-4	DOOR, ASSY, MLG STRUT; LH	32
113N8107-4	DOOR, ASSY, MLG STRUT; LH	32
113N8107-4	DOOR, ASSY, MLG STRUT; LH	32
113N8107-4	DOOR, ASSY, MLG STRUT; LH	32
113N8107-4	DOOR, ASSY, MLG STRUT; LH	32
113N8107-4	DOOR, ASSY, MLG STRUT; LH	32
113N8200-4	MLG DOOR, TRUNNION FAIRING, DOOR ASSY;	32
113T1223-1	LINK, AD; INBOARD FLAP O/B MECHANISM	27
113T1321-8	LINK, AD; OUTBOARD T/E FLAP	27
113T1322-7	LINK, AD; OUTBOARD T/E FLAP	27
113T1358-5	SCREW, BALL SCREW ASSY	27
113T1505-1	HINGE BEARING	57
113T1505-1	HINGE BEARING	57

113T1505-2	HINGE BEARING	57
113T1505-5	HINGE BEARING	57
113T1505-9	HINGE BEARING	57
113T1720-5	FAIRING I/B FLAP, O/B TRACK CENTER L/H,	57
113T1720-5	FAIRING I/B FLAP, O/B TRACK CENTER L/H,	57
113T1720-9	FAIRING I/B FLAP, O/B TRACK CENTER L/H,	57
113T2029-5	DOOR, L/H I/B FLAP,TORQUE TUBE SLOT,USED	27
113T2029-6	DOOR, L/H I/B FLAP,TORQUE TUBE SLOT,USED	27
113T2030-5	DOOR, L/H I/B FLAP,TORQUE TUBE SLOT,USED	27
113T2030-6	DOOR, L/H I/B FLAP,TORQUE TUBE SLOT,USED	27
113T2201-1	INBOARD TRAILING EDGE MAIN FLAP ASSEMBLY	27
113T2201-2	INBOARD TRAILING EDGE MAIN FLAP ASSEMBLY	27
113T2201-2	INBOARD TRAILING EDGE MAIN FLAP ASSEMBLY	27
113T2201-2	INBOARD TRAILING EDGE MAIN FLAP ASSEMBLY	27
113T2201-2	INBOARD TRAILING EDGE MAIN FLAP ASSEMBLY	27
113T2201-2	INBOARD TRAILING EDGE MAIN FLAP ASSEMBLY	27
113T2201-2	INBOARD TRAILING EDGE MAIN FLAP ASSEMBLY	27
113T2201-2	INBOARD TRAILING EDGE MAIN FLAP ASSEMBLY	27
113T2201-3	INBOARD TRAILING EDGE MAIN FLAP ASSEMBLY	27
113T2201-X	INBOARD TRAILING EDGE MAIN FLAP ASSEMBLY	
113T2301-1	INBOARD TRAILING EDGE FLAP AFT FLAP ASSEMBLY	27
113T2301-1	INBOARD TRAILING EDGE FLAP AFT FLAP ASSEMBLY	27
113T2301-2	INBOARD TRAILING EDGE FLAP AFT FLAP ASSEMBLY	27
113T2301-3	INBOARD TRAILING EDGE FLAP AFT FLAP ASSEMBLY	27
113T2301-3	INBOARD TRAILING EDGE FLAP AFT FLAP ASSEMBLY	27
113T2301-3	INBOARD TRAILING EDGE FLAP AFT FLAP ASSEMBLY	27
113T2301-7	INBOARD TRAILING EDGE FLAP AFT FLAP ASSEMBLY	27
113T2301-8	INBOARD TRAILING EDGE FLAP AFT FLAP ASSEMBLY	27
113T2301-X	INBOARD TRAILING EDGE FLAP AFT FLAP ASSEMBLY	
113T3100-4	PANEL, PANEL	57
113T3100-4	PANEL, PANEL	57
113T3100-4	PANEL, PANEL	57
113T3100-6	PANEL, PANEL	57

113T3100-7	PANEL, PANEL	27
113T3100-7	PANEL, PANEL	57
113T3100-8	PANEL, PANEL	27
113T3100-9	PANEL, PANEL	57
113T3140-2	PANEL, PANEL	57
113T5102-1	OUTBOARD SPOILER ASSEMBLY	27
113T5102-1	OUTBOARD SPOILER ASSEMBLY	27
113T5102-1	OUTBOARD SPOILER ASSEMBLY	27
113T5102-1	OUTBOARD SPOILER ASSEMBLY	27
113T5102-1	OUTBOARD SPOILER ASSEMBLY	27
113T5102-2	OUTBOARD SPOILER ASSEMBLY	27
113T5102-X	OUTBOARD SPOILER ASSEMBLY	
113T6100-1	INBOARD AILERON ASSEMBLY	
113T6100-3	INBOARD AILERON ASSEMBLY	
113T6100-5	INBOARD AILERON ASSEMBLY	
113T6100-7	INBOARD AILERON ASSEMBLY	27
113T6100-7	INBOARD AILERON ASSEMBLY	27
113T6100-8	INBOARD AILERON ASSEMBLY	27
113T6100-8	INBOARD AILERON ASSEMBLY	27
113T6100-X	INBOARD AILERON ASSEMBLY	
113T7100-1	ASSEMBLY, OUTBOARD AILERON	27
113T7100-1	ASSEMBLY, OUTBOARD AILERON	27
113T7100-2	ASSEMBLY, OUTBOARD AILERON	27
113T7100-2	AILERON ASSY., LH SIDE	27
113T7100-2	ASSEMBLY, OUTBOARD AILERON	27
113T7100-3	ASSEMBLY, OUTBOARD AILERON	27
113T7100-3	ASSEMBLY, OUTBOARD AILERON	27
113T7100-3	ASSEMBLY, OUTBOARD AILERON	27
113T7100-3	ASSEMBLY, OUTBOARD AILERON	27
113T7100-3	ASSEMBLY, OUTBOARD AILERON	27
113T7100-4	ASSEMBLY, OUTBOARD AILERON	27
113T7100-4	ASSEMBLY, OUTBOARD AILERON	27

113T7100-4	ASSEMBLY, OUTBOARD AILERON	27
113T7100-4	ASSEMBLY, OUTBOARD AILERON	27
113T7100-4	ASSEMBLY, OUTBOARD AILERON	27
113T7100-4	ASSEMBLY, OUTBOARD AILERON	27
113T7100-4	ASSEMBLY, OUTBOARD AILERON	27
113T7100-4	ASSEMBLY, OUTBOARD AILERON	
113T7100-4	ASSEMBLY, OUTBOARD AILERON	27
113T7100-6	ASSEMBLY, OUTBOARD AILERON	27
113T7100-6	ASSEMBLY, OUTBOARD AILERON	27
113T7100-7	ASSEMBLY, OUTBOARD AILERON	27
113T7100-9	ASSEMBLY, OUTBOARD AILERON	27
113T7100-9	ASSEMBLY, OUTBOARD AILERON	27
113T7100-9	ASSEMBLY, OUTBOARD AILERON	27
113T7100-9	ASSEMBLY, OUTBOARD AILERON	27
113T7100-X	ASSEMBLY, OUTBOARD AILERON	
113T8201-4	SHOCK STRUT DOOR ASSEMBLY	32
113T8201-5	SHOCK STRUT DOOR ASSEMBLY	
113T8201-5	SHOCK STRUT DOOR ASSEMBLY	
113T8201-7	SHOCK STRUT DOOR ASSEMBLY	
113T8201-7	SHOCK STRUT DOOR ASSEMBLY	
113T8201-7	SHOCK STRUT DOOR ASSEMBLY	
113T8201-7	SHOCK STRUT DOOR ASSEMBLY	32
113T8201-8	SHOCK STRUT DOOR ASSEMBLY	32
113T8301-1	TRUNNION DOOR ASSEMBLY	32
113T8301-1	TRUNNION DOOR ASSEMBLY	
113T8301-2	TRUNNION DOOR ASSEMBLY	32
113T8301-2	TRUNNION DOOR ASSEMBLY	
113T8301-2	TRUNNION DOOR ASSEMBLY	32
113T8301-2	TRUNNION DOOR ASSEMBLY	32
113T8301-2	TRUNNION DOOR ASSEMBLY	32
113T8301-3	TRUNNION DOOR ASSEMBLY	32
113T8301-3	TRUNNION DOOR ASSEMBLY	32

1140-0110-	FUEL MEASURING STICK FLEXI-STICK ASSEMBLY	28
1140-0110-	FUEL MEASURING STICK FLEXI-STICK ASSEMBLY	28
1140-0110-	FUEL MEASURING STICK FLEXI-STICK ASSEMBLY	28
1140-0110-	FUEL MEASURING STICK FLEXI-STICK ASSEMBLY	28
1140-0110-	FUEL MEASURING STICK FLEXI-STICK ASSEMBLY	28
1140-0110-	FUEL MEASURING STICK FLEXI-STICK ASSEMBLY	28
1140-0110-	FUEL MEASURING STICK FLEXI-STICK ASSEMBLY	28
1140-0110-	FUEL MEASURING STICK FLEXI-STICK ASSEMBLY	28
1140-0110-	FUEL MEASURING STICK FLEXI-STICK ASSEMBLY	28
1140-0110-	FUEL MEASURING STICK FLEXI-STICK ASSEMBLY	28
1140-0183-	FUEL MEASURING STICK FLEXI-STICK ASSEMBLY	28
1140-0183-	FUEL MEASURING STICK FLEXI-STICK ASSEMBLY	28
1140-0183-	FUEL MEASURING STICK FLEXI-STICK ASSEMBLY	28
1140-0183-	FUEL MEASURING STICK FLEXI-STICK ASSEMBLY	28
1140-0183-	FUEL MEASURING STICK FLEXI-STICK ASSEMBLY	28
114-029	INDICATOR, VALVE POSITION	21
114-115	INDICATOR, VALVE POSITION	21
114-174	INDICATOR, VALVE POSITION	21
114256004-	ACTUATOR, RETRACT, MLG GRTH	32
114256004-	ACTUATOR, RETRACT, MLG GRTH	32
114256004-	ACTUATOR, RETRACT, MLG GRTH	32
114A1110-7	NO. 1 AND 4 KRUEGER FLAP AND BULLNOSE ASSEMBLY	27
114A1110-1	NO. 1 AND 4 KRUEGER FLAP AND BULLNOSE ASSEMBLY	27
114A1220-1	NO.2 AND 3 KREUGER FLAP AND BULLNOSE ASSEMBLY	27
114A1220-2	NO.2 AND 3 KREUGER FLAP AND BULLNOSE ASSEMBLY	27
114A1220-2	NO.2 AND 3 KREUGER FLAP AND BULLNOSE ASSEMBLY	27
114A1220-6	NO.2 AND 3 KREUGER FLAP AND BULLNOSE ASSEMBLY	27
114A1220-8	NO.2 AND 3 KREUGER FLAP AND BULLNOSE ASSEMBLY	27
114A5010-1	WING LEADING EDGE NO.1 AND 8 SLAT ASSEMBLIES	27
114A5010-1	WING LEADING EDGE NO.1 AND 8 SLAT ASSEMBLIES	27
114A5010-1	WING LEADING EDGE NO.1 AND 8 SLAT ASSEMBLIES	27
114A5010-2	WING LEADING EDGE NO.1 AND 8 SLAT ASSEMBLIES	27
114A5010-3	WING LEADING EDGE NO.1 AND 8 SLAT ASSEMBLIES	27

114N4005-1	WING LEADING EDGE NO 4 & 7 SLAT ASSEMBLY	27
114N4005-1	WING LEADING EDGE NO 4 & 7 SLAT ASSEMBLY	27
114N4005-1	WING LEADING EDGE NO 4 & 7 SLAT ASSEMBLY	27
114N4005-2	WING LEADING EDGE NO 4 & 7 SLAT ASSEMBLY	27
114N4005-2	WING LEADING EDGE NO 4 & 7 SLAT ASSEMBLY	27
114N4005-2	WING LEADING EDGE NO 4 & 7 SLAT ASSEMBLY	27
114N4005-2	WING LEADING EDGE NO 4 & 7 SLAT ASSEMBLY	27
114N4005-2	WING LEADING EDGE NO 4 & 7 SLAT ASSEMBLY	27
114N4005-2	WING LEADING EDGE NO 4 & 7 SLAT ASSEMBLY	27
114N4005-2	WING LEADING EDGE NO 4 & 7 SLAT ASSEMBLY	27
114N4005-2	WING LEADING EDGE NO 4 & 7 SLAT ASSEMBLY	27
114N4005-2	WING LEADING EDGE NO 4 & 7 SLAT ASSEMBLY	57
114N4005-2	WING LEADING EDGE NO 4 & 7 SLAT ASSEMBLY	
114N4058-1	WING LEADING EDGE SLAT NO. 2 AND 9 ASSEMBLIES	27
114N4058-1	WING LEADING EDGE NO 4 & 7 SLAT ASSEMBLY	57
114N4058-2	WING LEADING EDGE NO 4 & 7 SLAT ASSEMBLY	27
114T3100-1	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27
114T3100-1	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27
114T3100-1	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27
114T3100-1	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27
114T3100-1	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27
114T3100-2	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27
114T3100-2	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTURE ASS	
114T3100-2	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27
114T3100-2	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTURE ASS	
114T3100-2	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27
114T3100-2	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27
114T3100-2	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27
114T3100-2	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27
114T3100-2	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27
114T3100-2	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27
114T3100-2	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27
114T3100-2	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27
114T3100-3	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27

114T3100-3	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27
114T3100-3	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27
114T3100-3	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27
114T3100-3	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27
114T3100-4	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27
114T3100-4	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27
114T3100-4	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27
114T3100-4	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27
114T3100-4	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27
114T3100-4	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27
114T3100-4	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27
114T3100-4	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27
114T3100-4	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27
114T3100-5	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27
114T3100-5	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTUF	27
114T3100-X	WING LEADING EDGE INBOARD SLAT No. 6, 7 STRUCTURE ASS	
114T4101-1	LE OUTBD SLAT ASSEMBLY #1 & #12	
114T4101-1	LE OUTBD SLAT ASSEMBLY #1 & #12	27
114T4101-1	LE OUTBD SLAT ASSEMBLY #1 & #12	27
114T4101-1	LE OUTBD SLAT ASSEMBLY #1 & #12	
114T4101-2	LE OUTBD SLAT ASSEMBLY #1 & #12	27
114T4101-2	LE OUTBD SLAT ASSEMBLY #1 & #12	27
114T4101-2	LE OUTBD SLAT ASSEMBLY #1 & #12	27
114T4101-3	LE OUTBD SLAT ASSEMBLY #1 & #12	27
114T4101-3	LE OUTBD SLAT ASSEMBLY #1 & #12	27
114T4101-3	LE OUTBD SLAT ASSEMBLY #1 & #12	27
114T4101-3	LE OUTBD SLAT ASSEMBLY #1 & #12	27
114T4101-3	LE OUTBD SLAT ASSEMBLY #1 & #12	27
114T4101-3	LE OUTBD SLAT ASSEMBLY #1 & #12	27
114T4101-3	LE OUTBD SLAT ASSEMBLY #1 & #12	27
114T4101-4	LE OUTBD SLAT ASSEMBLY #1 & #12	27
114T4101-4	LE OUTBD SLAT ASSEMBLY #1 & #12	
114T4101-4	LE OUTBD SLAT ASSEMBLY #1 & #12	27
114T4101-4	LE OUTBD SLAT ASSEMBLY #1 & #12	27

114T4105-1	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
114T4105-1	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
114T4105-2	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
114T4105-2	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
114T4105-2	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
114T4105-2	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
114T4105-2	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
114T4105-2	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
114T4105-2	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
114T4105-2	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
114T4105-2	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
114T4105-3	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
114T4105-3	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
114T4105-3	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
114T4105-3	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
114T4105-3	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
114T4105-3	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
114T4105-4	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
114T4105-4	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
114T4105-4	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
114T4105-4	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
114T4105-4	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
114T4105-4	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
114T4105-5	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
114T4105-5	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 S	27
114T4105-X	WING LEADING EDGE OUTBOARD SLAT NO.5 AND NO.8 STRUC	
1150010-1	TEMPERATURE SELECTOR	21
1150406-1	AUXILIARY ZONE TEMPERATURE CONTROLLER	21
1150406-2	AUXILIARY ZONE TEMPERATURE CONTROLLER	
1150880-1	CONTRLLR AIR CONDITIONING TEMPERATURE	21
115-099-6	BRAKE PRESSURE INDICATOR & HYDRAULIC PRESSURE	32
115-099-7	BRAKE PRESSURE INDICATOR & HYDRAULIC PRESSURE	32
115-099-8	BRAKE PRESSURE INDICATOR & HYDRAULIC PRESSURE	32
115-099-9	BRAKE PRESSURE INDICATOR & HYDRAULIC PRESSURE	32
115-160	WATER QUANTITY INDICATOR	38

115-161	WATER QUANTITY INDICATOR	38
115-164-2	INDICATR TAXI-SPEED, USED ON B767 A/C 10	31
1151864-1	PACK TEMPERATURE CONTROLLER	21
1151864-2	PACK TEMPERATURE CONTROLLER	21
1151866-1	AUXILIARY ZONE TEMPERATURE CONTROLLER	21
1151868-1	AUXILIARY ZONE TEMPERATURE CONTROLLER	21
1151870-1	AUXILIARY ZONE TEMPERATURE CONTROLLER	21
1151952-10	UNIT,STANDBY POWER CONTROL	
1151952-11	UNIT,STANDBY POWER CONTROL	24
1151952-12	UNIT,STANDBY POWER CONTROL	
1151952-13	UNIT,STANDBY POWER CONTROL	24
1151952-14	UNIT,STANDBY POWER CONTROL	24
1151952-16	UNIT,STANDBY POWER CONTROL	24
1151952-18	UNIT,STANDBY POWER CONTROL	24
1151952-19	UNIT,STANDBY POWER CONTROL	24
1151952-5	UNIT,STANDBY POWER CONTROL	24
1151952-6	UNIT,STANDBY POWER CONTROL	24
1151952-7	UNIT,STANDBY POWER CONTROL	
1151952-8	UNIT,STANDBY POWER CONTROL	24
1151952-9	UNIT,STANDBY POWER CONTROL	24
115-216	WATER QUANTITY INDICATOR	38
115-217	WATER QUANTITY INDICATOR	38
1152892-1	RESCU 40	23
115370-010	CONCENTRATOR, FLIGHT CONTROL.	27
115370-101	CONCENTRATOR, FLIGHT CONTROL.	27
115370-111	CONCENTRATOR, FLIGHT CONTROL.	27
115370-111	CONCENTRATOR, FLIGHT CONTROL.	27
115370-121	CONCENTRATOR, FLIGHT CONTROL.	27
115370-131	CONCENTRATOR, FLIGHT CONTROL.	27
1153P4-28	SWITCH OIL PRESSURE, LOW WARNING ENGINE	79
115A160-2	WATER QUANTITY INDICATOR	38
1163P0041	SWITCH OIL,Do not use per EA49-517127-14	79

118316-24	BOX, STOWAGE, ASSY, OXYGEN MASK; A330	35
118736-11	FULLFACE MASK STOWAGE BOX ASSEMBLY	35
118736-12	FULLFACE MASK STOWAGE BOX ASSEMBLY	35
118934-41	STOWAGE, COCKPIT, OBS SEAT,OXYGEN BOX,MO	35
118945-22	STOWAGE, COCKPIT, OBS SEAT,OXYGEN BOX,MO	35
118954-11	STOWAGE, COCKPIT, OBS SEAT,OXYGEN BOX,MO	35
118956-11	STOWAGE, COCKPIT, OBS SEAT,OXYGEN BOX,MO	35
118965-22	STOWAGE, COCKPIT, OBS SEAT,OXYGEN BOX,MO	25
1194P0050-	SWITCH ANEROID, CABIN AIR CONDITIONING	21
1194P0050-	SWITCH ANEROID, CABIN AIR CONDITIONING	35
1-200065	CAP LAVATORY WASTE, FWD & AFT EQUIV 10-6	38
1203P0107-	HYDRAULIC OIL FILTER	29
1203P0107-	SWITCH, HYD. PRESS. (INSOURCE MATERIAL)	29
1209457-10	DUCT ANTI-ICE ALT S332N303-13 V8120	30
1211092-00	ACTUATOR, VARIABLE BYPASS VALVE	
1211245-01	VALVE START BLEED CONTROL THREE VALVE BL	75
1211245-01	VALVE START BLEED CONTROL THREE VALVE BL	75
1211245-01	VALVE START BLEED CONTROL THREE VALVE BL	75
1211245-02	VALVE START BLEED CONTROL THREE VALVE BL	75
1211285-00	VBV ACTUATOR - CF6-80C2 PMC	75
1211285-00	VBV ACTUATOR - CF6-80C2 PMC	75
1211285-00	VBV ACTUATOR - CF6-80C2 PMC	
1211313-01	VARIABLE STATOR VANE ACTUATOR	75
121664-3S4	BALLSCREW ACTUATOR ASSEMBLY	75
121666-11	MASTER BALLSCREW ACTUATOR	75
121666-14	MASTER BALLSCREW ACTUATOR	75
121666-4	MASTER BALLSCREW ACTUATOR	75
121666-7	MASTER BALLSCREW ACTUATOR	75
121666-9	MASTER BALLSCREW ACTUATOR	75
1222-5-360	VALVE HYD PUMP PRESSURE RELIEF	29
1222-5-360	VALVE HYD PUMP PRESSURE RELIEF	29
1225P6-1	SWITCH HYD SYS PRESSURE MODULE FURNISHED	29

122944-1-1	VALVE, WING ICE-PROTECTION,SHUT OFF, S/L	30
123266-2-1	VALVE, CHECK 3.5	36
123558-1	3 1/2 INCH DIAMETER CHECK VALVE	
123558-1-1	3 1/2 INCH DIAMETER CHECK VALVE	36
123558-1-3	3 1/2 INCH DIAMETER CHECK VALVE	36
123558-1-4	3 1/2 INCH DIAMETER CHECK VALVE	36
123562-2-1	VALVE AIR CHECK 8TH STAGE BLEED UPON REC	36
123562-4-1	VALVE AIR CHECK 8TH STAGE BLEED UPON REC	36
125334D2	VALVE, FUEL SHUTOFF ROTARY TYPE	28
1268-503	LIGHT ASSEMBLY, FLT, ATTENDANT	33
129110-2-1	THERMSTT, PNEUMATIC DUCT, HIGH TEMP	36
129112-1-1	ANTICPTR, PNEUMATIC DUCT, HIGH TEMP	36
129626-4	BLEED AIR TEMP SENSOR	36
129626-5	BLEED AIR TEMP SENSOR	36
129666-1	PRECOOLER CONTROL VALVE SENSOR	36
129666-2	PRECOOLER CONTROL VALVE SENSOR	36
129666-3	PRECOOLER CONTROL VALVE SENSOR	36
129682-3	BLEED AIR OVERTEMP SENSOR	36
129682-5	BLEED AIR OVERTEMP SENSOR	36
129694-1	BLEED AIR OVERTEMP SENSOR	36
129694-2	BLEED AIR OVERTEMP SENSOR	36
129694-3	BLEED AIR OVERTEMP SENSOR	36
129738-1	THERMSTT COOLING PACKAGE 1EA PER PACK	21
12A092-003	ACTUATOR, VARIABLE BYPASS VALVE	75
12A092-3	ACTUATOR, VARIABLE BYPASS VALVE	75
12A092-4	ACTUATOR, VARIABLE BYPASS VALVE	75
12D1010	FILL WATER VALVE	38
12D1011	FILL WATER VALVE	38
12D1012	VALVE VACUUM WASTE SYSTEM RINSE	38
12D117-13	VALVE, BALL DRAIN	38
12D117-4	VALVE, BALL DRAIN	38
12D117-6	VALVE, BALL DRAIN	38

12D124-10	VALVE, POTABLE WATER,FILL AND OVERFLOW,U	38
12D140	VALVE WATER, DRAIN AND FILL FOURWAY	38
1303A0000-	VALVE,AIR,FLOW CONTROL;A/C3260-UP;A319	21
1303A0000-	VALVE,AIR,FLOW CONTROL;A/C3260-UP;A319	21
130502-4	CABIN PRESSURE SELECTOR	21
130502-5	CABIN PRESSURE SELECTOR	21
130502-5S4	CABIN PRESSURE SELECTOR	21
130502-6	CABIN PRESSURE SELECTOR	21
130502-7	CABIN PRESSURE SELECTOR	21
130502-7S1	CABIN PRESSURE SELECTOR	21
130590-1	SELECTOR CABIN PRESSURE(TRACKING PURPOSE	21
130590-2	SELECTOR CABIN PRESSURE(TRACKING PURPOSE	21
1311-126	VALVE FUEL, ENGINE GROUND FLIGHT IDLE SO	73
1324M94P0	HPTCC THERMOCOUPLE PROBE	73
13277-505	DUCT ANTI-ICE ALT 7958591-505 V8827	75
132VJ1RL1	LINEAR ACTUATOR ASSEMBLY	25
132VJ1RL1	LINEAR ACTUATOR ASSEMBLY	25
13976-528	DUCT 8TH STAGE ALT PN 13976-528 V706	36
13TX0115A	TRNSMTTR AILERON AND ELEVATOR POSITION	27
13TX0615A	TRANSMITTER, CONTROL SURFACE POSITION	27
140-025-1	WHEEL SPEED TRANSDUCER	32
140-025-2	WHEEL SPEED TRANSDUCER	32
140355-401	VALVE DRAIN, TOILET	38
1405-7	APU SHUTOFF VALVE	36
140N2635-1	LINK TORQUE TUBE HINGE USED ON B757 A/C	52
140N2635-2	LINK TORQUE TUBE HINGE USED ON B757 A/C	52
140N2635-2	LINK TORQUE TUBE HINGE USED ON B757 A/C	52
140N2635-2	LINK TORQUE TUBE HINGE USED ON B757 A/C	52
140N2640-2	**-ARM ASSY, FWD LH ENTRY DOOR GUIDE	52
140N2641-3	ARM ASSY, FWD RH, ENTRY DOOR GUIDE, MOD	52
140N2751-1	NO. 4 PASSENGER DOOR ASSEMBLY	52
140N2762-1	PASSENGER DOOR GIRT BAR ASSEMBLY	52

140N2762-1	PASSENGER DOOR GIRT BAR ASSEMBLY	25
140N2762-1	PASSENGER DOOR GIRT BAR ASSEMBLY	52
140N2762-1	PASSENGER DOOR GIRT BAR ASSEMBLY	25
140N2762-2	PASSENGER DOOR GIRT BAR ASSEMBLY	25
140N2762-2	PASSENGER DOOR GIRT BAR ASSEMBLY	25
140N2762-2	PASSENGER DOOR GIRT BAR ASSEMBLY	25
140N2762-2	PASSENGER DOOR GIRT BAR ASSEMBLY	25
1417200-1	THRUST REVERSER ISOLATION VALVE ASSEMBLY	
1417200-3	THRUST REVERSER ISOLATION VALVE ASSEMBLY	78
1417200-5	THRUST REVERSER ISOLATION VALVE ASSEMBLY	78
141A4810-1	SLIDING WINDSHIELD ASSEMBLY	56
141A4810-1	SLIDING WINDSHIELD ASSEMBLY	56
141A4810-1	SLIDING WINDSHIELD ASSEMBLY	56
141A4810-2	SLIDING WINDSHIELD ASSEMBLY	56
141A4810-2	SLIDING WINDSHIELD ASSEMBLY	56
141A4810-2	SLIDING WINDSHIELD ASSEMBLY	56
141A4810-3	SLIDING WINDSHIELD ASSEMBLY	56
141A4810-3	SLIDING WINDSHIELD ASSEMBLY	56
141A4810-3	SLIDING WINDSHIELD ASSEMBLY	56
141A4810-3	SLIDING WINDSHIELD ASSEMBLY	56
141A4810-3	SLIDING WINDSHIELD ASSEMBLY	56
141A4810-3	SLIDING WINDSHIELD ASSEMBLY	56
141A4810-3	SLIDING WINDSHIELD ASSEMBLY	56
141A4810-4	SLIDING WINDSHIELD ASSEMBLY	56
141A4810-4	SLIDING WINDSHIELD ASSEMBLY	56
141A4810-4	SLIDING WINDSHIELD ASSEMBLY	56
141A4810-5	WINDSHIELD, ASSY; #2; SLIDING; RH; COCKP	56
141A4810-5	WINDSHIELD, ASSY; #2; SLIDING; LH; COCKP	56
141A4810-5	WINDSHIELD, ASSY; #2; SLIDING; LH; COCKP	56
141A4810-5	WINDSHIELD, ASSY; #2; SLIDING; RH; COCKP	56
141A4810-7	SLIDING WINDSHIELD ASSEMBLY	56
141A4810-8	SLIDING WINDSHIELD ASSEMBLY	56
141A6075-2	FORWARD ENTRY DOOR GUIDE ARM ASSEMBLY	52

141A6150-3	FORWARD ENTRY DOOR ASSEMBLY	52
141A6710-1	EQUIPMENT ACCESS DOOR ASSEMBLY	52
141A6710-1	EQUIPMENT ACCESS DOOR ASSEMBLY	52
141A6710-9	EQUIPMENT ACCESS DOOR ASSEMBLY	52
141N4850-5	NO. 2 OPENABLE WINDOW ASSEMBLY	
141N4850-5	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141N4850-5	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141N4850-5	NO. 2 OPENABLE WINDOW ASSEMBLY	
141N4850-5	NO. 2 OPENABLE WINDOW ASSEMBLY	
141N4850-5	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141N4850-5	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141N4850-5	NO. 2 OPENABLE WINDOW ASSEMBLY	
141N4850-6	NO. 2 OPENABLE WINDOW ASSEMBLY	
141N4850-6	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141N4850-6	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141N4850-6	NO. 2 OPENABLE WINDOW ASSEMBLY	
141N4850-6	NO. 2 OPENABLE WINDOW ASSEMBLY	
141N4850-6	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141N4850-6	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141N4850-6	NO. 2 OPENABLE WINDOW ASSEMBLY	
141N4850-6	NO. 2 OPENABLE WINDOW ASSEMBLY	
141N4850-7	NO. 2 OPENABLE WINDOW ASSEMBLY	
141N6100-2	NO. 1 PASSENGER LEFT DOOR ASSEMBLY	52
141N6100-2	NO. 1 PASSENGER LEFT DOOR ASSEMBLY	52
141N6100-2	NO. 1 PASSENGER LEFT DOOR ASSEMBLY	52
141N6100-4	NO. 1 PASSENGER LEFT DOOR ASSEMBLY	52
141N6100-7	NO. 1 PASSENGER LEFT DOOR ASSEMBLY	
141N6120-2	NO. 1 PASSENGER LEFT DOOR ASSEMBLY	52
141N6120-2	NO. 1 PASSENGER LEFT DOOR ASSEMBLY	52
141N6195-1	PASSENGER DOOR COUNTERBALANCE ASSEMBLY	52
141N6195-2	PASSENGER DOOR COUNTERBALANCE ASSEMBLY	52
141N6195-3	PASSENGER DOOR COUNTERBALANCE ASSEMBLY	52

141N6195-4	PASSENGER DOOR COUNTERBALANCE ASSEMBLY	52
141N6196-1	CAMSHAFT, COUNTER BALANCE, ASSY,L/H DOOR	52
141N6200-2	NO. 1 PASSENGER RIGHT DOOR ASSEMBLY	52
141N6200-2	NO. 1 PASSENGER RIGHT DOOR ASSEMBLY	52
141N6200-2	NO. 1 PASSENGER RIGHT DOOR ASSEMBLY	52
141N6200-2	NO. 1 PASSENGER RIGHT DOOR ASSEMBLY	52
141N6200-2	NO. 1 PASSENGER RIGHT DOOR ASSEMBLY	52
141N6200-4	NO. 1 PASSENGER RIGHT DOOR ASSEMBLY	52
141N6200-7	NO. 1 PASSENGER RIGHT DOOR ASSEMBLY	
141N6205-1	NO. 1 PASSENGER RIGHT DOOR ASSEMBLY	52
141N6205-2	NO. 1 PASSENGER RIGHT DOOR ASSEMBLY	52
141N6205-3	NO. 1 PASSENGER RIGHT DOOR ASSEMBLY	52
141N6220-1	NO. 1 PASSENGER RIGHT DOOR ASSEMBLY	52
141N6220-2	NO. 1 PASSENGER RIGHT DOOR ASSEMBLY	52
141N6220-2	NO. 1 PASSENGER RIGHT DOOR ASSEMBLY	52
141N6353-2	PASSENGER DOOR COUNTERBALANCE ASSEMBLY	52
141N6353-3	PASSENGER DOOR COUNTERBALANCE ASSEMBLY	52
141N6354-1	CAMSHAFT, COUNTER BALANCE, ASSY,L/H DOOR	52
141N6910-4	FORWARD NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6910-4	FORWARD NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6910-4	FORWARD NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6910-5	FORWARD NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6910-5	FORWARD NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6910-5	FORWARD NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6910-5	FORWARD NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6910-5	FORWARD NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6910-5	FORWARD NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6910-5	FORWARD NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6910-5	FORWARD NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6910-5	FORWARD NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6910-5	FORWARD NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6910-5	FORWARD NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6910-6	FORWARD NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6910-6	FORWARD NOSE WHEEL WELL DOOR ASSEMBLY	32

141N6910-6	FORWARD NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6910-6	FORWARD NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6910-6	FORWARD NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6910-6	FORWARD NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6910-6	FORWARD NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6910-7	FORWARD NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6910-7	FORWARD NOSE WHEEL WELL DOOR ASSEMBLY	
141N6920-1	AFT NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6920-1	AFT NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6920-2	AFT NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6920-2	AFT NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6920-2	AFT NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6920-2	AFT NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6920-3	AFT NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6920-3	AFT NOSE WHEEL WELL DOOR ASSEMBLY	
141N6920-3	AFT NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6920-3	AFT NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6920-3	AFT NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6920-4	AFT NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6920-4	AFT NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6920-5	AFT NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6920-5	AFT NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6920-5	AFT NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6920-5	AFT NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6920-5	AFT NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6920-5	AFT NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6920-5	AFT NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6920-5	AFT NOSE WHEEL WELL DOOR ASSEMBLY	32
141N6920-7	AFT NOSE WHEEL WELL DOOR ASSEMBLY	
141N7820-1	RADOME ASSEMBLY	34
141N7820-1	RADOME ASSEMBLY	34
141N7820-1	RADOME ASSEMBLY	34
141N7820-1	RADOME ASSEMBLY	34

141N7820-1	RADOME ASSEMBLY	34
141N7820-1	RADOME ASSEMBLY	34
141N7820-1	RADOME ASSEMBLY	34
141N7820-2	RADOME ASSEMBLY	34
141N7820-6	RADOME ASSEMBLY	34
141N7820-7	RADOME ASSEMBLY	
141T4835-1	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-1	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-1	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-1	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-1	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-1	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-1	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-1	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-1	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-1	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-2	NO. 2 OPENABLE WINDOW ASSEMBLY	
141T4835-2	NO. 2 OPENABLE WINDOW ASSEMBLY	
141T4835-2	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-2	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-3	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-3	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-4	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-4	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-4	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-5	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-5	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-5	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-5	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-5	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-5	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-5	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-6	NO. 2 OPENABLE WINDOW ASSEMBLY	56

141T4835-6	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-7	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-7	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-8	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-8	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-8	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-9	NO. 2 OPENABLE WINDOW ASSEMBLY	56
141T4835-X	NO. 2 OPENABLE WINDOW ASSEMBLY	
141T6401-2	FORWARD ACCESS DOOR ASSEMBLY	52
141T6910-1	NOSE LANDING GEAR FORWARD DOOR ASEMBLY	
141T6910-3	NOSE LANDING GEAR FORWARD DOOR ASEMBLY	32
141T6910-3	NOSE LANDING GEAR FORWARD DOOR ASEMBLY	
141T6910-3	NOSE LANDING GEAR FORWARD DOOR ASEMBLY	32
141T6910-3	NOSE LANDING GEAR FORWARD DOOR ASEMBLY	32
141T6920-3	NOSE LANDING GEAR AFT DOOR ASSEMBLY	32
141T6920-4	NOSE LANDING GEAR AFT DOOR ASSEMBLY	32
141T6920-4	NOSE LANDING GEAR AFT DOOR ASSEMBLY	32
141T6920-5	NOSE LANDING GEAR AFT DOOR ASSEMBLY	32
141T6920-5	NOSE LANDING GEAR AFT DOOR ASSEMBLY	32
141T6920-5	NOSE LANDING GEAR AFT DOOR ASSEMBLY	32
141T6920-5	NOSE LANDING GEAR AFT DOOR ASSEMBLY	32
141T6920-5	NOSE LANDING GEAR AFT DOOR ASSEMBLY	32
141T6920-5	NOSE LANDING GEAR AFT DOOR ASSEMBLY	32
141T6920-5	NOSE LANDING GEAR AFT DOOR ASSEMBLY	32
141T6920-5	NOSE LANDING GEAR AFT DOOR ASSEMBLY	32
141T6920-5	NOSE LANDING GEAR AFT DOOR ASSEMBLY	32
141T6920-5	NOSE LANDING GEAR AFT DOOR ASSEMBLY	32
141T6920-6	NOSE LANDING GEAR AFT DOOR ASSEMBLY	32
141T6963-5	STRUT AFT NLG DOOR PACKAGE 1EA PER PACK	32
141T6963-6	STRUT AFT NLG DOOR PACKAGE 1EA PER PACK	32
142-027-1	UNIT, AUTOBRAKE/ANTISKID,STATIC SENSITIV	32
142-147	UNIT, ANTI-SKID CONTROL,BRAKES	32
14330-004A	VALVE, AD,RINSE;TOILET	38
14330-004B	VALVE, AD,RINSE;TOILET	38

14330-050	VALVE, FLUSH, ORBITAL	38
14330-230	VALVE, FLUSH, ORBITAL	38
143A6110-1	DOOR ASSY; FWD CARGO; 737 A/C 3709-3771	52
143A6110-1	DOOR ASSY; FWD CARGO; 737 A/C 3709-3771	52
143A6110-1	DOOR ASSY; FWD CARGO; 737 A/C 3709-3771	52
143A6110-1	DOOR ASSY; FWD CARGO; 737 A/C 3709-3771	52
143A6110-1	DOOR ASSY; FWD CARGO; 737 A/C 3709-3771	52
143A6110-1	DOOR ASSY; FWD CARGO; 737 A/C 3709-3771	52
143A6110-1	DOOR ASSY; FWD CARGO; 737 A/C 3709-3771	52
143A6110-2	DOOR ASSY; FWD CARGO; 737 A/C 3709-3771	52
143A6110-2	DOOR ASSY; FWD CARGO; 737 A/C 3709-3771	52
143A6110-2	DOOR ASSY; FWD CARGO; 737 A/C 3709-3771	52
143A6110-2	DOOR ASSY; FWD CARGO; 737 A/C 3709-3771	52
143A6110-2	DOOR ASSY; FWD CARGO; 737 A/C 3709-3771	52
143A6110-2	DOOR ASSY; FWD CARGO; 737 A/C 3709-3771	52
143A6110-2	DOOR ASSY; FWD CARGO; 737 A/C 3709-3771	52
143A6110-2	DOOR ASSY; FWD CARGO; 737 A/C 3709-3771	52
143A6110-2	DOOR ASSY; FWD CARGO; 737 A/C 3709-3771	52
143A6110-2	DOOR ASSY; FWD CARGO; 737 A/C 3709-3771	52
143A6110-3	DOOR ASSY; FWD CARGO; 737 A/C 3709-3771	52
143A6110-3	DOOR ASSY; FWD CARGO; 737 A/C 3709-3771	52
143A6110-3	DOOR ASSY; FWD CARGO; 737 A/C 3709-3771	52
143A6110-3	DOOR ASSY; FWD CARGO; 737 A/C 3709-3771	52
143A6110-5	DOOR ASSY; FWD CARGO; 737 A/C 3709-3771	52
143A6110-6	DOOR ASSY; FWD CARGO; 737 A/C 3709-3771	52
143A6110-7	DOOR ASSY; FWD CARGO; 737 A/C 3709-3771	52
143A6110-8	DOOR ASSY; FWD CARGO; 737 A/C 3709-3771	52
143A6110-9	DOOR ASSY; FWD CARGO; 737 A/C 3709-3771	52
143D6354G	THRUST MODE SELECT PANEL	22
143D6470P	THRUST MODE SELECT PANEL	22
143N6100-2	NO. 2 PASSENGER DOOR ASSEMBLY	52
143N6100-2	NO. 2 PASSENGER DOOR ASSEMBLY	52
143N6100-2	NO. 2 PASSENGER DOOR ASSEMBLY	52
143N6100-2	NO. 2 PASSENGER DOOR ASSEMBLY	52

143N6100-2	NO. 2 PASSENGER DOOR ASSEMBLY	52
143N6100-2	NO. 2 PASSENGER DOOR ASSEMBLY	52
143N6100-3	NO. 2 PASSENGER DOOR ASSEMBLY	52
143N6100-4	NO. 2 PASSENGER DOOR ASSEMBLY	52
143N6100-7	NO. 2 PASSENGER DOOR ASSEMBLY	52
143N6100-8	NO. 2 PASSENGER DOOR ASSEMBLY	52
143N6100-7	NO. 2 PASSENGER DOOR ASSEMBLY	
143N6105-1	NO. 2 PASSENGER DOOR ASSEMBLY	52
143N6105-2	NO. 2 PASSENGER DOOR ASSEMBLY	52
143N6106-3	GATE, LWR PASS DOOR NO 2 LEFT; ALUMINUM	52
143N6106-4	GATE, LWR PASS DOOR NO 2 LEFT; ALUMINUM	52
143N6106-5	NO. 4 PASSENGER DOOR ASSEMBLY	52
143N6106-6	NO. 4 PASSENGER DOOR ASSEMBLY	52
143N6191-7	PASSENGER DOOR COUNTERBALANCE ASSEMBLY	52
143N6191-8	PASSENGER DOOR COUNTERBALANCE ASSEMBLY	52
143N6192-1	CAMSHAFT, COUNTER BALANCE, ASSY,L/H DOOR	52
143N6603-1	NO. 1 CARGO DOOR ASSEMBLY	52
143N6603-4	NO. 1 CARGO DOOR ASSEMBLY	52
143N6603-4	NO. 1 CARGO DOOR ASSEMBLY	52
143N6603-5	NO. 1 CARGO DOOR ASSEMBLY	52
143N6603-5	NO. 1 CARGO DOOR ASSEMBLY	52
143N6603-5	NO. 1 CARGO DOOR ASSEMBLY	52
143N6603-7	NO. 1 CARGO DOOR ASSEMBLY	
144-127-00	NBR 1 BEARING VIBRATION SENSOR ACCELEROMETER	77
144-127-00	NBR 1 BEARING VIBRATION SENSOR ACCELEROMETER	77
144-151-00	NBR 1 BEARING VIBRATION SENSOR ACCELEROMETER	71
144-151-00	ACCLRMTR VIBRATION ALT 144-151-000-201	71
144-155-00	ACCELEROMETER	77
144-186-00	NO. 1 BEARING ACCELEROMETER	77
144-187-00	FAN FRAME COMPRESSOR CASE VIBRATION SENSOR	77
14438-13	DUCT ANTI-ICE ALT S332N303-13 V8120	30
144-407-00	ACCLRMTR, VIBRATION SENSOR A321	77

146N6100-2	NO. 4 PASSENGER DOOR ASSEMBLY	52
146N6100-2	NO. 4 PASSENGER DOOR ASSEMBLY	52
146N6100-3	NO. 4 PASSENGER DOOR ASSEMBLY	52
146N6100-4	NO. 4 PASSENGER DOOR ASSEMBLY	52
146N6100-7	NO. 4 PASSENGER DOOR ASSEMBLY	
146N6105-3	NO. 4 PASSENGER DOOR ASSEMBLY	52
146N6105-5	NO. 4 PASSENGER DOOR ASSEMBLY	52
146N6105-6	NO. 4 PASSENGER DOOR ASSEMBLY	52
146N6106-5	NO. 4 PASSENGER DOOR ASSEMBLY	52
146N6106-6	NO. 4 PASSENGER DOOR ASSEMBLY	52
146N6106-6	NO. 4 PASSENGER DOOR ASSEMBLY	52
146N6133-4	PASSENGER DOOR COUNTERBALANCE ASSEMBLY	52
146N6133-5	PASSENGER DOOR COUNTERBALANCE ASSEMBLY	52
146N6133-6	PASSENGER DOOR COUNTERBALANCE ASSEMBLY	52
146N6134-1	CAMSHAFT, COUNTER BALANCE, ASSY,L/H DOOR	52
146N6134-2	CAMSHAFT, COUNTER BALANCE, ASSY,L/H DOOR	52
146N6603-1	NO. 2 CARGO DOOR ASSEMBLY	52
146N6603-1	NO. 2 CARGO DOOR ASSEMBLY	52
146N6603-1	NO. 2 CARGO DOOR ASSEMBLY	52
146N6603-1	NO. 2 CARGO DOOR ASSEMBLY	52
146N6603-2	NO. 2 CARGO DOOR ASSEMBLY	52
146N6603-2	NO. 2 CARGO DOOR ASSEMBLY	52
146N6603-5	NO. 2 CARGO DOOR ASSEMBLY	52
146N6603-5	NO. 2 CARGO DOOR ASSEMBLY	52
146N6603-5	NO. 2 CARGO DOOR ASSEMBLY	52
146N6603-5	NO. 2 CARGO DOOR ASSEMBLY	52
146N6603-5	NO. 2 CARGO DOOR ASSEMBLY	52
146N6603-5	NO. 2 CARGO DOOR ASSEMBLY	52
146N6603-5	NO. 2 CARGO DOOR ASSEMBLY	52
146N6603-5	NO. 2 CARGO DOOR ASSEMBLY	52
146N6603-7	NO. 2 CARGO DOOR ASSEMBLY	
146T6387-6	TUBE.SPRING.BAL.SYS BULK CARGO DOOR	52
146T6387-8	TUBE.SPRING.BAL.SYS BULK CARGO DOOR	52
147425-2	VALVE, HYD MANUAL,3-POSITION 3-PORT,FUSE	32

147425-3	VALVE, HYD MANUAL,3-POSITION 3-PORT,FUSE	32
147820-1	SELECTOR CABIN PRESSURE(TRACKING PURPOSE	21
147A6116-1	WINDOW OBSERVATION	52
147A6116-2	WINDOW OBSERVATION	52
147A6116-2	WINDOW OBSERVATION	52
147A6502-1	DOOR ASSY, AFT GALLEY; 737 ACFT 3701-71	52
148N6401-2	DOOR,ASSY	52
148N6660-1	AUXILLARY POWER UNIT ACCESS DOOR ASSEMBLY	52
148N6660-1	AUXILLARY POWER UNIT ACCESS DOOR ASSEMBLY	52
148N6660-1	AUXILLARY POWER UNIT ACCESS DOOR ASSEMBLY	52
148N6660-1	AUXILLARY POWER UNIT ACCESS DOOR ASSEMBLY	52
148N6660-1	AUXILLARY POWER UNIT ACCESS DOOR ASSEMBLY	52
148N6660-2	AUXILLARY POWER UNIT ACCESS DOOR ASSEMBLY	52
148N6660-2	AUXILLARY POWER UNIT ACCESS DOOR ASSEMBLY	52
148N6660-2	AUXILLARY POWER UNIT ACCESS DOOR ASSEMBLY	52
148N6660-2	AUXILLARY POWER UNIT ACCESS DOOR ASSEMBLY	52
148N6660-3	AUXILLARY POWER UNIT ACCESS DOOR ASSEMBLY	52
148N6660-3	AUXILLARY POWER UNIT ACCESS DOOR ASSEMBLY	
148T6402-2	DOOR,ASSY	52
149N6002-6	MAIN LANDING GEAR DOOR ASSEMBLY	32
149N6002-7	MAIN LANDING GEAR DOOR ASSEMBLY	32
149N6002-7	MAIN LANDING GEAR DOOR ASSEMBLY	32
149N6002-7	MAIN LANDING GEAR DOOR ASSEMBLY	32
149N7314-1	AIR CONDITION ACCESS DOOR ASSEMBLY	52
149N7314-1	AIR CONDITION ACCESS DOOR ASSEMBLY	52
149N7314-5	AIR CONDITION ACCESS DOOR ASSEMBLY	52
149N7314-6	AIR CONDITION ACCESS DOOR ASSEMBLY	52
149N7314-7	AIR CONDITION ACCESS DOOR ASSEMBLY	52
149N7314-7	AIR CONDITION ACCESS DOOR ASSEMBLY	52
149N7314-8	AIR CONDITION ACCESS DOOR ASSEMBLY	52
149N7314-8	AIR CONDITION ACCESS DOOR ASSEMBLY	52
149N7314-9	AIR CONDITION ACCESS DOOR ASSEMBLY	52

149N7314-9	AIR CONDITION ACCESS DOOR ASSEMBLY	52
149N7314-9	AIR CONDITION ACCESS DOOR ASSEMBLY	52
149N7314-7	AIR CONDITION ACCESS DOOR ASSEMBLY	
149N7316-1	AIR CONDITION ACCESS DOOR ASSEMBLY	52
149N7316-1	AIR CONDITION ACCESS DOOR ASSEMBLY	52
149N7316-1	AIR CONDITION ACCESS DOOR ASSEMBLY	52
149N7316-1	AIR CONDITION ACCESS DOOR ASSEMBLY	52
149N7316-1	AIR CONDITION ACCESS DOOR ASSEMBLY	52
149N7316-1	AIR CONDITION ACCESS DOOR ASSEMBLY	52
149N7316-1	AIR CONDITION ACCESS DOOR ASSEMBLY	52
149N7316-2	AIR CONDITION ACCESS DOOR ASSEMBLY	52
149N7316-3	AIR CONDITION ACCESS DOOR ASSEMBLY	52
149N7316-4	AIR CONDITION ACCESS DOOR ASSEMBLY	52
149N7316-9	AIR CONDITION ACCESS DOOR ASSEMBLY	52
149N7316-9	AIR CONDITION ACCESS DOOR ASSEMBLY	
149N7316-7	AIR CONDITION ACCESS DOOR ASSEMBLY	
149T6100-3	MAIN LANDING GEAR DOOR ASSEMBLY	32
149T6100-4	MAIN LANDING GEAR DOOR ASSEMBLY	32
149T6100-4	MAIN LANDING GEAR DOOR ASSEMBLY	32
149T6910-1	DOOR MLG LH, KIT ASSY MUST BE USABLE ON	32
149T6910-6	DOOR MLG LH, KIT ASSY MUST BE USABLE ON	32
14A640-101	DUCT PWA4060 QEC-START SYSTEM IN STL	36
14A641-105	DUCT PWA4060 QEC-START SYSTEM IN STL	36
14J44-1	BLEED AIR DUCT ASSEMBLY	49
14J45-1	FLEXIBLE JOINT ASSEMBLY	36
14J81-2	BLEED AIR DUCT ASSEMBLY	49
1500-0500-	MULTIPLE MODEL HGS CONTROL PANEL	31
1500-2300-	MODEL 4000 OVERHEAD UNIT	34
1500-2310-	COMBINER-MODEL 4000 HGS	34
1500-2310-	COMBINER-MODEL 4000 HGS	34
1500-2360-	MODEL 4000 OVERHEAD UNIT	34
1500-2430-	MULTIPLE MODEL DIGITAL HGS ANNUNCIATOR PANEL	31
1500-2460-	MODEL 4000 HGS COMPUTER	34

1500-2460-	MODEL 4000 HGS COMPUTER	34
1500-2460-	MODEL 4000 HGS COMPUTER	34
1500P0205	SWITCH	38
1500P0228	SWITCH CLIMB PRESS....	21
15-0726-3	LIGHT CHART AND HEADS UP DISPLAY CAPTAIN	33
15-0726-9	LIGHT CHART AND HEADS UP DISPLAY CAPTAIN	33
1519M89P2	UNIT, ELECTRONIC, CNTL; ECU; INSOURCE;	73
1519M89P2	UNIT, ELECTRONIC, CNTL; ECU; INSOURCE;	73
1519M89P3	UNIT, ELECTRONIC, CNTL; ECU; INSOURCE;	73
1519M89P3	UNIT, ELECTRONIC, CNTL; ECU; INSOURCE;	73
1519M97P0	THERMOCOUPLE CABLES AND JUNCTION BOXES	77
1527100-1	SERVO YAW DAMPER USED ON A/C 101-115 AND	22
1527100-3	SERVO YAW DAMPER USED ON A/C 101-115 AND	22
1527700-3	POWER CONTROL UNIT - AILERON	27
1527700-5	POWER CONTROL UNIT - AILERON	27
1529200-1	YAW DAMPER SERVO	27
1536600-1	YAW DAMPER SERVO	22
1536600-3	YAW DAMPER SERVO	22
1536600-5	YAW DAMPER SERVO	22
1536600-7	YAW DAMPER SERVO	22
1540500-1	YAW DAMPER SERVO	22
1540500-11	YAW DAMPER SERVO	22
1540500-3	YAW DAMPER SERVO	22
1540500-5	YAW DAMPER SERVO	22
1540500-7	YAW DAMPER SERVO	22
1540500-9	YAW DAMPER SERVO	22
1540600-1	AILERON POWER CONTROL UNIT ASSEMBLY	27
1540600-3	AILERON POWER CONTROL UNIT ASSEMBLY	27
154152-3	VALVE HYD TRANSFER PUMP SHUTOFF USED ON	29
1542500-1	INBOARD SPOILER POWER CONTROL ACTUATOR ASSEM	27
1542500-11	INBOARD SPOILER POWER CONTROL ACTUATOR ASSEM	27
1542500-3	INBOARD SPOILER POWER CONTROL ACTUATOR ASSEM	27

1542500-5	INBOARD SPOILER POWER CONTROL ACTUATOR ASSEM	27
1542500-7	INBOARD SPOILER POWER CONTROL ACTUATOR ASSEM	27
1542500-9	INBOARD SPOILER POWER CONTROL ACTUATOR ASSEM	27
1542600-1	OUTBOARD SPOILER POWER CONTROL ACTUATOR ASS	27
1542600-13	OUTBOARD SPOILER POWER CONTROL ACTUATOR ASS	27
1542600-3	OUTBOARD SPOILER POWER CONTROL ACTUATOR ASS	27
1542600-5	OUTBOARD SPOILER POWER CONTROL ACTUATOR ASS	27
1542600-7	OUTBOARD SPOILER POWER CONTROL ACTUATOR ASS	27
1542600-9	OUTBOARD SPOILER POWER CONTROL ACTUATOR ASS	27
1546-1-2	FLIGHT COMPARTMENT INSTRUMENT PANEL FLOODLIGI	33
1546-1-3	FLIGHT COMPARTMENT INSTRUMENT PANEL FLOODLIGI	33
1546-1-4	FLIGHT COMPARTMENT INSTRUMENT PANEL FLOODLIGI	33
1546-1-5	FLIGHT COMPARTMENT INSTRUMENT PANEL FLOODLIGI	33
1546-1-6	FLIGHT COMPARTMENT INSTRUMENT PANEL FLOODLIGI	33
1547-1	FLIGHT COMPARTMENT INSTRUMENT PANEL FLOODLIGI	33
1547-1-1	FLIGHT COMPARTMENT INSTRUMENT PANEL FLOODLIGI	33
1548-1-2	FLIGHT COMPARTMENT INSTRUMENT PANEL FLOODLIGI	33
154LUA102	VALVE POSITION INDICATOR	21
154LUA103	VALVE POSITION INDICATOR	21
154LUA104	VALVE POSITION INDICATOR	21
154LUA105	VALVE POSITION INDICATOR	21
157720-1	ACTUATOR VALVE SHIP IN ATA SPEC 300	27
15800-011-	VACUUM TOILET ASSEMBY	38
15800-012-	VACUUM TOILET ASSEMBY	38
15800-019-	VACUUM TOILET ASSEMBY	38
15800-019-	VACUUM TOILET ASSEMBY	38
15800-029-	VACUUM TOILET ASSEMBY	
15800-029-	VACUUM TOILET ASSEMBY	38
15800-029-	VACUUM TOILET ASSEMBY	38
15800-305	TOILET BOWL	38
15800-348	VALVE, FLUSH, ORBITAL	38
15800-348A	VALVE, FLUSH, ORBITAL	38

15800-358	VALVE,RINSE;TOILET	38
158300-101	HYDRAULIC AUTOPILOT ACTUATOR ASSEMBLY	27
160000-101	STABALIZER TRIM CONTROL MODULE ASSEMBLY	27
160000-101	STABALIZER TRIM CONTROL MODULE ASSEMBLY	
160000-102	STABALIZER TRIM CONTROL MODULE ASSEMBLY	27
160000-103	STABALIZER TRIM CONTROL MODULE ASSEMBLY	27
160000-104	STABALIZER TRIM CONTROL MODULE ASSEMBLY	27
160100-105	STABILIZER TRIM CONTROL MODULE	27
160100-106	STABILIZER TRIM CONTROL MODULE	27
160100-107	STABILIZER TRIM CONTROL MODULE	27
160100-113	STABILIZER TRIM CONTROL MODULE	27
160100-114	STABILIZER TRIM CONTROL MODULE	27
160201-100	STABILIZER CONTROL MODULE	27
160201-101	STABILIZER CONTROL MODULE	27
160201-102	STABILIZER CONTROL MODULE	27
160202-100	STABILIZER CONTROL MODULE	27
160202-101	STABILIZER CONTROL MODULE	27
1604220-00	TURBINE CASE COOLING AIR VAVLE CONTROL CABLE - I	75
160500-100	STABILIZER CONTROL BRAKE ASSEMBLY	27
160500-101	STABILIZER CONTROL BRAKE ASSEMBLY	27
1610000-10	ACTUATOR, THRUST REVERSER FEEDBACK; A330	78
1610000-17	ACTUATOR ASSY, THRUST REVERSER LOCKING	78
161N0001-1	MLG TRUCK POSITIONER ACTUATOR ASSEMBLY	32
161N0001-1	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
161N0001-1	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
161N0001-1	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
161N0001-1	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
161N0001-2	MLG TRUCK POSITIONER ACTUATOR ASSEMBLY	32
161N0001-4	MLG TRUCK POSITIONER ACTUATOR ASSEMBLY	32
161N0001-5	MLG DOWNLOCK ACTUATOR ASSEMBLY	32
161N0001-5	MLG DOWNLOCK ACTUATOR ASSEMBLY	
161N0001-8	MLG DOWNLOCK ACTUATOR ASSEMBLY	32

161N5001-5	ACTUATOR MLG UPLOCK RELEASE ASSY	32
161N5001-7	ACTUATOR MLG UPLOCK RELEASE ASSY	32
161T1211-1	CAP ASSY, MLG HUB, UPON RECEIPT SENT TO	32
16200-001	TOILET ASSEMBLY	38
16200-002	TOILET ASSEMBLY	38
16200-007	TOILET ASSEMBLY	38
16200-008	TOILET ASSEMBLY	38
162000-101	ELEVATOR FEEL SYSTEM COMPUTER ASSEMBLY	
162000-102	ELEVATOR FEEL SYSTEM COMPUTER ASSEMBLY	27
162000-103	ELEVATOR FEEL SYSTEM COMPUTER ASSEMBLY	27
162000-104	ELEVATOR FEEL SYSTEM COMPUTER ASSEMBLY	27
162000-105	ELEVATOR FEEL SYSTEM COMPUTER ASSEMBLY	27
162000-106	ELEVATOR FEEL SYSTEM COMPUTER ASSEMBLY	
16200-011	TOILET ASSEMBLY	38
16200-013	TOILET ASSEMBLY	38
16200-018	TOILET ASSEMBLY	38
16200-019	TOILET ASSEMBLY	38
16200-020	TOILET ASSEMBLY	38
16200-022	TOILET ASSEMBLY	38
16200-023	TOILET ASSEMBLY	38
16200-024	TOILET ASSEMBLY	38
16200-024S	TOILET ASSEMBLY	38
16200-025	TOILET ASSEMBLY	38
16200-028	TOILET ASSY, LAV. C , POST EO 06-467452-	38
16200-029	TOILET ASSY, LAV. C , POST EO 06-467452-	38
16200-030	TOILET ASSY, LAV. C , POST EO 06-467452-	38
162005-102	ELEVATOR FEEL SYSTEM COMPUTER ASSEMBLY	27
16204-001	MOTOR-PUMP-FILTER ASSEMBLY	38
16204-002	MOTOR-PUMP-FILTER ASSEMBLY	38
16205-001	DRAIN VALVE ASSEMBLY	38
16205-002	DRAIN VALVE ASSEMBLY	38
16205-012	DRAIN VALVE ASSEMBLY	38

162300-103	ELEVATOR FEEL SYSTEM COMPUTER ASSEMBLY	27
162700-100	ELEVATOR FEEL SYSTEM COMPUTER ASSEMBLY	27
162900-100	ELEVATOR FEEL SYSTEM COMPUTER ASSEMBLY	27
162A3108-3	ROD PUSH, NLG DOOR MECHANISM	32
162BL701	ELECTRICAL RESISTANCE THERMOMETER	28
162BL704D	ELECTRICAL RESISTANCE THERMOMETER	79
162BL708	ELECTRICAL RESISTANCE THERMOMETER	21
162BL801	ELECTRICAL RESISTANCE THERMOMETER	28
162BL802A	ELECTRICAL RESISTANCE THERMOMETER	79
162BL903	ELECTRICAL RESISTANCE THERMOMETER	79
162N0001-1	NOSE LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
162N0001-3	NOSE LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
16300-001	TOILET ASSEMBLY	38
16300-008	TOILET ASSEMBLY	38
163000-103	LATERAL CONTROL AUTOPILOT SERVO ASSEMBLY	22
163000-104	LATERAL CONTROL AUTOPILOT SERVO ASSEMBLY	22
163000-105	LATERAL CONTROL AUTOPILOT SERVO ASSEMBLY	22
163000-106	LATERAL CONTROL AUTOPILOT SERVO ASSEMBLY	22
163000-108	LATERAL CONTROL AUTOPILOT SERVO ASSEMBLY	22
16300-011	TOILET ASSEMBLY	38
16300-013	TOILET ASSEMBLY	38
163100-101	PITCH CONTROL AUTOPILOT	22
163100-102	PITCH CONTROL AUTOPILOT	22
163100-103	PITCH CONTROL AUTOPILOT	22
163100-104	PITCH CONTROL AUTOPILOT	22
163100-105	PITCH CONTROL AUTOPILOT	22
163100-106	PITCH CONTROL AUTOPILOT	22
163100-107	PITCH CONTROL AUTOPILOT	22
163200-100	ROLLOUT GUIDANCE AUTOPILOT SERVO ASSEMBLY	22
163200-101	ROLLOUT GUIDANCE AUTOPILOT SERVO ASSEMBLY	22
163200-102	ROLLOUT GUIDANCE AUTOPILOT SERVO ASSEMBLY	22
163200-103	ROLLOUT GUIDANCE AUTOPILOT SERVO ASSEMBLY	22

163200-105	ROLLOUT GUIDANCE AUTOPILOT SERVO ASSEMBLY	22
163CV57	WATER & WASTE QUANTITY INDICATOR	38
163CV58	WATER & WASTE QUANTITY INDICATOR	38
163CV60	WATER & WASTE QUANTITY INDICATOR	38
163CV61	WATER & WASTE QUANTITY INDICATOR	38
163CV65	WATER & WASTE QUANTITY INDICATOR	38
163CV67	WATER QUANTITY INDICATOR	38
163LCP78	BRAKE ACCUMULATOR PRESSURE INDICATORS	32
163LCP80	BRAKE ACCUMULATOR PRESSURE INDICATOR	32
163T0000-0	STRUT TAIL SKID SHOCK USED ON B767 A/C 1	32
1655-1-2	UNIT, HEATER CONTROL UNIT,USED ON A/C 90	30
165T0210-1	CAP ASSY, MLG HUB, UPON RECEIPT SENT TO	32
16600-007	TOILET ASSEMBLY	38
16600-007S	TOILET ASSEMBLY	38
16600-008	TOILET ASSEMBLY	38
16600-016	TOILET ASSEMBLY	38
16600-017	TOILET ASSEMBLY	38
16600-021	TOILET ASSEMBLY	38
16600-022	TOILET ASSEMBLY	38
16632142-0	COMPUTER, PROBE HEAT, A319/A32...	30
16632142-0	COMPUTER, PROBE HEAT, A319/A32...	30
16800-1	SEAT, OBSERVERS, ALL DC9;	25
16810-1	FIRST & SECOND OBSERVER SEAT ASSEMBLIES	25
16810-3	FIRST & SECOND OBSERVER SEAT ASSEMBLIES	25
1696M81P1	PROBE, EGT THERMOCOUPLE CF680C2/80E1	77
1696M81P1	PROBE, EGT THERMOCOUPLE CF680C2/80E1	77
1697EA	VALVE SPEED BRAKE CONTROL EQUIV 1697EA	27
1697EA1	VALVE SPEED BRAKE CONTROL EQUIV 1697EA	27
1697M50G0	HARNESS, CONTROL AMPLIFIER	72
1697M50G0	HARNESS, CONTROL AMPLIFIER	74
1697M50G0	HARNESS, CONTROL AMPLIFIER	74
1697M51G0	HARNESS, CONTROL AMPLIFIER	72

1700667D	CONTROL UNIT, GROUND POWER, GAPCU; A330	24
1701422A	ROTOR,HOUSING, B737NG IDG	24
1705800-1	ELEVATOR FEEL SHIFT MODULE	27
171497-05-	FLIGHT MANAGEMENT COMPUTER	34
173A0100-6	RUDDER, ASSY; 737NG	27
173A0103-1	RUDDER, ASSY; 737NG	55
173A0103-1	RUDDER, ASSY; 737NG	55
173A0103-2	RUDDER, ASSY; 737NG	55
173A0103-3	RUDDER, ASSY; 737NG	55
173A0103-4	RUDDER, ASSY; 737NG	55
173A0103-5	RUDDER, ASSY; 737NG	55
173A0103-6	RUDDER, ASSY; 737NG	55
173A0103-7	RUDDER, ASSY; 737NG	27
173A0103-8	RUDDER, ASSY; 737NG	55
173A0103-9	RUDDER, ASSY; 737NG	55
173N1032-1	RUDDER, ASSY; 737NG	55
173N2101-1	RUDDER ASSEMBLY	27
173N2101-1	RUDDER ASSEMBLY	27
173N2101-4	RUDDER ASSEMBLY	27
173N2101-4	RUDDER ASSEMBLY	55
173N2101-9	RUDDER ASSEMBLY	27
173N2101-9	RUDDER ASSEMBLY	55
173N2101-7	RUDDER ASSEMBLY	
173T2001-1	RUDDER ASSEMBLY	55
173T2001-1	RUDDER ASSEMBLY	27
173T2001-2	RUDDER ASSEMBLY	55
173T2001-2	RUDDER ASSEMBLY	55
173T2001-4	RUDDER ASSEMBLY	55
174101-02-	UNIT MULTI PURPOSE CONTROL AND DISPLAY	34
174101-02-	UNIT MULTI PURPOSE CONTROL AND DISPLAY	34
174101-03-	UNIT MULTI PURPOSE CONTROL AND DISPLAY	34
1742F3	LOGIC CONTROL MODULE	38

1742F5	LOGIC CONTROL MODULE	38
1742F6	LOGIC CONTROL MODULE	38
1742F8	LOGIC CONTROL MODULE	38
1742F9	LOGIC CONTROL MODULE	38
176236-50	BOTTLE, CYLINDER ASSY, CREW O2; 717	35
176529-47	CYLINDER, AD, O2, CREW; 48CF DC9-30/-50	35
176529-67	CYLINDER, AD, O2, CREW; 48CF DC9-30/-50	35
1774J1	ELECTRICAL CABLE	38
1797MK3	ACTUATOR MASTER, FURNISHED WITH SELECTED	75
17P67-1	VALVE, NBR 2 BEARING DAMPER	72
18-1958-11	FLAP POSITION TRANSMITTER	27
18-1958-12	FLAP POSITION TRANSMITTER	27
18-1958-13	FLAP POSITION TRANSMITTER	27
18-1958-15	FLAP POSITION TRANSMITTER	27
18-1958-16	FLAP POSITION TRANSMITTER	27
18-1958-17	FLAP POSITION TRANSMITTER	27
18-1958-20	FLAP POSITION TRANSMITTER	27
18-1958-21	FLAP POSITION TRANSMITTER	27
18-1958-9	FLAP POSITION TRANSMITTER	27
181RA71R2	CARGO SYSTEM POWER DRIVE UNIT	25
181RA71R2	CARGO SYSTEM POWER DRIVE UNIT	25
181RA71R2	CARGO SYSTEM POWER DRIVE UNIT	25
1820M33P0	ELECTRONIC CONTROL UNIT (ECU) - CF6-80C2	73
1820M33P0	ELECTRONIC CONTROL UNIT (ECU) - CF6-80C2	73
1820M33P0	ELECTRONIC CONTROL UNIT (ECU) - CF6-80C2	73
1820M33P0	ELECTRONIC CONTROL UNIT (ECU) - CF6-80C2	73
1820M33P0	ELECTRONIC CONTROL UNIT (ECU) - CF6-80C2	73
1820M33P0	ELECTRONIC CONTROL UNIT (ECU) - CF6-80C2	73
1820M33P0	ELECTRONIC CONTROL UNIT (ECU) - CF6-80C2	73
1820M33P0	ELECTRONIC CONTROL UNIT (ECU) - CF6-80C2	73
1820M33P1	ELECTRONIC CONTROL UNIT (ECU) - CF6-80C2	73
1820M33P1	ELECTRONIC CONTROL UNIT (ECU) - CF6-80C2	73
1820M33P1	ELECTRONIC CONTROL UNIT (ECU) - CF6-80C2	73

1820M33P1	ELECTRONIC CONTROL UNIT (ECU) - CF6-80C2	73
1827T100-3	ACTUATOR, CARGO HANDLING,STOP LOCK FWD A	25
1827T100-5	ACTUATOR, CARGO HANDLING,STOP LOCK FWD A	25
1827T100-7	ACTUATOR, CARGO HANDLING,STOP LOCK FWD A	25
183A0103-1	ELEVATOR ASSEMBLY AND TAB ASSEMBLY	55
183A0103-1	ELEVATOR ASSEMBLY AND TAB ASSEMBLY	55
183A0103-1	ELEVATOR ASSEMBLY AND TAB ASSEMBLY	55
183A0103-1	ELEVATOR ASSEMBLY AND TAB ASSEMBLY	55
183A0103-1	ELEVATOR ASSEMBLY AND TAB ASSEMBLY	55
183A0103-1	ELEVATOR ASSEMBLY AND TAB ASSEMBLY	55
183A0103-2	ELEVATOR ASSEMBLY AND TAB ASSEMBLY	55
183A0103-3	ELEVATOR ASSEMBLY AND TAB ASSEMBLY	55
183A0103-4	ELEVATOR ASSEMBLY AND TAB ASSEMBLY	55
183A0103-5	ELEVATOR ASSEMBLY AND TAB ASSEMBLY	55
183A0103-7	ELEVATOR ASSEMBLY AND TAB ASSEMBLY	55
183A0103-8	ELEVATOR ASSEMBLY AND TAB ASSEMBLY	55
183A8100-5	ELEVATOR ASSEMBLY AND TAB ASSEMBLY	55
183A8100-6	ELEVATOR ASSEMBLY AND TAB ASSEMBLY	55
183N2003-1	ELEVATOR ASSEMBLY	55
183N2003-2	ELEVATOR ASSEMBLY	55
183N2003-2	ELEVATOR ASSEMBLY	55
183N2003-2	ELEVATOR ASSEMBLY	55
183N2003-2	ELEVATOR ASSEMBLY	55
183N2003-2	ELEVATOR ASSEMBLY	55
183N2003-2	ELEVATOR ASSEMBLY	55
183N2003-2	ELEVATOR ASSEMBLY	55
183N2003-3	ELEVATOR ASSEMBLY	55
183N2003-3	ELEVATOR ASSEMBLY	55
183N2003-3	ELEVATOR ASSEMBLY	55
183N2003-3	ELEVATOR ASSEMBLY	55
183N2003-3	ELEVATOR ASSEMBLY	55
183N2003-3	ELEVATOR ASSEMBLY	55
183N2003-4	ELEVATOR ASSEMBLY	55
183N2003-4	ELEVATOR ASSEMBLY	55

1853M33P0	ELECTRONIC CONTROL UNIT	73
1853M33P0	ELECTRONIC CONTROL UNIT	73
1853M33P0	ELECTRONIC CONTROL UNIT	73
1853M33P0	ELECTRONIC CONTROL UNIT	73
1853M56P0	HYDROMECHANICAL UNIT	73
1853M56P0	HYDROMECHANICAL UNIT	73
1853M56P0	HYDROMECHANICAL UNIT	73
1853M56P1	HYDROMECHANICAL UNIT	73
1853M56P1	HYDROMECHANICAL UNIT	73
1853M56P1	HYDROMECHANICAL UNIT	73
1853M56P1	HYDROMECHANICAL UNIT	73
1853M56P1	HYDROMECHANICAL UNIT	73
1853M56P1	HYDROMECHANICAL UNIT	73
1853M58G0	HARNESS, ELECTRICAL W11,	73
1853M59G0	HARNESS, ELECTRICAL W11,	72
1853M60G0	HARNESS, ELECTRICAL W11,	73
1853M61G0	HARNESS, ELECTRICAL W11,	73
1853M62G0	HARNESS, ELECTRICAL W11,	73
1853M63G0	HARNESS, ELECTRICAL W11,	73
1853M64G0	HARNESS, ELECTRICAL W11,	73
1853M64G0	HARNESS, ELECTRICAL W11,	73
18-5600-1	PRECHARGE SHUTOFF VALVE ASSEMBLY	38
1867M63G0	FUEL MANIFOLD	73
1867M64G0	FUEL MANIFOLD	73
186A1001-1	EDGE HORIZONTAL STAB, RH LEADING USED ON	55
186A1001-1	EDGE HORIZONTAL STAB, RH LEADING USED ON	55
186A1001-3	EDGE HORIZONTAL STAB, RH LEADING USED ON	55
186A1001-4	EDGE HORIZONTAL STAB, RH LEADING USED ON	55
186A1001-7	EDGE HORIZONTAL STAB, RH LEADING USED ON	55
186A1001-8	EDGE HORIZONTAL STAB, RH LEADING USED ON	55
18-8000-2	VALVE SHUT OFF, TOILET	38
1880T100-1	ROTARY ACTUATOR	25
1882M60G0	FUEL MANIFOLD	73

1882M60G0	FUEL MANIFOLD	73
1882M61G0	FUEL MANIFOLD	73
1882M61G0	FUEL MANIFOLD	73
1882M62G0	FUEL MANIFOLD	73
1882M62G0	FUEL MANIFOLD	73
1882M63G0	FUEL MANIFOLD	73
1882M63G0	FUEL MANIFOLD	73
18928HAS	CABLE ASSY OF THERMOCOUPLE, 1,2,3 UPON.R	77
18929HAS	EGT THERMOCOUPLE CABLE AND BOX ASSEMBLY	77
192AD1R21	UNIT, PWR DRIVE CARGO COMPARTMENT CONVEY	25
194278-4	WATER EXTRACTOR	21
1962M86P0	EGT THERMOCOUPLE PROBE	77
1971M17G0	FUEL MANIFOLD	73
1971M18G0	FUEL MANIFOLD	73
1971M63G0	FUEL MANIFOLD	73
1971M63G0	FUEL MANIFOLD	73
19-99-21	PANEL AUTOBRAKE CONTROL MUST BE USABLE O	32
1A071-0315	SEAT, CO PILOT W/OUT HEADREST	25
1A071-0316	SEAT, CO PILOT W/OUT HEADREST	25
1A081-0155	FLUSH TIMER SWITCH	38
1A081-0155	FLUSH TIMER SWITCH	38
1A081-0157	LAVATORY WATER HEATER	38
1A081-0163	LATCH BI-FOLD DOOR, LAV M PACKAGE 1EA PE	25
1A081-0163	LATCH BI-FOLD DOOR, LAV M PACKAGE 1EA PE	25
1A082-0213	FAUCET AND DRAIN VALVE	38
1A082-0213	FAUCET AND DRAIN VALVE	38
1A102-0441	CREW SEAT	25
1A102-0442	CREW SEAT	25
1A6133	EGT THERMOCOUPLE PROBE	77
1A6134	EGT THERMOCOUPLE PROBE	77
1A6714	THERMCPL OIL TEMP EQUIV 1A6714	73
1A8211-01	MANIFOLD MAIN BRG BREATHER SHIP IN ATA S	79

1B0085	ACTUATOR, INTERCOMPRESSOR	75
1B0399	EEC SPEED TRANSDUCER	77
1B1564	TUBE NO.4 BRG SCAVANGE	72
1B1884-01	No 4 BEARING SCAVENGE TUBE	79
1B2599	TUBE NO.4 BRG SCAVANGE	72
1B3125	ACTUATOR, INTERCOMPRESSOR	75
1B3378	PLUG, DATA ENTRY, CLASS 204;	73
1B5239	No.4 BEARING SCAVENGE VALVE	79
1B5847	ACTUATOR, INTERCOMPRESSOR	75
1B6287	STATOR VANE ACTUATOR ASSEMBLY	75
1B6288	STATOR VANE ACTUATOR ASSEMBLY	75
1B6732	EEC WIRING HARNESS	73
1B7023	FUEL DISTRIBUTION VALVE - PW2000	73
1B7063	ENGINE OIL DIFFERENTIAL PRESSURE SWITCH	79
1B7063-001	ENGINE OIL DIFFERENTIAL PRESSURE SWITCH	79
1B7150	PLUG, DATA ENTRY, CLASS 204;	73
1B7361	OIL PRESSURE DIFFERENTIAL SWITCH	79
1B7361-001	OIL PRESSURE DIFFERENTIAL SWITCH	79
1B7555	EEC THERMOCOUPLE	73
1B7628	FUEL CONTROL	73
1B7768	VALVE COMPRESSOR AND TURBINE CASE COOLIN	75
1B7769	VALVE COMPRESSOR AND TURBINE CASE COOLIN	75
1B7880	IGNITION EXCITER	74
1FA01114-3	VALVE MODULE - DIRECTIONAL CONTROL	78
1FA01114-4	VALVE MODULE - DIRECTIONAL CONTROL	78
1FA06101-1	DOOR RELEASE INTERLOCK ACTUATOR ASSEMBLY	27
1FA10019-5	THRUST REVERSER COWL OPENING ACTUATOR ASSEMBLY	78
1FA10019-7	THRUST REVERSER COWL OPENING ACTUATOR ASSEMBLY	78
1FA13012-6	COWL OPENING HYDRAULIC POWER UNIT ASSEMBLY	78
1FA140122	COWL OPENING HYDRAULIC POWER UNIT ASSEMBLY	78
1FA14012-6	THRUST REVERSER COWL OPENING ACTUATOR	71
1FA14012-7	THRUST REVERSER COWL OPENING ACTUATOR	71

1FA14012-8	THRUST REVERSER COWL OPENING ACTUATOR	78
1FA140132	THRUST REVERSER COWL OPENING ACTUATOR	78
1FA14013-4	THRUST REVERSER COWL OPENING ACTUATOR	78
1FA14013-5	THRUST REVERSER COWL OPENING ACTUATOR	78
1FA14013-6	THRUST REVERSER COWL OPENING ACTUATOR	78
1FA14013-7	THRUST REVERSER COWL OPENING ACTUATOR	78
1FA14013-8	THRUST REVERSER COWL OPENING ACTUATOR	78
1FA14013-9	THRUST REVERSER COWL OPENING ACTUATOR	78
1FA14013-X	THRUST REVERSER COWL OPENING ACTUATOR	
1G216	SWITCH, PRESSURE, POTABLE WATER	38
1G390	SWITCH	38
1G407	SWITCH	38
1G409	SWITCH	38
1U1065-2	COMPNSTR, FLIGHT CONTROL,MODULE, REF ERA	27
1U1302-1	LANDING GEAR SELECTOR VALVE ASSEMBLY	32
2000866-2	STARTER, APU; A320 ONLY	49
2000866-4	STARTER, APU; A320 ONLY	49
20081-0000	COMPENSATOR	28
2012-1	BATTERY POWER SUPPLY	33
20128-0101	FUEL QUANTITY TANK UNITS	28
20128-0103	FUEL QUANTITY TANK UNITS	28
20128-0104	FUEL QUANTITY TANK UNITS	28
20128-0105	FUEL QUANTITY TANK UNITS	28
20128-0107	FUEL QUANTITY TANK UNITS	28
20128-0108	FUEL QUANTITY TANK UNITS	28
20128-0109	FUEL QUANTITY TANK UNITS	28
20128-0110	FUEL QUANTITY TANK UNITS	28
20128-0112	FUEL QUANTITY TANK UNITS	28
20128-0113	FUEL QUANTITY TANK UNITS	28
20128-0115	FUEL QUANTITY TANK UNITS	28
20128-0116	FUEL QUANTITY TANK UNITS	28
20128-0117	FUEL QUANTITY TANK UNITS	28

20128-0118	FUEL QUANTITY TANK UNITS	28
20128-0119	FUEL QUANTITY TANK UNITS	28
20128-0120	FUEL QUANTITY TANK UNITS	28
20128-0121	FUEL QUANTITY TANK UNITS	28
20128-0122	FUEL QUANTITY TANK UNITS	28
20128-0123	FUEL QUANTITY TANK UNITS	28
20128-0124	FUEL QUANTITY TANK UNITS	28
20128-0125	FUEL QUANTITY TANK UNITS	28
20128-0127	FUEL QUANTITY TANK UNITS	28
20128-0128	FUEL QUANTITY TANK UNITS	28
20128-0129	FUEL QUANTITY TANK UNITS	28
20128-0130	FUEL QUANTITY TANK UNITS	28
20128-0131	FUEL QUANTITY TANK UNITS	28
20128-0132	FUEL QUANTITY TANK UNITS	28
201EDP1-1	PANEL SYSTEMS DISPLAY ELECTRO STATIC SEN	31
20200-0103	UNIT, FUEL QTY,TRANSMITTER,NO 1 AND 2 TA	28
20200-0206	UNIT, FUEL QTY,TRANSMITTER,NO 1 AND 2 TA	28
20200-0209	UNIT, FUEL QTY,TRANSMITTER,NO 1 AND 2 TA	28
20200-0213	UNIT, FUEL QTY,TRANSMITTER,NO 1 AND 2 TA	28
20200-0216	UNIT, FUEL QTY,TRANSMITTER,NO 1 AND 2 TA	28
20202-01	COMPENSATOR, FUEL QTY; RESTRICTED AIR SH	28
20202-02	COMPENSATOR, FUEL QTY; RESTRICTED AIR SH	28
20-210-01	COMPARTMENT TEMPERATURE INDICATOR	21
20-212-04	FUEL QUANTITY INDICATOR	28
20-212-07	FUEL QUANTITY INDICATOR	28
20-212-09	FUEL QUANTITY INDICATOR	28
20217-8	VALVE SOLENOID, IDLE.	73
20217-9	VALVE SOLENOID, IDLE.	73
20219-0101	HYDRAULIC OIL QUANTITY TRANSMITTER	29
2021974-1	MOTOR, ACTUATOR, RAM AIR DOOR.	21
2021974-2	MOTOR, ACTUATOR, RAM AIR DOOR.	21
20220-0101	HYDRAULIC OIL QUANTITY TRANSMITTER	29

2022014-1	MOTOR, ACTUATOR, RAM AIR DOOR.	21
2022014-2	MOTOR, ACTUATOR, RAM AIR DOOR.	21
2022014-3	MOTOR, ACTUATOR, RAM AIR DOOR.	21
2022432-1	RAM AIR DOOR ACTUATOR	21
2022432-3	RAM AIR DOOR ACTUATOR	21
2022432-4	RAM AIR DOOR ACTUATOR	21
2022432-4-	RAM AIR DOOR ACTUATOR	21
2022478-2	ALTERNATING CURRENT MOTOR	21
2022478-3	ALTERNATING CURRENT MOTOR	21
2022478-4	ALTERNATING CURRENT MOTOR	21
2022478-5	ALTERNATING CURRENT MOTOR	21
2022480-10	CABIN PRESSURE OUTFLOW VALVE ACTUATOR	21
2022480-11	CABIN PRESSURE OUTFLOW VALVE ACTUATOR	21
2022480-13	CABIN PRESSURE OUTFLOW VALVE ACTUATOR	21
2022480-14	CABIN PRESSURE OUTFLOW VALVE ACTUATOR	21
2022480-5	CABIN PRESSURE OUTFLOW VALVE ACTUATOR	21
2022480-6	CABIN PRESSURE OUTFLOW VALVE ACTUATOR	21
2022480-7	CABIN PRESSURE OUTFLOW VALVE ACTUATOR	21
2022480-8	CABIN PRESSURE OUTFLOW VALVE ACTUATOR	21
2022480-9	CABIN PRESSURE OUTFLOW VALVE ACTUATOR	21
2022522-2	ROTARY ELECTROMECHANICAL ACTUATOR	21
2022522-3	ROTARY ELECTROMECHANICAL ACTUATOR	21
2022522-4	ROTARY ELECTROMECHANICAL ACTUATOR	21
2022522-5	ROTARY ELECTROMECHANICAL ACTUATOR	21
2022538-4	CARGO POWERED DRIVE UNIT	25
2022538-5	CARGO POWERED DRIVE UNIT	25
2022538-6	CARGO POWERED DRIVE UNIT	25
2022538-7	CARGO POWERED DRIVE UNIT	25
2022538-8	CARGO POWERED DRIVE UNIT	25
2023M27G0	MANIFOLD LOW PRESSURE TURBINE PACKAGE 1	73
203BC101-	SENSOR BATTERY PACKAGE 1EA PER PACK,	24
203BC102-	SENSOR BATTERY PACKAGE 1EA PER PACK,	24

203BC102-1	CHARGER,BATTERY MAIN	24
203SA101-1	SENSOR BATTERY PACKAGE 1EA PER PACK,	24
2041167-37	DMA-37A DME INTERROGATOR	34
2041167-37	DMA-37A DME INTERROGATOR	34
2041167-37	DMA-37A DME INTERROGATOR	34
2041167-37	DMA-37A DME INTERROGATOR	34
2041168-75	ADF RECEIVER	34
2041168-75	ADF RECEIVER	34
2041168-75	ADF RECEIVER	34
2041168-75	ADF RECEIVER	34
2041168-75	ADF RECEIVER	34
2041213-04	MOUNT RECEIVER/TRANSMITTER WEATHER RADAR	34
2041217-04	RTA-4A RECEIVER-TRANSMITTER	34
2041217-04	RTA-4A RECEIVER-TRANSMITTER	34
2041217-04	RTA-4A RECEIVER-TRANSMITTER	34
2041222-04	INDICATR RADAR, TCAS.COMPATIBLE	34
2041222-04	INDICATR RADAR, TCAS.COMPATIBLE	34
2041222-04	INDICATR RADAR, TCAS.COMPATIBLE	34
2041222-04	INDICATR RADAR, TCAS.COMPATIBLE	34
2041222-04	INDICATR RADAR, TCAS.COMPATIBLE	34
2041222-04	INDICATR RADAR, TCAS.COMPATIBLE	34
2041222-24	WEATHER RADAR INDICATOR	34
2041222-24	WEATHER RADAR INDICATOR	34
2041222-24	WEATHER RADAR INDICATOR	34
2041222-44	WEATHER RADAR INDICATOR	34
2041222-44	WEATHER RADAR INDICATOR	34
2041222-64	WEATHER RADAR INDICATOR	34
2041234-34	RECEIVER, VOR/ILS,ARINC 547,STATIC SENSI	34
2041234-34	RECEIVER, VOR/ILS,ARINC 547,STATIC SENSI	34
2041234-34	RECEIVER, VOR/ILS,ARINC 547,STATIC SENSI	34
2041237-44	RTA-44A VHF TRANCEIVER	23
2041237-44	RTA-44A VHF TRANCEIVER	23

2041237-44	RTA-44A VHF TRANCEIVER	23
2041444-04	DAA-4A DRIVE UNIT	34
2041444-04	DAA-4A DRIVE UNIT	34
2041444-04	DAA-4A DRIVE UNIT	34
2041444-04	DAA-4A DRIVE UNIT	34
2041444-04	DAA-4A DRIVE UNIT	34
2041444-04	DAA-4A DRIVE UNIT	34
2041444-04	DAA-4A DRIVE UNIT	34
2041444-04	DAA-4A DRIVE UNIT	34
2041444-04	DAA-4A DRIVE UNIT	34
2041444-04	DAA-4A DRIVE UNIT	34
2042M67P0	FULL AUTHORITY DIGITAL ENGINE CONTROL	73
2042M67P0	FULL AUTHORITY DIGITAL ENGINE CONTROL	73
204950-5-1	TURBINE COOLING, S/L 12 MONTHS FRNSHD W/	21
204950-5-2	TURBINE COOLING, S/L 12 MONTHS FRNSHD W/	21
204950-5-3	TURBINE COOLING, S/L 12 MONTHS FRNSHD W/	21
204950-5-4	TURBINE COOLING, S/L 12 MONTHS FRNSHD W/	21
204950-5-5	TURBINE COOLING, S/L 12 MONTHS FRNSHD W/	21
204950-6-1	TURBINE COOLING, S/L 12 MONTHS FRNSHD W/	21
204950-6-2	TURBINE COOLING, S/L 12 MONTHS FRNSHD W/	21
204950-7-2	TURBINE COOLING, S/L 12 MONTHS FRNSHD W/	21
2056-1	EIGHT DIRECTION SWITCH ASSEMBLY	25
2056A0000	PLENUM, CHAMBER, AIR-COND; A319/A320;	21
2056B0000	PLENUM, CHAMBER, AIR-COND; A319/A320;	21
2056B0000	PLENUM, CHAMBER, AIR-COND; A319/A320;	21
2056B0000	PLENUM, CHAMBER, AIR-COND; A319/A320;	21
2056C0000	PLENUM, CHAMBER, AIR-COND; A319/A320;	21
205E1592-0	FLIGHT DATA RECORDER	31
205PN01Y0	TRNSFRMR RECTIFIER 50AMP UNREGULATED DC	24
2061-15-1	MOTOR OPERATED BYPASS VALVE	27
207072-5	MOTOR DRIVEN FAN	21
2085-7DT	SEAT, FLIGHT ATTENDANT	25
20P78-5	Valve turbine Vane Cooling	75

20P78-6	Valve turbine Vane Cooling	75
2100-1020-	COCKPIT VOICE RECORDER	23
2100-1025-	COCKPIT VOICE RECORDER	23
2100-4043-	FLIGHT DATA RECORDER	31
2100-4043-	FLIGHT DATA RECORDER	31
2100-4045-	FLIGHT DATA RECORDER	31
2100-4045-	FLIGHT DATA RECORDER	31
21-0470-50	CLAMP, HEAT EXCHANGER HEADER	21
21-0470-50	CLAMP, HEAT EXCHANGER HEADER	21
2110-301EM	SEAT, FLIGHT ATTENDANT SEAT	25
2110-301FM	NARROW DOUBLE WALL MOUNTED ATTENDANT SEAT	25
2110-302EM	SEAT, FLIGHT ATTENDANT SEAT	25
2110-302FM	NARROW DOUBLE WALL MOUNTED ATTENDANT SEAT	25
211051A03	FLAP, RAM AIR OUTLET;3249-3259	21
2112-301BM	SGL WALL MOUNTED F/A SEAT	25
2112-301FM	SEAT, SINGLE WALL MOUNTED, FA	25
2112-502BM	SGL WALL MOUNTED F/A SEAT	25
2112-516AE02		25
2115-502AE	SEAT, F/A SEAT, DBL WALL MOUNTED.	25
2115-502AE	SEAT, F/A SEAT, DBL WALL MOUNTED.	25
2115-502BM	SEAT, SEAT-ASSY	25
2115-502DT	SEAT, FLIGHT ATTENDANT	25
2115-502DT	SEAT, FLIGHT ATTENDANT	25
2117342-10	AUXILIARY POWER UNIT CONTROLLER	49
2117342-11	AUXILIARY POWER UNIT CONTROLLER	49
2117342-17	AUXILIARY POWER UNIT CONTROLLER	49
2117342-18	AUXILIARY POWER UNIT CONTROLLER	49
2117342-19	AUXILIARY POWER UNIT CONTROLLER	49
2117342-19	AUXILIARY POWER UNIT CONTROLLER	49
2117342-20	AUXILIARY POWER UNIT CONTROLLER	49
2117342-8	AUXILIARY POWER UNIT CONTROLLER	49
2117342-9	AUXILIARY POWER UNIT CONTROLLER	49

2117388-06	CABIN PRESSURE CONTROLLER	
2117388-08	CABIN PRESSURE CONTROLLER	
2117388-10	CABIN PRESSURE CONTROLLER	21
2117388-11	CABIN PRESSURE CONTROLLER	21
2117388-13	CABIN PRESSURE CONTROLLER	21
2117388-15	CABIN PRESSURE CONTROLLER	21
2117388-5	CABIN PRESSURE CONTROLLER	21
2117388-6	CABIN PRESSURE CONTROLLER	21
2117388-7	CABIN PRESSURE CONTROLLER	21
2117388-8	CABIN PRESSURE CONTROLLER	21
2118490-1	PANEL SELECTOR-FLIGHT CONTROL PRESS	21
2118490-4	PANEL SELECTOR-FLIGHT CONTROL PRESS	21
2118490-4S	PANEL SELECTOR-FLIGHT CONTROL PRESS	21
2118490-4S	PANEL SELECTOR-FLIGHT CONTROL PRESS	
2118490-4S	PANEL SELECTOR-FLIGHT CONTROL PRESS	
2118490-4S	PANEL SELECTOR-FLIGHT CONTROL PRESS	
212N3016-7	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36
212N3022-3	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36
212N3026-3	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36
212N3027-3	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36
212N3028-8	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36
212N3036-3	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36
212N3039-3	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36
212N3045-5	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36
212N3046-1	DUCT ASSY, AIR SUPPLY(USE IN AOG SITUATI	36
212N3046-3	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36
212N3049-7	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36
212N3050-4	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36
212N3051-5	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36
212N3052-5	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36
212N3052-7	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36
212N3053-1	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36

212N3053-3	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36
212N3053-9	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36
212N3060-4	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36
212N3060-6	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36
212N3071-1	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36
212N3071-1	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36
212N3071-2	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36
212N3071-2	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36
212N3076-1	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36
212N3076-2	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36
212N3076-9	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36
212T3121-4	DUCT PWA4060 QEC-START SYSTEM IN STL	36
212T3138-1	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36
212T3138-7	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36
212T3138-8	DUCT PWA4060 QEC-START SYSTEM IN STL	36
213N1100-6	DUCT.. WHL WELL AND U/WING AIR SUPPLY	21
213N1100-7	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36
213N3011-1	OUTLET, RAM AIR EXHAUST USED ON B757 A/C	21
213T1114-6	ADAPTER EXTERNAL AIR HOOKUP WITH OUT REC	21
213T2102-8	DUCT PWA4060 QEC-START SYSTEM IN STL	21
213T3101-5	DOOR MODULATING RAM AIR INLET FURNISHED	21
213T3102-8	EXHAUST RAM AIR R/H, USED ON B767 A/C 10	21
214C40-1-1	ALTITUDE SWITCHES	21
214C40-1-7	ALTITUDE SWITCHES	21
215-016-00	FLAP POSITION INDICATOR	27
2156-204	SMOKE DETECTOR SENSOR ASSEMBLY	26
2156-204A	SMOKE DETECTOR SENSOR ASSEMBLY	26
2156-55	SMOKE DETECTOR SENSOR ASSEMBLY	26
2156-604	SMOKE DETECTOR SENSOR ASSEMBLY	26
2156-604A	SMOKE DETECTOR SENSOR ASSEMBLY	26
2157-1P120	SEAT, F/A, 1L AFT / 1R FWD;	25
2160M11P0	W7 AIRCRAFT (GRAY) - CF34-8	73

2160M12P0	W7 AIRCRAFT (GRAY) - CF34-8	77
2170-001-1	767-58 GALLON VACUUM WASTE TANKS	38
2170-001-1	767-58 GALLON VACUUM WASTE TANKS	38
218-012-00	HYDRAULIC QUANTITY REMOTE INDICATOR	29
218-012-00	HYDRAULIC QUANTITY REMOTE INDICATOR	29
218-013-00	HYDRAULIC QUANTITY REMOTE INDICATOR	29
218N1011-1	DUCT.. WHL WELL AND U/WING AIR SUPPLY	30
218N1011-2	DUCT.. WHL WELL AND U/WING AIR SUPPLY	30
218N1011-4	DUCT.. WHL WELL AND U/WING AIR SUPPLY	30
218N1017-1	DUCT.. WHL WELL AND U/WING AIR SUPPLY	30
218N1017-4	DUCT.. WHL WELL AND U/WING AIR SUPPLY	30
218T1102-2	DUCT PWA4060 QEC-START SYSTEM IN STL	30
2190000-13	ACTUATOR ASSEMBLY, THRUST REVERSER MODEL 2190	78
2190000-15	ACTUATOR ASSEMBLY, THRUST REVERSER MODEL 2190	78
2190000-15	ACTUATOR ASSEMBLY, THRUST REVERSER MODEL 2190	78
2190000-18	ACTUATOR ASSEMBLY, THRUST REVERSER MODEL 2190	78
2190000-20	ACTUATOR ASSEMBLY, THRUST REVERSER MODEL 2190	78
2190000-21	ACTUATOR ASSEMBLY, THRUST REVERSER MODEL 2190	78
2190000-22	ACTUATOR ASSEMBLY, THRUST REVERSER MODEL 2190	78
2190000-22	ACTUATOR ASSEMBLY, THRUST REVERSER MODEL 2190	78
2190000-23	ACTUATOR ASSEMBLY, THRUST REVERSER MODEL 2190	78
2190000-26	ACTUATOR ASSEMBLY, THRUST REVERSER MODEL 2190	78
2190000-32	ACTUATOR ASSEMBLY, THRUST REVERSER MODEL 2190	78
2190000-34	ACTUATOR ASSEMBLY, THRUST REVERSER MODEL 2190	78
2190000-36	ACTUATOR ASSEMBLY, THRUST REVERSER MODEL 2190	78
2190000-40	ACTUATOR ASSEMBLY, THRUST REVERSER MODEL 2190	78
2190000-42	ACTUATOR ASSEMBLY, THRUST REVERSER MODEL 2190	78
2190000-42	ACTUATOR ASSEMBLY, THRUST REVERSER MODEL 2190	78
2190000-44	ACTUATOR ASSEMBLY, THRUST REVERSER MODEL 2190	78
2190000-44	ACTUATOR ASSEMBLY, THRUST REVERSER MODEL 2190	78
2190000-46	ACTUATOR ASSEMBLY, THRUST REVERSER MODEL 2190	78
2190000-48	ACTUATOR ASSEMBLY, THRUST REVERSER MODEL 2190	78

2190000-50	ACTUATOR ASSEMBLY, THRUST REVERSER MODEL 2190	78
21C1-1-22	SWITCH NBR 4 BEARING PRESSURE TRANSDUCER	79
21SN04-180	DIFFERENTIAL PRESSURE SWITCH	73
21SN04-185	OIL FILTER PRESSURE SWITCH	79
21SN04-209	DIFFERENTIAL PRESSURE SWITCH	28
21SN04-209	DIFFERENTIAL PRESSURE SWITCH	28
21SN04-211	DIFFERENTIAL PRESSURE SWITCH	79
21SN04-211	DIFFERENTIAL PRESSURE SWITCH	79
21SN04-223	FUEL PRESSURE SWITCH - CF6-80C2	73
21SN04-224	DIFFERENTIAL PRESSURE SWITCH	79
21SN04-225	DIFFERENTIAL PRESSURE SWITCH	79
21SN04-226	DIFFERENTIAL PRESSURE SWITCH	79
21SN04-226	DIFFERENTIAL PRESSURE SWITCH	79
21SN04-259	SWITCH PRESSURE	79
21SN04-260	DIFFERENTIAL PRESSURE SWITCH	79
21SN04-268	OIL FILTER PRESSURE SWITCH	79
21SN04-269	DIFFERENTIAL PRESSURE SWITCH	73
21SN04-324	DIFFERENTIAL PRESSURE SWITCH	79
21SN04-325	DIFFERENTIAL PRESSURE SWITCH	79
21SN04-333	FUEL PRESSURE SWITCH - CF6-80C2	73
21SN04-334	DIFFERENTIAL PRESSURE SWITCH	79
21SN04-335	DIFFERENTIAL PRESSURE SWITCH	79
21SN04-352	DIFFERENTIAL PRESSURE SWITCH	79
21SN04-353	SWITCH PRESSURE	79
21SN04-370	SWITCH OIL DIFFERENTIAL PRESSURE SHIP IN	79
21SN04-371	SWITCH DIFFERENTIAL PRESSURE SHIP IN ATA	79
21SN04-383	ENGINE OIL DIFFERENTIAL PRESSURE SWITCH	79
21SN04-383	ENGINE OIL DIFFERENTIAL PRESSURE SWITCH	79
21SN04-389	OIL FILTER DIFFERENTIAL PRESSURE SWITCH	79
21SN04-391	ENGINE OIL DIFFERENTIAL PRESSURE SWITCH	79
21SN04-391	ENGINE OIL DIFFERENTIAL PRESSURE SWITCH	79
21SN04-402	OIL FILTER DIFFERENTIAL PRESSURE SWITCH	79

21SN04-403	OIL FILTER DIFFERENTIAL PRESSURE SWITCH	79
21SN04-404	ENGINE OIL DIFFERENTIAL PRESSURE SWITCH	79
21SN04-405	ENGINE OIL DIFFERENTIAL PRESSURE SWITCH	79
21SN04-414	OIL FILTER DIFFERENTIAL PRESSURE SWITCH	79
21SN04-415	OIL FILTER DIFFERENTIAL PRESSURE SWITCH	79
21SN04-416	ENGINE OIL DIFFERENTIAL PRESSURE SWITCH	79
21SN04-417	ENGINE OIL DIFFERENTIAL PRESSURE SWITCH	79
21SN04-460	OIL FILTER DIFFERENTIAL PRESSURE SWITCH	79
21SN04-461	OIL FILTER DIFFERENTIAL PRESSURE SWITCH	79
21SN04-466	FUEL PRESSURE SWITCH - CF6-80C2	73
21SN04-467	DIFFERENTIAL PRESSURE SWITCH	79
21SN04-468	DIFFERENTIAL PRESSURE SWITCH	79
21SN41-42	PRESSURE SWITCH	30
21SN41-52	PRESSURE SWITCH	36
21SN41-82	SWITCH PRESSURE, PNEUMATIC, DUCT USED ON	36
21SN41-82A	SWITCH PRESSURE, PNEUMATIC, DUCT USED ON	36
21SN41-83	SWITCH PRESSURE, PNEUMATIC, DUCT USED ON	36
21SN41-84	PRESSURE SWITCH	30
21SN41-88	PRESSURE SWITCH	80
21SN41-88A	PRESSURE SWITCH	80
21W4068-50	ENGINE HARNESS CJ9, CJ10	71
21W4068-51	HARNESS, HARNESS	71
21W4068-52	HARNESS, HARNESS	71
21W4072-50	HARNESS, HARNESS	71
21W4075-50	HARNESS, HARNESS	71
21W4076-50	HARNESS, HARNESS	71
21W4076-51	HARNESS, HARNESS	71
21W4076-52	HARNESS, HARNESS	71
21W4083-50	HARNESS, HARNESS	71
21W4083-51	HARNESS, HARNESS	71
21W4114-50	HARNESS, HARNESS	71
21W4116-50	HARNESS, HARNESS	71

21W4116-5	HARNESS, HARNESS	71
21W4118-5	ENGINE HARNESS CJ9, CJ10	72
21W4118-5	HARNESS, HARNESS	71
21W4120-5	HARNESS, HARNESS	71
21W4132-5	HARNESS, HARNESS	71
21W4132-5	HARNESS, HARNESS	71
21W4140-5	HARNESS, HARNESS	71
21W4140-5	HARNESS, HARNESS	71
21W4140-5	HARNESS, HARNESS	71
21W4150-5	HARNESS, HARNESS	71
21W4150-5	HARNESS, HARNESS	71
2202322-4	DUCT REHEATER INLET USED ON B767 A/C 101	21
2202323-2	DUCT REHEATER INLET USED ON B767 A/C 101	21
2202323-4	DUCT PACK ASSY, AIR CONDITIONING AND TEM	21
2202623-2	COOLING PACK	21
2202623-3	COOLING PACK	21
2203085-1	NOZZLE H2O SPRAY, WATER EXTRACTOR FURNIS	21
2203924-1	DUCT PACK ASSY, AIR CONDITIONING AND TEM	21
2206400-1	AIR CYCLE MACHINE	21
2206400-2	AIR CYCLE MACHINE	21
2215628-3	LH PRIMARY HEAT EXCHANGER UNIT	21
2215634-1	RAM AIR EXHAUST PLENUM	21
2215634-2	RAM AIR EXHAUST PLENUM	21
2215634-3	RAM AIR EXHAUST PLENUM	21
2215634-4	RAM AIR EXHAUST PLENUM	21
221W5102-	NACELLE HARNESS MW0311	71
221W5102-	NACELLE HARNESS MW0311	71
221W5104-	NACELLE HARNESS MW0311	71
221W5106-	NACELLE HARNESS MW0311	71
221W5114-	NACELLE HARNESS MW0311	71
221W5116-	NACELLE HARNESS MW0311	71
221W5118-	NACELLE HARNESS MW0311	71

221W5120-	NACELLE HARNESS MW0311	71
221W5132-	NACELLE HARNESS MW0311	71
221W5132-	NACELLE HARNESS MW0311	71
221W5148-	NACELLE HARNESS MW0311	78
221W5150-	NACELLE HARNESS MW0311	71
221W5150-	NACELLE HARNESS MW0311	71
221W5152-	NACELLE HARNESS MW0311	78
221W5192-	NACELLE HARNESS MW0311	71
221W5192-	NACELLE HARNESS MW0311	71
221W5197-	NACELLE HARNESS MW0311	71
2227000-59	DIGITAL FLIGHT DATA ACQUISITION UNIT	31
2227000-85	DIGITAL FLIGHT DATA ACQUISITION UNIT	31
2230A0000-	PLENUM, CHAMBER, AIR-COND; A319/A320;	21
2232000-02	DATA MANAGEMENT UNIT (DMU)	31
2233000-3E	DIGITAL FLIGHT DATA ACQUISITION UNIT	31
2233000-3-	DIGITAL FLIGHT DATA ACQUISITION UNIT	31
2233000-81	DIGITAL FLIGHT DATA ACQUISITION UNIT	31
2233000-81	DIGITAL FLIGHT DATA ACQUISITION UNIT	31
2233000-91	DIGITAL FLIGHT DATA ACQUISITION UNIT	31
2234320-02	UNIT, FLIGHT DATA INTERFACE MANAGEMENT	31
2234340-02	UNIT, FLIGHT DATA MAN, FDIMU; A330	31
224-0152-5	DETECTOR ASSY,FIRE-CF6C2D1F (TRACKING ON	26
224-2101-5	INLET COWL - CF6-80C2	71
224-2101-5	INLET COWL - CF6-80C2	71
224-2101-5	INLET COWL - CF6-80C2	71
224-2101-5	INLET COWL - CF6-80C2	71
224-2101-5	INLET COWL - CF6-80C2	71
224-2101-5	INLET COWL - CF6-80C2	71
224-2101-5	INLET COWL - CF6-80C2	71
224-2101-5	INLET COWL - CF6-80C2	71
224-2201-5	LEFT HAND FAN COWL - CF6-80C2	71
224-2201-5	LEFT HAND FAN COWL - CF6-80C2	71
224-2202-5	RIGHT HAND FAN COWL - CF6-80C2	71

224-2202-5	RIGHT HAND FAN COWL - CF6-80C2	71
224-2280-5	LEFT HAND FAN COWL - CF6-80C2	71
224-2280-5	LEFT HAND FAN COWL - CF6-80C2	71
224-2281-5	RIGHT HAND FAN COWL - CF6-80C2	71
224-2281-5	RIGHT HAND FAN COWL - CF6-80C2	
224-2301-5	LEFT HAND CORE COWL	71
224-2301-5	LEFT HAND CORE COWL	
224-2301-5	LEFT HAND CORE COWL	71
224-2302-5	RIGHT HAND CORE COWL	
224-2302-5	RIGHT HAND CORE COWL	
224-2302-5	RIGHT HAND CORE COWL	
224-2302-5	RIGHT HAND CORE COWL	71
224-2302-5	RIGHT HAND CORE COWL	
224-2302-5	RIGHT HAND CORE COWL	71
224-2302-5	RIGHT HAND CORE COWL	
224-2302-5	RIGHT HAND CORE COWL	
224-2302-5	RIGHT HAND CORE COWL	71
224-2302-5	RIGHT HAND CORE COWL	71
224-2302-X	RIGHT HAND CORE COWL	
2243800-36	RECORDER, WIRELESS QUICK ACCESS;	31
224M4761-5	RIGHT HAND CORE COWL	71
224M4761-5	RIGHT HAND CORE COWL	71
224M4761-5	RIGHT HAND CORE COWL	71
224M4761-5	RIGHT HAND CORE COWL	
224M4761-5	RIGHT HAND CORE COWL	71
224M4761-5	RIGHT HAND CORE COWL	71
224M4761-5	RIGHT HAND CORE COWL	
224M4761-5	RIGHT HAND CORE COWL	
224M4761-5	RIGHT HAND CORE COWL	71
224M4761-5	RIGHT HAND CORE COWL	
225BS101-5	BATTERY POWER PACK, MD88 IRS NO 1 and 2	34
22640-005	IMMERSION THERMOCOUPLE	75

228-1	REFRIGERATOR/FREEZER	25
228-505	REFRIGERATOR/FREEZER	25
2290A03	VALVE, BLEED AIR CHECK, 5TH	36
2290A03000	VALVE, BLEED AIR CHECK, 5TH	36
2290A04000	VALVE, BLEED AIR CHECK, 5TH	36
2290A05000	VALVE, BLEED AIR CHECK, 5TH	36
2290B01000	IP BLEED CHECK VALVE	36
2290B02000	IP BLEED CHECK VALVE	36
2293B01000	IP BLEED CHECK VALVE	36
2293B02000	IP BLEED CHECK VALVE	36
22J46-2	BLEED AIR DUCT ASSEMBLY	49
23-0415-50	PANEL,ATTENDANT, FWD.MOD.PER DWG 23-0415	31
23-0616-50	AMPLIFIR PUBLIC ADDRESS, TYPE 346 DIB, U	23
23-0616-50	AMPLIFIR PUBLIC ADDRESS, TYPE 346 DIB, U	23
23-0616-50	AMPLIFIR PUBLIC ADDRESS, TYPE 346 DIB, U	
23-0616-51	PASSENGER ADDRESS UNIT PAU-700	23
23-0616-51	AMPLIFIR PUBLIC ADDRESS, TYPE 346 DIB, U	23
23-0616-52	PASSENGER ADDRESS UNIT PAU-700	23
23-0616-52	AMPLIFIR PUBLIC ADDRESS, TYPE 346 DIB, U	
23-0616-52	AMPLIFIR PUBLIC ADDRESS, TYPE 346 DIB, U	
23-1103-50	UNIT, PCU,RH	23
23-1103-50	UNIT, PCU,RH	23
23-1105-50	UNIT, CONTROL PASS. SEAT RH	23
23-1105-50	UNIT, CONTROL PASS. SEAT RH	23
23-1126-50	AUDIO CONTROL PANE	23
2311M84-1	MOTOR WINDSHIELD WIPER	30
232T4243-1	HOLDER APPROACH PLATE AND CHART CONTROL	25
232T4243-6	HOLDER APPROACH PLATE AND CHART CONTROL	25
233A2221-5	PANEL ASSY., P1-3 CDS DISPLAY, CAPT	31
233A2224-3	ENGINE - AUTOBRAKE CONTROL PANEL ASSEMBLY	31
233A2227-1	CAPTAIN LIGHTING CONTROL PANEL ASSEMBLY, P1-9	33
233A2228-1	RIGHT DISPLAY LIGHTING CONTROL PANEL	31

233A2229-3	MODULE FLOODLIGHT CONTROL, P1-5, USED ON	31
233A3201-1	WINDOW AND PITOT HEAT MODULE ASSEMBLY	30
233A3201-2	WINDOW AND PITOT HEAT MODULE ASSEMBLY	30
233A3201-3	WINDOW AND PITOT HEAT MODULE ASSEMBLY	30
233A3201-3	WINDOW AND PITOT HEAT MODULE ASSEMBLY	30
233A3201-3	WINDOW AND PITOT HEAT MODULE ASSEMBLY	30
233A3201-5	WINDOW AND PITOT HEAT MODULE ASSEMBLY	30
233A3202-1	FUEL CONTROL MODULE	28
233A3202-2	FUEL CONTROL MODULE	28
233A3202-3	FUEL CONTROL MODULE	28
233A3202-4	FUEL CONTROL MODULE	28
233A3202-5	FUEL CONTROL MODULE	28
233A3202-6	FUEL CONTROL MODULE	28
233A3204-1	AC SYSTEM GENERATOR/APU CONTROL MODULE ASSEMBLY	24
233A3205-3	POWER MODULE ASSEMBLY	24
233A3206-2	MODULE DISPLAY SELECT SHIP IN ATA SPEC 3	31
233A3207-6	DOOR WARNING ANNUNCIATOR MODULE ASSY P5-20	31
233A3208-2	FLIGHT RECORDER & MACH AIRSPEED WARN MODULE ASSEMBLY	34
233A3209-1	FLIGHT CONTROL MODULE ASSEMBLY	31
233A3209-2	FLIGHT CONTROL MODULE ASSEMBLY	27
233A3213-4	MODULE, P5-16 HIGH ALT PANEL *EA 12-4728	21
233A7201-2	MAP/CHART LIGHT CTRL PANEL ASSY P21-1	33
233A7201-3	MAP/CHART LIGHT CTRL PANEL ASSY P21-1	33
233A7202-1	MAP/CHART LIGHT CTRL PANEL ASSY P21-1	33
233A7202-2	MAP/CHART LIGHT CTRL PANEL ASSY P21-1	33
233N3201-1	WINDSHIELD CLEARANCE PANEL ASSEMBLY M10023	31
233N3201-3	WINDSHIELD CLEARANCE PANEL ASSEMBLY M10023	30
233N3201-3	WINDSHIELD CLEARANCE PANEL ASSEMBLY M10023	30
233N3201-3	WINDSHIELD CLEARANCE PANEL ASSEMBLY M10023	
233N3202-1	ANNUNCIATOR PANEL	22
233N3202-1	ANNUNCIATOR PANEL	22
233N3202-1	ANNUNCIATOR PANEL	22

233N3202-8	ANNUNCIATOR PANEL	31
233N3203-1	WINDSHIELD CLEARANCE PANEL ASSEMBLY M10023	31
233N3203-1	WINDSHIELD CLEARANCE PANEL ASSEMBLY M10023	21
233N3203-1	WINDSHIELD CLEARANCE PANEL ASSEMBLY M10023	21
233N3203-1	WINDSHIELD CLEARANCE PANEL ASSEMBLY M10023	21
233N3203-2	WINDSHIELD CLEARANCE PANEL ASSEMBLY M10023	31
233N3203-2	WINDSHIELD CLEARANCE PANEL ASSEMBLY M10023	21
233N3203-3	WINDSHIELD CLEARANCE PANEL ASSEMBLY M10023	21
233N3203-3	WINDSHIELD CLEARANCE PANEL ASSEMBLY M10023	21
233N3203-3	WINDSHIELD CLEARANCE PANEL ASSEMBLY M10023	21
233N3203-7	WINDSHIELD CLEARANCE PANEL ASSEMBLY M10023	
233N3204-1	ANTI-ICE PANEL ASSEMBLY M10397	30
233N3204-1	ANTI-ICE PANEL ASSEMBLY M10397	30
233N3204-1	ANTI-ICE PANEL ASSEMBLY M10397	31
233N3204-1	ANTI-ICE PANEL ASSEMBLY M10397	30
233N3204-1	ANTI-ICE PANEL ASSEMBLY M10397	30
233N3204-1	ANTI-ICE PANEL ASSEMBLY M10397	31
233N3204-1	ANTI-ICE PANEL ASSEMBLY M10397	30
233N3204-2	ANTI-ICE PANEL ASSEMBLY M10397	31
233N3204-2	ANTI-ICE PANEL ASSEMBLY M10397	31
233N3204-2	ANTI-ICE PANEL ASSEMBLY M10397	30
233N3204-2	ANTI-ICE PANEL ASSEMBLY M10397	30
233N3204-3	ANTI-ICE PANEL ASSEMBLY M10397	31
233N3204-3	ANTI-ICE PANEL ASSEMBLY M10397	31
233N3204-3	ANTI-ICE PANEL ASSEMBLY M10397	
233N3204-3	ANTI-ICE PANEL ASSEMBLY M10397	30
233N3204-7	ANTI-ICE PANEL ASSEMBLY M10397	
233N3205-1	HYDRAULICS PANEL ASSEMBLY WITHOUT LIGHTPLATES	29
233N3205-2	HYDRAULICS PANEL ASSEMBLY WITHOUT LIGHTPLATES	29
233N3205-2	HYDRAULICS PANEL ASSEMBLY WITHOUT LIGHTPLATES	29
233N3205-2	HYDRAULICS PANEL ASSEMBLY WITHOUT LIGHTPLATES	29
233N3205-2	HYDRAULICS PANEL ASSEMBLY WITHOUT LIGHTPLATES	29

233N3205-2	HYDRAULICS PANEL ASSEMBLY WITHOUT LIGHTPLATES	29
233N3205-3	HYDRAULICS PANEL ASSEMBLY WITHOUT LIGHTPLATES	29
233N3205-3	HYDRAULICS PANEL ASSEMBLY WITHOUT LIGHTPLATES	29
233N3205-3	HYDRAULICS PANEL ASSEMBLY WITHOUT LIGHTPLATES	29
233N3205-7	HYDRAULICS PANEL ASSEMBLY WITHOUT LIGHTPLATES	
233N3206-1	FUEL CONTROL PANEL ASSEMBLY, M10055	28
233N3206-1	FUEL CONTROL PANEL ASSEMBLY, M10055	28
233N3206-1	FUEL CONTROL PANEL ASSEMBLY, M10055	28
233N3206-1	FUEL CONTROL PANEL ASSEMBLY, M10055	28
233N3206-1	FUEL CONTROL PANEL ASSEMBLY, M10055	28
233N3206-1	FUEL CONTROL PANEL ASSEMBLY, M10055	28
233N3206-1	FUEL CONTROL PANEL ASSEMBLY, M10055	28
233N3206-1	FUEL CONTROL PANEL ASSEMBLY, M10055	28
233N3206-1	FUEL CONTROL PANEL ASSEMBLY, M10055	28
233N3206-1	FUEL CONTROL PANEL ASSEMBLY, M10055	31
233N3206-2	FUEL CONTROL PANEL ASSEMBLY, M10055	28
233N3206-2	FUEL CONTROL PANEL ASSEMBLY, M10055	28
233N3206-2	FUEL CONTROL PANEL ASSEMBLY, M10055	28
233N3206-2	FUEL CONTROL PANEL ASSEMBLY, M10055	28
233N3206-2	FUEL CONTROL PANEL ASSEMBLY, M10055	28
233N3206-2	FUEL CONTROL PANEL ASSEMBLY, M10055	31
233N3206-3	FUEL CONTROL PANEL ASSEMBLY, M10055	31
233N3206-3	FUEL CONTROL PANEL ASSEMBLY, M10055	28
233N3206-3	FUEL CONTROL PANEL ASSEMBLY, M10055	28
233N3206-3	FUEL CONTROL PANEL ASSEMBLY, M10055	28
233N3206-3	FUEL CONTROL PANEL ASSEMBLY, M10055	28
233N3206-3	FUEL CONTROL PANEL ASSEMBLY, M10055	28
233N3206-3	FUEL CONTROL PANEL ASSEMBLY, M10055	28
233N3206-3	FUEL CONTROL PANEL ASSEMBLY, M10055	28
233N3206-3	FUEL CONTROL PANEL ASSEMBLY, M10055	28
233N3209-1	ELECTRICAL SYSTEM PANEL ASSEMBLY M10063	31
233N3209-1	ELECTRICAL SYSTEM PANEL ASSEMBLY M10063	24
233N3209-1	ELECTRICAL SYSTEM PANEL ASSEMBLY M10063	24
233N3209-1	ELECTRICAL SYSTEM PANEL ASSEMBLY M10063	24
233N3209-1	ELECTRICAL SYSTEM PANEL ASSEMBLY M10063	24

233N3211-1	PANEL, STANDBY POWER	31
233N3211-1	BATTERY/STANDBY POWER PANEL ASSEMBLY, M10062	31
233N3211-1	PANEL, STANDBY POWER	31
233N3211-1	BATTERY/STANDBY POWER PANEL ASSEMBLY, M10062	31
233N3211-1	BATTERY/STANDBY POWER PANEL ASSEMBLY, M10062	31
233N3211-1	PANEL, STANDBY POWER	31
233N3211-1	PANEL, STANDBY POWER	31
233N3211-1	BATTERY/STANDBY POWER PANEL ASSEMBLY, M10062	31
233N3211-1	BATTERY/STANDBY POWER PANEL ASSEMBLY, M10062	31
233N3211-1	BATTERY/STANDBY POWER PANEL ASSEMBLY, M10062	31
233N3211-1	BATTERY/STANDBY POWER PANEL ASSEMBLY, M10062	31
233N3211-1	BATTERY/STANDBY POWER PANEL ASSEMBLY, M10062	31
233N3211-1	BATTERY/STANDBY POWER PANEL ASSEMBLY, M10062	31
233N3211-1	BATTERY/STANDBY POWER PANEL ASSEMBLY, M10062	24
233N3211-1	BATTERY/STANDBY POWER PANEL ASSEMBLY, M10062	24
233N3211-1	BATTERY/STANDBY POWER PANEL ASSEMBLY, M10062	
233N3211-1	BATTERY/STANDBY POWER PANEL ASSEMBLY, M10062	24
233N3211-1	BATTERY/STANDBY POWER PANEL ASSEMBLY, M10062	31
233N3211-1	BATTERY/STANDBY POWER PANEL ASSEMBLY, M10062	31
233N3211-2	PANEL, STANDBY POWER	31
233N3211-2	PANEL, STANDBY POWER	31
233N3211-2	PANEL, STANDBY POWER	31
233N3211-2	BATTERY/STANDBY POWER PANEL ASSEMBLY, M10062	
233N3211-2	BATTERY/STANDBY POWER PANEL ASSEMBLY, M10062	31
233N3211-3	PANEL, STANDBY POWER	31
233N3211-3	BATTERY/STANDBY POWER PANEL ASSEMBLY, M10062	24
233N3211-3	BATTERY/STANDBY POWER PANEL ASSEMBLY, M10062	31
233N3211-3	BATTERY/STANDBY POWER PANEL ASSEMBLY, M10062	31
233N3211-3	BATTERY/STANDBY POWER PANEL ASSEMBLY, M10062	31
233N3211-3	BATTERY/STANDBY POWER PANEL ASSEMBLY, M10062	31
233N3211-3	BATTERY/STANDBY POWER PANEL ASSEMBLY, M10062	31
233N3211-3	BATTERY/STANDBY POWER PANEL ASSEMBLY, M10062	31
233N3211-3	BATTERY/STANDBY POWER PANEL ASSEMBLY, M10062	31
233N3211-3	BATTERY/STANDBY POWER PANEL ASSEMBLY, M10062	31

233N3211-4	BATTERY/STANDBY POWER PANEL ASSEMBLY, M10062	31
233N3211-4	BATTERY/STANDBY POWER PANEL ASSEMBLY, M10062	31
233N3211-5	BATTERY/STANDBY POWER PANEL ASSEMBLY, M10062	31
233N3211-8	PANEL, STANDBY POWER	31
233N3212-1	WINDOW HEAT PANEL ASSEMBLY	30
233N3212-1	WINDOW HEAT PANEL ASSEMBLY	30
233N3212-1	WINDOW HEAT PANEL ASSEMBLY	30
233N3212-1	WINDOW HEAT PANEL ASSEMBLY	30
233N3212-3	WINDOW HEAT PANEL ASSEMBLY	30
233N3212-8	WINDOW HEAT PANEL ASSEMBLY	30
233N3214-2	LIGHTING CONTROL PANEL ASSEMBLY	33
233N3214-2	LIGHTING CONTROL PANEL ASSEMBLY	33
233N3214-2	LIGHTING CONTROL PANEL ASSEMBLY	31
233N3214-2	LIGHTING CONTROL PANEL ASSEMBLY	33
233N3214-3	LIGHTING CONTROL PANEL ASSEMBLY	31
233N3214-3	LIGHTING CONTROL PANEL ASSEMBLY	31
233N3214-3	LIGHTING CONTROL PANEL ASSEMBLY	31
233N3214-3	LIGHTING CONTROL PANEL ASSEMBLY	33
233N3215-1	BLEED AIR PANEL ASSEMBLY, M10259	31
233N3215-1	BLEED AIR PANEL ASSEMBLY, M10259	36
233N3215-1	BLEED AIR PANEL ASSEMBLY, M10259	36
233N3215-1	BLEED AIR PANEL ASSEMBLY, M10259	31
233N3215-1	BLEED AIR PANEL ASSEMBLY, M10259	36
233N3215-1	BLEED AIR PANEL ASSEMBLY, M10259	36
233N3215-1	BLEED AIR PANEL ASSEMBLY, M10259	31
233N3215-1	BLEED AIR PANEL ASSEMBLY, M10259	31
233N3215-1	BLEED AIR PANEL ASSEMBLY, M10259	36
233N3215-1	BLEED AIR PANEL ASSEMBLY, M10259	31
233N3215-1	BLEED AIR PANEL ASSEMBLY, M10259	36
233N3215-1	BLEED AIR PANEL ASSEMBLY, M10259	31
233N3215-2	BLEED AIR PANEL ASSEMBLY, M10259	31

233N3215-2	BLEED AIR PANEL ASSEMBLY, M10259	36
233N3215-3	BLEED AIR PANEL ASSEMBLY, M10259	36
233N3215-9	BLEED AIR PANEL ASSEMBLY, M10259	31
233N3216-1	YAW DAMPER PANEL ASSEMBLY, M10250	22
233N3216-1	YAW DAMPER PANEL ASSEMBLY, M10250	22
233N3216-1	YAW DAMPER PANEL ASSEMBLY, M10250	22
233N3216-1	YAW DAMPER PANEL ASSEMBLY, M10250	22
233N3216-1	YAW DAMPER PANEL ASSEMBLY, M10250	22
233N3216-1	YAW DAMPER PANEL ASSEMBLY, M10250	22
233N3216-1	YAW DAMPER PANEL ASSEMBLY, M10250	31
233N3216-1	YAW DAMPER PANEL ASSEMBLY, M10250	22
233N3216-1	YAW DAMPER PANEL ASSEMBLY, M10250	22
233N3216-1	YAW DAMPER PANEL ASSEMBLY, M10250	22
233N3216-1	YAW DAMPER PANEL ASSEMBLY, M10250	31
233N3216-1	YAW DAMPER PANEL ASSEMBLY, M10250	22
233N3216-1	YAW DAMPER PANEL ASSEMBLY, M10250	22
233N3216-1	YAW DAMPER PANEL ASSEMBLY, M10250	22
233N3216-1	YAW DAMPER PANEL ASSEMBLY, M10250	31
233N3216-2	YAW DAMPER PANEL ASSEMBLY, M10250	22
233N3216-2	YAW DAMPER PANEL ASSEMBLY, M10250	22
233N3216-2	YAW DAMPER PANEL ASSEMBLY, M10250	31
233N3216-2	YAW DAMPER PANEL ASSEMBLY, M10250	31
233N3216-2	YAW DAMPER PANEL ASSEMBLY, M10250	22
233N3216-3	YAW DAMPER PANEL ASSEMBLY, M10250	22
233N3216-3	YAW DAMPER PANEL ASSEMBLY, M10250	22
233N3217-1	AIR CONDITIONING CONTROL PANEL ASSEMBLY, M10193	21
233N3217-1	AIR CONDITIONING CONTROL PANEL ASSEMBLY, M10193	21
233N3217-1	AIR CONDITIONING CONTROL PANEL ASSEMBLY, M10193	21
233N3217-1	AIR CONDITIONING CONTROL PANEL ASSEMBLY, M10193	21
233N3217-3	AIR CONDITIONING CONTROL PANEL ASSEMBLY, M10193	21
233N3217-8	AIR CONDITIONING CONTROL PANEL ASSEMBLY, M10193	21
233N3221-3	RIGHT LIGHTING CONTROL PANEL ASSEMBLY M10057	31
233N3221-3	RIGHT LIGHTING CONTROL PANEL ASSEMBLY M10057	31
233N3221-3	RIGHT LIGHTING CONTROL PANEL ASSEMBLY M10057	31
233N3221-3	RIGHT LIGHTING CONTROL PANEL ASSEMBLY M10057	31

233N3221-3	RIGHT LIGHTING CONTROL PANEL ASSEMBLY M10057	31
233N3221-4	RIGHT LIGHTING CONTROL PANEL ASSEMBLY M10057	31
233N3221-4	RIGHT LIGHTING CONTROL PANEL ASSEMBLY M10057	31
233N3221-5	RIGHT LIGHTING CONTROL PANEL ASSEMBLY M10057	31
233N3221-6	RIGHT LIGHTING CONTROL PANEL ASSEMBLY M10057	31
233N3221-7	RIGHT LIGHTING CONTROL PANEL ASSEMBLY M10057	33
233N3221-8	RIGHT LIGHTING CONTROL PANEL ASSEMBLY M10057	33
233N3221-8	RIGHT LIGHTING CONTROL PANEL ASSEMBLY M10057	33
233N3223-1	ENGINE START/RAT PANEL ASSEMBLY, M10468	31
233N3223-1	ENGINE START/RAT PANEL ASSEMBLY, M10468	74
233N3223-1	ENGINE START/RAT PANEL ASSEMBLY, M10468	74
233N3223-1	ENGINE START/RAT PANEL ASSEMBLY, M10468	74
233N3223-2	ENGINE START/RAT PANEL ASSEMBLY, M10468	31
233N3223-2	ENGINE START/RAT PANEL ASSEMBLY, M10468	31
233N3223-3	ENGINE START/RAT PANEL ASSEMBLY, M10468	31
233N3223-4	ENGINE START/RAT PANEL ASSEMBLY, M10468	31
233N3223-4	ENGINE START/RAT PANEL ASSEMBLY, M10468	31
233N3223-5	ENGINE START/RAT PANEL ASSEMBLY, M10468	74
233N3224-1	ELECTRONIC ENGINE CONTROL POWER PANEL ASSEMBLY	31
233N3224-1	ELECTRONIC ENGINE CONTROL POWER PANEL ASSEMBLY	31
233N3224-1	ELECTRONIC ENGINE CONTROL POWER PANEL ASSEMBLY	31
233N3224-1	ELECTRONIC ENGINE CONTROL POWER PANEL ASSEMBLY	31
233N3224-1	ELECTRONIC ENGINE CONTROL POWER PANEL ASSEMBLY	31
233N3224-1	ELECTRONIC ENGINE CONTROL POWER PANEL ASSEMBLY	31
233N3224-3	ELECTRONIC ENGINE CONTROL POWER PANEL ASSEMBLY	31
233N3225-1	PANEL POWER TRANSFER, USED ON B757 A/C 6	31
233N3225-9	PANEL POWER TRANSFER, USED ON B757 A/C 6	31
233N6203-1	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10057	26
233N6203-1	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10057	26
233N6203-1	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10057	26
233N6203-1	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10057	22
233N6203-1	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10057	26

233N6203-1	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10	26
233N6203-1	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10	26
233N6203-1	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10	26
233N6203-1	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10	26
233N6203-1	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10	26
233N6203-1	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10	26
233N6203-1	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10	26
233N6203-1	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10	26
233N6203-1	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10	26
233N6203-1	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10	26
233N6203-1	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10	26
233N6203-1	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10	22
233N6203-1	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10	26
233N6203-2	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10	26
233N6203-3	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10	26
233N6203-3	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10	26
233N6203-3	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10	26
233N6203-3	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10	26
233N6203-3	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10	26
233N6203-3	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10	26
233N6203-3	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10	26
233N6203-3	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10	26
233N6203-4	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10	22
233N6203-4	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10	26
233N6203-7	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10	26
233N6203-7	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10	26
233N6203-7	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10	26
233N6203-7	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10	26
233N6203-7	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10	26
233N6203-8	APU AND CARGO FIRE CONTROL PANEL ASSEMBLY, M10	26
233N6205-1	LATERAL CONTROL AUTOPILOT SERVO ASSEMBLY	26
233N6205-6	LATERAL CONTROL AUTOPILOT SERVO ASSEMBLY	26
233N6205-8	LATERAL CONTROL AUTOPILOT SERVO ASSEMBLY	26
233N7501-1	TEST PANEL ASSEMBLY M10398	31

233N7501-2	TEST PANEL ASSEMBLY M10398	31
233N7501-3	TEST PANEL ASSEMBLY M10398	30
233N7503-3	GENERATOR FIELD AND HYDRAULICS PANEL ASSEMBLY	31
233N7503-3	GENERATOR FIELD AND HYDRAULICS PANEL ASSEMBLY	31
233N7503-5	GENERATOR FIELD AND HYDRAULICS PANEL ASSEMBLY	31
233N7503-5	GENERATOR FIELD AND HYDRAULICS PANEL ASSEMBLY	31
233N7508-1	SERVICE INTERPHONE RECORDER	31
233N7508-7	SERVICE INTERPHONE RECORDER	31
233N7508-9	SERVICE INTERPHONE RECORDER	31
233N7509-1	MAINTENANCE PANEL ASSEMBLY	31
233N7509-6	MAINTENANCE PANEL ASSEMBLY	31
233N7513-1	PANEL, ELECTRONIC,ENGINE CONTROL,USED ON	73
233T3210-1	EMERGENCY LIGHTS PANEL ASSEMBLY	33
233T3210-1	EMERGENCY LIGHTS PANEL ASSEMBLY	33
233T3210-1	EMERGENCY LIGHTS PANEL ASSEMBLY	33
233T3210-1	EMERGENCY LIGHTS PANEL ASSEMBLY	33
233T3210-1	EMERGENCY LIGHTS PANEL ASSEMBLY	33
233T3210-1	EMERGENCY LIGHTS PANEL ASSEMBLY	33
233T3210-1	EMERGENCY LIGHTS PANEL ASSEMBLY	33
233T3210-1	EMERGENCY LIGHTS PANEL ASSEMBLY	33
233T3210-1	EMERGENCY LIGHTS PANEL ASSEMBLY	33
233T3210-2	EMERGENCY LIGHTS PANEL ASSEMBLY	33
233T3210-2	EMERGENCY LIGHTS PANEL ASSEMBLY	33
233T3210-2	EMERGENCY LIGHTS PANEL ASSEMBLY	33
233T3210-2	EMERGENCY LIGHTS PANEL ASSEMBLY	33
233T3210-2	EMERGENCY LIGHTS PANEL ASSEMBLY	33
233T3210-2	EMERGENCY LIGHTS PANEL ASSEMBLY	33
233T3210-2	EMERGENCY LIGHTS PANEL ASSEMBLY	33
233T3210-3	EMERGENCY LIGHTS PANEL ASSEMBLY	33
233T3210-3	EMERGENCY LIGHTS PANEL ASSEMBLY	33
233T3210-3	EMERGENCY LIGHTS PANEL ASSEMBLY	33
233T3210-4	EMERGENCY LIGHTS PANEL ASSEMBLY	33
233T3215-1	ELECTRICAL CONTROL MODULE ASSEMBLY, M10063	31
233T3215-3	ELECTRICAL CONTROL MODULE ASSEMBLY, M10063	31
233T3216-1	PASSENGER SIGN CONTROL PANEL ASSEMBLY	31
233T3217-3	ANTI-COLLISION AND LANDING PANEL ASSEMBLY, M56	33

233T3217-3	ANTI-COLLISION AND LANDING PANEL ASSEMBLY, M56	33
233T3217-3	ANTI-COLLISION AND LANDING PANEL ASSEMBLY, M56	33
233T3217-4	ANTI-COLLISION AND LANDING PANEL ASSEMBLY, M56	33
233T3217-4	ANTI-COLLISION AND LANDING PANEL ASSEMBLY, M56	33
233T3217-4	ANTI-COLLISION AND LANDING PANEL ASSEMBLY, M56	33
233T3232-1	APU CONTROL PANEL	49
233T3232-1	APU CONTROL PANEL	49
233T3232-1	APU CONTROL PANEL	49
233T3232-1	APU CONTROL PANEL	49
233T3232-1	APU CONTROL PANEL	49
233T3232-2	APU CONTROL PANEL	49
233T3232-2	APU CONTROL PANEL	49
233T3232-3	APU CONTROL PANEL	49
233T3232-3	APU CONTROL PANEL	49
233T3232-3	APU CONTROL PANEL	49
233T3232-3	APU CONTROL PANEL	49
233T3232-5	APU CONTROL PANEL	
233T3232-7	APU CONTROL PANEL	
233T3232-9	APU CONTROL PANEL	49
233T3233-1	ANNUNCIATOR PANEL	27
233T3233-1	ANNUNCIATOR PANEL	31
233T3233-1	ANNUNCIATOR PANEL	31
233T3233-1	ANNUNCIATOR PANEL	31
233T3233-2	ANNUNCIATOR PANEL	27
233T3233-2	ANNUNCIATOR PANEL	
233T3233-3	ANNUNCIATOR PANEL	24
233T3233-5	ANNUNCIATOR PANEL	31
233T3234-1	HYDRAULIC SYSTEM CONTROL PANEL ASSEMBLY, M10	29
233T3234-1	HYDRAULIC SYSTEM CONTROL PANEL ASSEMBLY, M10	29
233T3234-1	HYDRAULIC SYSTEM CONTROL PANEL ASSEMBLY, M10	29
233T3234-1	HYDRAULIC SYSTEM CONTROL PANEL ASSEMBLY, M10	29
233T3234-1	HYDRAULIC SYSTEM CONTROL PANEL ASSEMBLY, M10	29

233T3234-1	HYDRAULIC SYSTEM CONTROL PANEL ASSEMBLY, M10	29
233T3234-2	HYDRAULIC SYSTEM CONTROL PANEL ASSEMBLY, M10	29
233T3234-2	HYDRAULIC SYSTEM CONTROL PANEL ASSEMBLY, M10	29
233T3234-3	HYDRAULIC SYSTEM CONTROL PANEL ASSEMBLY, M10	29
233T3234-3	HYDRAULIC SYSTEM CONTROL PANEL ASSEMBLY, M10	29
233T3234-3	HYDRAULIC SYSTEM CONTROL PANEL ASSEMBLY, M10	29
233T3234-3	HYDRAULIC SYSTEM CONTROL PANEL ASSEMBLY, M10	29
233T3234-3	HYDRAULIC SYSTEM CONTROL PANEL ASSEMBLY, M10	31
233T3234-3	HYDRAULIC SYSTEM CONTROL PANEL ASSEMBLY, M10	29
233T3234-3	HYDRAULIC SYSTEM CONTROL PANEL ASSEMBLY, M10	29
233T3234-5	HYDRAULIC SYSTEM CONTROL PANEL ASSEMBLY, M10	29
233T3234-7	HYDRAULIC SYSTEM CONTROL PANEL ASSEMBLY, M10	29
233T3234-8	HYDRAULIC SYSTEM CONTROL PANEL ASSEMBLY, M10	29
233T3235-1	FUEL MANAGEMENT PANEL ASSEMBLY, M10055	31
233T3235-1	FUEL MANAGEMENT PANEL ASSEMBLY, M10055	31
233T3235-1	FUEL MANAGEMENT PANEL ASSEMBLY, M10055	28
233T3235-1	FUEL MANAGEMENT PANEL ASSEMBLY, M10055	28
233T3235-1	FUEL MANAGEMENT PANEL ASSEMBLY, M10055	28
233T3235-1	FUEL MANAGEMENT PANEL ASSEMBLY, M10055	31
233T3235-1	FUEL MANAGEMENT PANEL ASSEMBLY, M10055	31
233T3235-1	FUEL MANAGEMENT PANEL ASSEMBLY, M10055	31
233T3235-1	FUEL MANAGEMENT PANEL ASSEMBLY, M10055	28
233T3235-2	FUEL MANAGEMENT PANEL ASSEMBLY, M10055	28
233T3235-2	FUEL MANAGEMENT PANEL ASSEMBLY, M10055	28
233T3235-3	FUEL MANAGEMENT PANEL ASSEMBLY, M10055	28
233T3235-5	FUEL MANAGEMENT PANEL ASSEMBLY, M10055	31
233T3235-7	FUEL MANAGEMENT PANEL ASSEMBLY, M10055	31
233T3236-1	PANEL, TEMP CONTROL, EA 10-464496-03AD	24
233T3236-1	TEMPERATURE CONTROL PANEL ASSEMBLY, M14	21
233T3236-1	TEMPERATURE CONTROL PANEL ASSEMBLY, M14	21
233T3236-1	TEMPERATURE CONTROL PANEL ASSEMBLY, M14	21

233T3237-2	BLEED AIR CONTROL PANEL ASSEMBLY, M15	36
233T3237-2	BLEED AIR CONTROL PANEL ASSEMBLY, M15	36
233T3237-2	BLEED AIR CONTROL PANEL ASSEMBLY, M15	36
233T3237-3	BLEED AIR CONTROL PANEL ASSEMBLY, M15	36
233T3237-3	BLEED AIR CONTROL PANEL ASSEMBLY, M15	36
233T3237-3	BLEED AIR CONTROL PANEL ASSEMBLY, M15	36
233T3237-5	BLEED AIR CONTROL PANEL ASSEMBLY, M15	36
233T3237-7	BLEED AIR CONTROL PANEL ASSEMBLY, M15	36
233T3238-1	EQUIPMENT COOLING PANEL ASSEMBLY	21
233T3238-1	EQUIPMENT COOLING PANEL ASSEMBLY	21
233T3238-3	EQUIPMENT COOLING PANEL ASSEMBLY	21
233T3238-8	EQUIPMENT COOLING PANEL ASSEMBLY	21
233T3239-1	CARGO HEAT PANEL ASSEMBLY M29	31
233T3239-1	CARGO HEAT PANEL ASSEMBLY M29	31
233T3239-1	CARGO HEAT PANEL ASSEMBLY M29	31
233T3239-8	CARGO HEAT PANEL ASSEMBLY M29	31
233T3241-1	PANL, ANTI-ICE	30
233T3241-1	PANL, ANTI-ICE	31
233T3241-1	PANL, ANTI-ICE	30
233T3241-1	CARGO HEAT PANEL ASSEMBLY M29	30
233T3241-1	CARGO HEAT PANEL ASSEMBLY M29	30
233T3241-1	WING AND ENGINE ANTI-ICE CONTROL PANEL ASSEMBL	30
233T3241-1	CARGO HEAT PANEL ASSEMBLY M29	30
233T3241-1	WING AND ENGINE ANTI-ICE CONTROL PANEL ASSEMBL	30
233T3241-1	PANL, ANTI-ICE	30
233T3241-4	PANL, ANTI-ICE	30
233T3241-4	PANL, ANTI-ICE	30
233T3241-4	WING AND ENGINE ANTI-ICE CONTROL PANEL ASSEMBL	30
233T3241-4	WING AND ENGINE ANTI-ICE CONTROL PANEL ASSEMBL	30
233T3241-4	WING AND ENGINE ANTI-ICE CONTROL PANEL ASSEMBL	30
233T3241-5	PANL, ANTI-ICE	30
233T3241-5	WING AND ENGINE ANTI-ICE CONTROL PANEL ASSEMBL	30

233T3241-6	WING AND ENGINE ANTI-ICE CONTROL PANEL ASSEMBL	30
233T3241-6	WING AND ENGINE ANTI-ICE CONTROL PANEL ASSEMBL	30
233T3241-6	WING AND ENGINE ANTI-ICE CONTROL PANEL ASSEMBL	30
233T3241-6	WING AND ENGINE ANTI-ICE CONTROL PANEL ASSEMBLY, M10	
233T3242-1	EEC CONTROL PANEL ASSEMBLY M10761	31
233T3242-1	EEC CONTROL PANEL ASSEMBLY M10761	31
233T3242-1	EEC CONTROL PANEL ASSEMBLY M10761	31
233T3242-1	EEC CONTROL PANEL ASSEMBLY M10761	31
233T3242-1	EEC CONTROL PANEL ASSEMBLY M10761	31
233T3242-1	EEC CONTROL PANEL ASSEMBLY M10761	73
233T3242-4	EEC CONTROL PANEL ASSEMBLY M10761	31
233T3242-6	EEC CONTROL PANEL ASSEMBLY M10761	31
233T3242-8	EEC CONTROL PANEL ASSEMBLY M10761	73
233T3244-1	ENGINE IGNITION AND START CONTROL PANEL ASSEMB	31
233T3244-1	ENGINE IGNITION AND START CONTROL PANEL ASSEMB	31
233T3244-1	ENGINE IGNITION AND START CONTROL PANEL ASSEMB	31
233T3244-1	ENGINE IGNITION AND START CONTROL PANEL ASSEMB	31
233T3244-1	ENGINE IGNITION AND START CONTROL PANEL ASSEMB	31
233T3244-1	ENGINE IGNITION AND START CONTROL PANEL ASSEMB	31
233T3244-1	ENGINE IGNITION AND START CONTROL PANEL ASSEMB	31
233T3244-1	ENGINE IGNITION AND START CONTROL PANEL ASSEMB	31
233T3244-1	ENGINE IGNITION AND START CONTROL PANEL ASSEMB	31
233T3244-1	ENGINE IGNITION AND START CONTROL PANEL ASSEMB	31
233T3244-1	ENGINE IGNITION AND START CONTROL PANEL ASSEMB	31
233T3244-1	ENGINE IGNITION AND START CONTROL PANEL ASSEMB	31
233T3244-2	ENGINE IGNITION AND START CONTROL PANEL ASSEMB	31
233T3244-2	ENGINE IGNITION AND START CONTROL PANEL ASSEMB	31
233T3244-3	ENGINE IGNITION AND START CONTROL PANEL ASSEMB	31
233T3244-3	ENGINE IGNITION AND START CONTROL PANEL ASSEMB	31
233T3244-5	ENGINE IGNITION AND START CONTROL PANEL ASSEMB	31
233T3244-6	ENGINE IGNITION AND START CONTROL PANEL ASSEMB	31
233T3244-9	ENGINE IGNITION AND START CONTROL PANEL ASSEMB	31
233T3246-1	HF/SAT SELECT PANEL ASSEMBLY	23
233T4222-8	INTERPHONE JACK PANEL ASSEMBLY	31

233T4228-9	BULK CARGO HEAT PANEL ASSEMBLY	21
233T4239-1	MISC TEST PANEL ASSEMBLY	31
233T4239-2	MISC TEST PANEL ASSEMBLY	31
233T4239-2	MISC TEST PANEL ASSEMBLY	31
233T4239-3	MISC TEST PANEL ASSEMBLY	26
233T4240-1	MISCELLANEOUS SYSTEMS CONTROL PANEL ASSEMBLY	31
233T4240-1	MISCELLANEOUS SYSTEMS CONTROL PANEL ASSEMBLY	31
233T4240-1	MISCELLANEOUS SYSTEMS CONTROL PANEL ASSEMBLY	31
233T4240-6	MISCELLANEOUS SYSTEMS CONTROL PANEL ASSEMBLY	31
233T4240-7	MISCELLANEOUS SYSTEMS CONTROL PANEL ASSEMBLY	31
233T4243-7	WING/BODY DUCT LEAK PANEL ASSEMBLY	26
233T4244-1	PANEL, LIGHTING CONTROL, USED ON A/C 185	33
233T4244-3	PANEL, LIGHTING CONTROL, USED ON A/C 185	33
233T4246-1	SQUIB TEST PANEL ASSEMBLY	26
233T4246-2	SQUIB TEST PANEL ASSEMBLY	26
233T4246-4	SQUIB TEST PANEL ASSEMBLY	26
233T4246-7	SQUIB TEST PANEL ASSEMBLY	26
233T4248-1	RESERVE BRAKES AND STEERING PANEL ASSY M1216	31
233T4248-1	RESERVE BRAKES AND STEERING PANEL ASSY M1216	29
233T4248-1	RESERVE BRAKES AND STEERING PANEL ASSY M1216	31
233T6201-1	AILERON RUDDER TRIM PANEL ASSEMBLY M74	27
233T6201-2	AILERON RUDDER TRIM PANEL ASSEMBLY M74	27
233T6201-2	AILERON RUDDER TRIM PANEL ASSEMBLY M74	27
233T6201-3	AILERON RUDDER TRIM PANEL ASSEMBLY M74	27
233T6204-1	FIRE/OVERHEAT TEST PANEL ASSEMBLY, M10455	31
233T6204-1	FIRE/OVERHEAT TEST PANEL ASSEMBLY, M10455	31
233T6204-1	FIRE/OVERHEAT TEST PANEL ASSEMBLY, M10455	31
233T6204-1	FIRE/OVERHEAT TEST PANEL ASSEMBLY, M10455	31
233T6204-3	FIRE/OVERHEAT TEST PANEL ASSEMBLY, M10455	26
233T6204-7	FIRE/OVERHEAT TEST PANEL ASSEMBLY, M10455	31
233T6209-1	ACARS MODE CONTROL PANEL ASSEMBLY	31
233T6210-1	ENGINE FIRE CONTROL MODULE ASSEMBLY	26

233T6211-1	APU AND CARGO FIRE CONTROL MODULE ASSEMBLY	26
233T6211-1	APU AND CARGO FIRE CONTROL MODULE ASSEMBLY	26
233T7205-6	INTERPHONE JACK PANEL ASSEMBLY	23
233W3201-5	TURBINE, RAM AIR, LEG & PUMP ASSY	29
2350-0033	ACTUATOR POTABLE WATER OVERFLOW AND DRAI	38
2350-0048	ACTUATOR ACTUATOR, VALVE SELECTOR EQUIV	38
23504-001	EEC THERMOCOUPLE	73
236-508	AIR CHILLER	25
236-6	AIR CHILLER	25
236-8	AIR CHILLER	25
238-0101-5	TUBE, ASSY; COWL 238-0101-501;	71
238-0101-5	TUBE, ASSY; COWL 238-0101-501;	71
238-0101-5	TUBE, ASSY; COWL 238-0101-501;	71
238-0105-1	TUBE, ASSY; COWL 238-0101-501;	71
238-0105-1	TUBE, ASSY; COWL 238-0101-501;	30
238-0108-5	TUBE, ASSY; COWL 238-0101-501;	71
238-0113-5	TUBE, ASSY; COWL 238-0101-501;	71
238-0114-5	TUBE, ASSY; COWL 238-0101-501;	71
238-0114-5	TUBE, ASSY; COWL 238-0101-501;	71
238-0114-5	TUBE, ASSY; COWL 238-0101-501;	71
238-0123-5	BARREL ASSY., LOWER OUTER; INLET COWL	71
238-0123-5	TUBE OIL B SUMP SUPPLY LT SIDE	71
238-0124-5	TUBE, ASSY; COWL 238-0101-501;	71
238-0124-5	TUBE, ASSY; COWL 238-0101-501;	71
238-0301-5	COWL, FAN, LH; W/STRAKE; A319/320	71
238-0301-5	COWL, FAN, LH; W/STRAKE; A319/320	71
238-0301-5	COWL, FAN, LH; W/STRAKE; A319/320	71
238-0301-5	COWL, FAN, LH; W/STRAKE; A319/320	71
238-0301-5	COWL, FAN, LH; W/STRAKE; A319/320	71
238-0301-5	COWL, FAN, LH; W/STRAKE; A319/320	71
238-0301-5	COWL, FAN, LH; W/STRAKE; A319/320	71
238-0301-5	COWL, FAN, LH; W/STRAKE; A319/320	71

238-0301-5	COWL, FAN, LH; W/STRAKE; A319/320	71
238-0301-5	TUBE OIL B SUMP SUPPLY LT SIDE	71
238-0302-5	COWL, FAN, RH; W/STRAKE; A319/320	71
238-0302-5	COWL, FAN, RH; W/STRAKE; A319/320	71
238-0302-5	COWL, FAN, RH; W/STRAKE; A319/320	71
238-0302-5	COWL, FAN, RH; W/STRAKE; A319/320	71
238-0302-5	COWL, FAN, RH; W/STRAKE; A319/320	71
238-0302-5	COWL, FAN, RH; W/STRAKE; A319/320	71
238-0302-5	COWL, FAN, RH; W/STRAKE; A319/320	71
238-0302-5	TUBE OIL B SUMP SUPPLY LT SIDE	71
238-0302-5	COWL, FAN, RH; W/STRAKE; A319/320	71
238-0302-5	COWL, FAN, RH; W/STRAKE; A319/320	71
238-0302-5	COWL, FAN, RH; W/STRAKE; A319/320	71
238-0302-5	COWL, FAN, RH; W/STRAKE; A319/320	71
238-0302-5	COWL, FAN, RH; W/STRAKE; A319/320	71
238-0302-5	COWL, FAN, RH; W/STRAKE; A319/320	71
238-0302-5	COWL, FAN, RH; W/STRAKE; A319/320	71
238-0302-5	COWL, FAN, RH; W/STRAKE; A319/320	71
238-2101-5	TUBE, ASSY; COWL 238-0101-501;	71
238-2101-5	TUBE, ASSY; COWL 238-0101-501;	71
238-2101-5	TUBE, ASSY; COWL 238-0101-501;	71
238-2101-5	TUBE, ASSY; COWL 238-0101-501;	71
238D0912-5	HARNESS ASSY; VIBRATION SENSOR;	72
238M2160-5	TUBE, ASSY; COWL 238-0101-501;	71
238W0904-5	ENGINE FAN CASE PRIMARY WIRING BUNDLE	71
238W0904-5	ENGINE FAN CASE PRIMARY WIRING BUNDLE	71
238W0904-5	ENGINE FAN CASE PRIMARY WIRING BUNDLE	71
238W0907-5	ENGINE FAN CASE PRIMARY WIRING BUNDLE	71
238W0958-5	ENGINE FAN CASE PRIMARY WIRING BUNDLE	71
240-1	FREEZER REFRIGERATION UNIT	25
240-11-1	FREEZER REFRIGERATION UNIT	25
24-0124-50	COVER,DUST-PRESSURE OILER, 3/8"	24
24-0162-50	ELECTRICAL SYSTEM PANEL ASSEMBLY M10063	31

24-0162-50	ELECTRICAL SYSTEM PANEL ASSEMBLY M10063	31
24-0162-50	ELECTRICAL SYSTEM PANEL ASSEMBLY M10063	31
24-0162-50	ELECTRICAL SYSTEM PANEL ASSEMBLY M10063	31
24-0162-51	ELECTRICAL SYSTEM PANEL ASSEMBLY M10063	31
24-0162-51	ELECTRICAL SYSTEM PANEL ASSEMBLY M10063	31
24-0162-51	ELECTRICAL SYSTEM PANEL ASSEMBLY M10063	31
24-0162-51	ELECTRICAL SYSTEM PANEL ASSEMBLY M10063	24
24-0174-50	ELECTRICAL SYSTEM PANEL ASSEMBLY M10063	31
24-0174-50	ELECTRICAL SYSTEM PANEL ASSEMBLY M10063	31
24-0174-50	ELECTRICAL SYSTEM PANEL ASSEMBLY M10063	31
24-0174-50	ELECTRICAL SYSTEM PANEL ASSEMBLY M10063	31
24-0174-50	ELECTRICAL SYSTEM PANEL ASSEMBLY M10063	31
24-0174-51	ELECTRICAL SYSTEM PANEL ASSEMBLY M10063	24
24-0174-51	ELECTRICAL SYSTEM PANEL ASSEMBLY M10063	31
2406-5D75	STRIKE FLIGHT COMPARTMENT DOOR ELECTRICA	52
240695-2	VALVE HYD TRANSFER PUMP SHUTOFF USED ON	29
241-191-00	UNIT,INSOURCE FOR NWA/TRKINGONLY	77
241-191-20	UNIT,INSOURCE FOR NWA/TRKINGONLY	77
241-191-20	UNIT,INSOURCE FOR NWA/TRKINGONLY	77
241-191-30	UNIT,INSOURCE FOR NWA/TRKINGONLY	77
241-191-50	UNIT,INSOURCE FOR NWA/TRKINGONLY	77
24E5070090	WATER HEATER	38
24E5070400	LAVATORY WATER HEATER	38
24E5070400	LAVATORY WATER HEATER	38
250T1017-7	AUTOTHROTTLE MICROSWITCH PACK ASSEMBLY	22
250T1018-7	PACK MICRO SWITCH AUTOTHROTTLE USED ON A	22
2510144-27	SEAT,.CREW, PILOT;MECHANICAL;HAS INSP	25
2510144-38	SEAT,.CREW, PILOT;MECHANICAL;HAS INSP	25
2510144-53	SEAT,.CREW, PILOT;MECHANICAL;HAS INSP	25
2510145-03	SEAT,.CREW, PILOT;MECHANICAL;HAS INSP	25
2510145-13	SEAT,.CREW, PILOT;MECHANICAL;HAS INSP	25
2510145-23	SEAT,.CREW, PILOT;MECHANICAL;HAS INSP	25

2510145-26	SEAT,.CREW, PILOT;MECHANICAL;HAS INSP	25
2510145-27	SEAT,.CREW, PILOT;MECHANICAL;HAS INSP	25
2510145-33	SEAT,.CREW, PILOT;MECHANICAL;HAS INSP	25
2510145-38	SEAT,.CREW, PILOT;MECHANICAL;HAS INSP	25
2510145-43	SEAT,.CREW, PILOT;MECHANICAL;HAS INSP	25
2510145-53	SEAT,.CREW, PILOT;MECHANICAL;HAS INSP	25
2510145-63	SEAT,.CREW, PILOT;MECHANICAL;HAS INSP	25
25130-1	FAN RADIO RACK EXHAUST AND CARGO HEATING	21
251A1240-3	SPOILER ACTUATION POWER CONTROL UNIT ASSEMBLY	27
251A1240-5	SPOILER ACTUATION POWER CONTROL UNIT ASSEMBLY	27
251A1270-2	SPOILER ACTUATION POWER CONTROL UNIT ASSEMBLY	27
251A1270-4	SPOILER ACTUATION POWER CONTROL UNIT ASSEMBLY	27
251A1270-5	SPOILER ACTUATION POWER CONTROL UNIT ASSEMBLY	27
251A1641-1	AILERON CENTERING MECHANISM ASSEMBLY	27
251A1741-5	MIXER ASSY, SPOILER	27
251A1641-5	AILERON CENTERING MECHANISM ASSEMBLY	27
251A2160-2	AILERON/ELEVATOR POWER CONTROL UNIT ASSY	27
251A2420-1	ELEVATOR CONROL COMPONENTS	27
251A2420-7	ELEVATOR CONROL COMPONENTS	27
251A2430-1	ELEVATOR CONTROL- TAB MECHANISM ASSEMBLY	27
251A2430-1	ELEVATOR CONTROL- TAB MECHANISM ASSEMBLY	27
251A2430-1	ELEVATOR CONTROL- TAB MECHANISM ASSEMBLY	27
251A2430-1	ELEVATOR CONTROL- TAB MECHANISM ASSEMBLY	27
251A2430-1	ELEVATOR CONTROL- TAB MECHANISM ASSEMBLY	27
251A2430-1	ELEVATOR CONTROL- TAB MECHANISM ASSEMBLY	27
251A2430-2	ELEVATOR CONTROL- TAB MECHANISM ASSEMBLY	27
251A2430-2	ELEVATOR CONTROL- TAB MECHANISM ASSEMBLY	27
251A2430-2	ELEVATOR CONTROL- TAB MECHANISM ASSEMBLY	27
251A3495-7	ROD ASSY, CONTROL, POST EO 12-086343-3AD	27
251N1009-1	MECHANISM, ASSY, FEEL & TRIM, USED ON A/C	27
251N2040-2	RUDDER RATIO CHANGER BYPASS VALVE ASSEMBLY	27
251N2089-1	ELEVATOR PCU CONTROL POGO ROD ASSEMBLY	27

251N2114-1	STABILIZER CONTROL BRAKE ASSEMBLY	27
251N2158-1	STABILIZER CONTROL BRAKE ASSEMBLY	27
251N2656-2	ROD, ELEVATOR ASSY.	55
251N3018-2	RUDDER RATIO CHANGER BYPASS VALVE ASSEMBLY	27
251N3018-3	RUDDER RATIO CHANGER BYPASS VALVE ASSEMBLY	27
251N3018-4	RUDDER RATIO CHANGER BYPASS VALVE ASSEMBLY	27
251N3095-1	LINK, RUDDER PWR CONTROL UNIT	27
251N3095-1	LINK, RUDDER PWR CONTROL UNIT	27
251N3095-9	LINK, RUDDER PWR CONTROL UNIT	27
251N3182-1	RUDDER CONTROLS PCU INSTALLATION COMPONENTS	27
251N3182-1	RUDDER CONTROLS PCU INSTALLATION COMPONENTS	27
251N3182-1	RUDDER CONTROLS PCU INSTALLATION COMPONENTS	27
251N3182-1	RUDDER CONTROLS PCU INSTALLATION COMPONENTS	27
251N3182-6	RUDDER CONTROLS PCU INSTALLATION COMPONENTS	27
251N3182-7	RUDDER CONTROLS PCU INSTALLATION COMPONENTS	27
251N3182-8	RUDDER CONTROLS PCU INSTALLATION COMPONENTS	27
251N3182-9	RUDDER CONTROLS PCU INSTALLATION COMPONENTS	27
251N3244-5	RUDDER RATIO CHANGER BYPASS VALVE ASSEMBLY	27
251N4002-5	MOTOR, FLAP DRIVE, HYD; 757	27
251N4022-2	TRAILING EDGE FLAP TRANSMISSION ASSEMBLY	27
251N4022-2	TRAILING EDGE FLAP TRANSMISSION ASSEMBLY	27
251N4022-2	TRAILING EDGE FLAP TRANSMISSION ASSEMBLY	27
251N4022-2	TRAILING EDGE FLAP TRANSMISSION ASSEMBLY	27
251N4022-2	TRAILING EDGE FLAP TRANSMISSION ASSEMBLY	27
251N4022-2	TRAILING EDGE FLAP TRANSMISSION ASSEMBLY	27
251N4022-2	TRAILING EDGE FLAP TRANSMISSION ASSEMBLY	27
251N4022-3	TRAILING EDGE FLAP TRANSMISSION ASSEMBLY	27
251N4022-3	TRAILING EDGE FLAP TRANSMISSION ASSEMBLY	27
251N4022-3	TRAILING EDGE FLAP TRANSMISSION ASSEMBLY	27
251N4022-3	TRAILING EDGE FLAP TRANSMISSION ASSEMBLY	27
251N4022-3	TRAILING EDGE FLAP TRANSMISSION ASSEMBLY	27
251N4022-3	TRAILING EDGE FLAP TRANSMISSION ASSEMBLY	27
251N4022-3	TRAILING EDGE FLAP TRANSMISSION ASSEMBLY	27
251N4050-3	TRAILING EDGE FLAP DRIVE OUTBOARD FLAP INBOARD	27

251N4092-2	OUTBOARD INBOARD FLAPS TEE GEARBOX ASSEMBLY	27
251N4092-2	OUTBOARD INBOARD FLAPS TEE GEARBOX ASSEMBLY	27
251N4092-2	OUTBOARD INBOARD FLAPS TEE GEARBOX ASSEMBLY	27
251N4092-2	OUTBOARD INBOARD FLAPS TEE GEARBOX ASSEMBLY	27
251N4092-2	OUTBOARD INBOARD FLAPS TEE GEARBOX ASSEMBLY	27
251N4098-4	TRAILING EDGE FLAP DRIVE AND CONTROL COMPONENT	27
251N4098-5	TRAILING EDGE FLAP DRIVE AND CONTROL COMPONENT	27
251N4098-6	TRAILING EDGE FLAP DRIVE AND CONTROL COMPONENT	27
251N4114-2	TRAILING EDGE FLAP TRANSMISSION ASSEMBLY	27
251N4154-3	JOINT ASSY., BALLSCREW - FLAP DRIVE TRAN	27
251N4155-3	JOINT ASSY., BALLSCREW - FLAP DRIVE TRAN	27
251N4156-3	JOINT ASSY., BALLSCREW - FLAP DRIVE TRAN	27
251N4157-3	JOINT ASSY., BALLSCREW - FLAP DRIVE TRAN	27
251N4204-1	GEARBOX ASSEMBLY OB/OB TEE	27
251N4204-2	GEARBOX ASSEMBLY OB/OB TEE	27
251N4204-4	GEARBOX ASSEMBLY OB/OB TEE	27
251N4204-5	GEARBOX ASSEMBLY OB/OB TEE	27
251N4204-6	GEARBOX ASSEMBLY OB/OB TEE	27
251N4204-9	GEARBOX ASSEMBLY OB/OB TEE	27
251N4218-1	GEARBX TE FLAP.IB TEE(RB D276702475 PCD)	27
251N4218-2	GEARBX TE FLAP.IB TEE(RB D276702475 PCD)	27
251N4218-3	GEARBX TE FLAP.IB TEE(RB D276702475 PCD)	27
251N4218-4	GEARBX TE FLAP.IB TEE(RB D276702475 PCD)	27
251N4218-5	GEARBX TE FLAP.IB TEE(RB D276702475 PCD)	27
251N4218-6	GEARBX TE FLAP.IB TEE(RB D276702475 PCD)	27
251N4218-9	GEARBX TE FLAP.IB TEE(RB D276702475 PCD)	27
251N4218-7	GEARBX TE FLAP.IB TEE(RB D276702475 PCD)	
251N4222-2	ANGLE GEARBOX ASSEMBLY	27
251N4222-3	ANGLE GEARBOX ASSEMBLY	27
251N4222-4	ANGLE GEARBOX ASSEMBLY	27
251N4222-5	ANGLE GEARBOX ASSEMBLY	27
251N4222-6	ANGLE GEARBOX ASSEMBLY	27

251N4235-1	BEARING, FLAP TORQUE TUBE	27
251N4241-1	ANGLE TEE GEARBOX ASSEMBLY	27
251N4241-1	ANGLE TEE GEARBOX ASSEMBLY	27
251N4241-1	ANGLE TEE GEARBOX ASSEMBLY	27
251N4241-1	ANGLE TEE GEARBOX ASSEMBLY	27
251N4241-1	ANGLE TEE GEARBOX ASSEMBLY	27
251N4241-1	ANGLE TEE GEARBOX ASSEMBLY	27
251N4241-1	ANGLE TEE GEARBOX ASSEMBLY	27
251N4241-1	ANGLE TEE GEARBOX ASSEMBLY	27
251N4241-1	ANGLE TEE GEARBOX ASSEMBLY	27
251N4241-2	ANGLE TEE GEARBOX ASSEMBLY	27
251N4241-2	ANGLE TEE GEARBOX ASSEMBLY	27
251N4241-2	ANGLE TEE GEARBOX ASSEMBLY	27
251N4241-2	ANGLE TEE GEARBOX ASSEMBLY	27
251N4241-2	ANGLE TEE GEARBOX ASSEMBLY	27
251N4241-2	ANGLE TEE GEARBOX ASSEMBLY	27
251N4241-2	ANGLE TEE GEARBOX ASSEMBLY	27
251N4241-2	ANGLE TEE GEARBOX ASSEMBLY	27
251N4241-4	ANGLE TEE GEARBOX ASSEMBLY	27
251N4270-1	ANGLE TEE GEARBOX ASSEMBLY	27
251N4281-2	TUBE TE FLAP DRIVE TORQUE POST EO 6-6089	27
251N5091-1	LEADING EDGE SLAT DRIVE POWER DRIVE UNIT ASSEMBLY	27
251N5091-1	LEADING EDGE SLAT DRIVE POWER DRIVE UNIT ASSEMBLY	27
251N5091-1	LEADING EDGE SLAT DRIVE POWER DRIVE UNIT ASSEMBLY	27
251N5091-1	LEADING EDGE SLAT DRIVE POWER DRIVE UNIT ASSEMBLY	27
251N5091-1	LEADING EDGE SLAT DRIVE POWER DRIVE UNIT ASSEMBLY	27
251N5091-2	LEADING EDGE SLAT DRIVE POWER DRIVE UNIT ASSEMBLY	27
251N5091-7	LEADING EDGE SLAT DRIVE POWER DRIVE UNIT ASSEMBLY	
251T1205-1	MECHANISM, AILERON CONTROL, SET UP FOR AIR	27
251T1205-2	MECHANISM, AILERON CONTROL, SET UP FOR AIR	27
251T1305-1	TUBE INPUT CRANK TORQUE ASSY EQUIV 251T1	27
251T1509-1	ROD LATERAL CENTRAL CONTROL AND OVERRIDE	27
251T1710-1	OUTBOARD AILERON LOCKOUT MECHANISM ASSEMBLY	27

251T1710-1	OUTBOARD AILERON LOCKOUT MECHANISM ASSEMBLY	27
251T1710-1	OUTBOARD AILERON LOCKOUT MECHANISM ASSEMBLY	27
251T1710-5	OUTBOARD AILERON LOCKOUT MECHANISM ASSEMBLY	27
251T1710-6	OUTBOARD AILERON LOCKOUT MECHANISM ASSEMBLY	27
251T1710-7	OUTBOARD AILERON LOCKOUT MECHANISM ASSEMBLY	27
251T1710-8	OUTBOARD AILERON LOCKOUT MECHANISM ASSEMBLY	27
251T1710-9	OUTBOARD AILERON LOCKOUT MECHANISM ASSEMBLY	27
251T2210-1	UNIT, FEEL AND CENTERING	27
251T2210-1	UNIT, FEEL AND CENTERING	27
251T2210-1	UNIT, FEEL AND CENTERING	27
251T2210-1	UNIT, FEEL AND CENTERING	27
251T2210-1	UNIT, FEEL AND CENTERING	27
251T2210-1	UNIT, FEEL AND CENTERING	27
251T2210-1	UNIT, FEEL AND CENTERING	27
251T2210-1	UNIT, FEEL AND CENTERING	27
252T1172-5	LINK ASSY INBD AILERON ACTUATOR	27
252T1301-1	INBOARD SPOILER POWER CONTROL ACTUATOR ASSEM	27
252T1301-2	INBOARD SPOILER POWER CONTROL ACTUATOR ASSEM	27
252T1301-3	INBOARD SPOILER POWER CONTROL ACTUATOR ASSEM	27
252T1401-1	OUTBOARD SPOILER POWER CONTROL ACTUATOR ASS	27
252T1401-2	OUTBOARD SPOILER POWER CONTROL ACTUATOR ASS	27
252T1401-3	OUTBOARD SPOILER POWER CONTROL ACTUATOR ASS	27
252T2110-3	ROD, ELEVATOR ASSY.	27
252T2110-4	ROD, ELEVATOR ASSY.	27
252T2118-5	BELLCRANK, POST AD, 13-25-03; ELEVATOR P	27
252T2118-6	BELLCRANK, POST AD, 13-25-03; ELEVATOR P	27
25357-1	FAN RADIO RACK EXHAUST AND CARGO HEATING	21
253E1568-0	FLIGHT DATA RECORDER	31
253T7204-1	AUTOTHROTTLE SPRAG CLUTCH PACK ASSEMBLY	22
253T7204-2	AUTOTHROTTLE SPRAG CLUTCH PACK ASSEMBLY	22
253T7317-1	PACK MICRO SWITCH AUTOTHROTTLE USED ON A	22
25-4275-50	COFFEE MAKER	25
25-4275-50	COFFEE MAKER	25

254A1150-1	AUTOTHROTTLE SWITCH PACK ASSEMBLY	22
254A1150-1	AUTOTHROTTLE SWITCH PACK ASSEMBLY	22
254A1150-2	AUTOTHROTTLE SWITCH PACK ASSEMBLY	22
254A1150-7	AUTOTHROTTLE SWITCH PACK ASSEMBLY	22
254A1150-8	AUTOTHROTTLE SWITCH PACK ASSEMBLY	22
254A1150-9	AUTOTHROTTLE SWITCH PACK ASSEMBLY	22
254A1150-1	AUTOTHROTTLE SWITCH PACK ASSEMBLY	22
254A1150-1	AUTOTHROTTLE SWITCH PACK ASSEMBLY	22
254N1185-1	AUTOTHROTTLE MICROSWITCH PACK ASSEMBLY	22
254N1185-3	AUTOTHROTTLE MICROSWITCH PACK ASSEMBLY	22
254N1185-9	AUTOTHROTTLE MICROSWITCH PACK ASSEMBLY	22
254N1195-1	MODULE ASSY, FUEL CONTROL PANE...	76
254N1195-1	MODULE ASSY, FUEL CONTROL PANE...	76
254N1195-6	MODULE ASSY, FUEL CONTROL PANE...	76
25-5380-50	DOOR, CARGO BARRIER	25
256A3580-1	VALVE, FLAP ACTUATION CONTROL	27
256A3580-2	VALVE, FLAP ACTUATION CONTROL	27
256T2110-2	INBOARD LEADING EDGE SLAT DRIVE ROTARY ACTUATO	27
256T2110-2	INBOARD LEADING EDGE SLAT DRIVE ROTARY ACTUATOR ASS	
256T2110-3	INBOARD LEADING EDGE SLAT DRIVE ROTARY ACTUATO	27
256T2110-4	INBOARD LEADING EDGE SLAT DRIVE ROTARY ACTUATO	27
256T2120-1	OUTBOARD LEADING EDGE ROTARY ACTUATOR	27
256T2120-1	OUTBOARD LEADING EDGE ROTARY ACTUATOR	27
256T2120-1	OUTBOARD LEADING EDGE ROTARY ACTUATOR	27
256T2120-4	OUTBOARD LEADING EDGE ROTARY ACTUATOR	27
256T2120-4	OUTBOARD LEADING EDGE ROTARY ACTUATOR	
256T2120-5	OUTBOARD LEADING EDGE ROTARY ACTUATOR	27
256T2120-5	OUTBOARD LEADING EDGE ROTARY ACTUATOR	27
256T2120-6	OUTBOARD LEADING EDGE ROTARY ACTUATOR	27
256T2120-9	OUTBOARD LEADING EDGE ROTARY ACTUATOR	27
256T2150-7	OUTBOARD LEADING EDGE ROTARY ACTUATOR	27
256T2151-6	OUTBOARD LEADING EDGE ROTARY ACTUATOR	27

256T2152-2	OUTBOARD LEADING EDGE ROTARY ACTUATOR	27
256T2153-2	OUTBOARD LEADING EDGE ROTARY ACTUATOR	27
256T2210-1	OUTBOARD LEADING EDGE SLAT DRIVE OFFSET GEARBOX	27
256T2220-1	OUTBOARD LEADING EDGE SLAT DRIVE OFFSET GEARBOX	27
256T2220-1	OUTBOARD LEADING EDGE SLAT DRIVE OFFSET GEARBOX	27
256T2220-1	OUTBOARD LEADING EDGE SLAT DRIVE OFFSET GEARBOX	27
2610-11-1	UNIT CHRONOMETER STATIC SENSITIVE	31
2610-13-1	IND, CLOCK, A319/A320/A321	31
256T2610-8	DRIVE SLAT POWER, IB L/E, USED ON B767 A	27
256T2610-9	DRIVE SLAT POWER, IB L/E, USED ON B767 A	27
256T3160-5	FLAP SHUT-OFF VALVE	27
256T3570-3	TRAILING EDGE FLAP DRIVE OFFSET GEARBOX ASSEMBLY	27
256T3570-5	TRAILING EDGE FLAP DRIVE OFFSET GEARBOX ASSEMBLY	27
257T1103-1	LANDING GEAR LEVER CONTROL MODULE ASSEMBLY	32
257T1103-1	LANDING GEAR LEVER CONTROL MODULE ASSEMBLY	32
257T1103-1	LANDING GEAR LEVER CONTROL MODULE ASSEMBLY	32
257T1103-1	LANDING GEAR LEVER CONTROL MODULE ASSEMBLY	32
257T1103-1	LANDING GEAR LEVER CONTROL MODULE ASSEMBLY	32
257T1103-1	LANDING GEAR LEVER CONTROL MODULE ASSEMBLY	32
257T1103-2	LANDING GEAR LEVER CONTROL MODULE ASSEMBLY	32
257T1103-7	LANDING GEAR LEVER CONTROL MODULE ASSEMBLY	32
257T1103-9	LANDING GEAR LEVER CONTROL MODULE ASSEMBLY	32
257T1200-1	MAIN LANDING GEAR DOOR LATCH ACTUATOR ASSEMBLY	32
257T1200-1	MAIN LANDING GEAR DOOR LATCH ACTUATOR ASSEMBLY	32
257U0002-1	MODULE, LANDING GEAR CONTROL.....	32
257U0002-1	MODULE, LANDING GEAR CONTROL.....	32
257U0002-1	MODULE, LANDING GEAR CONTROL.....	32
257U0002-1	MODULE, LANDING GEAR CONTROL.....	32
257U0002-1	MODULE, LANDING GEAR CONTROL.....	32
257U0002-1	MODULE, LANDING GEAR CONTROL.....	32
257U0002-2	MODULE, LANDING GEAR CONTROL.....	32
257U0002-2	MODULE, LANDING GEAR CONTROL.....	32
257U0002-2	MODULE, LANDING GEAR CONTROL.....	32

257U0002-2	MODULE, LANDING GEAR CONTROL.....	32
257U0002-2	MODULE, LANDING GEAR CONTROL.....	32
257U0002-3	MODULE, LANDING GEAR CONTROL.....	32
257U0002-3	MODULE, LANDING GEAR CONTROL.....	32
257U0002-3	MODULE, LANDING GEAR CONTROL.....	32
2587284-96	ACTUATOR YAW DAMPENING COMPENSATION LINE	22
2587781-90	SERVO AUTO-THROTTLE SHIP IN ATA SPEC 300	22
2589445-93	ACTUATOR YAW DAMPENING COMPENSATION LINE	22
258T1190-4	ENTRY AND SERVICE DOOR COUNTERBALANCE ASSEMBLY	52
258T1190-8	ENTRY AND SERVICE DOOR COUNTERBALANCE ASSEMBLY	52
260BA101-1	BATTERY MAIN DC POWER SHELF LIFE 3 MONTH	24
262-1	DIMMER FLIGHT GUIDANCE LIGHTING CONTROL..	33
26257-000	EGT THERMOCOUPLE CABLES & JUNCTION BOXES	77
263-2	DIMMER OVERHEAD PANEL LIGHTING CONTROL	33
2651-269-5	CAP AND FLANGE ASSY; LAV DRAIN	38
2651-278-1	LAVATORY DRAIN BALL VALVE ASSEMBLY	38
2651-278-1	LAVATORY DRAIN BALL VALVE ASSEMBLY	38
2651-278-1	LAVATORY DRAIN BALL VALVE ASSEMBLY	38
2651-278-2	LAVATORY DRAIN BALL VALVE ASSEMBLY	38
2651-278-7	LAVATORY DRAIN BALL VALVE ASSEMBLY	38
2651-278-8	LAVATORY DRAIN BALL VALVE ASSEMBLY	38
2651-311-6	VALVE, DRAIN,LAVATORY WASTE	38
2651-357-1	VALVE PANEL, BALL KIT POST EO 9-70021-3A	38
2651-357-2	VALVE PANEL, BALL KIT POST EO 9-70021-3A	38
26669-000	HARNESS EGT, T/C 1 & 2	77
2670288-6	DOOR OPERATED GEAR SEQUENCE VALVE ASSEMBLY	32
2670288-7	DOOR OPERATED GEAR SEQUENCE VALVE ASSEMBLY	32
2670288-8	DOOR OPERATED GEAR SEQUENCE VALVE ASSEMBLY	32
2670288-9	DOOR OPERATED GEAR SEQUENCE VALVE ASSEMBLY	32
2670296M1	GEAR OPERATED DOOR SEQUENCE VALVE ASSEMBLY	32
267-100	AIR CHILLER	25
267-3	AIR CHILLER	25

267-500	AIR CHILLER	25
267-6	AIR CHILLER	25
267-6SB020	AIR CHILLER	25
267SV	AIR CHILLER	25
267XP	AIR CHILLER	25
2695A0000	SENSOR, PRESSURE, INLET	47
2704506-2	STARTER, APU; A320 ONLY	49
271N2040-2	FILTER ASSY., PTU PRESSURE MODULE	29
271N3005-1	LEFT SYSTEM HYDRAULIC RESERVOIR ASSEMBLY	29
271N3054-2	CENTRAL GROUND SERVICE RESERVOIR PRESSURIZATION	29
271N3054-3	CENTRAL GROUND SERVICE RESERVOIR PRESSURIZATION	29
271T0042-2	AC MOTOR PUMP PRESSURE AND CASE DRAIN FILTER M	29
271T0042-3	AC MOTOR PUMP PRESSURE AND CASE DRAIN FILTER M	29
271T0042-4	AC MOTOR PUMP PRESSURE AND CASE DRAIN FILTER M	29
271T0068-1	ENGINE-DRIVEN PUMP & AIR-DRIVEN PUMP PRESSURE AND C	
271T0068-1	ENGINE-DRIVEN PUMP & AIR-DRIVEN PUMP PRESSURE	29
271T0068-1	ENGINE-DRIVEN PUMP & AIR-DRIVEN PUMP PRESSURE AND C	
271T0068-1	ENGINE-DRIVEN PUMP & AIR-DRIVEN PUMP PRESSURE	29
271T0068-4	ENGINE-DRIVEN PUMP & AIR-DRIVEN PUMP PRESSURE AND C	
271T0068-5	ENGINE-DRIVEN PUMP & AIR-DRIVEN PUMP PRESSURE	29
271T0068-6	ENGINE-DRIVEN PUMP & AIR-DRIVEN PUMP PRESSURE AND C	
271T0068-7	ENGINE-DRIVEN PUMP & AIR-DRIVEN PUMP PRESSURE	29
271T0068-8	ENGINE-DRIVEN PUMP & AIR-DRIVEN PUMP PRESSURE AND C	
271T0068-9	ENGINE-DRIVEN PUMP & AIR-DRIVEN PUMP PRESSURE AND C	
273A1101-1	NOSE LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
273A1101-2	NOSE LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
273A1201-1	NOSE LANDING GEAR LOCK ACTUATOR ASSEMBLY	32
273A1201-2	NOSE LANDING GEAR LOCK ACTUATOR ASSEMBLY	32
273A2101-1	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
273A2101-1	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
273A2101-2	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
273A2101-3	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32

273A2101-4	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
273A2101-5	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
273A2101-6	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
273A2101-7	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
273A2101-8	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
273A2101-9	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
273A2201-1	MAIN LANDING GEAR DOWNLOCK ACTUATOR ASSEMBLY	32
273A2501-1	MAIN LANDING GEAR UPLOCK ACTUATOR ASSEMBLY	32
273A3301-6	MODULE ASSY., LANDING GEAR CONTROL LE	32
273A3301-8	MODULE ASSY., LANDING GEAR CONTROL LE	32
273A3610-2	MAIN GEAR SHIMMY DAMPER ASSEMBLY	32
273A3610-4	MAIN GEAR SHIMMY DAMPER ASSEMBLY	32
273A3610-5	MAIN GEAR SHIMMY DAMPER ASSEMBLY	32
273A3610-7	MAIN GEAR SHIMMY DAMPER ASSEMBLY	32
273N1004-2	NOSE LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
273N1004-3	NOSE LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
273N1004-4	NOSE LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
273N1004-5	NOSE LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
273N1005-1	NOSE GEAR LOCK ACTUATOR ASSEMBLY	32
273N1005-2	NOSE GEAR LOCK ACTUATOR ASSEMBLY	32
273N1095-2	VALVE NLG LOCK UNLOAD	32
273N2004-1	MLG TRUCK POSITIONER ACTUATOR ASSEMBLY	32
273N2004-2	MLG TRUCK POSITIONER ACTUATOR ASSEMBLY	32
273N2004-3	MLG TRUCK POSITIONER ACTUATOR ASSEMBLY	32
273N2004-6	MLG TRUCK POSITIONER ACTUATOR ASSEMBLY	32
273N2006-1	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
273N2006-2	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
273N2006-3	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
273N2006-4	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
273N2006-5	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
273N2007-1	ACTUATOR MLG UPLOCK RELEASE ASSY	32
273N2008-2	MLG DOWNLOCK ACTUATOR ASSEMBLY	32

273N2008-3	MLG DOWNLOCK ACTUATOR ASSEMBLY	32
273N2087-3	TRUCK POSITIONER SHUTTLE VALVE MODULE ASSEMBL	32
273N2087-5	TRUCK POSITIONER SHUTTLE VALVE MODULE ASSEMBL	32
273N2088-1	TRUCK POSITIONER SHUTTLE VALVE MODULE ASSEMBL	32
273N2088-2	TRUCK POSITIONER SHUTTLE VALVE MODULE ASSEMBL	32
273N4006-2	ALTERNATE EXTENSION SYSTEM DOOR LOCK RELEASE	32
273N4006-3	ALTERNATE EXTENSION SYSTEM DOOR LOCK RELEASE	32
273N4041-2	DOOR RELEASE INTERLOCK ACTUATOR ASSEMBLY	32
273N4041-6	DOOR RELEASE INTERLOCK ACTUATOR ASSEMBLY	32
273N4171-1	DOOR RELEASE INTERLOCK ACTUATOR ASSEMBLY	32
273N4171-3	DOOR RELEASE INTERLOCK ACTUATOR ASSEMBLY	32
273N4171-4	DOOR RELEASE INTERLOCK ACTUATOR ASSEMBLY	32
273T0073-1	MAIN LANDING GEAR DOOR ACTUATOR ASSEMBLY	32
273T1100-5	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
273T1100-6	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
273T1102-7	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
273T1102-8	MAIN LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
273T4110-4	NOSE LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
273T4110-6	NOSE LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
273T4112-4	NOSE LANDING GEAR RETRACT ACTUATOR ASSEMBLY	32
273T4120-2	NOSE GEAR LOCK ACTUATOR	32
273T4520-9	ACTUATOR MLG DOOR	32
273T4551-2	ACTUATOR, ASSY	32
273T4561-9	CYLINDER MLG RETRACT, LH AND RH EQUIV 59	32
273T4702-1	ACTUATOR, TAIL SKID	32
273T6100-1	MAIN LANDING GEAR TRUCK POSITIONER ASSEMBLY	32
273T6100-4	MAIN LANDING GEAR TRUCK POSITIONER ASSEMBLY	32
273T6100-6	MAIN LANDING GEAR TRUCK POSITIONER ASSEMBLY	32
273T6100-8	MAIN LANDING GEAR TRUCK POSITIONER ASSEMBLY	32
273T6101-8	MAIN LANDING GEAR TRUCK POSITIONER ASSEMBLY	32
273T6101-9	MAIN LANDING GEAR TRUCK POSITIONER ASSEMBLY	32
273T6102-7	MAIN LANDING GEAR TRUCK POSITIONER ASSEMBLY	32

273T6110-2	MAIN LANDING GEAR TRUCK POSITIONER ASSEMBLY	32
273T6151-1	MLG TRUCK POSITIONER ACTUATOR ASSEMBLY	32
273T6200-2	MAIN LANDING GEAR SIDE BRACE LOCK ACTUATOR ASS	32
273T6200-4	MAIN LANDING GEAR SIDE BRACE LOCK ACTUATOR ASS	32
273T6200-6	MAIN LANDING GEAR SIDE BRACE LOCK ACTUATOR ASS	32
273T6200-9	MAIN LANDING GEAR SIDE BRACE LOCK ACTUATOR ASS	32
273T6201-1	MAIN LANDING GEAR SIDE BRACE LOCK ACTUATOR ASS	32
273T6201-3	MAIN LANDING GEAR SIDE BRACE LOCK ACTUATOR ASS	32
273T6251-1	ACTUATOR,ASSY	32
273T6300-1	MAIN LANDING GEAR DRAG BRACE LOCK ACTUATOR AS	32
273T6300-2	MAIN LANDING GEAR DRAG BRACE LOCK ACTUATOR AS	32
273T6300-3	MAIN LANDING GEAR DRAG BRACE LOCK ACTUATOR AS	32
273T6300-4	MAIN LANDING GEAR DRAG BRACE LOCK ACTUATOR AS	32
273T6300-6	MAIN LANDING GEAR DRAG BRACE LOCK ACTUATOR AS	32
273T6300-8	MAIN LANDING GEAR DRAG BRACE LOCK ACTUATOR AS	32
273T6301-3	MAIN LANDING GEAR DRAG BRACE LOCK ACTUATOR AS	32
273T6301-5	MAIN LANDING GEAR DRAG BRACE LOCK ACTUATOR AS	32
273T6301-6	MAIN LANDING GEAR DRAG BRACE LOCK ACTUATOR AS	32
273T6301-7	MAIN LANDING GEAR DRAG BRACE LOCK ACTUATOR AS	32
2-7457-10	ACTUATOR ASSEMBLY, MAIN LANDING GEAR DOOR	32
2-7457-11	ACTUATOR ASSEMBLY, MAIN LANDING GEAR DOOR	32
2-7457-11P	ACTUATOR ASSEMBLY, MAIN LANDING GEAR DOOR	32
2-7457-12	ACTUATOR ASSEMBLY, MAIN LANDING GEAR DOOR	32
2-7457-13	ACTUATOR ASSEMBLY, MAIN LANDING GEAR DOOR	32
2-7457-6	ACTUATOR ASSEMBLY, MAIN LANDING GEAR DOOR	32
2-7457-7	ACTUATOR ASSEMBLY, MAIN LANDING GEAR DOOR	32
2-7457-8	ACTUATOR ASSEMBLY, MAIN LANDING GEAR DOOR	32
2-7457-9	ACTUATOR ASSEMBLY, MAIN LANDING GEAR DOOR	32
2-7460-2	AUTOBRAKE SELECTOR SWITCH ASSEMBLY	32
2-7460-3	AUTOBRAKE SELECTOR SWITCH ASSEMBLY	32
2-7460-4	AUTOBRAKE SELECTOR SWITCH ASSEMBLY	32
2-7460-5	AUTOBRAKE SELECTOR SWITCH ASSEMBLY	32

2-7462-1	AUTO-BRAKE SHUTTLE VALVE MODULE	32
2-7462-2	AUTO-BRAKE SHUTTLE VALVE MODULE	32
2-7462-3	AUTO-BRAKE SHUTTLE VALVE MODULE	32
2-7462-4	AUTO-BRAKE SHUTTLE VALVE MODULE	32
2-7464-3	ACTUATOR, NLG DOOR, DO NOT USE UNLESS 2	32
2-7464-4	ACTUATOR, NLG DOOR, DO NOT USE UNLESS 2	32
2-7464-5	ACTUATOR, NLG DOOR, DO NOT USE UNLESS 2	32
2-7464-5B	ACTUATOR, NLG DOOR, DO NOT USE UNLESS 2	32
2-7464-6	ACTUATOR, NLG DOOR, DO NOT USE UNLESS 2	32
2-7464-6C	ACTUATOR NLG DOOR, IF NIS USE 2-7464-4/-	32
2-7464-7	ACTUATOR, NLG DOOR, DO NOT USE UNLESS 2	32
2-7464-7A	ACTUATOR, NLG DOOR, DO NOT USE UNLESS 2	32
274N1051-1	BRAKE ACCUMULATOR ISOLATION VALVE ASSEMBLY AL	32
274N1051-3	BRAKE ACCUMULATOR ISOLATION VALVE ASSEMBLY AL	32
274T4621-3	ALTERNATE BRAKE ACCUMULATOR ISOLATION VALVE AS	32
274T4621-4	ALTERNATE BRAKE ACCUMULATOR ISOLATION VALVE AS	32
2758A	BATTERY, MAIN AIRCRAFT, A319/A	24
275A1101-3	NOSE LANDING GEAR STEERING ACTUATOR ASSEMBLY	32
275A1101-4	NOSE LANDING GEAR STEERING ACTUATOR ASSEMBLY	32
275A1101-5	NOSE LANDING GEAR STEERING ACTUATOR ASSEMBLY	32
275A1101-6	NOSE LANDING GEAR STEERING ACTUATOR ASSEMBLY	32
275A1101-7	NOSE LANDING GEAR STEERING ACTUATOR ASSEMBLY	32
275A1101-8	NOSE LANDING GEAR STEERING ACTUATOR ASSEMBLY	32
275A1101-9	NOSE LANDING GEAR STEERING ACTUATOR ASSEMBLY	32
275A1101-1	NOSE LANDING GEAR STEERING ACTUATOR ASSEMBLY	32
275N1211-2	NOSE GEAR STEERING ACTUATOR ASSEMBLY	32
275N1230-1	NOSE GEAR STEERING ACTUATOR ASSEMBLY	32
275N2059-2	CARTRIDG ASSY, NLG QUADRANT	32
275N2059-3	CARTRIDG ASSY, NLG QUADRANT	32
275T4112-2	NOSE GEAR STEERING CHECK VALVE MODULAR ASSEM	32
275T4112-3	NOSE GEAR STEERING CHECK VALVE MODULAR ASSEM	32
275T6221-2	NOSE GEAR STEERING ACTUATOR ASSEMBLY	32

275T6221-3	NOSE GEAR STEERING ACTUATOR ASSEMBLY	32
2-7679-1	FLOW RATE FUSE ASSEMBLY	29
2-7679-2	FLOW RATE FUSE ASSEMBLY	29
2-7680-1	FLOW RATE FUSE ASSEMBLY	29
2-7680-2	FLOW RATE FUSE ASSEMBLY	29
2-7681-1	FLOW RATE FUSE ASSEMBLY	29
2-7681-2	FLOW RATE FUSE ASSEMBLY	29
2-7756-1	FUSE ASSEMBLY	32
2780536-10	2-INCH CARGO HEATING VALVE	21
2780536-10	2-INCH CARGO HEATING VALVE	21
2780537-10	WING THERMAL ANTI-ICE PRESSURE REGULATING & SH	30
2780539-10	6 INCH BLEED AIR MANIFOLD ISOLATION VALVE	36
2780539-10	6 INCH BLEED AIR MANIFOLD ISOLATION VALVE	36
2780539-10	6 INCH BLEED AIR MANIFOLD ISOLATION VALVE	36
2780539-10	6 INCH BLEED AIR MANIFOLD ISOLATION VALVE	36
2780539-10	6 INCH BLEED AIR MANIFOLD ISOLATION VALVE	36
2780539-10	6 INCH BLEED AIR MANIFOLD ISOLATION VALVE	36
2780539-10	6 INCH BLEED AIR MANIFOLD ISOLATION VALVE	36
2780540-10	4.5 INCH BLEED AIR VALVE ASSEMBLY	36
2780540-10	4.5 INCH BLEED AIR VALVE ASSEMBLY	36
2783942-2	FAN, VARIABLE SPEED, CONSTANT FREQUENCY,C	21
2790409-10	PRESSURE FUELING ADAPTER	28
2790409-10	PRESSURE FUELING ADAPTER	28
2790521-10	CARTRIDGE CHECK VALVE, SIZE 12	29
2790583-10	COWL ANTI ICE 3 1/2 INCH CONTROL VALVE ASSY	30
2790583-10	COWL ANTI ICE 3 1/2 INCH CONTROL VALVE ASSY	30
2790583-10	COWL ANTI ICE 3 1/2 INCH CONTROL VALVE ASSY	30
2790583-10	COWL ANTI ICE 3 1/2 INCH CONTROL VALVE ASSY	30
2790583-10	COWL ANTI ICE 3 1/2 INCH CONTROL VALVE ASSY	30
2790583-10	COWL ANTI ICE 3 1/2 INCH CONTROL VALVE ASSY	30
2790592-10	IDGS 3.5 INCH SHUTOFF VALVE ASSEMBLY	75
2790592-10	IDGS 3.5 INCH SHUTOFF VALVE ASSEMBLY	75
2790598-10	5- INCH SHUTOFF VALVE	36

2790598-10	5- INCH SHUTOFF VALVE	36
2790598-10	5- INCH SHUTOFF VALVE	36
2790611-10	COOLING AIR VALVE - CF6-80A	75
2790711-10	3.5 INCH COOLING AIR VALVE - CF6-80A	75
2800014-10	PRESSURE FUELING ADAPTER	28
2800014-10	PRESSURE FUELING ADAPTER	28
2-8020-1	FUSE ASSEMBLY, QUANTITY MEASURING	29
2-8020-18	FUSE ASSEMBLY, QUANTITY MEASURING	32
2-8020-2	FUSE ASSEMBLY, QUANTITY MEASURING	29
2-8020-25	FUSE ASSEMBLY, QUANTITY MEASURING	29
2-8020-26	FUSE ASSEMBLY, QUANTITY MEASURING	29
2-8020-27	FUSE ASSEMBLY, QUANTITY MEASURING	29
2-8020-28	FUSE ASSEMBLY, QUANTITY MEASURING	29
2-8020-29	FUSE ASSEMBLY, QUANTITY MEASURING	32
2-8020-3	FUSE ASSEMBLY, QUANTITY MEASURING	29
2-8020-5	FUSE ASSEMBLY, QUANTITY MEASURING	32
2-8020-6	FUSE ASSEMBLY, QUANTITY MEASURING	32
2-8041-1	ANTISKID VOLUMETRIC FUSE ASSEMBLY	32
2-8051-1	VALVE MODULE, ANTI-SKID SHUTTLE	32
2810181-10	3.5 INCH COOLING AIR VALVE - CF6-80A	75
2810181-10	3.5 INCH COOLING AIR VALVE - CF6-80A	75
2810182-10	3.5 INCH COOLING AIR VALVE - CF6-80A	75
2810182-10	3.5 INCH COOLING AIR VALVE - CF6-80A	75
2810193-10	AIR/OIL HEAT EXCHANGER VALVE	79
2810193-11	AIR/OIL HEAT EXCHANGER VALVE	79
2810193-11	AIR/OIL HEAT EXCHANGER VALVE	79
2810218-10	3.5 INCH COOLING AIR VALVE - CF6-80A	75
2810219-10	3.5 INCH COOLING AIR VALVE - CF6-80A	75
2812125-10	ACTUATOR ASSEMBLY	36
2812125-10	ACTUATOR ASSEMBLY	36
2812125-10	ACTUATOR ASSEMBLY	36
2825-3	LATCH ASSY, FWD LAV RH DOOR, AFT LAV RH	25

2825-3S12	LATCH ASSY, FWD LAV RH DOOR, AFT LAV RH	25
2825-4	LATCH ASSY, FWD LAV RH DOOR, AFT LAV RH	25
282700-100	ELEVATOR POWER CONTROL ACTUATOR	27
282700-100	ELEVATOR POWER CONTROL ACTUATOR	27
282700-100	ELEVATOR POWER CONTROL ACTUATOR	27
282700-101	ELEVATOR POWER CONTROL ACTUATOR	27
282800-100	INBOARD AILERON POWER CONTROL ACTUATOR	27
282800-100	INBOARD AILERON POWER CONTROL ACTUATOR	27
282800-100	INBOARD AILERON POWER CONTROL ACTUATOR	27
282800-100	INBOARD AILERON POWER CONTROL ACTUATOR	27
282800-101	INBOARD AILERON POWER CONTROL ACTUATOR	27
282900-100	RUDDER POWER CONTROL ACTUATOR	
282900-100	RUDDER POWER CONTROL ACTUATOR	
282900-100	RUDDER POWER CONTROL ACTUATOR	
282900-100	RUDDER POWER CONTROL ACTUATOR	27
282900-101	RUDDER POWER CONTROL ACTUATOR	27
283200-100	OUTBD AILERON LOCKOUT ACTUATOR ASSEMBLY	27
283200-100	OUTBD AILERON LOCKOUT ACTUATOR ASSEMBLY	27
28470-1	VALVE BRAKE CONTROL BUILT INTO CONVENN..	32
28470-2	VALVE BRAKE CONTROL BUILT INTO CONVENN..	32
28470-3	VALVE BRAKE CONTROL BUILT INTO CONVENN..	32
284T0052-2	RADOME ASSEMBLY	34
284T0052-2	RADOME ASSEMBLY	53
284T0052-2	RADOME ASSEMBLY	34
284T0052-2	RADOME ASSEMBLY	34
284T0052-3	RADOME ASSEMBLY	34
284T0052-3	RADOME ASSEMBLY	53
284T0052-3	RADOME ASSEMBLY	34
284T0052-3	RADOME ASSEMBLY	34
284T0052-3	RADOME ASSEMBLY	34
284T0759-1	PENDANT CONTROL MODULE	25
284T0759-3	PENDANT CONTROL MODULE	25

284T0759-5	PENDANT CONTROL MODULE	25
284T0759-6	PENDANT CONTROL MODULE	25
284T0783-3	PENDANT CONTROL MODULE	25
285A1010-1	STALL MANAGEMENT YAW DAMPER MODULE ASSEMBLY	22
285A1010-1	STALL MANAGEMENT YAW DAMPER MODULE ASSEMBLY	22
285A1010-1	STALL MANAGEMENT YAW DAMPER MODULE ASSEMBLY	22
285A1010-1	STALL MANAGEMENT YAW DAMPER MODULE ASSEMBLY	22
285A1010-2	STALL MANAGEMENT YAW DAMPER MODULE ASSEMBLY	22
285A1010-3	STALL MANAGEMENT YAW DAMPER MODULE ASSEMBLY	22
285A1010-4	STALL MANAGEMENT YAW DAMPER MODULE ASSEMBLY	22
285A1010-5	STALL MANAGEMENT YAW DAMPER MODULE ASSEMBLY	27
285A1010-6	STALL MANAGEMENT YAW DAMPER MODULE ASSEMBLY	22
285A1010-7	STALL MANAGEMENT YAW DAMPER MODULE ASSEMBLY	22
285A1010-9	STALL MANAGEMENT YAW DAMPER MODULE ASSEMBLY	22
285A1300-1	UNIT ENGINE ACCESSORY STATIC SENSITIVE	77
285A1710-8	MODULE ASSY., LIGHTING ATTENDANT PANEL	33
285A1720-1	MODULE, ASSY., ATTENDANT PANEL,POTABLE W	38
285A1760-2	UNIT SEAT ELECTRONICS STATIC SENSITIVE	23
285N0006-1	BLEED CONFIGURATION PRINTED CIRCUIT ASSEMBLY	36
285N0006-1	BLEED CONFIGURATION PRINTED CIRCUIT ASSEMBLY	36
285N0006-1	BLEED CONFIGURATION PRINTED CIRCUIT ASSEMBLY	36
285N0009-1	CARD,RESERVE DIGITAL FLAP/SLATA6 STATIC	27
285N0009-1	CARD,RESERVE DIGITAL FLAP/SLATA6 STATIC	27
285N0009-2	CARD,RESERVE DIGITAL FLAP/SLATA6 STATIC	27
285N0011-1	FLAP AND SLAT ELECTRONIC UNIT ASSEMBLY	27
285N0011-1	FLAP AND SLAT ELECTRONIC UNIT ASSEMBLY	27
285N0011-3	FLAP AND SLAT ELECTRONIC UNIT ASSEMBLY	27
285N0011-3	FLAP AND SLAT ELECTRONIC UNIT ASSEMBLY	27
285N0011-3	FLAP AND SLAT ELECTRONIC UNIT ASSEMBLY	27
285N0011-3	FLAP AND SLAT ELECTRONIC UNIT ASSEMBLY	
285N0011-4	FLAP AND SLAT ELECTRONIC UNIT ASSEMBLY	27
285N0028-1	AUTOMATIC FIRE/OVERHEAT LOGIC/TEST SYSTEM	26

285N0028-1	AUTOMATIC FIRE/OVERHEAT LOGIC/TEST SYSTEM	26
285N0028-1	BOARD AUTO FIRE-OVERHEAT	26
285N0028-1	AUTOMATIC FIRE/OVERHEAT LOGIC/TEST SYSTEM	26
285N0028-2	AUTOMATIC FIRE/OVERHEAT LOGIC/TEST SYSTEM	26
285N0028-2	AUTOMATIC FIRE/OVERHEAT LOGIC/TEST SYSTEM	26
285N0028-3	AUTOMATIC FIRE/OVERHEAT LOGIC/TEST SYSTEM	26
285N0028-3	AUTOMATIC FIRE/OVERHEAT LOGIC/TEST SYSTEM	26
285N0028-4	AUTOMATIC FIRE/OVERHEAT LOGIC/TEST SYSTEM	26
285N0028-4	AUTOMATIC FIRE/OVERHEAT LOGIC/TEST SYSTEM	26
285N0029-1	STABILIZER POSITION MOD PRINTED CIRCUIT ASSY	27
285N0029-9	STABILIZER POSITION MOD PRINTED CIRCUIT ASSY	27
285N0029-9	STABILIZER POSITION MOD PRINTED CIRCUIT ASSY	27
285N0055-1	EICAS DISPLAY SWITCHING UNIT PRINTED CIRCUIT ASSY	31
285N0078-1	PEM PCU MONITOR ELECTRONICS MODULE PRINTED CI	27
285N0121-2	CARD EQUIP COOLING STATIC SENSITIVE	21
285N0121-3	CARD EQUIP COOLING STATIC SENSITIVE	21
285N0121-3	CARD EQUIP COOLING STATIC SENSITIVE	21
285N0121-3	CARD EQUIP COOLING STATIC SENSITIVE	21
285N0200-2	ENGINE SPEED PRINTED WIRING ASSEMBLY	77
285N0200-2	ENGINE SPEED PRINTED WIRING ASSEMBLY	77
285N0412-1	HANDSET ASSEMBLY	23
285N0412-2	HANDSET ASSEMBLY	23
285N0412-3	HANDSET ASSEMBLY	23
285N0412-4	HANDSET ASSEMBLY	23
285N0412-8	HANDSET ASSEMBLY	23
285N0412-9	HANDSET ASSEMBLY	23
285N0432-8	SIGNAL CONSOLIDATION PRINTED CIRCUIT ASSEMBLY	31
285N0432-9	SIGNAL CONSOLIDATION PRINTED CIRCUIT ASSEMBLY	31
285T0001-2	AUDIO ACCESSORY UNIT ASSEMBLY	23
285T0001-2	AUDIO ACCESSORY UNIT ASSEMBLY	23
285T0001-4	AUDIO ACCESSORY UNIT ASSEMBLY	23
285T0001-4	AUDIO ACCESSORY UNIT ASSEMBLY	23

285T0001-4	AUDIO ACCESSORY UNIT ASSEMBLY	23
285T0001-5	AUDIO ACCESSORY UNIT ASSEMBLY	23
285T0001-5	AUDIO ACCESSORY UNIT ASSEMBLY	23
285T0001-5	AUDIO ACCESSORY UNIT ASSEMBLY	23
285T0001-5	AUDIO ACCESSORY UNIT ASSEMBLY	23
285T0001-5	AUDIO ACCESSORY UNIT ASSEMBLY	23
285T0001-6	AUDIO ACCESSORY UNIT ASSEMBLY	23
285T0012-1	SPOILER CONTROL MODULE ASSY	27
285T0012-1	SPOILER CONTROL MODULE ASSY	27
285T0012-1	SPOILER CONTROL MODULE ASSY	27
285T0012-1	SPOILER CONTROL MODULE ASSY	27
285T0012-1	SPOILER CONTROL MODULE ASSY	27
285T0012-1	SPOILER CONTROL MODULE ASSY	27
285T0012-1	SPOILER CONTROL MODULE ASSY	27
285T0012-1	SPOILER CONTROL MODULE ASSY	27
285T0012-2	SPOILER CONTROL MODULE ASSY	27
285T0013-1	YAW DAMPER UNIT MODULE ASSEMBLY	22
285T0013-1	YAW DAMPER UNIT MODULE ASSEMBLY	22
285T0013-1	YAW DAMPER UNIT MODULE ASSEMBLY	22
285T0013-1	YAW DAMPER UNIT MODULE ASSEMBLY	22
285T0013-1	YAW DAMPER UNIT MODULE ASSEMBLY	22
285T0013-1	YAW DAMPER UNIT MODULE ASSEMBLY	22
285T0013-1	YAW DAMPER UNIT MODULE ASSEMBLY	22
285T0013-1	YAW DAMPER UNIT MODULE ASSEMBLY	22
285T0013-1	YAW DAMPER UNIT MODULE ASSEMBLY	22
285T0013-1	YAW DAMPER UNIT MODULE ASSEMBLY	22
285T0013-1	YAW DAMPER UNIT MODULE ASSEMBLY	22
285T0014-1	RUDDER RATIO CHANGER MODULE ASSEMBLY	27
285T0014-1	RUDDER RATIO CHANGER MODULE ASSEMBLY	27
285T0014-1	RUDDER RATIO CHANGER MODULE ASSEMBLY	27
285T0014-1	RUDDER RATIO CHANGER MODULE ASSEMBLY	27
285T0015-1	STABILIZER TRIM AND AILERON LOCKOUT MODULE ASS	27
285T0015-1	STABILIZER TRIM AND AILERON LOCKOUT MODULE ASS	27

285T0015-1	STABILIZER TRIM AND AILERON LOCKOUT MODULE ASS	27
285T0015-1	STABILIZER TRIM AND AILERON LOCKOUT MODULE ASS	27
285T0015-1	STABILIZER TRIM AND AILERON LOCKOUT MODULE ASS	27
285T0015-1	STABILIZER TRIM AND AILERON LOCKOUT MODULE ASSEMBL	
285T0015-1	STABILIZER TRIM AND AILERON LOCKOUT MODULE ASS	27
285T0015-1	STABILIZER TRIM AND AILERON LOCKOUT MODULE ASSEMBL	
285T0015-1	STABILIZER TRIM AND AILERON LOCKOUT MODULE ASS	27
285T0020-1	ILS CONTROL PANEL ASSEMBLY	34
285T0020-1	ILS CONTROL PANEL ASSEMBLY	
285T0020-2	ILS CONTROL PANEL ASSEMBLY	
285T0020-8	ILS CONTROL PANEL ASSEMBLY	34
285T0021-1	VOR/DME CONTROL PANEL	34
285T0021-1	VOR/DME CONTROL PANEL	34
285T0022-2	AUDIO SELECTOR PANEL ASSEMBLY	23
285T0022-2	AUDIO SELECTOR PANEL ASSEMBLY	23
285T0022-2	AUDIO SELECTOR PANEL ASSEMBLY	23
285T0022-2	AUDIO SELECTOR PANEL ASSEMBLY	23
285T0022-2	AUDIO SELECTOR PANEL ASSEMBLY	23
285T0022-2	AUDIO SELECTOR PANEL ASSEMBLY	23
285T0022-3	AUDIO SELECTOR PANEL ASSEMBLY	23
285T0022-3	AUDIO SELECTOR PANEL ASSEMBLY	23
285T0022-3	AUDIO SELECTOR PANEL ASSEMBLY	23
285T0022-3	AUDIO SELECTOR PANEL ASSEMBLY	23
285T0022-4	AUDIO SELECTOR PANEL ASSEMBLY	23
285T0022-4	AUDIO SELECTOR PANEL ASSEMBLY	23
285T0022-4	AUDIO SELECTOR PANEL ASSEMBLY	23
285T0022-4	AUDIO SELECTOR PANEL ASSEMBLY	23
285T0022-4	AUDIO SELECTOR PANEL ASSEMBLY	23
285T0022-4	AUDIO SELECTOR PANEL ASSEMBLY	23
285T0022-4	AUDIO SELECTOR PANEL ASSEMBLY	23
285T0022-4	AUDIO SELECTOR PANEL ASSEMBLY	23
285T0024-2	PILOTS CALL PANEL MODULE ASSEMBLY	31
285T0024-2	PILOTS CALL PANEL MODULE ASSEMBLY	31
285T0024-5	PILOTS CALL PANEL MODULE ASSEMBLY	31
285T0024-5	PILOTS CALL PANEL MODULE ASSEMBLY	31

285T0027-1	ADF CONTROL PANEL ASSEMBLY	34
285T0030-1	WARNING ELECTRONICS UNIT ALTITUDE ALERT PRINTED	34
285T0030-1	WARNING ELECTRONICS UNIT ALTITUDE ALERT PRINTED	34
285T0030-2	WARNING ELECTRONICS UNIT ALTITUDE ALERT PRINTED	34
285T0031-1	PRINTED CIRCUIT ASSEMBLY	32
285T0031-1	PRINTED CIRCUIT ASSEMBLY	32
285T0031-1	PRINTED CIRCUIT ASSEMBLY	31
285T0032-1	MASTER WARNING PC BOARD	31
285T0034-1	PRINTED CIRCUIT ASSEMBLY	
285T0034-1	PRINTED CIRCUIT ASSEMBLY	
285T0034-1	PRINTED CIRCUIT ASSEMBLY	31
285T0034-1	PRINTED CIRCUIT ASSEMBLY	31
285T0034-2	PRINTED CIRCUIT ASSEMBLY	31
285T0034-2	PRINTED CIRCUIT ASSEMBLY	31
285T0034-2	PRINTED CIRCUIT ASSEMBLY	31
285T0034-2	PRINTED CIRCUIT ASSEMBLY	31
285T0034-3	PRINTED CIRCUIT ASSEMBLY	31
285T0034-3	PRINTED CIRCUIT ASSEMBLY	31
285T0034-3	PRINTED CIRCUIT ASSEMBLY	31
285T0035-1	WARNING ELECTRONICS UNIT POWER SUPPLY ASSEMB	31
285T0035-1	WARNING ELECTRONICS UNIT POWER SUPPLY ASSEMB	31
285T0035-2	WARNING ELECTRONICS UNIT POWER SUPPLY ASSEMB	31
285T0035-9	WARNING ELECTRONICS UNIT POWER SUPPLY ASSEMB	31
285T0039-1	ELECTRONIC ENGINE CONTROL MONITOR MODULE ASS	77
285T0039-1	ELECTRONIC ENGINE CONTROL MONITOR MODULE ASS	77
285T0039-2	ELECTRONIC ENGINE CONTROL MONITOR MODULE ASS	77
285T0039-2	ELECTRONIC ENGINE CONTROL MONITOR MODULE ASS	77
285T0049-5	FLAP AND SLAT ELECTRONICS UNIT	27
285T0049-5	FLAP AND SLAT ELECTRONICS UNIT	27
285T0078-1	ECS FAN CONTROL PRINTED CIRCUIT ASSEMBLY	21
285T0078-1	ECS FAN CONTROL PRINTED CIRCUIT ASSEMBLY	21
285T0078-1	ECS FAN CONTROL PRINTED CIRCUIT ASSEMBLY	21

285T0079-1	BLEED AIR CONTROL PRINTED WIRING ASSEMBLY	36
285T0079-1	BLEED AIR CONTROL PRINTED WIRING ASSEMBLY	36
285T0079-7	BLEED AIR CONTROL PRINTED WIRING ASSEMBLY	36
285T0093-1	PACK FLOW CONTROL PRINTED CIRCUIT ASSEMBLY	21
285T0093-8	PACK FLOW CONTROL PRINTED CIRCUIT ASSEMBLY	21
285T0094-3	PACK BACKUP TEMP CONTROL PRINTED WIRING ASSEM	21
285T0094-6	PACK BACKUP TEMP CONTROL PRINTED WIRING ASSEM	21
285T0095-5	EQUIPMENT COOLING INDICATION , PRINTED CIRCUIT AS	21
285T0095-7	EQUIPMENT COOLING INDICATION , PRINTED CIRCUIT AS	21
285T0095-8	EQUIPMENT COOLING INDICATION , PRINTED CIRCUIT AS	21
285T0096-1	EEC DISCRETE PRINTED CIRCUIT	73
285T0096-3	EEC DISCRETE PRINTED CIRCUIT	77
285T0096-5	EEC DISCRETE PRINTED CIRCUIT	77
285T0096-7	EEC DISCRETE PRINTED CIRCUIT	77
285T0097-6	MASTER DIM AND TEST TYPE I DIMMER CONTROL PRINT	33
285T0097-9	MASTER DIM AND TEST TYPE I DIMMER CONTROL PRINT	33
285T0099-1	FLAP/STAB POSITION MODULE ASSEMBLY	27
285T0099-1	FLAP/STAB POSITION MODULE ASSEMBLY	27
285T0099-1	FLAP/STAB POSITION MODULE ASSEMBLY	27
285T0177-3	CURRENT RELAY SENSOR	21
285T0259-1	WARNING ELECTRONICS UNIT TAKEOFF CONFIGURATIO	22
285T0259-1	WARNING ELECTRONICS UNIT TAKEOFF CONFIGURATIO	22
285T0259-1	WARNING ELECTRONICS UNIT TAKEOFF CONFIGURATIO	22
285T0259-1	WARNING ELECTRONICS UNIT TAKEOFF CONFIGURATIO	22
285T0259-1	WARNING ELECTRONICS UNIT TAKEOFF CONFIGURATIO	22
285T0259-1	WARNING ELECTRONICS UNIT TAKEOFF CONFIGURATIO	31
285T0259-1	WARNING ELECTRONICS UNIT TAKEOFF CONFIGURATIO	22
285T0259-2	WARNING ELECTRONICS UNIT TAKEOFF CONFIGURATIO	22
285T0259-2	WARNING ELECTRONICS UNIT TAKEOFF CONFIGURATIO	22
285T0259-7	WARNING ELECTRONICS UNIT TAKEOFF CONFIGURATIO	22
285T0259-9	WARNING ELECTRONICS UNIT TAKEOFF CONFIGURATIO	22
285T0385-5	WARNING ELECTRONIC UNIT BELL-CHIME AURAL WARN	31

285T0385-6	WARNING ELECTRONIC UNIT BELL-CHIME AURAL WARN	31
285T0458-1	N2 ENGINE SPEED DISCRETE CIRCUIT ASSEMBLY	73
285T0458-1	N2 ENGINE SPEED DISCRETE CIRCUIT ASSEMBLY	73
285T0458-1	N2 ENGINE SPEED DISCRETE CIRCUIT ASSEMBLY	73
285T0458-1	N2 ENGINE SPEED DISCRETE CIRCUIT ASSEMBLY	73
285T0458-2	N2 ENGINE SPEED DISCRETE CIRCUIT ASSEMBLY	73
285T0458-2	N2 ENGINE SPEED DISCRETE CIRCUIT ASSEMBLY	73
285T0458-2	N2 ENGINE SPEED DISCRETE CIRCUIT ASSEMBLY	73
285T0458-2	N2 ENGINE SPEED DISCRETE CIRCUIT ASSEMBLY	73
285T0458-3	N2 ENGINE SPEED DISCRETE CIRCUIT ASSEMBLY	73
285T0458-3	N2 ENGINE SPEED DISCRETE CIRCUIT ASSEMBLY	73
285T0464-4	BOARD DIODE CARD PRINTED STATIC SENSITIV	33
285T0496-1	EICAS DISPLAY SWITCHING UNIT PRINTED CIRCUIT ASSY	31
285T0524-6	ILS CONTROL PANEL ASSEMBLY	34
285T0524-7	ILS CONTROL PANEL ASSEMBLY	34
285T0524-8	ILS CONTROL PANEL ASSEMBLY	34
285T0553-1	ILS CONTROL PANEL ASSEMBLY	34
285T0553-2	ILS CONTROL PANEL ASSEMBLY	34
285T0553-3	ILS CONTROL PANEL ASSEMBLY	34
285T0553-4	ILS CONTROL PANEL ASSEMBLY	34
285T0554-3	VOR CONTROL PANEL ASSY	34
285T0554-5	VOR CONTROL PANEL ASSY	34
285T0554-6	VOR CONTROL PANEL ASSY	34
285T0557-2	DUAL ADF CONTROL PANEL ASSEMBLY	34
285T0607-1	PROPULSION INTERFACE AND MONITOR UNIT MODULE	77
285T0607-1	PROPULSION INTERFACE AND MONITOR UNIT MODULE	77
285T0629-1	AFT ATTENDANT'S PANEL ASSEMBLY	25
285T0708-2	THRUST REVERSER RELAY MODULE ASSY	78
285T0708-3	THRUST REVERSER RELAY MODULE ASSY	78
285T0708-4	THRUST REVERSER RELAY MODULE ASSY	78
285T0852-1	FLIGHT DECK ACCESS SYSTEM KEYPAD MODULE ASSY	52
285T1104-1	WEU STALL WARNING WIND SHEAR DETECTION PRINTED	27

285T1104-1	WEU STALL WARNING WIND SHEAR DETECTION PRINTED CIRCUIT BOARD	27
285T1104-1	WEU STALL WARNING WIND SHEAR DETECTION PRINTED CIRCUIT BOARD	27
285T1104-1	WEU STALL WARNING WIND SHEAR DETECTION PRINTED CIRCUIT BOARD	27
285T1104-1	WEU STALL WARNING WIND SHEAR DETECTION PRINTED CIRCUIT BOARD	27
285T1104-2	WEU STALL WARNING WIND SHEAR DETECTION PRINTED CIRCUIT BOARD	27
285T1104-2	WEU STALL WARNING WIND SHEAR DETECTION PRINTED CIRCUIT BOARD	27
285T1104-9	WEU STALL WARNING WIND SHEAR DETECTION PRINTED CIRCUIT BOARD	27
285T1111-1	WARNING ELECTRONICS UNIT BITE DISPLAY PRINTED CIRCUIT BOARD	36
285T1115-1	BLEED AIR CONTROL PRINTED CIRCUIT ASSY	36
285T1115-1	BLEED AIR CONTROL PRINTED CIRCUIT ASSY	36
285T1115-8	BLEED AIR CONTROL PRINTED CIRCUIT ASSY	36
285W0024-	HANDSET, MODULE ASSY - CABIN ATTENDANT/F	23
285W0024-	HANDSET, MODULE ASSY - CABIN ATTENDANT/F	23
285W0024-	HANDSET, MODULE ASSY - CABIN ATTENDANT/F	23
285W0024-	HANDSET, MODULE ASSY - CABIN ATTENDANT/F	23
286A1062-0	WIRING HARNESS	24
286N5300-0	FIRE DETECTOR AND IGNITION HARNESS - PW2000	73
286N5300-0	FIRE DETECTOR AND IGNITION HARNESS - PW2000	71
286N5300-0	FIRE DETECTOR AND IGNITION HARNESS - PW2000	71
286N5300-3	FIRE DETECTOR AND IGNITION HARNESS - PW2000	71
286N5302-0	PW2000 CORE ENGINE WIRE BUNDLE	36
286N5302-0	PW2000 CORE ENGINE WIRE BUNDLE	71
286N5302-0	PW2000 CORE ENGINE WIRE BUNDLE	71
286N5302-0	PW2000 CORE ENGINE WIRE BUNDLE	36
286N5302-3	PW2000 CORE ENGINE WIRE BUNDLE	71
286N5600-0	PW2000 WIRE BUNDLE HARNESS	73
286N5600-0	PW2000 WIRE BUNDLE HARNESS	73
286N5600-3	PW2000 WIRE BUNDLE HARNESS	73
286N5600-7	PW2000 WIRE BUNDLE HARNESS	71
286N5602-0	PW2000 FAN CASE ELECTRICAL HARNESS	71
286N5602-0	PW2000 FAN CASE ELECTRICAL HARNESS	71
286N5602-0	PW2000 FAN CASE ELECTRICAL HARNESS	71

286N5602-3	PW2000 FAN CASE ELECTRICAL HARNESS	71
286N5602-3	PW2000 FAN CASE ELECTRICAL HARNESS	71
286N5604-0	WIRE BUNDLE HARNESS	73
286N5604-0	WIRE BUNDLE HARNESS	71
286N5604-0	WIRE BUNDLE HARNESS	71
286N5604-3	WIRE BUNDLE HARNESS	71
286N5608-0	IDG CONTROL HARNESS	71
286N5608-0	IDG CONTROL HARNESS	71
286N5608-0	IDG CONTROL HARNESS	71
286N5608-0	IDG CONTROL HARNESS	71
286N5608-3	IDG CONTROL HARNESS	71
286N5608-3	IDG CONTROL HARNESS	71
286N5614-0	ENGINE FAN CASE WIRE BUNDLE	71
286N5614-0	ENGINE FAN CASE WIRE BUNDLE	71
286N5614-0	ENGINE FAN CASE WIRE BUNDLE	71
286N5614-3	ENGINE FAN CASE WIRE BUNDLE	71
286N5614-7	ENGINE FAN CASE WIRE BUNDLE	71
286N5616-0	FAN CASE WIRE BUNDLE	71
286N5616-0	FAN CASE WIRE BUNDLE	71
286N5616-0	FAN CASE WIRE BUNDLE	71
286N5616-3	FAN CASE WIRE BUNDLE	71
286N5616-6	FAN CASE WIRE BUNDLE	71
286N5616-7	FAN CASE WIRE BUNDLE	71
286N5616-7	FAN CASE WIRE BUNDLE	71
286T0314	HARNESS, FAN CASE,..	71
286T0320-0	HARNESS, FAN CASE,..	71
286T0354	HARNESS, FAN CASE,..	71
286T0358	HARNESS, FAN CASE,..	71
286T0368	HARNESS, FAN CASE,..	71
286T0370	HARNESS, FAN CASE,..	71
286T3502-0	HARNESS, HARNESS	77
286T3502-0	PW4060 ENGINE WIRE HARNESS	73

286T3504-0	HARNESS, HARNESS	77
286T3504-0	PW4060 ENGINE WIRE HARNESS	77
286T3504-0	HARNESS, HARNESS	71
286T3506-0	PW4060 ENGINE WIRE HARNESS	77
286T3508-0	PW4060 ENGINE WIRE HARNESS	77
286T3510-0	ENGINE HARNESS CJ9, CJ10	77
286T3512-0	HARNESS, HARNESS	36
286T3514-0	HARNESS, HARNESS	71
286T3516-0	HARNESS, HARNESS	71
286T3520-0	HARNESS, HARNESS	77
286T3522-0	HARNESS, HARNESS	71
286T3538-0	PW4060 ENGINE WIRE HARNESS	77
286T5320	HARNESS, BUNDLE ASSY., W5320:	71
28823-1	POTABLE WATER SYSTEM COMPRESSOR ASSEMBLY	38
28823-10	POTABLE WATER SYSTEM COMPRESSOR ASSEMBLY	38
28823-17	POTABLE WATER SYSTEM COMPRESSOR ASSEMBLY	38
28823-2	POTABLE WATER SYSTEM COMPRESSOR ASSEMBLY	38
28823-5	POTABLE WATER SYSTEM COMPRESSOR ASSEMBLY	38
28823-7	POTABLE WATER SYSTEM COMPRESSOR ASSEMBLY	38
28823-9	POTABLE WATER SYSTEM COMPRESSOR ASSEMBLY	38
290-0069-5	STRUT COMPRESSION, L/H AND R/H T/R	78
290-0069-5	STRUT COMPRESSION, L/H AND R/H T/R	78
290-0069-5	STRUT COMPRESSION, L/H AND R/H T/R	78
290-0069-5	STRUT COMPRESSION, L/H AND R/H T/R	78
290-0401-5	SUPPORT UPPER RH THRUST REVERSER MANUAL	71
290-0402-5	SUPPORT UPPER RH THRUST REVERSER MANUAL	71
290-0402-5	SUPPORT UPPER RH THRUST REVERSER MANUAL	71
290-1004-5	SUPPORT UPPER RH THRUST REVERSER MANUAL	71
290-3000-5	FITTING, THERMAL ANTI ICE DUCT	71
290-3000-5	COWL NOSE, NBR 1 and NBR 2 ENGINES	71
290-3000-5	COWL NOSE, NBR 1 and NBR 2 ENGINES	71
290-3395-5	FITTING, THERMAL ANTI ICE DUCT	30

290-3395-5	FITTING, THERMAL ANTI ICE DUCT	30
290-3395-5	FITTING, THERMAL ANTI ICE DUCT	30
290-3416-5	FITTING, THERMAL ANTI ICE DUCT	71
290-4001-5	COWL LOWER FAN DOOR NBR 2 ENGINE POST SE	71
290-4003-5	COWL LOWER FAN DOOR NBR 2 ENGINE POST SE	71
290-4004-5	COWL LOWER FAN DOOR NBR 2 ENGINE POST SE	71
290-5036-5	HARNESS, FAN CASE,..	36
290-5131-5	HARNESS, FAN CASE,..	26
290-5132-5	HARNESS, FAN CASE,..	26
290-5132-5	HARNESS, FAN CASE,..	26
290W5211-4	HARNESS VAR SPEED CONSTANT FREQ CONTROL	24
290W5211-4	HARNESS VAR SPEED CONSTANT FREQ CONTROL	24
2955810-3	ROLLER, ASSY; SINGLE ROLLER PDU;	25
2987T100-1	LATCH,DOUBLE;XZ	25
2A122-0089	PANEL, UTILITY LAV M	33
2A122-0089	PANEL, UTILITY LAV M	33
2CM9ABH7	GENERATR TACH, N1 AND N2	77
2CM9ABY7	GENERATR TACH, N1 AND N2	77
2LA003968	LOWER FUSELAGE ANTI-COLLISION LIGHT	33
2LA005127	LIGHT, EMREGENCY; OVERWING; A320	33
2LA005127	LIGHT, EMREGENCY; OVERWING; A320	33
2LA005308	LIGHT, ANTI COLLISION, STROBE,...	33
2LA005308	LIGHT, ANTI COLLISION, STROBE,...	33
2LA005469	PANEL, WARNING LIGHT; A319/320	52
2LA005542	LIGHT, WORK, F/O TRAY TABLE 32	33
2LA005542	LIGHT, WORK, F/O TRAY TABLE 32	33
2LA005543	LIGHT, WORK, F/O TRAY TABLE 32	33
2LA402515	LOWER FUSELAGE ANTI-COLLISION LIGHT	33
2LA410330	LIGHT, ASSY, 2LA455010-00	33
2LA455010	LIGHT, ASSY, 2LA455010-00	33
2R6211A	ACTUATOR, APU INLET DOOR.....	52
3001-01-11	ACCLRMTR TRIAXIAL FLIGHT RECORDER.	34

30030-000	THERMCPL OPTION, EGT IMMERSION MUST BE U	77
30071-0202	PROCESSOR	28
30071-0404	PROCESSOR	28
30071-0505	PROCESSOR	28
30071-0606	PROCESSOR	28
30071-0607	PROCESSOR	28
30-0909-10	AIRCRAFT TAIL POSITION FLASHTUBE LIGHT	33
30-0909-20	AIRCRAFT TAIL POSITION FLASHTUBE LIGHT	33
30100022-1	BOTTLE LAV AUTOMATIC EXTINGUISHER 1LB	26
30100022-1	BOTTLE LAV AUTOMATIC EXTINGUISHER 1LB	26
30100022-3	DETECTOR ENGINE, RIGHT HAND	26
30100022-3	BOTTLE LAV AUTOMATIC EXTINGUISHER 1LB	26
30-1133-1	LIGHT, WING TIP, RH;	33
30-1133-2	LIGHT, WING TIP, RH;	33
30-1133-2M	LIGHT, WING TIP, RH;	33
30-1133-3	LIGHT, WING TIP, RH;	33
30-1133-4	LIGHT, WING TIP, RH;	33
30-1133-5	LIGHT, WING TIP, RH;	33
301-324-50	SHIELD LPT STTR SHRD STG 4	72
30136-0102	WATER QUANTITY TRANSMITTER	38
30136-0105	WATER QUANTITY TRANSMITTER	38
30136-0106	WATER QUANTITY TRANSMITTER	38
30-1404-1	LIGHT EXTERIOR EMERGENCY EXIT	33
30-1521-3	REAR POSITION NAVIGATIONAL LIGHT ASSEMBLY	33
30-1521-4	REAR POSITION NAVIGATIONAL LIGHT ASSEMBLY	33
30-1521-5	REAR POSITION NAVIGATIONAL LIGHT ASSEMBLY	33
30-1521-6	REAR POSITION NAVIGATIONAL LIGHT ASSEMBLY	33
30-1526-3	AIRCRAFT ANTI-COLLISION LIGHT UPPER AND LOWER F	33
30-1526-5	AIRCRAFT ANTI-COLLISION LIGHT UPPER AND LOWER F	33
30-1526-7	AIRCRAFT ANTI-COLLISION LIGHT UPPER AND LOWER F	33
30-1526-9	AIRCRAFT ANTI-COLLISION LIGHT UPPER AND LOWER F	33
30-1543-1	WING SCANNING LIGHT	33

30-1543-2	WING SCANNING LIGHT	33
30-1554-1	OVERWING EMERGENCY LIGHT	33
30-1554-3	OVERWING EMERGENCY LIGHT	33
30-1554-5	OVERWING EMERGENCY LIGHT	33
30-1554-7	OVERWING EMERGENCY LIGHT	33
30-1564-3	WING SLIDE FLOODLIGHT	33
30-1564-4	WING SLIDE FLOODLIGHT	33
30-1564-5	WING SLIDE FLOODLIGHT	33
30-1564-6	WING SLIDE FLOODLIGHT	33
30-1588-5	AIRCRAFT NAVIGATION LIGHT - FORWARD WING POSITIC	33
30-1588-6	AIRCRAFT NAVIGATION LIGHT - FORWARD WING POSITIC	33
30-1627-1	LIGHT BULK CARGO DOOR GND ILLUMINATION,	33
30-1637-6	LIGHT, WING ILLUMINATION; (RH)	33
30-1637-8	LIGHT, WING ILLUMINATION; (RH)	33
30-1660-5	REAR POSITION NAVIGATIONAL LIGHT ASSEMBLY	33
30-1667-1	AIRCRAFT NAVIGATION LIGHT - FORWARD WING POSITIC	33
30-1667-2	AIRCRAFT NAVIGATION LIGHT - FORWARD WING POSITIC	33
30-1670-1	LIGHT SLIDE ILLUMINATION CTR DOOR ALT S2	33
30-1670-2	LIGHT SLIDE ILLUMINATION CTR DOOR ALT S2	33
30-1672-2	LIGHT,SLIDE ILLUM, AFT RH DOOR ALT S283T	33
30-1685-1	STROBE POWER SUPPLY	33
30-1685-2	STROBE POWER SUPPLY	33
30-1691-1	LIGHT ANTI-COLLISION, WHITE, RH	33
30-1691-2	LIGHT ANTI-COLLISION, WHITE, RH	33
30-1691-3	LIGHT ANTI-COLLISION, WHITE, RH	33
30-1691-4	LIGHT ANTI-COLLISION, WHITE, RH	33
30-1768-3	AFT GROUND ILLUMINATION SLIDE LIGHT	33
30-1770-1	FORWARD GROUND ILLUMINATION SLIDE LIGHT	33
30-1770-3	FORWARD GROUND ILLUMINATION SLIDE LIGHT	33
301-785-50	MAIN FUEL PUMP (POST-SB 73-A0062)	73
301-785-50	MAIN FUEL PUMP (POST-SB 73-A0062)	73
301-795-90	EGT WIRING HARNESS	77

301-796-00	THERMOCOUPLE CABLES AND JUNCTION BOXES	77
301-800-10	EGT WIRING HARNESS	77
30-1867-6	WING SCANNING FLOODLIGHT	33
30-1883-3	LIGHT, FLOOD, (LH); WING AND NAC	33
30-1883-5	LIGHT, FLOOD, (LH); WING AND NAC	33
301EDP1-1	PANEL ENGINE DISPLAY STATIC SENSITIVE	77
301EDP1-3	PANEL ENGINE DISPLAY STATIC SENSITIVE	77
301EDP1-4	PANEL ENGINE DISPLAY STATIC SENSITIVE	77
301EDP1-5	PANEL ENGINE DISPLAY STATIC SENSITIVE	77
301EDP2-2	PANEL ENGINE DISPLAY STATIC SENSITIVE	77
30-2041-1	LIGHT,SLIDE ILLUMINATION FWD DOOR	33
30-2042-1	LIGHT, EVACUATION SLIDES LEFT SIDE	33
30-2042-4	LIGHT, EVACUATION SLIDES LEFT SIDE	33
30-2044-1	LIGHT,SLIDE ILLUM, AFT RH DOOR ALT S283T	33
30-2044-2	LIGHT,SLIDE ILLUM, AFT RH DOOR ALT S283T	33
30-2044-3	LIGHT,SLIDE ILLUM, AFT RH DOOR ALT S283T	33
30-2044-4	LIGHT,SLIDE ILLUM, AFT RH DOOR ALT S283T	33
30-2044-5	LIGHT,SLIDE ILLUM, AFT RH DOOR ALT S283T	33
30-2044-6	LIGHT,SLIDE ILLUM, AFT RH DOOR ALT S283T	33
3022053-00	PUMP, HYDRAULIC; A330	29
30-2335-3	STROBE POWER SUPPLY	33
30-2392-3	POWER SUPPLY, A319/A320, A/C 3251-3270;A	33
30-2392-4	POWER SUPPLY, A319/A320, A/C 3251-3270;A	33
30-2407-1	LIGHT, WING TIP, RH;	33
30-2414-3	LIGHT AFT WING TIP POSITION	33
30-2481-3	REAR POSITION NAVIGATIONAL LIGHT	33
30-2481-5	REAR POSITION NAVIGATIONAL LIGHT	33
30-2505-3	UPPER FUSELAGE ANTI-COLLISON LIGHT	33
30-2506-3	LOWER FUSELAGE ANTI-COLLISION LIGHT	33
30-2672-2	LIGHT,	33
30-2672-4	LIGHT,	33
30-3086-1	LIGHT, WINGLET WINGTIP NAV LIGHT	33

3031863-00	VARIABLE DISPLACEMENT HYDRAULIC PUMP	29
3033096-10	PUMP - AC ELECTRIC ASSEMBLY	29
304300-2	FILTER SWITCH	49
304640-5	BOX, APU ELECT CONTROL, ECB; A320; CURE	49
30475-002	BATTERY MAIN DC POWER SHELF LIFE 3 MONTH	24
304817-3	BOX, APU ELECT CONTROL, ECB; A320; CURE	49
3054272-2	SHELL, ACCUMULATOR	27
3059103-1	VALVE HYD PUMP PRESSURE RELIEF	29
3059103-8	VALVE HYD PUMP PRESSURE RELIEF	32
307-0104-0	VALVE ASSY., SHUTOFF; LAV. RINSE FILL	38
307-0127-0	VALVE SHUT OFF, LAV. RINSE/FILL	38
3100080-00	CABLE DRAIN, REMOTE CONTROL VALVE ACTUAT	38
31-0134-50	ENGINE START/RAT PANEL ASSEMBLY, M10468	31
31-0242-50	ENGINE START/RAT PANEL ASSEMBLY, M10468	31
31073-060	AILERON SERVOCONTROL	27
31073-060A	AILERON SERVOCONTROL	27
31073-064	AILERON SERVOCONTROL	27
31073-065	AILERON SERVOCONTROL	27
31073-068	AILERON SERVOCONTROL	27
31073-080	AILERON SERVOCONTROL	27
31073-090	AILERON SERVOCONTROL	27
31073-110	AILERON SERVOCONTROL	27
31075-207	ELEVATOR SERVOCONTROL	27
31075-210	ELEVATOR SERVOCONTROL	27
31075-217	ELEVATOR SERVOCONTROL	27
31075-218	ELEVATOR SERVOCONTROL	27
31075-220	ELEVATOR SERVOCONTROL	27
31075-230	ELEVATOR SERVOCONTROL	27
31075-250	ELEVATOR SERVOCONTROL	27
31075-260	ELEVATOR SERVOCONTROL	27
31075-270	ELEVATOR SERVOCONTROL	27
31075-430	ELEVATOR SERVOCONTROL	27

31075-440	ELEVATOR SERVOCONTROL	27
31075-620	ELEVATOR SERVOCONTROL	27
31075-630	ELEVATOR SERVOCONTROL	27
31075-660	ELEVATOR SERVOCONTROL	27
31075-670	ELEVATOR SERVOCONTROL	27
31075-830	ELEVATOR SERVOCONTROL	27
31075-840	ELEVATOR SERVOCONTROL	27
31076-080	SERVO, SPOILER, OUTBD;A320	27
31076-110	SERVO, SPOILER, OUTBD;A320	27
31077-100	SERVO, SPOILER, INBD; HA	27
31077-111	SERVO, SPOILER, INBD; HA	27
310A1020-2	AFT ENGINE MOUNT ASSEMBLY - CF6-80A	71
310N3020-1	AFT ENGINE MOUNT - PW2000	71
310N3020-1	AFT ENGINE MOUNT - PW2000	71
310N3020-1	AFT ENGINE MOUNT - PW2000	71
310N3020-1	AFT ENGINE MOUNT - PW2000	72
310N3020-1	FRONT ENGINE MOUNT - PW2000	71
310N3020-1	FRONT ENGINE MOUNT - PW2000	71
310N3020-1	FRONT ENGINE MOUNT - PW2000	71
310N3020-1	FRONT ENGINE MOUNT - PW2000	71
310N3020-1	AFT ENGINE MOUNT - PW2000	71
310N3020-1	AFT ENGINE MOUNT - PW2000	71
310N3020-1	FRONT ENGINE MOUNT - PW2000	71
310N3020-1	AFT ENGINE MOUNT - PW2000	71
310N3020-2	FRONT ENGINE MOUNT - PW2000	71
310N3020-2	AFT ENGINE MOUNT - PW2000	71
310N3020-3	AFT ENGINE MOUNT - PW2000	71
310N3020-6	FRONT ENGINE MOUNT - PW2000	71
310N3020-7	AFT ENGINE MOUNT - PW2000	71
310N3022-1	AFT ENGINE MOUNT - PW2000	71
310N3032-1	AFT ENGINE MOUNT - PW2000	71
310N3037-1	AFT ENGINE MOUNT - PW2000	71

310N3037-3	AFT ENGINE MOUNT - PW2000	71
310T1020-3	AFT ENGINE MOUNT ASSEMBLY - CF6-80A	71
310T3033-1	AFT MOUNT ASSEMBLY - PW4000	71
310T3152-1	AFT ENGINE MOUNT - PW2000	71
310T3152-3	AFT ENGINE MOUNT - PW2000	71
310T4020-1	AFT MOUNT ASSEMBLY - PW4000	71
310T4020-1	AFT MOUNT ASSEMBLY - PW4000	71
310T4020-1	AFT MOUNT ASSEMBLY - PW4000	71
310T4020-1	AFT MOUNT ASSEMBLY - PW4000	71
310T4020-2	AFT MOUNT ASSEMBLY - PW4000	71
310T4020-2	AFT MOUNT ASSEMBLY - PW4000	71
310T4020-3	AFT MOUNT ASSEMBLY - PW4000	71
310T4020-5	AFT MOUNT ASSEMBLY - PW4000	71
310T4020-5	AFT MOUNT ASSEMBLY - PW4000	71
310T4020-8	AFT MOUNT ASSEMBLY - PW4000	71
310T4020-8	AFT MOUNT ASSEMBLY - PW4000	71
310T4020-9	AFT MOUNT ASSEMBLY - PW4000	71
310T4021-1	AFT MOUNT ASSEMBLY - PW4000	71
310T4022-1	AFT MOUNT ASSEMBLY - PW4000	71
310U4020-2	AFT MOUNT ASSEMBLY - PW4000	71
310U4020-3	AFT MOUNT ASSEMBLY - PW4000	71
310U4020-5	AFT MOUNT ASSEMBLY - PW4000	71
310U4020-6	AFT MOUNT ASSEMBLY - PW4000	71
3-111794	RESERVOIR DRAIN VALVE	29
3-118605	RESERVOIR DRAIN VALVE	38
312BS101-1	CHARGER, ISFD DEDICATED BATTERY	34
312N3101-4	THRUST REVERSER INTERLOCK ACTUATOR	78
312N3101-5	THRUST REVERSER INTERLOCK ACTUATOR	78
312N3341-1	AIR BLEED DUCTS	80
312T1241-1	DUCT PWA4060 QEC-START SYSTEM IN STL	30
312T3216-2	LINK PRECOOLER SUPPORT MUST BE USABLE ON	36
312T3216-3	LINK PRECOOLER SUPPORT MUST BE USABLE ON	36

312T3216-3	LINK PRECOOLER SUPPORT MUST BE USABLE ON	36
312T3216-3	LINK PRECOOLER SUPPORT MUST BE USABLE ON	36
312T4311-1	DUCT PWA4060 QEC-START SYSTEM IN STL	36
31330-1	FAN, COOLING, HEAT EXCHANGER; DC9.	21
31330-2	FAN, COOLING, HEAT EXCHANGER; DC9.	21
31330-3	FAN, COOLING, HEAT EXCHANGER; DC9.	21
31330-3G	FAN, COOLING, HEAT EXCHANGER; DC9.	21
313T1100-1	FAIRING FWD PYLON SHIP IN ATA SPEC 300	54
313T1100-7	FAIRING FWD PYLON SHIP IN ATA SPEC 300	54
313T1100-9	FAIRING FWD PYLON SHIP IN ATA SPEC 300	54
313T3350-1	ROD HOLD OPEN, AFT FAIRING STRUT O/B AND	54
313T3350-1	ROD HOLD OPEN, AFT FAIRING STRUT O/B AND	54
313T3350-1	ROD HOLD OPEN, AFT FAIRING STRUT O/B AND	54
313T3350-1	ROD HOLD OPEN, AFT FAIRING STRUT O/B AND	54
313T3350-1	ROD HOLD OPEN, AFT FAIRING STRUT O/B AND	54
313T3350-2	ROD HOLD OPEN, AFT FAIRING STRUT O/B AND	54
313T3350-2	ROD HOLD OPEN, AFT FAIRING STRUT O/B AND	54
313T3350-2	ROD HOLD OPEN, AFT FAIRING STRUT O/B AND	54
313T3350-5	ROD HOLD OPEN, AFT FAIRING STRUT O/B AND	54
313T3350-7	ROD HOLD OPEN, AFT FAIRING STRUT O/B AND	54
313T3350-9	ROD HOLD OPEN, AFT FAIRING STRUT O/B AND	54
313T3381-2	PANEL, PYLON, I/B STRUT FAIRING AFT ...	54
314-2100-2	INLET COWL ASSEMBLY	71
314-2100-3	INLET COWL ASSEMBLY	71
314-2120-1	INLET COWL ASSEMBLY	71
314-2200-1	FAN COWL	71
314-2200-1	FAN COWL	71
314-2200-1	FAN COWL	71
314-2200-3	FAN COWL	71
314-2200-5	FAN COWL	71
314A1010-1	LEFT HAND FAN COWL - CF6-80C2	71
314A1010-2	LEFT HAND FAN COWL - CF6-80C2	71

314N3011-6	PW2000 ENGINE INLET ASSEMBLY	71
314N3012-1	PW2000 ENGINE INLET ASSEMBLY	71
314N3012-1	PW2000 ENGINE INLET ASSEMBLY	71
314N3012-1	PW2000 ENGINE INLET ASSEMBLY	71
314N3012-1	PW2000 ENGINE INLET ASSEMBLY	71
314N3012-1	PW2000 ENGINE INLET ASSEMBLY	71
314N3012-7	PW2000 ENGINE INLET ASSEMBLY	71
314N3080-1	PW2000 ENGINE INLET ASSEMBLY	71
314N3080-1	PW2000 ENGINE INLET ASSEMBLY	71
314N3080-2	PW2000 ENGINE INLET ASSEMBLY	71
314N3080-5	PW2000 ENGINE INLET ASSEMBLY	71
314N3080-6	PW2000 ENGINE INLET ASSEMBLY	71
314N3080-9	PW2000 ENGINE INLET ASSEMBLY	71
314N3085-1	COWLING FAN, ENGINE, LH EQUIV 314N3110-5	71
314N3090-1	PW2000 ENGINE CORE COWL ASSEMBLY	71
314N3090-1	PW2000 ENGINE CORE COWL ASSEMBLY	71
314N3090-1	PW2000 ENGINE CORE COWL ASSEMBLY	71
314N3090-1	PW2000 ENGINE CORE COWL ASSEMBLY	71
314N3090-1	PW2000 ENGINE CORE COWL ASSEMBLY	71
314N3090-2	PW2000 ENGINE CORE COWL ASSEMBLY	71
314N3090-2	PW2000 ENGINE CORE COWL ASSEMBLY	71
314N3090-2	PW2000 ENGINE CORE COWL ASSEMBLY	71
314N3090-3	PW2000 ENGINE CORE COWL ASSEMBLY	71
314N3090-4	PW2000 ENGINE CORE COWL ASSEMBLY	71
314N3110-5	FAN COWL ASSEMBLY	71
314N3110-5	FAN COWL ASSEMBLY	71
314N3110-5	FAN COWL ASSEMBLY	71
314N3110-5	FAN COWL ASSEMBLY	71
314N3110-5	FAN COWL ASSEMBLY	71
314N3110-5	FAN COWL ASSEMBLY	71
314N3110-5	FAN COWL ASSEMBLY	71
314N3110-5	FAN COWL ASSEMBLY	71

314N3110-5	FAN COWL ASSEMBLY	71
314N3110-7	FAN COWL ASSEMBLY	71
314N3110-7	FAN COWL ASSEMBLY	71
314N3110-7	FAN COWL ASSEMBLY	71
314N3113-2	FAN COWL ASSEMBLY	71
314N3113-2	FAN COWL ASSEMBLY	71
314N3200-1	PLUG EXHAUST INSTL SHIP IN ATA SPEC 300	78
314N3200-7	PLUG EXHAUST INSTL SHIP IN ATA SPEC 300	78
314N3200-9	PLUG EXHAUST INSTL SHIP IN ATA SPEC 300	78
314N3210-1	PW2000 ENGINE CORE COWL ASSEMBLY	71
314N3210-1	PW2000 ENGINE CORE COWL ASSEMBLY	71
314N3210-1	PW2000 ENGINE CORE COWL ASSEMBLY	71
314N3210-1	PW2000 ENGINE CORE COWL ASSEMBLY	71
314N3210-1	PW2000 ENGINE CORE COWL ASSEMBLY	71
314N3210-1	PW2000 ENGINE CORE COWL ASSEMBLY	71
314N3210-1	PW2000 ENGINE CORE COWL ASSEMBLY	71
314N3210-1	PW2000 ENGINE CORE COWL ASSEMBLY	71
314N3210-2	PW2000 ENGINE CORE COWL ASSEMBLY	71
314N3210-7	PW2000 ENGINE CORE COWL ASSEMBLY	71
314N3210-8	PW2000 ENGINE CORE COWL ASSEMBLY	71
314N3210-9	PW2000 ENGINE CORE COWL ASSEMBLY	71
314N3210-9	PW2000 ENGINE CORE COWL ASSEMBLY	71
314N3210-9	PW2000 ENGINE CORE COWL ASSEMBLY	71
314N3310-1	EXHAUST NOZZLE	78
314N3310-2	EXHAUST NOZZLE	78
314N3310-2	EXHAUST NOZZLE	78
314N3310-3	EXHAUST NOZZLE	78
314N3310-3	EXHAUST NOZZLE	78
314N3310-3	EXHAUST NOZZLE	78
314N3320-1	PLUG EXHAUST INSTL SHIP IN ATA SPEC 300	78
314N3320-7	PLUG EXHAUST INSTL SHIP IN ATA SPEC 300	78
314T1010-1	INLET COWL ASSEMBLY	71
314T1010-1	INLET COWL ASSEMBLY	71

314T1010-1	INLET COWL ASSEMBLY	71
314T1010-1	INLET COWL ASSEMBLY	71
314T1010-1	INLET COWL ASSEMBLY	71
314T1010-1	INLET COWL ASSEMBLY	71
314T1010-1	INLET COWL ASSEMBLY	71
314T1010-8	INLET COWL ASSEMBLY	71
314T1010-8	INLET COWL ASSEMBLY	71
314T1010-8	INLET COWL ASSEMBLY	71
314T1010-9	INLET COWL ASSEMBLY	71
314T1010-9	INLET COWL ASSEMBLY	71
314T1010-9	INLET COWL ASSEMBLY	71
314T1012-1	INLET COWL ASSEMBLY	71
314T1110-4	FAN COWL ASSEMBLY	71
314T1110-4	FAN COWL ASSEMBLY	71
314T1110-4	FAN COWL ASSEMBLY	71
314T1110-4	FAN COWL ASSEMBLY	71
314T1110-4	FAN COWL ASSEMBLY	71
314T1110-4	FAN COWL ASSEMBLY	71
314T1110-5	FAN COWL ASSEMBLY	71
314T1110-5	FAN COWL ASSEMBLY	71
314T1110-5	FAN COWL ASSEMBLY	71
314T1110-5	FAN COWL ASSEMBLY	71
314T1110-6	FAN COWL ASSEMBLY	71
314T1110-7	FAN COWL ASSEMBLY	71
314T1210-1	CORE COWL ASSEMBLY, LH OR RH, CF6-80A	71
314T1210-2	CORE COWL ASSEMBLY, LH OR RH, CF6-80A	71
314T1210-3	CORE COWL ASSEMBLY, LH OR RH, CF6-80A	71
314T1210-4	CORE COWL ASSEMBLY, LH OR RH, CF6-80A	71
314T1210-4	CORE COWL ASSEMBLY, LH OR RH, CF6-80A	71
314T1210-4	CORE COWL ASSEMBLY, LH OR RH, CF6-80A	71
314T1210-4	CORE COWL ASSEMBLY, LH OR RH, CF6-80A	71
314T1310-1	SLEEVE, ENGINE EXHAUST,	78
314T1320-1	PLUG TURBINE EXHUAST SHIP IN ATA SPEC 30	78

314T1325-5	INLET COWL ASSEMBLY	71
314T3310-1	SLEEVE, ENGINE EXHAUST,	78
314T3310-1	SLEEVE, ENGINE EXHAUST,	78
314T3310-3	SLEEVE, ENGINE EXHAUST,	78
314T3310-5	SLEEVE, ENGINE EXHAUST,	78
314T3310-7	SLEEVE, ENGINE EXHAUST,	78
314T3310-9	SLEEVE, ENGINE EXHAUST,	78
314T4010-1	INLET ASSEMBLY	71
314T4010-1	INLET ASSEMBLY	71
314T4010-1	INLET ASSEMBLY	71
314T4010-1	INLET ASSEMBLY	71
314T4010-1	INLET ASSEMBLY	71
314T4010-1	INLET ASSEMBLY	71
314T4010-1	INLET ASSEMBLY	71
314T4010-1	INLET ASSEMBLY	71
314T4010-6	INLET ASSEMBLY	71
314T4010-6	INLET ASSEMBLY	71
314T4080-1	COWL,NOSE,PW4000;1ST GENERATION	71
314T4080-1	COWL,NOSE,PW4000;1ST GENERATION	71
314T4080-1	COWL,NOSE,PW4000;1ST GENERATION	71
314T4080-1	COWL,NOSE,PW4000;1ST GENERATION	71
314T4080-1	COWL,NOSE,PW4000;1ST GENERATION	71
314T4080-9	COWL,NOSE,PW4000;1ST GENERATION	71
314T4090-1	COWLING CORE ENG R/H USED ON B767 A/C 17	71
314T4090-2	COWLING CORE ENG R/H USED ON B767 A/C 17	71
314T4090-4	COWLING CORE ENG R/H USED ON B767 A/C 17	71
314T4110-1	COWLING FAN, ENGINE, RH MUST BE USABLE O	71
314T4110-1	COWLING FAN, ENGINE, RH MUST BE USABLE O	71
314T4110-1	COWLING FAN, ENGINE, RH MUST BE USABLE O	71
314T4110-1	COWLING FAN, ENGINE, RH MUST BE USABLE O	71
314T4110-1	COWLING FAN, ENGINE, RH MUST BE USABLE O	71
314T4110-1	COWLING FAN, ENGINE, RH MUST BE USABLE O	71
314T4110-1	COWLING FAN, ENGINE, RH MUST BE USABLE O	71

314T4110-1	COWLING FAN, ENGINE, RH MUST BE USABLE O	71
314T4110-5	COWLING FAN, ENGINE, RH MUST BE USABLE O	71
314T4110-5	COWLING FAN, ENGINE, RH MUST BE USABLE O	71
314T4110-6	COWLING FAN, ENGINE, RH MUST BE USABLE O	
314T4210-3	CORE COWL ASSEMBLY, LH OR RH - PW4000	71
314T4210-5	CORE COWL ASSEMBLY, LH OR RH - PW4000	71
314T4210-6	CORE COWL ASSEMBLY, LH OR RH - PW4000	71
314T4210-6	CORE COWL ASSEMBLY, LH OR RH - PW4000	71
314T4210-6	CORE COWL ASSEMBLY, LH OR RH - PW4000	71
314T4210-7	CORE COWL ASSEMBLY, LH OR RH - PW4000	71
314T4210-7	CORE COWL ASSEMBLY, LH OR RH - PW4000	71
314T4320-1	PLUG, PWA4060 QEC-EXHAUST	78
314T4320-1	PLUG, PWA4060 QEC-EXHAUST	78
314U2200-2	PLUG TURBINE EXHAUST USED ON CF6-80C2B6	78
314U4012-1	INLET ASSEMBLY	71
314U4012-1	INLET ASSEMBLY	71
314U4012-1	INLET ASSEMBLY	71
314U4012-1	INLET ASSEMBLY	71
31-5268-1	AIRCRAFT NAVIGATION LIGHT - FORWARD WING POSITIC	33
31-5268-2	AIRCRAFT NAVIGATION LIGHT - FORWARD WING POSITIC	33
31-5268-3	AIRCRAFT NAVIGATION LIGHT - FORWARD WING POSITIC	33
31-5268-4	AIRCRAFT NAVIGATION LIGHT - FORWARD WING POSITIC	33
31-5270-3	AIRCRAFT ANTI-COLLISION LIGHT UPPER AND LOWER F	33
31-5270-7	AIRCRAFT ANTI-COLLISION LIGHT UPPER AND LOWER F	33
31-5451-1	AIRCRAFT NAVIGATION LIGHT - FORWARD WING POSITIC	33
31-5473-1	AIRCRAFT NAVIGATION LIGHT - FORWARD WING POSITIC	33
31-5473-2	AIRCRAFT NAVIGATION LIGHT - FORWARD WING POSITIC	33
315A1800-3	THRUST REVERSER NON-LOCKING ACTUATOR ASSEMBL	78
315A1800-4	THRUST REVERSER NON-LOCKING ACTUATOR ASSEMBL	78
315A1800-5	THRUST REVERSER NON-LOCKING ACTUATOR ASSEMBL	78
315A1800-6	THRUST REVERSER NON-LOCKING ACTUATOR ASSEMBL	78
315A1800-7	THRUST REVERSER NON-LOCKING ACTUATOR ASSEMBL	78

315A1801-1	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	
315A1801-1	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	78
315A1801-1	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	78
315A1801-1	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	78
315A1801-2	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	78
315A1801-2	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	78
315A1801-2	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	
315A1801-2	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	78
315A1819-4	THRUST REVERSER NON-LOCKING ACTUATOR ASSEMBLY	78
315A2800-1	THRUST REVERSER NON-LOCKING ACTUATOR ASSEMBLY	78
315A2800-2	THRUST REVERSER NON-LOCKING ACTUATOR ASSEMBLY	78
315A2801-1	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	78
315A2801-4	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	78
315A2801-5	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	78
315N3301-1	PANEL, BIFURCATION, R/H LOWER	78
315N3401-8	PANEL, BIFURCATION, R/H LOWER	78
315N3416-4	PANEL, BIFURCATION, R/H LOWER	78
315N3800-1	THRUST REVERSER NON-LOCKING ACTUATOR ASSEMBLY	78
315N3801-1	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	78
315T1040-1	ENGINE THROTTLE CONTROL BOX - CF6-80A, CF6-80C2	76
315T1040-1	ENGINE THROTTLE CONTROL BOX - CF6-80A, CF6-80C2	76
315T1040-1	ENGINE THROTTLE CONTROL BOX - CF6-80A, CF6-80C2	76
315T3056-2	VALVE FLOW CONTROL, T/R ACTUATION SYSTEM	78
317100-100	PRESSURE DIFFERENTIAL SENSOR ASSEMBLY	27
317100-100	PRESSURE DIFFERENTIAL SENSOR ASSEMBLY	27
317100-100	PRESSURE DIFFERENTIAL SENSOR ASSEMBLY	27
317100-100	PRESSURE DIFFERENTIAL SENSOR ASSEMBLY	27
3171144-7	IN-LINE POPPET VALVE	36
31-7760-3	LIGHT, WING TIP, RH;	33
3180131-1	SWITCH, HYD. PRESS. (INSOURCE MATERIAL)	29
3180131-2	SWITCH, HYD. PRESS. (INSOURCE MATERIAL)	29
3180131-3	SWITCH, HYD. PRESS. (INSOURCE MATERIAL)	29

31-8137-1	POWER SUPPLY, A319/A320, A/C 3251-3270;A	33
31-8137-3	LIGHT.ASSY, WING TIP, ANTI-COLLISION	33
31-8138-1	POWER SUPPLY, A319/A320, A/C 3251-3270;A	33
31-9289-1	REAR POSITION NAVIGATIONAL LIGHT	33
31-9289-4	REAR POSITION NAVIGATIONAL LIGHT	33
31-9292-1	AIRCRAFT POSITION AND ANTICOLLISION LIGHT ASSEMBLY	33
31-9292-2	AIRCRAFT POSITION AND ANTICOLLISION LIGHT ASSEMBLY	33
31-9299-3	AIRCRAFT POSITION AND ANTICOLLISION LIGHT ASSEMBLY	33
31-9299-4	AIRCRAFT POSITION AND ANTICOLLISION LIGHT ASSEMBLY	33
31-9301-1	REAR POSITION NAVIGATIONAL LIGHT	33
319886-21-	VALVE FLOW CONTROL, BYPASS S/L 12 MONTHS	21
320-094-00	SENSOR N1, SPEED	77
3202096-2	RECIRCULATION AIR CHECK VALVE	21
3202122-1	NINE-INCH DIAMETER CHECK VALVE	21
3202130-1	6" DIAMETER CHECK VALVE	36
3202130-2	6" DIAMETER CHECK VALVE	36
3202130-3	6" DIAMETER CHECK VALVE	36
3202142-1	CONDITIONED AIR CHECK VALVE	21
3202142-2	CONDITIONED AIR CHECK VALVE	21
3202164-1	IN-LINE POPPET VALVE	36
3202164-3	IN-LINE POPPET VALVE	36
3202166-1	VALVE ZONE TRIM AIR, USED ON A/C 601-690	21
3202166-2	VALVE ZONE TRIM AIR, USED ON A/C 601-690	21
3202222-1	BLEED AIR CHECK VALVE	36
3202442-2	VALVE ZONE TRIM AIR, USED ON A/C 601-690	21
3202544-2	IN-LINE POPPET VALVE	36
3202544-3	IN-LINE POPPET VALVE	36
3202544-4	IN-LINE POPPET VALVE	36
3202544-5	IN-LINE POPPET VALVE	36
3202726-1	CHECK ZONE TRIM VALVE	21
320-298-10	HARNESS, CHIP DETECTOR, ELECTR	72
320-862-40	SENSOR, N1 SPEED	77

320-862-40	SENSOR, N1 SPEED	77
321-031-00	REVERSER PANEL	78
321-031-00	REVERSER PANEL	78
321-031-00	REVERSER PANEL	78
321-041-90	REAR LEFT HAND FAIRING ASSEMBLY	78
321-080-40	REAR LEFT HAND FAIRING ASSEMBLY	78
321-080-40	REAR LEFT HAND FAIRING ASSEMBLY	78
321-310-00	DOOR, PIVOTING LOWER LH	78
321-310-00	DOOR, PIVOTING LOWER LH	78
321-310-05	DOOR, PIVOTING LOWER LH	78
321-360-00	DOOR, PIVOTING LOWER LH	78
321-360-01	DOOR, PIVOTING LOWER LH	78
321-360-05	DOOR, PIVOTING LOWER LH	78
321-400-10	UNIT, HYDRAULIC CONTROL, THRUST REVER...	78
321-400-50	THRUST REVERSER NON-LOCKING ACTUATOR ASSEMBI	78
321-400-50	THRUST REVERSER NON-LOCKING ACTUATOR ASSEMBI	78
321-400-50	THRUST REVERSER NON-LOCKING ACTUATOR ASSEMBI	78
321-400-70	UNIT, HYDRAULIC CONTROL, THRUST REVER...	78
321-400-70	UNIT, HYDRAULIC CONTROL, THRUST REVER...	78
321-400-70	UNIT, HYDRAULIC CONTROL, THRUST REVER...	78
321-400-70	UNIT, HYDRAULIC CONTROL, THRUST REVER...	
321-400-70	UNIT, HYDRAULIC CONTROL, THRUST REVER...	
321-400-70	UNIT, HYDRAULIC CONTROL, THRUST REVER...	
321-400-70	UNIT, HYDRAULIC CONTROL, THRUST REVER...	78
321-404-70	THRUST REVERSER RIGHT SIDE HARNESS	71
3214176-1-	REGULATR PILOT PNEUMATIC PRESSURE	36
3214230-2	TRIM AIR PRESSURE REGULATING & SHUTOFF VALVE	21
3214334-1	FOUR INCH DIAMETER REGULATING AND SHUTOFF VALV	36
3214334-2	FOUR INCH DIAMETER REGULATING AND SHUTOFF VALV	36
3214334-3	FOUR INCH DIAMETER REGULATING AND SHUTOFF VALV	36
3214336-2	FOUR INCH DIAMETER MODULATING VALVE	29

3214336-3	FOUR INCH DIAMETER MODULATING VALVE	29
3214446-2	HIGH STAGE VALVE	
3214446-3	HIGH STAGE VALVE	36
3214446-4	HIGH STAGE VALVE	36
3214488-1	DUAL PURPOSE VALVE	36
3214488-2	DUAL PURPOSE VALVE	36
3214488-3	DUAL PURPOSE VALVE	36
3214488-4	DUAL PURPOSE VALVE	36
3214488-5	DUAL PURPOSE VALVE	36
3214488-6	DUAL PURPOSE VALVE	36
3214488-7	DUAL PURPOSE VALVE	36
3214488-X	DUAL PURPOSE VALVE	
3214552-3	PRESSURE REGULATOR AND SHUTOFF VALVE	36
3214552-4	PRESSURE REGULATOR AND SHUTOFF VALVE	36
3214552-5	PRESSURE REGULATOR AND SHUTOFF VALVE	36
3214552-6	PRESSURE REGULATOR AND SHUTOFF VALVE	36
3214862-1	TRIM AIR PRESSURE REGULATING & SHUTOFF VALVE	21
3214972-1	TRIM AIR PRESSURE REGULATING & SHUTOFF VALVE	21
3215580-1	VALVE PRESS REGULATOR TRIM AIR	21
3215KGB01	SENSOR, N1 SPEED	77
321812-2-1	VALVE PNEUMATIC CROSSFEED S/L 36 MONTHS	36
321858-3-1	VALVE TEMP CONTROL CABIN AND COCKPIT	21
3224996-1	VALVE, PNEUMATIC SUPPLY DUCT	36
322895-10	14TH STAGE BLEED CONVERTER VALVE	75
322895-11	14TH STAGE BLEED CONVERTER VALVE	75
322895-12	14TH STAGE BLEED CONVERTER VALVE	75
322895-13	14TH STAGE BLEED CONVERTER VALVE	75
322895-13D	14TH STAGE BLEED CONVERTER VALVE	75
322895-14	14TH STAGE BLEED CONVERTER VALVE	75
322895-14D	14TH STAGE BLEED CONVERTER VALVE	75
322895-15	14TH STAGE BLEED CONVERTER VALVE	75
322895-16	14TH STAGE BLEED CONVERTER VALVE	75

322895-17	14TH STAGE BLEED CONVERTER VALVE	75
322895-18	14TH STAGE BLEED CONVERTER VALVE	75
322895-20	14TH STAGE BLEED CONVERTER VALVE	75
322895-2	14TH STAGE BLEED CONVERTER VALVE	75
322895-4	14TH STAGE BLEED CONVERTER VALVE	75
322895-5	14TH STAGE BLEED CONVERTER VALVE	75
322895-6	14TH STAGE BLEED CONVERTER VALVE	75
322895-7	14TH STAGE BLEED CONVERTER VALVE	75
322895-8	14TH STAGE BLEED CONVERTER VALVE	75
322895-9	14TH STAGE BLEED CONVERTER VALVE	75
32364-001	BATTERY MAIN DC POWER	24
325-015-00	ENGINE HARNESS CJ9, CJ10	71
325-025-20	ENGINE HARNESS CJ9, CJ10	
325-025-20	ENGINE HARNESS CJ9, CJ10	73
325-025-40	ENGINE HARNESS CJ9, CJ10	73
325-025-40	ENGINE HARNESS CJ9, CJ10	73
325-025-70	ENGINE HARNESS CJ9, CJ10	73
325-025-70	ENGINE HARNESS CJ9, CJ10	73
325-025-80	ENGINE HARNESS CJ9, CJ10	73
325-025-80	ENGINE HARNESS CJ9, CJ10	73
325-025-80	ENGINE HARNESS CJ9, CJ10	73
325-026-70	ENGINE HARNESS CJ9, CJ10	71
325-026-80	ENGINE HARNESS CJ9, CJ10	71
325-026-90	ENGINE HARNESS CJ9, CJ10	71
325-026-90	ENGINE HARNESS CJ9, CJ10	72
325-027-30	HARNESS POWER MANAGEMENT CONTROL SYSTEM,	26
325-027-30	HARNESS POWER MANAGEMENT CONTROL SYSTEM,	26
325-027-40	HARNESS POWER MANAGEMENT CONTROL SYSTEM,	26
325-027-40	HARNESS POWER MANAGEMENT CONTROL SYSTEM,	26
325-027-40	HARNESS POWER MANAGEMENT CONTROL SYSTEM,	26
325-027-50	HARNESS POWER MANAGEMENT CONTROL SYSTEM,	26
325-027-50	HARNESS POWER MANAGEMENT CONTROL SYSTEM,	26

325-027-50	HARNESS POWER MANAGEMENT CONTROL SYSTEM,	26
325-027-50	HARNESS POWER MANAGEMENT CONTROL SYSTEM,	26
325-027-60	HARNESS POWER MANAGEMENT CONTROL SYSTEM,	72
325-027-60	HARNESS POWER MANAGEMENT CONTROL SYSTEM,	26
325-027-60	HARNESS POWER MANAGEMENT CONTROL SYSTEM,	26
325-027-60	HARNESS POWER MANAGEMENT CONTROL SYSTEM,	26
325-027-70	HARNESS POWER MANAGEMENT CONTROL SYSTEM,	73
325-029-90	NACELLE HARNESS MW0311	71
325-029-90	NACELLE HARNESS MW0311	71
325-029-90	NACELLE HARNESS MW0311	72
325-029-90	NACELLE HARNESS MW0311	72
325-029-90	NACELLE HARNESS MW0311	72
325-029-90	NACELLE HARNESS MW0311	72
325-034-80	ENGINE HARNESS J5, J6, J7, J8	73
325-034-80	ENGINE HARNESS J5, J6, J7, J8	73
325-034-90	ENGINE HARNESS J5, J6, J7, J8	73
325-034-90	ENGINE HARNESS J5, J6, J7, J8	73
325-035-00	ENGINE HARNESS J5, J6, J7, J8	73
325-035-00	ENGINE HARNESS J5, J6, J7, J8	73
325-035-20	ENGINE HARNESS CJ9, CJ10	71
325-035-50	ENGINE HARNESS CJ9, CJ10	72
325-035-50	ENGINE HARNESS CJ9, CJ10	72
325-035-50	ENGINE HARNESS CJ9, CJ10	72
325-043-40	ENGINE HARNESS CJ9, CJ10	73
325-043-40	ENGINE HARNESS CJ9, CJ10	73
325-043-50	ENGINE HARNESS CJ9, CJ10	73
325-043-50	ENGINE HARNESS CJ9, CJ10	73
325-045-20	ENGINE HARNESS CJ9, CJ10	73
325-045-30	ENGINE HARNESS CJ9, CJ10	71
325-045-50	ENGINE HARNESS CJ9, CJ10	73
32669-001	BATTERY MAIN EQUIP CENTER S/L 6 MOS @ ST	24
3268792-10	AIR TURBINE DRIVEN PUMP SYSTEM	29

3268792-4	AIR TURBINE DRIVEN PUMP SYSTEM	29
3268792-5	AIR TURBINE DRIVEN PUMP SYSTEM	29
3268792-6	AIR TURBINE DRIVEN PUMP SYSTEM	29
3268792-8	AIR TURBINE DRIVEN PUMP SYSTEM	29
3268792-9	AIR TURBINE DRIVEN PUMP SYSTEM	29
3289514-1	GEARBOX SHUTOFF VALVE	49
3289562-2	FOUR INCH DIAMETER PRECOOLER CONTROL VALVE	
3289562-3	FOUR INCH DIAMETER PRECOOLER CONTROL VALVE	
3289562-4	FOUR INCH DIAMETER PRECOOLER CONTROL VALVE	36
3289562-5	FOUR INCH DIAMETER PRECOOLER CONTROL VALVE	36
3289562-6	FOUR INCH DIAMETER PRECOOLER CONTROL VALVE	36
3289562-7	FOUR INCH DIAMETER PRECOOLER CONTROL VALVE	36
3289628-1	MODULATING PRE-COOLER COOLING AIR VALVE	36
3289628-2	MODULATING PRE-COOLER COOLING AIR VALVE	36
3289628-3	MODULATING PRE-COOLER COOLING AIR VALVE	36
3289628-5	MODULATING PRE-COOLER COOLING AIR VALVE	36
3289630-2	THREE INCH DIAMETER STARTER CONTROL VALVE	80
3289630-3	THREE INCH DIAMETER STARTER CONTROL VALVE	80
3289696-1	LOW LIMIT CONTROL VALVE	21
3290052-1	VALVE, APU, LOAD CONTROL; A-320	49
3290052-2	VALVE, APU, LOAD CONTROL; A-320	49
3290052-3	VALVE, APU, LOAD CONTROL; A-320	49
3290206-1	STANDBY PACK TEMPERATURE CONTROL VALVE	21
3290580-1	VALVE CONTROL, 35DEG F/1.67DEG C MUST BE	21
3290594-1	CHAMBER, VARIABLE VOLUME; (VVC)	49
3290718-1	OVERPRESSURE VALVE	36
3290736-1	VALVE PNEUMATIC DUCT FURNISHED WITH ATTA	36
3290738-1	VALVE FAN AIR MUST BE USABLE ON	36
3291214-2	THREE AND ONE HALF-INCH DIAMETER APU BLEED AIR	49
3291238-1	VALVE, APU SURGE CONTROL	49
3291238-2	VALVE, APU SURGE CONTROL	49
3291432-1	VALVE-LOAD CONTROL	49

3291432-2	VALVE-LOAD CONTROL	49
3291766-2	1.50 INCH DIAMETER NGS SHUTOFF VALVE	47
32D37	SWITCH PACK SHUTDOWN SHIP IN ATA SPEC 30	21
32V92	VACUUM SMOKE DETECTOR SWITCH	26
33000027-1	CONTAINR, FIRE EXTINGUISHER, APU INITIAL	26
33-019	MODULE AUTO BRAKE RH	32
33-021	MODULE AUTO BRAKE RH	32
33-0351-60	RIGHT LIGHTING CONTROL PANEL ASSEMBLY M10057	33
33-0351-61	RIGHT LIGHTING CONTROL PANEL ASSEMBLY M10057	33
33-0351-61	RIGHT LIGHTING CONTROL PANEL ASSEMBLY M10057	33
33-0351-61	RIGHT LIGHTING CONTROL PANEL ASSEMBLY M10057	33
33-0351-61	RIGHT LIGHTING CONTROL PANEL ASSEMBLY M10057	33
33-0389-50	ANNUNCIATOR PANEL	31
33-0389-50	ANNUNCIATOR PANEL	31
33-067-1	ANTISKID VALVE MODULE	32
331-0001-0	VALVE, LAV WASTE DRAIN,A/C 629 -699 AND	38
331-0006-0	VALVE, LAV WASTE DRAIN,A/C 629 -699 AND	38
3311586-1	SHELL, ACCUMULATOR	27
3311586-3	SHELL, ACCUMULATOR	27
33183-001	NICKEL-CADMIUM BATTERY	24
332-0001-0	VALVE LAV DRAIN USED ON A/C 9015 AND SUB	38
3321480-10	FLIGHT SPOILER POWER CONTROL UNIT	27
3321480-11	FLIGHT SPOILER POWER CONTROL UNIT	27
3321480-11	FLIGHT SPOILER POWER CONTROL UNIT	27
3321480-12	FLIGHT SPOILER POWER CONTROL UNIT	27
3321480-13	FLIGHT SPOILER POWER CONTROL UNIT	27
3321480-14	FLIGHT SPOILER POWER CONTROL UNIT	27
3321480-15	FLIGHT SPOILER POWER CONTROL UNIT	27
3321480-16	FLIGHT SPOILER POWER CONTROL UNIT	27
3321480-4A	FLIGHT SPOILER POWER CONTROL UNIT	27
3321480-5	FLIGHT SPOILER POWER CONTROL UNIT	
3321480-5A	FLIGHT SPOILER POWER CONTROL UNIT	27
3321480-6	FLIGHT SPOILER POWER CONTROL UNIT	27

3321480-6A	FLIGHT SPOILER POWER CONTROL UNIT	27
3321480-7	FLIGHT SPOILER POWER CONTROL UNIT	27
3321480-7A	FLIGHT SPOILER POWER CONTROL UNIT	27
3321480-8A	FLIGHT SPOILER POWER CONTROL UNIT	27
3321480-9	FLIGHT SPOILER POWER CONTROL UNIT	27
3321480-9A	FLIGHT SPOILER POWER CONTROL UNIT	27
3321500-10	FLIGHT SPOILER POWER CONTROL UNIT	27
3321500-10	FLIGHT SPOILER POWER CONTROL UNIT	27
3321500-11	FLIGHT SPOILER POWER CONTROL UNIT	27
3321500-11	FLIGHT SPOILER POWER CONTROL UNIT	27
3321500-12	FLIGHT SPOILER POWER CONTROL UNIT	27
3321500-13	FLIGHT SPOILER POWER CONTROL UNIT	27
3321500-14	FLIGHT SPOILER POWER CONTROL UNIT	27
3321500-15	FLIGHT SPOILER POWER CONTROL UNIT	27
3321500-16	FLIGHT SPOILER POWER CONTROL UNIT	27
3321500-3A	FLIGHT SPOILER POWER CONTROL UNIT	27
3321500-4A	FLIGHT SPOILER POWER CONTROL UNIT	27
3321500-5A	FLIGHT SPOILER POWER CONTROL UNIT	27
3321500-6	FLIGHT SPOILER POWER CONTROL UNIT	27
3321500-6A	FLIGHT SPOILER POWER CONTROL UNIT	27
3321500-7A	FLIGHT SPOILER POWER CONTROL UNIT	27
3321500-8	FLIGHT SPOILER POWER CONTROL UNIT	27
3321500-8A	FLIGHT SPOILER POWER CONTROL UNIT	27
3321500-9A	FLIGHT SPOILER POWER CONTROL UNIT	27
3321520-10	RUDDER POWER CONTROL UNIT ASSEMBLY	27
3321520-4	RUDDER POWER CONTROL UNIT ASSEMBLY	
3321520-5	RUDDER POWER CONTROL UNIT ASSEMBLY	27
3321520-6	RUDDER POWER CONTROL UNIT ASSEMBLY	27
3321520-7	RUDDER POWER CONTROL UNIT ASSEMBLY	27
3321520-8	RUDDER POWER CONTROL UNIT ASSEMBLY	27
3321520-9	RUDDER POWER CONTROL UNIT ASSEMBLY	27
3321530-10	ELEVATOR POWER CONTROL UNIT ASSY	27

3321530-11	ELEVATOR POWER CONTROL UNIT ASSY	27
3321530-12	ELEVATOR POWER CONTROL UNIT ASSY	27
3321530-7	ELEVATOR POWER CONTROL UNIT ASSY	27
3321530-8	ELEVATOR POWER CONTROL UNIT ASSY	27
3321530-9	ELEVATOR POWER CONTROL UNIT ASSY	27
332A2321-1	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36
332A2326-3	DUCT.. WHL WELL AND U/WING AIR SUPPLY	36
332N3311-1	DUCT.. WHL WELL AND U/WING AIR SUPPLY	80
332N3312-1	DUCT.. WHL WELL AND U/WING AIR SUPPLY	80
332N3312-1	DUCT.. WHL WELL AND U/WING AIR SUPPLY	80
332N3312-1	DUCT.. WHL WELL AND U/WING AIR SUPPLY	80
332N3321-1	AIR BLEED DUCTS	75
332N3331-7	AIR BLEED DUCTS	36
332N3331-9	AIR BLEED DUCTS	36
332N3751-1	AIR BLEED DUCTS	75
332N3751-1	AIR BLEED DUCTS	75
332N3751-1	AIR BLEED DUCTS	75
332T1226-6	DUCT PWA4060 QEC-START SYSTEM IN STL	80
332T1229-6	DUCT PWA4060 QEC-START SYSTEM IN STL	36
332T1236-1	DUCT PWA4060 QEC-START SYSTEM IN STL	36
332T1240-5	DUCT PWA4060 QEC-START SYSTEM IN STL	36
332T1240-9	DUCT PWA4060 QEC-START SYSTEM IN STL	36
332T1241-2	DUCT PWA4060 QEC-START SYSTEM IN STL	75
332T1246-1	DUCT PWA4060 QEC-START SYSTEM IN STL	71
332T3072-2	DUCT PW4060 QEC-SURGE BLEED EXHAUST	75
332T3072-4	DUCT PW4060 QEC-SURGE BLEED EXHAUST	75
332T4313-1	DUCT PWA4060 QEC-START SYSTEM IN STL	71
332T4324-1	DUCT PWA4060 QEC-START SYSTEM IN STL	71
332T4521-5	SHIELD PWA4060 QEC-HEAT SHIELD ASSY	71
332T4521-5	SHIELD PWA4060 QEC-HEAT SHIELD ASSY	71
332U2312-9	DUCT PWA4060 QEC-START SYSTEM IN STL	80
3351003-51	BIN ASSY., OVERHEAD COMPARTMENT, RT 1	25

335-260-90	CAP ASSY, INDICATOR OIL TANK PACKAGE 1EA	79
336-023-20	PANEL, ACOUSTICAL; AFT; FAN CASE	72
336-023-21	PANEL, ACOUSTICAL; AFT; FAN CASE	72
336-023-22	PANEL, ACOUSTICAL; AFT; FAN CASE	72
336-023-22	PANEL, ACOUSTICAL; AFT; FAN CASE	72
336-023-40	PANEL, ACOUSTICAL; AFT; FAN CASE	72
336-023-41	PANEL, ACOUSTICAL; AFT; FAN CASE	72
336-030-10	PANEL, ACOUSTICAL; FWD	72
336-030-40	PANEL, ACOUSTICAL; MID	72
336-030-40	PANEL, ACOUSTICAL; MID	72
3399004-1	FOURTEENTH STAGE PILOT	36
3399004-2	FOURTEENTH STAGE PILOT	36
3399004-3	FOURTEENTH STAGE PILOT	36
3399004-5	FOURTEENTH STAGE PILOT	36
3399004-6	FOURTEENTH STAGE PILOT	36
3399004-7	FOURTEENTH STAGE PILOT	36
3399004-9	FOURTEENTH STAGE PILOT	36
3399104-1	VALVE,HIGH STAGE PILOT BLEED MUST BE USA	36
3399106-2	VALVE, PRSOV PILOT	36
3399108-1	VALVE FAN AIR PILOT MUST BE USABLE ON	36
340-010-40	Misc Fuel Tubes	75
340-010-80	Misc Fuel Tubes	72
340-011-00	Misc Fuel Tubes	72
340-011-60	Misc Fuel Tubes	72
340-400-00	LUBRICATION UNIT	79
340-400-00	LUBRICATION UNIT	79
340-401-00	NO. 1 BEARING ACCELEROMETER	77
340-401-40	FAN FRAME COMPRESSOR CASE VIBRATION SENSOR	72
340-401-50	FAN FRAME COMPRESSOR CASE VIBRATION SENSOR	77
340-402-50	PROBE T49.5	77
340-402-50	PROBE T49.5	77
340-402-50	PROBE T49.5	77

340-403-80	OIL TANK	79
34-1004-50	EFIC-701 ELECTRONIC FLIGHT INSTRUMENT CONTROL	34
34-1004-50	EFIC-701 ELECTRONIC FLIGHT INSTRUMENT CONTROL	34
341203-500	ELEVATOR SERVOCONTROL	27
341525-1	2-WAY 2-POSITION SHUTOFF BALL VALVE	29
341E030000	THERMOSTAT, PNEUMATIC; TEMP LIMIT; A319/	36
342B050000	THERMOSTAT, PNEU., EO 3610-01105 REVD	36
34600010-1	BOTTLE FIRE, FWD CARGO FWD BOTTLE 800 CU	26
34600010-1	BOTTLE FIRE, FWD CARGO FWD BOTTLE 800 CU	26
34600010-2	BOTTLE, FIRE, CARGO;RH; NAFE; HAS INSP	26
34600010-2	BOTTLE, FIRE, CARGO;RH; NAFE; HAS INSP	26
34600010-2	BOTTLE, FIRE, CARGO;RH; NAFE; HAS INSP	26
34600010-3	BOTTLE, FIRE, CARGO;RH; NAFE; HAS INSP	26
34600010-4	BOTTLE FIRE, FWD CARGO FWD BOTTLE 800 CU	26
34600010-4	BOTTLE FIRE, FWD CARGO FWD BOTTLE 800 CU	26
34600010-8	BOTTLE FIRE, FWD CARGO FWD BOTTLE 800 CU	26
34600010-8	BOTTLE FIRE, FWD CARGO FWD BOTTLE 800 CU	26
34600012-1	630 CUBIC INCH FIRE EXTINGUISHERS	26
34600012-2	630 CUBIC INCH FIRE EXTINGUISHERS	26
34600012-2	630 CUBIC INCH FIRE EXTINGUISHERS	26
34600012-2	630 CUBIC INCH FIRE EXTINGUISHERS	26
34600012-2	630 CUBIC INCH FIRE EXTINGUISHERS	26
34600012-2	630 CUBIC INCH FIRE EXTINGUISHERS	26
34600012-6	630 CUBIC INCH FIRE EXTINGUISHERS	26
34600013-1	630 CUBIC INCH FIRE EXTINGUISHERS	26
34600013-2	630 CUBIC INCH FIRE EXTINGUISHERS	26
34600013-2	630 CUBIC INCH FIRE EXTINGUISHERS	26
34600013-2	630 CUBIC INCH FIRE EXTINGUISHERS	26
34600013-2	630 CUBIC INCH FIRE EXTINGUISHERS	26
34600013-7	630 CUBIC INCH FIRE EXTINGUISHERS	26
34600013-7	630 CUBIC INCH FIRE EXTINGUISHERS	26
34600013-9	630 CUBIC INCH FIRE EXTINGUISHERS	26
34600013-9	630 CUBIC INCH FIRE EXTINGUISHERS	26
348-100	AIR CHILLER REFRIGERATION UNIT	25

348-19	CHILLER, AIR, GALLEY G1A, 3000 BTU; A330	25
348-519	CHILLER, AIR, GALLEY G1A, 3000 BTU; A330	25
348-8	AIR CHILLER REFRIGERATION UNIT	25
35008-300	CONTINUOUS FIRE & OVERHEAT DET CONTROL UNIT	26
35008-307	CONTINUOUS FIRE & OVERHEAT DET CONTROL UNIT	26
35008-33	CONTINUOUS FIRE & OVERHEAT DET CONTROL UNIT	26
35008-38	CONTINUOUS FIRE & OVERHEAT DET CONTROL UNIT	26
35008-72	CONTINUOUS FIRE & OVERHEAT DET CONTROL UNIT	26
3505945-10	ENGINE AIR TURBINE STARTER	80
3505945-12	ENGINE AIR TURBINE STARTER	80
3505945-2	ENGINE AIR TURBINE STARTER	80
3505945-3	ENGINE AIR TURBINE STARTER	80
3505945-4	ENGINE AIR TURBINE STARTER	80
3505945-5	ENGINE AIR TURBINE STARTER	80
3505945-6	ENGINE AIR TURBINE STARTER	80
3505945-7	ENGINE AIR TURBINE STARTER	80
3505945-8	ENGINE AIR TURBINE STARTER	80
3505945-9	ENGINE AIR TURBINE STARTER	80
350880-3	VARIABLE DISPLACEMENT HYDRAULIC PUMP	29
350880-6	VARIABLE DISPLACEMENT HYDRAULIC PUMP	29
350880-7	VARIABLE DISPLACEMENT HYDRAULIC PUMP	29
3510-0006-	FRESH BREW COFFEEMAKER	25
3510-0044-	DISPENSER, COFFEE, WORLD AIRWAYS PART	25
3510-0044-	DISPENSER, COFFEE, WORLD AIRWAYS PART	25
3510-0044-	DISPENSER, COFFEE, WORLD AIRWAYS PART	25
3510-0053-	FRESH BREW COFFEEMAKER	25
35-1H5-100	MONITOR, BRAKE, TEMPERATURE.	32
35-1H5-100	MONITOR, BRAKE, TEMPERATURE.	32
3520-0263-	SWITCH, ASSY; COFFEE MAKER 3510-0053-01	25
35200-3	CABLE DRAIN, REMOTE CONTROL VALVE ACTUAT	38
353N1010-1	DOOR, APU INLET	49
353N1010-2	DOOR, APU INLET	49

353N1010-4	DOOR, APU INLET	49
3601-54	ENGINE FIRE AND OVERHEAT LOWER DETECTOR	26
3616848-1	SHUTOFF VALVE	49
3616848-2	SHUTOFF VALVE	49
361N3001-1	PROPULSION DISCRETE INTERFACE UNIT	73
361N3001-2	PROPULSION DISCRETE INTERFACE UNIT	73
362-021-00	RUDDER TRIM INDICATOR	27
362-021-00	RUDDER TRIM INDICATOR	27
3645797-50	SPRING COCKPIT ELEVATOR LOAD FEEL AND.CE	27
3645797-50	SPRING COCKPIT ELEVATOR LOAD FEEL AND.CE	27
366-006-00	UNIT REFUELING WING LEADING EDGE STATIC	28
366-006-00	UNIT REFUELING WING LEADING EDGE STATIC	
367-027-00	HYDRAULIC QUANTITY CONTROL MONITOR	29
367-027-00	HYDRAULIC QUANTITY CONTROL MONITOR	29
367-027-01	HYDRAULIC QUANTITY CONTROL MONITOR	29
367-027-02	HYDRAULIC QUANTITY CONTROL MONITOR	29
36E14-1	SHUTOFF VALVE - CF6-80C2	75
36E14-2	SHUTOFF VALVE - CF6-80C2	
36E14-3	SHUTOFF VALVE - CF6-80C2	75
36E14-4	SHUTOFF VALVE - CF6-80C2	75
36E14-5	SHUTOFF VALVE - CF6-80C2	75
36E14-6	SHUTOFF VALVE - CF6-80C2	72
373500-1	WARMER, BUN, FIRST CLASS GALLE	25
375-0001-1	DISPENSER, COFFEE, WORLD AIRWAYS PART	25
375-0001-1	DISPENSER, COFFEE, WORLD AIRWAYS PART	25
3760963-50	SPRING ASSY, RUDDER LOAD FEEL AND TRIM	27
3760963-50	SPRING ASSY, RUDDER LOAD FEEL AND TRIM	27
3772374-55	VALVE RUDDER SHUT-OFF	27
37821-1	FUEL PRESENCE SENSOR SYSTEM CARD	28
37822-1	FUEL PRESENCE SENSOR SYSTEM CARD	28
3790011-10	SERVO ACTUATOR RUDDER RATIO CHANGER	
3790011-10	SERVO ACTUATOR RUDDER RATIO CHANGER	27

3790011-10	SERVO ACTUATOR RUDDER RATIO CHANGER	27
3790011-10	SERVO ACTUATOR RUDDER RATIO CHANGER	27
3790011L10	SERVO ACTUATOR RUDDER RATIO CHANGER	
3790033-10	ROTARY INPUT SHEAR SEAL VALVE MODULE	32
3790034-10	ROTARY INPUT SHEAR SEAL VALVE MODULE	32
3790034-10	ROTARY INPUT SHEAR SEAL VALVE MODULE	32
3790037-10	NOSE GEAR STEERING METERING VALVE MODULE	32
3790037-10	NOSE GEAR STEERING METERING VALVE MODULE	32
3790037-10	NOSE GEAR STEERING METERING VALVE MODULE	32
3790037-10	NOSE GEAR STEERING METERING VALVE MODULE	32
3790055-10	CYLINDER RUDDER CONTROL TRANSFER AND LAN	27
3800014-10	NOSE GEAR STEERING METERING VALVE MODULE	32
3800014-10	NOSE GEAR STEERING METERING VALVE MODULE	32
3800014-10	NOSE GEAR STEERING METERING VALVE MODULE	32
3800022-10	SERVO ACTUATOR RUDDER RATIO CHANGER	
3800022-10	SERVO ACTUATOR RUDDER RATIO CHANGER	27
3800022-10	SERVO ACTUATOR RUDDER RATIO CHANGER	27
3800022-10	SERVO ACTUATOR RUDDER RATIO CHANGER	27
3800022-10	SERVO ACTUATOR RUDDER RATIO CHANGER	27
3800022-10	SERVO ACTUATOR RUDDER RATIO CHANGER	27
3800022L10	SERVO ACTUATOR RUDDER RATIO CHANGER	27
3800035-10	STATOR VANE ACTUATOR ASSEMBLY	75
3800035-11	STATOR VANE ACTUATOR ASSEMBLY	75
3800035-11	STATOR VANE ACTUATOR ASSEMBLY	75
3800035-11	STATOR VANE ACTUATOR ASSEMBLY	75
3800035-11	STATOR VANE ACTUATOR ASSEMBLY	75
3800035-11	STATOR VANE ACTUATOR ASSEMBLY	75
3800035-11	STATOR VANE ACTUATOR ASSEMBLY	75
3800035-11	STATOR VANE ACTUATOR ASSEMBLY	75
3800035-11	STATOR VANE ACTUATOR ASSEMBLY	75
3800035-12	STATOR VANE ACTUATOR ASSEMBLY	75
3810056-10	MODULE CONTROL VALVE, THRUST REVERSER	29
3810056-10	MODULE CONTROL VALVE, THRUST REVERSER	29

3810056-10	MODULE CONTROL VALVE, THRUST REVERSER	29
3810056-10	MODULE CONTROL VALVE, THRUST REVERSER	29
3810056-10	MODULE CONTROL VALVE, THRUST REVERSER	29
3810056-10	MODULE CONTROL VALVE, THRUST REVERSER	29
381200-100	STANDBY RUDDER POWER CONTROL UNIT	27
381200-100	STANDBY RUDDER POWER CONTROL UNIT	27
381800-100	LEADING EDGE SLAT ACTUATOR ASSEMBLY	27
381800-100	LEADING EDGE SLAT ACTUATOR ASSEMBLY	27
381800-100	LEADING EDGE SLAT ACTUATOR ASSEMBLY	27
382000-100	LEADING EDGE SLAT ACTUATOR ASSEMBLY	27
3825-39780	DOOR, GALLEY, W/ROLLER ASSY;COMP 1-1;1-7	25
3830041-10	ACTUATOR, INTERCOMPRESSOR	75
3830041-10	ACTUATOR, INTERCOMPRESSOR	75
3830041-10	ACTUATOR, INTERCOMPRESSOR	75
3830041-10	ACTUATOR, INTERCOMPRESSOR	75
3830041-10	ACTUATOR, INTERCOMPRESSOR	75
3830041-10	ACTUATOR, INTERCOMPRESSOR	75
3830041-10	ACTUATOR, INTERCOMPRESSOR	75
3830041-10	ACTUATOR, INTERCOMPRESSOR	75
3830041-10	ACTUATOR, INTERCOMPRESSOR	75
3830041-10	ACTUATOR, INTERCOMPRESSOR	75
3830041-10	ACTUATOR, INTERCOMPRESSOR	75
383222-1-1	STARTER,ENGINE PNUM;NOT FLANGE,CLAMP MOU	80
383342-1-1	STARTER,ENGINE PNUM;NOT FLANGE,CLAMP MOU	80
383342-13	STARTER,ENGINE PNUM;NOT FLANGE,CLAMP MOU	80
383342-14	STARTER,ENGINE PNUM;NOT FLANGE,CLAMP MOU	80
383342-2-1	STARTER,ENGINE PNUM;NOT FLANGE,CLAMP MOU	80
383900-100	STEERING VALVE ASSEMBLY	32
383900-100	STEERING VALVE ASSEMBLY	32
383900-101	STEERING VALVE ASSEMBLY	32
384301-10	PUMP FUEL.ENGINE.DRIVEN.EO 49-73700-3.	73
384301-4	PUMP FUEL.ENGINE.DRIVEN.EO 49-73700-3.	
384301-5	PUMP FUEL.ENGINE.DRIVEN.EO 49-73700-3.	
384301-6	PUMP FUEL.ENGINE.DRIVEN.EO 49-73700-3.	73

384301-7	PUMP FUEL.ENGINE.DRIVEN.EO 49-73700-3.	73
384301-8	PUMP FUEL.ENGINE.DRIVEN.EO 49-73700-3.	73
384301-9	PUMP FUEL.ENGINE.DRIVEN.EO 49-73700-3.	73
3862775-1	FAN, APU, OIL COOLING; POST SB 49-6520	49
3862775-2	FAN, APU, OIL COOLING; POST SB 49-6520	49
3876024-4	APU LOW OIL PRESSURE SWITCH	49
3876024-5	APU LOW OIL PRESSURE SWITCH	49
3876024-6	APU LOW OIL PRESSURE SWITCH	49
3876024-8	APU LOW OIL PRESSURE SWITCH	49
3876026-2	APU MOTIONAL TRANSDUCER	49
3876026-3	APU MOTIONAL TRANSDUCER	49
3876027-3	APU THERMOCOUPLE	49
3876027-4	APU THERMOCOUPLE	49
3876035-4	APU AIR PRESSURE SENSOR	49
3876035-4K	APU AIR PRESSURE SENSOR	49
3876035-5	APU AIR PRESSURE SENSOR	49
3876048-1	APU DELTA P SWITCH	49
3876048-2	APU DELTA P SWITCH	49
3876048-3	APU DELTA P SWITCH	49
3876059-2	APU OIL LEVEL SWITCH	49
3876084-1	APU TOTAL PRESSURE SENSOR	49
3876084-2	APU TOTAL PRESSURE SENSOR	49
3876085-1	APU DIFFERENTIAL SURGE VALVE TRANSDUCER	49
3876085-2	APU DIFFERENTIAL SURGE VALVE TRANSDUCER	49
3876085-3	APU DIFFERENTIAL SURGE VALVE TRANSDUCER	49
3876085-4	APU DIFFERENTIAL SURGE VALVE TRANSDUCER	49
3876085-5	APU DIFFERENTIAL SURGE VALVE TRANSDUCER	49
3876166-1	DE-OIL SOLENOID VALVE	49
3876186-3	SWITCH APU, LOW OIL PRESSURE	49
3876186-4	SWITCH APU, LOW OIL PRESSURE	49
3876225-2	SENSOR APU INLET PRESSURE SHIP IN ATA SP	49
3880190-10	LUBE PUMP ASSEMBLY	49

3880190-3	LUBE PUMP ASSEMBLY	49
3880190-4	LUBE PUMP ASSEMBLY	49
3880190-5	LUBE PUMP ASSEMBLY	49
3880190-8	LUBE PUMP ASSEMBLY	49
3880200-5	GENERATOR SCAVENGE PUMP ASSEMBLY	49
3880200-6	GENERATOR SCAVENGE PUMP ASSEMBLY	49
3880271-1	APU DIFFERENTIAL PRESSURE INDICATOR	49
3882500-10	FUEL CONTROL ASSEMBLY	49
3882500-11	FUEL CONTROL ASSEMBLY	49
3882500-12	FUEL CONTROL ASSEMBLY	49
3882500-13	FUEL CONTROL ASSEMBLY	49
3882500-14	FUEL CONTROL ASSEMBLY	49
3882500-15	FUEL CONTROL ASSEMBLY	49
3882500-16	FUEL CONTROL ASSEMBLY	49
3882500-17	FUEL CONTROL ASSEMBLY	49
3882500-5	FUEL CONTROL ASSEMBLY	49
3882500-6	FUEL CONTROL ASSEMBLY	49
3882500-8	FUEL CONTROL ASSEMBLY	49
3882500-9	FUEL CONTROL ASSEMBLY	49
3882550-1	FLOW DIVIDER & DRAIN VALVE ASSEMBLY	49
3882550-2	FLOW DIVIDER & DRAIN VALVE ASSEMBLY	49
3882550-3	FLOW DIVIDER & DRAIN VALVE ASSEMBLY	49
3888000-7	UNIT APU IGNITION MUST BE USABLE ON	49
3888058-1	IGNITION EXCITER ACCESSORY CH92036	49
3888058-3	IGNITION EXCITER ACCESSORY CH92036	49
3888058-4	IGNITION EXCITER ACCESSORY CH92036	49
3888058-5T	IGNITION EXCITER ACCESSORY CH92036	49
3888058-6	IGNITION EXCITER ACCESSORY CH92036	49
3888123-1	GTCP331-200 APU WIRE HARNESS	49
3888123-2	GTCP331-200 APU WIRE HARNESS	49
3888123-4	GTCP331-200 APU WIRE HARNESS	49
3888123-6	GTCP331-200 APU WIRE HARNESS	49

3888123-7	GTCP331-200 APU WIRE HARNESS	49
3888123-8	GTCP331-200 APU WIRE HARNESS	49
3888123-9	GTCP331-200 APU WIRE HARNESS	49
3888123-X	GTCP331-200 APU WIRE HARNESS	
3888449-1	ENGINE WIRING HARNESS ASSEMBLY	49
3888449-2	ENGINE WIRING HARNESS ASSEMBLY	49
3888465-1	GTCP331-200 APU WIRE HARNESS	49
38E93-5	VALVE, ANTI-ICE, WING	30
38E93-6	VALVE, ANTI-ICE, WING	30
3910028-10	VALVE.NLG.SELECTOR/BYPASS INITIAL PURCHA	32
3910028-10	VALVE.NLG.SELECTOR/BYPASS INITIAL PURCHA	32
3912754-1	HINGE AFT & FWD CARGO COMPT DOOR	52
3912754-50	HINGE AFT & FWD CARGO COMPT DOOR	52
3912754-50	HINGE AFT & FWD CARGO COMPT DOOR	52
3914016-50	CYLINDER,MLG,BUNGEE...	32
3914016-55	CYLINDER,MLG,BUNGEE...	32
3914136-50	END, RUDDER LIMITER; PUSH ROD	27
3914163-1	TUBE-TORQUE DRIVE ACME SCREW	27
3914163-50	TUBE-TORQUE DRIVE ACME SCREW	27
3914179-50	TUBE-TORQUE DRIVE ACME SCREW	27
3914203-51	LEVER, SPEED BRAKE	27
3914267-50	ACTUATOR AILERON TRIM TAB	27
3914478-1	TUBE PSGR DOOR HOOK ACTUATOR	52
3914625-55	CYLINDER, INSOURCE, CONTRACT PART,SET UP	32
3915180-50	GLAND, SWIVEL, MLG; DC9-50/MD88/MD90/B71	32
3915180-50	GLAND, SWIVEL, MLG; DC9-50/MD88/MD90/B71	32
3915180-55	GLAND, SWIVEL, MLG; DC9-50/MD88/MD90/B71	32
3915878-50	MANIFOLD BRAKE SYSTEM PRESSURE UPON RECE	32
3915878-55	MANIFOLD BRAKE SYSTEM PRESSURE UPON RECE	32
3915878-55	MANIFOLD BRAKE SYSTEM PRESSURE UPON RECE	32
3917382-50	CYLINDER VENTRAL STAIR	52
3917778-55	VALVE WING FLAP, TWO SPEED HYD	27

3917935-50	ROD RUDDER LIMITER PUSH	27
3917935-50	ROD RUDDER LIMITER PUSH	27
3918165-55	VALVE HYD RELIEF 100 PSI AND MANUALLY OP	27
3920048-55	CYLINDER, SLAT, ACTUATOR; ALL DC9-30-40&	27
392-112-20	SUPPLY, POWER, EEC;STATIC SENSITIVE	73
3924229-1	TUBE-TORQUE DRIVE ACME SCREW	27
392444-2-1	VALVE, PRESS REGULATOR,STABILIZER ICE PR	30
392454-3-1	REGULATR, AIR CONDITIONING, PRESS PILOT	21
3924649-50	LINK SPOILER ACTUATING MECHANISM IDLER	27
39-249	CONTROL VALVE	32
39-249-1	VALVE, MLG ANTI-SKID.	32
39-249-2	VALVE, MLG ANTI-SKID.	32
39-249-2A	VALVE, MLG ANTI-SKID.	32
392550-2-1	VALVE,ANTI-ICING; DC9-50 ONLY	75
392550-3-1	VALVE,ANTI-ICING; DC9-50 ONLY	75
392550-4	VALVE,ANTI-ICING; DC9-50 ONLY	75
392550-5	VALVE,ANTI-ICING; DC9-50 ONLY	75
392678-1-1	VALVE, PNEUMATIC,SHUT-OFF,COOLING TURBIN	21
392678-3-1	VALVE, PNEUMATIC,SHUT-OFF,COOLING TURBIN	21
392710-1-1	VALVE, PNEUMATIC, AUGMENTATION;DC9-30/-4	36
392710-1-2	VALVE, PNEUMATIC, AUGMENTATION;DC9-30/-4	36
392710-2	VALVE, PNEUMATIC, AUGMENTATION;DC9-30/-4	36
392714-1-1	VALVE, PRESS REGULATOR, TAIL SECTION	21
3927223-1	TUBE-TORQUE DRIVE ACME SCREW	27
392796-2-1	VALVE ENGINE STARTER CONTROL USED ON JT8	80
392796-2-2	VALVE ENGINE STARTER CONTROL USED ON JT8	80
392796-5	VALVE ENGINE STARTER CONTROL USED ON JT8	80
392796-6	VALVE ENGINE STARTER CONTROL USED ON JT8	80
3928137-50	MAIN LANDING GEAR SIDE BRACE LOCK ACTUATOR ASS	32
3934689-50	NOSEWHEEL STEERING CYLINDER ASSEMBLY	32
3934689-55	NOSEWHEEL STEERING CYLINDER ASSEMBLY	32
3936347-53	ROLLER WING LE TRACK	57

3936678-50	STRUT VENTRAL STAIR DOOR ACTUATOR RIGHT	52
3936678-50	STRUT VENTRAL STAIR DOOR ACTUATOR RIGHT	52
3936784-1	LINK, GROUND SPOILER	27
3936845-50	CRANK ASSY GROUND SPOILER	27
3937033-55	CYLINDER MLG BUNGEE, LH AND RH	32
3937033-55	CYLINDER MLG BUNGEE, LH AND RH	32
3937466-1	SLAT,NO.2 R/H DC9-30/-40/-50	27
3937860-55	GLAND, MLG RETRACT CYL, RH	32
3937860-55	GLAND, MLG RETRACT CYL, RH	32
394100-100	SOLENOID OPERATED SHUTOFF VALVE	27
3952485-50	PLUNGER CAM FOLLOWER, SLAT NO 1 AND 3 SW	27
3952531-50	CYLINDER RUDDER CONTROL TRANSFER AND LAN	27
3954557-1	SPOILER..FLIGHT, LH; DC9/MD80 (SEE /FOR	27
3954558-50	SPOILER NUMBER 7 RH UPON RECEIPT SENT TO	27
3955262-1	LINK ASSY, COMPOSITE RUBBER FLEX HINGE	55
3955421-1	CRANK ASSY, AILERON TRIM TAB CONTROL	27
3955423-1	EYEBOLT ASSY, AILERON BOX TRIM TAB SUPPO	27
3955518-1	LINK RUDDER DAMPER	27
3955969-1	HINGE, FWD; AFT NOSE GEAR DOOR;	32
3955969-50	HINGE, FWD; AFT NOSE GEAR DOOR;	32
3955969-51	HINGE AFT DOOR, NLG LH AND RH FWD HINGE	32
3955969-51	HINGE, FWD; AFT NOSE GEAR DOOR;	32
396130-1-1	VALVE AIR COND FLOW CONTROL TAIL SECTION	21
396398-2	FLOW CONTROL AND SHUTOFF VALVE	21
396430-1	FLOW CONTROL & SHUTOFF VALVE	21
396430-2	FLOW CONTROL & SHUTOFF VALVE	21
396430-4	FLOW CONTROL & SHUTOFF VALVE	21
396442-1	FLOW CONTROL VALVE	21
396462-1	FLOW CONTROL & SHUTOFF VALVE	21
396462-2	FLOW CONTROL & SHUTOFF VALVE	21
396480-1	FLOW CONTROL AND SHUTOFF VALVE	21
396496-1	AIR CYCLE MACHINE	21

396498-2	FLOW CONTROL VALVE	21
396582-2	VALVE FLOW CONTROL MUST BE USABLE ON	21
396608-1	FLOW CONTROL VALVE	21
397364-3-1	VALVE, PNEUMATIC,SHUT-OFF,COOLING TURBIN	21
398000-1	VOLUTE AUXILIARY MAIN BOOST	28
398000-2	VOLUTE AUXILIARY MAIN BOOST	28
398750-2	THREE-INCH DIAMETER TEMPERATURE CONTROL VALVE	21
398750-3	THREE-INCH DIAMETER TEMPERATURE CONTROL VALVE	21
398750-4	THREE-INCH DIAMETER TEMPERATURE CONTROL VALVE	21
398750-5	THREE-INCH DIAMETER TEMPERATURE CONTROL VALVE	21
398786-2	TWO-INCH DIAMETER TRIM AIR SUPPLY MODULATING VA	21
398786-3	TWO-INCH DIAMETER TRIM AIR SUPPLY MODULATING VA	21
398786-4	TWO-INCH DIAMETER TRIM AIR SUPPLY MODULATING VA	21
398786-5	TWO-INCH DIAMETER TRIM AIR SUPPLY MODULATING VA	21
398908-2	TEMPERATURE CONTROL VALVE	21
398908-3	TEMPERATURE CONTROL VALVE	21
398908-4	TEMPERATURE CONTROL VALVE	21
398908-5	TEMPERATURE CONTROL VALVE	21
3A064-0003	CREW SEAT ASSEMBLY	25
3A064-0004	CREW SEAT ASSEMBLY	25
3A071-0003	SEAT, CO PILOT W/OUT HEADREST	25
3A071-0004	SEAT, CO PILOT W/OUT HEADREST	25
3A071-0004	SEAT, CO PILOT W/OUT HEADREST	25
3A071-0005	SEAT, CO PILOT W/OUT HEADREST	25
3A071-0005	SEAT, CO PILOT W/OUT HEADREST	25
3A071-0005	SEAT, CO PILOT W/OUT HEADREST	25
3A071-0005	SEAT, CO PILOT W/OUT HEADREST	25
3A071-0005	SEAT, CO PILOT W/OUT HEADREST	25
3A071-0005	SEAT, CO PILOT W/OUT HEADREST	25
3A071-0006	SEAT, CO PILOT W/OUT HEADREST	25
3A071-0006	SEAT, CO PILOT W/OUT HEADREST	25
3A071-0006	SEAT, CO PILOT W/OUT HEADREST	25
3A071-0006	SEAT, CO PILOT W/OUT HEADREST	25

3A071-0006	SEAT, CO PILOT W/OUT HEADREST	25
3A071-0006	SEAT, CO PILOT W/OUT HEADREST	25
3A071-0006	SEAT, CO PILOT W/OUT HEADREST	25
3A071-0006	SEAT, CO PILOT W/OUT HEADREST	25
3A090-0015	CREW SEAT ASSEMBLY	25
3A090-0015	CREW SEAT ASSEMBLY	25
3A090-0016	CREW SEAT ASSEMBLY	25
3A090-0016	CREW SEAT ASSEMBLY	25
3A090-0025	CREW SEAT ASSEMBLY	25
3A090-0026	CREW SEAT ASSEMBLY	25
3A090-0077	CREW SEAT ASSEMBLY	25
3A090-0077	CREW SEAT ASSEMBLY	25
3A090-0078	CREW SEAT ASSEMBLY	25
3A090-0078	CREW SEAT ASSEMBLY	25
3A102-0003	CREW SEAT ASSEMBLY	25
3A201-0007	ACTUATOR ASSEMBLY	25
3A201-0008	ACTUATOR ASSEMBLY	25
3A226-0007	CREW SEAT ASSEMBLY	25
3A226-0008	CREW SEAT ASSEMBLY	25
3A254-0007	CREW SEAT	
3A254-0007	CREW SEAT	25
3A254-0008	CREW SEAT	
3A254-0008	CREW SEAT	25
3A254-0012	CREW SEAT	25
3A254-0051	CREW SEAT	25
3A254-0052	CREW SEAT	25
3A258-0007	CREW SEAT	25
3A258-0008	CREW SEAT	25
3A258-0041	CREW SEAT	25
3A258-0042	CREW SEAT	25
3A296-0007	CREW SEAT	25
3A296-0008	CREW SEAT	25

3B25-39780	TABLE, G1 FOLDING; NBA; A319	25
3B25-39780	TABLE, G1 FOLDING; NBA; A319	25
3B25-41844	TABLE, G1 FOLDING; NBA; A319	25
3B39-1B	ELECTRICAL LOAD CONTROL UNIT	25
3B39-1C	ELECTRICAL LOAD CONTROL UNIT	25
3B41-1A	ELECTRICAL LOAD CONTROL UNIT	29
3B41-1B	ELECTRICAL LOAD CONTROL UNIT	24
3B41-3A	ELECTRICAL LOAD CONTROL UNIT	29
3B41-3B	ELECTRICAL LOAD CONTROL UNIT	29
3B41-3C	ELECTRICAL LOAD CONTROL UNIT	
3C71-37598	ENGINE FAN CASE PRIMARY WIRING BUNDLE	71
3D25-37498	PANEL, FLOORBOARD, 232FF;	53
3D25-37498	PANEL, FLOORBOARD, 232FF;	53
3D25-37498	PANEL, FLOORBOARD, 232FF;	53
3D25-38273	DOOR, ROLLER, ASSY; GALLEY COMPT 5-3/4 &	25
3D25-38273	DOOR, ROLLER, ASSY; GALLEY COMPT 5-3/4 &	25
3D25-38273	DOOR, ROLLER, ASSY; GALLEY COMPT 5-3/4 &	25
3D25-38273	DOOR, ROLLER, ASSY; GALLEY COMPT 5-3/4 &	25
3D25-38273	DOOR, ROLLER, ASSY; GALLEY COMPT 5-3/4 &	25
3D25-38273	DOOR, ROLLER, ASSY; GALLEY COMPT 5-3/4 &	25
3D25-38273	DOOR, ROLLER, ASSY; GALLEY COMPT 5-3/4 &	25
3D25-38273	DOOR, ROLLER, ASSY; GALLEY COMPT 5-3/4 &	25
3D25-38273	DOOR, ROLLER, ASSY; GALLEY COMPT 5-3/4 &	25
3D25-38721	PANEL, CARGO COMPARTMENT, DECOMPRESSION,	25
3D25-38721	PANEL, CARGO COMPARTMENT, DECOMPRESSION,	25
3U3323-1	CYLINDER HORIZ STAB, ELEVATOR CONTROL	27
40006-0000	EEC SPEED TRANSDUCER	77
400300-1	VALVE SHUTOFF MOTOR ACTIVATED	38
400300-2	VALVE SHUTOFF MOTOR ACTIVATED	38
4005123-90	ELECTRICAL ALTIMETER	34
400800-1	OVEN ASSEMBLIES	25
401-9000-0	MODULE, LOGIC CONTROL	38
401-9000-4	LOGIC CONTROL MODULE	38

40192-1	COMPRESSOR, WATER, AIR	38
401EED1-1	STANDBY ENGINE INDICATOR	77
40250-1003	VALVE BRAKE METERING-STEEL DISC ALT 60B0	32
40250-1003	VALVE BRAKE METERING-STEEL DISC ALT 60B0	32
402EED1-1	STANDBY ENGINE INDICATOR	77
402EED1-3	STANDBY ENGINE INDICATOR	77
402EED2-1	STANDBY ENGINE INDICATOR	77
40340-1000	VALVE ASSEMBLY, LANDING GEAR SELECTOR	
40340-1000	VALVE ASSEMBLY, LANDING GEAR SELECTOR	32
40340-1001	VALVE ASSEMBLY, LANDING GEAR SELECTOR	32
40340-1001	VALVE ASSEMBLY, LANDING GEAR SELECTOR	32
4034233-90	SENSOR HORIZ STAB POSITIONER	22
4034233-90	SENSOR HORIZ STAB POSITIONER	22
4034234-90	FLIGHT MODE ANNUCIATOR	22
4034234-90	FLIGHT MODE ANNUCIATOR	22
4034240-90	PANEL CONTROL, VHF NAV STATIC SENSITIVE	34
4034241-97	COMPUTER, INSOURCE, CONTRACT PART,SET UP	22
4034241-97	COMPUTER, INSOURCE, CONTRACT PART,SET UP	22
4034241-97	COMPUTER, INSOURCE, CONTRACT PART,SET UP	22
4034241-97	COMPUTER, INSOURCE, CONTRACT PART,SET UP	22
4034242-91	PANEL, FLIGHT GUIDANCE, INSOURCE PART	22
4034242-97	PANEL, FLIGHT GUIDANCE, INSOURCE PART	22
4035022-90	CARD AUTO THROTTLE STATIC SENSITIVE	22
4035028-90	CARD A/P ENGAGE AND ELEVATOR SERVO AMPLI	22
4038170-90	CONTROL DISPLAY UNIT	34
4038170-90	CONTROL DISPLAY UNIT	34
4039891-90	MODEL SEI-800 AIRSPEED/MACH INDICATOR	34
4039891-90	MODEL SEI-800 AIRSPEED/MACH INDICATOR	34
4039892-90	BAROMETRIC ALTIMETER	34
4039892-90	BAROMETRIC ALTIMETER	34
4039892-90	BAROMETRIC ALTIMETER	34
4039893-90	MODEL VS-800 VERTICAL SPEEN INDICATOR	34

4039948-90	CARD DISCRETE I/O AND SERIAL DATA TEST	22
4040800-90	AIR DATA COMPUTER	34
4040800-90	AIR DATA COMPUTER	34
4040800-90	AIR DATA COMPUTER	34
4040800-91	AIR DATA COMPUTER	34
4040800-91	AIR DATA COMPUTER	34
4040800-91	AIR DATA COMPUTER	34
4040800-91	AIR DATA COMPUTER	34
4040800-91	AIR DATA COMPUTER	34
4040800-91	AIR DATA COMPUTER	34
4040831-90	AIR DATA COMPUTER PS/PT PRESSURE CONVERTER	34
4041-58	CEILING LIGHT	33
4042-10	CEILING LIGHT	33
4052500-92	FLIGHT MANAGEMENT COMPUTER SYSTEM	34
4052500-92	FLIGHT MANAGEMENT COMPUTER SYSTEM	34
4052500-94	FLIGHT MANAGEMENT COMPUTER SYSTEM	34
4052500-96	FLIGHT MANAGEMENT COMPUTER SYSTEM	34
4052500-96	FLIGHT MANAGEMENT COMPUTER SYSTEM	34
4052500-96	FLIGHT MANAGEMENT COMPUTER SYSTEM	34
4052504-92	PANEL, COMPUTER; DISPLAY UNIT STATIC SEN	34
4052504-92	PANEL, COMPUTER; DISPLAY UNIT STATIC SEN	34
4052504-92	PANEL, COMPUTER; DISPLAY UNIT STATIC SEN	34
4052506-94	FLIGHT MANAGEMENT COMPUTER	34
4052506-95	FLIGHT MANAGEMENT COMPUTER	34
4052854-10	CARD, COMPUTER ADVANCED FLIGHT MANAGEMEN	34
4052854-91	CARD, COMPUTER ADVANCED FLIGHT MANAGEMEN	34
4055900-90	UNIT DISPLAY STATIC SENSITIVE	34
4055900-90	UNIT DISPLAY STATIC SENSITIVE	34
4055900-90	UNIT DISPLAY STATIC SENSITIVE	34
4055911-90	UNIT DISPLAY STATIC SENSITIVE	34
4055911-90	UNIT DISPLAY STATIC SENSITIVE	34
4055971-91	UNIT DISPLAY STATIC SENSITIVE	34
4055971-91	UNIT DISPLAY STATIC SENSITIVE	34

4055971-91	UNIT DISPLAY STATIC SENSITIVE	34
4055972-91	UNIT DISPLAY STATIC SENSITIVE	34
4055972-91	UNIT DISPLAY STATIC SENSITIVE	34
4055972-91	UNIT DISPLAY STATIC SENSITIVE	34
4056510-90	UNIT DISPLAY STATIC SENSITIVE	
4056510-90	UNIT DISPLAY STATIC SENSITIVE	34
4056511-90	DIMMING CONTROL PANEL	34
4056511-90	DIMMING CONTROL PANEL	34
4057800-90	MACH AIRSPEED INDICATOR	34
4058000-90	PANEL, COMPUTER; DISPLAY UNIT STATIC SEN	34
4058000-90	PANEL, COMPUTER; DISPLAY UNIT STATIC SEN	34
4058000-90	PANEL, COMPUTER; DISPLAY UNIT STATIC SEN	34
4058000-90	PANEL, COMPUTER; DISPLAY UNIT STATIC SEN	34
4058254-90	PANEL THRUST RATING STATIC SENSITIVE	34
4058650-90	MULTIPURPOSE CONTROL DISPLAY UNIT	34
4058650-90	MULTIPURPOSE CONTROL DISPLAY UNIT	34
4058650-90	MULTIPURPOSE CONTROL DISPLAY UNIT	34
4058650-93	MULTIPURPOSE CONTROL DISPLAY UNIT	34
4058650-93	MULTIPURPOSE CONTROL DISPLAY UNIT	34
4058650-95	MULTIPURPOSE CONTROL DISPLAY UNIT	34
4059013-90	PANEL SYSTEM CONTROL, PEDESTAL STATIC SE	31
4059028-90	PANEL APU CONTROL STATIC SENSITIVE	49
4059060-90	COMPUTER AIR DATA, DIGITAL "RVSM CRITICA	34
4059845-91	COMPUTER WINDSHEAR, MODIFIED PER EO 2-70	34
405CH	BATTERY, A/C & APU, A330	24
405EED1-2	STANDBY ENGINE INDICATOR VOL 2	77
40-618-11	STAB TRIM INDICATOR	27
40-618-2	STAB TRIM INDICATOR	27
40-618-6	STAB TRIM INDICATOR	27
40-618-8	STAB TRIM INDICATOR	27
40-625-2	XDUCER, ANTI-SKID, DC9-30/40/50/80	32
40-625-5	XDUCER, ANTI-SKID, DC9-30/40/50/80	32

40-625-6	XDUCER, ANTI-SKID, DC9-30/40/50/80	32
40-625-8	XDUCER, ANTI-SKID, DC9-30/40/50/80	32
4063-18139	VALVE,CHECK;A330	21
4066010-91	TCAS COMPUTER UNIT	34
406EED1-1	STANDBY ENGINE INDICATOR	77
4073100-90	COMPUTER,DFGC ,RVSM CRITICAL	22
4073100-90	COMPUTER,DFGC ,RVSM CRITICAL	22
4073100-90	COMPUTER,DFGC ,RVSM CRITICAL	22
4073100-90	COMPUTER,DFGC ,RVSM CRITICAL	22
4073100-93	COMPUTER,DFGC ,RVSM CRITICAL	22
4073241-90	FLIGHT MANAGEMENT COMPUTER	34
4073241-92	FLIGHT MANAGEMENT COMPUTER	34
4073400-90	COMPUTER AUXILIARY CONTROL STATIC SENSIT	22
4073400-90	COMPUTER AUXILIARY CONTROL STATIC SENSIT	22
4073610-90	DISPLAY UNIT	31
4073610-90	DISPLAY UNIT	31
4073610-90	DISPLAY UNIT	31
4073610-91	DISPLAY UNIT	31
4073610-91	DISPLAY UNIT	31
4074730-90	COMPUTER AIR DATA "RVSM CRITICAL"	34
4074730-90	COMPUTER, AIR DATA "RVSM CRITICAL"	34
4077880-90	MULTIPURPOSE CONTROL DISPLAY UNIT	34
4077880-90	MULTIPURPOSE CONTROL DISPLAY UNIT	34
4077880-90	MULTIPURPOSE CONTROL DISPLAY UNIT	
4077880-90	MULTIPURPOSE CONTROL DISPLAY UNIT	34
4077880-91	MULTIPURPOSE CONTROL DISPLAY UNIT	
4077880-96	MULTIPURPOSE CONTROL DISPLAY UNIT	22
4077880-98	MULTIPURPOSE CONTROL DISPLAY UNIT	34
4081600-93	DISPLAY ELECTRONICS UNIT DIGITAL COMPUTER	31
4081600-94	DISPLAY ELECTRONICS UNIT DIGITAL COMPUTER	31
4082170-91	UNIT, DISPLAY; LIQUID CRYSTAL	31
4082260-93	MODE CONTROL PANEL	22

4082260-93	MODE CONTROL PANEL	22
4082499-90	FLIGHT CONTROL COMPUTER	22
4082499-90	FLIGHT CONTROL COMPUTER	22
4082730-90	ELECTRONIC FLIGHT INSTRUMENT SYSTEM CONTROL P	34
4086850-92	UNIT, FLT INFO DSPLY, FLAT PANEL, USD	31
4086850-92	UNIT, FLT INFO DSPLY, FLAT PANEL, USD	31
4087440-92	UNIT, FLT INFO DSPLY, FLAT PANEL, USD	31
4091900-93	PHASE 3 DISPLAY UNIT	31
4091900-94	PHASE 3 DISPLAY UNIT	31
4091900-94	PHASE 3 DISPLAY UNIT	31
41000740-1	VALVE THRUST REVERSER HYD CONTROL FUSELA	78
4100-100R	RADOME ASSEMBLY	34
4100310-4	PUMP HYD TRANSFER NOT MODIFIED PER EO	29
4100310-5	PUMP HYD TRANSFER NOT MODIFIED PER EO	29
4100310-6	PUMP HYD TRANSFER NOT MODIFIED PER EO	29
4100310-7	PUMP HYD TRANSFER NOT MODIFIED PER EO	29
4100406-1	HYDRAULIC MOTOR	27
4100406-2	HYDRAULIC MOTOR	27
4100720-1	ROTOR, HOUSING, ELECTRONIC FWD COMPT..	21
4100941A	SWITCH PACK SHUTDOWN SHIP IN ATA SPEC 30	21
4100941B	SWITCH PACK SHUTDOWN SHIP IN ATA SPEC 30	21
4100941C	SWITCH PACK SHUTDOWN SHIP IN ATA SPEC 30	21
4100941D	SWITCH PACK SHUTDOWN SHIP IN ATA SPEC 30	21
4100945A	MOTOR DRIVEN FAN	21
4101041A	ROTOR, HOUSING, ELECTRONIC FWD COMPT..	21
411-0001-1	COFFEE MAKER	25
411-0001-1	COFFEE MAKER	25
411-0001-1	COFFEE MAKER	25
4110302-4	AIR TURBINE DRIVEN HYDRAULIC PUMP	29
4110302-5	AIR TURBINE DRIVEN HYDRAULIC PUMP	29
4110302-6	AIR TURBINE DRIVEN HYDRAULIC PUMP	29
4110302-7	AIR TURBINE DRIVEN HYDRAULIC PUMP	29

4120T04P01	PUMP, FUEL	73
4120T14P02	ACCELEROMETER, VIBRATION ACCELEROMETER W	77
4120T21P03	W7 AIRCRAFT (GRAY) - CF34-8	73
4120T21P04	W7 AIRCRAFT (GRAY) - CF34-8	73
4120T24P04	W7 AIRCRAFT (GRAY) - CF34-8	77
412N1140-2	DOOR O/H STOWAGE COMPT 60IN USED ON A/C	25
412N1155-2	OVERHEAD STOWAGE COMPARTMENT ASSEMBLY	25
412N1155-3	OVERHEAD STOWAGE COMPARTMENT ASSEMBLY	25
412N1155-8	OVERHEAD STOWAGE COMPARTMENT ASSEMBLY	25
413T1024-2	LATCH OUTBD OVERHD STOWAGE BIN DOOR	25
413T1045-1	TUBE OVERHEAD TORQUE, USED ON A/C 101-13	25
413T1045-1	TUBE OVERHEAD TORQUE, USED ON A/C 101-13	25
4142T52P04	W7 AIRCRAFT (GRAY) - CF34-8	73
4142T52P05	W7 AIRCRAFT (GRAY) - CF34-8	73
4142T55P03	W7 AIRCRAFT (GRAY) - CF34-8	73
415110-1	WARMER, BUN, UPPER DECK GALLEY	25
415110-101	WARMER, BUN, UPPER DECK GALLEY	25
415110-3	WARMER, BUN, UPPER DECK GALLEY	25
415110-301	WARMER, BUN, UPPER DECK GALLEY	25
415-1675	WINDOW AND PITOT HEAT MODULE ASSEMBLY	30
415-654	SEAT, INSOURCE CUSTOMER NWA FOR TRACKING	76
416-0001-2	FRESH BREW COFFEEMAKER	25
4163DA	VALVE FLAP CONTROL L/E LIFT AUGMENTING,	27
4165X	RADOME FUSELAGE NOSE, WHITE, USD ON A/C..	53
416T2811-1	INTEGRTR ASSY RH POST OFF WING ESCAPE SY	25
416T2811-1	INTEGRTR ASSY RH POST OFF WING ESCAPE SY	25
4177-0108-5	FUEL MEASURING STICK FLEXI-STICK ASSEMBLY	28
417A2093-1	WASTE WATER DRAIN MAST AY	38
417A2093-2	WASTE WATER DRAIN MAST AY	38
417A2093-4	WASTE WATER DRAIN MAST AY	38
417A2093-5	WASTE WATER DRAIN MAST ASSEMBLY	38
417A2093-6	WASTE WATER DRAIN MAST AY	38

417A2093-7	WASTE WATER DRAIN MAST AY	38
417A6110-6	ATTENDANT PANEL ASSEMBLY	31
417A6110-6	ATTENDANT PANEL ASSEMBLY	31
417N2117-1	MAST, DRAIN, ASSY	38
417N2117-4	MAST, DRAIN, ASSY	38
417N2117-5	MAST, DRAIN, ASSY	38
417N2117-7	MAST, DRAIN, ASSY	38
417N2117-8	MAST, DRAIN, ASSY	38
417N6002-8	PANEL,ATTENDANT, FWD.MOD.PER DWG 23-0415	31
417N6002-8	PANEL,ATTENDANT, FWD.MOD.PER DWG 23-0415	31
417t1303-2	VACUUM TOILET ASSEMBY	
417T1303-3	TOILET, LAVATORY, VACUUM FLUSH	38
417T1351-1	ELBOW, AFT VACUUM WASTE TANK	38
417T2093-1	WASTE WATER DRAIN MAST ASSEMBLY	38
417T2093-1	MAST, DRAIN, ASSY	38
417T2093-8	MAST, DRAIN, ASSY	38
417T6008-4	PANEL ATTENDANTS-FWD PASS LOADING LIGHTS	33
417T6010-6	AFT ATTENDANT'S PANEL ASSEMBLY	33
417T6024-1	INTERPHONE HANDSET CRADLE	23
417T6024-1	INTERPHONE HANDSET CRADLE	23
417T6024-1	INTERPHONE HANDSET CRADLE	23
418-00044	OIL PRESSURE TRANSMITTER	79
418-01104	OIL PRESSURE TRANSMITTER	79
418-01114	NBR 4 BEARING OIL PRESSURE TRANSMITTER	79
418-01124	OIL PRESSURE TRANSMITTER	79
418-04124	TRNSMTTR, OIL/FUEL PRESSURE	79
418-05124	TRNSMTTR, OIL/FUEL PRESSURE	79
418-06124	TRNSMTTR, OIL/FUEL PRESSURE	79
418-08104	OIL PRESSURE TRANSMITTER	79
418-09104	OIL PRESSURE TRANSMITTER	79
418-15054	FUEL PRESSURE TRANSMITTER	73
418-16054	DIFFERENTIAL OIL PRESSURE TRANSMITTER	79

41F1004	LUBRICATION UNIT	79
41F1005	LUBRICATION UNIT	79
41F1204	ELECTRONIC CHIP DETECTOR	79
41F1205	ELECTRONIC CHIP DETECTOR	79
41F1303	ELECTRONIC CHIP DETECTOR	79
41F1304	ELECTRONIC CHIP DETECTOR	79
41F5102	OIL TANK	79
41P1018-7	HOUSING, LURICATION UNIT(TRACKING ONLY)	79
41SG118-1	PRESSURE TRANSDUCER	21
41SG240-3	TRNSMTTR OIL PRESSURE MUST BE USABLE ON	79
420085-3	W1 AND W2 EEC HARNESS - PW4000	77
420085-5	W1 AND W2 EEC HARNESS - PW4000	73
420086-3	W1 AND W2 EEC HARNESS - PW4000	73
420087-3	W1 AND W2 EEC HARNESS - PW4000	73
420087-5	W1 AND W2 EEC HARNESS - PW4000	73
420088-3	W1 AND W2 EEC HARNESS - PW4000	71
420437-3	W1 AND W2 EEC HARNESS - PW4000	72
420438-3	W1 AND W2 EEC HARNESS - PW4000	73
42-091	CONTROL SPOILER, AUTOMATIC	27
42-091-1	CONTROL SPOILER, AUTOMATIC	27
42-091-1A	CONTROL SPOILER, AUTOMATIC	27
42-091-3	CONTROL SPOILER, AUTOMATIC	27
425-3	LIGHTPLATE	52
4-254-02	BATTERY CHARGER	24
4-254-02MC	BATTERY CHARGER	24
4-254-03	BATTERY CHARGER	24
4-254-04	BATTERY CHARGER	24
42-629	ANTI-SKID/AUTO-BRAKE CONTROL UNIT	32
42-629-1	ANTI-SKID/AUTO-BRAKE CONTROL UNIT	32
42-629-2	ANTI-SKID/AUTO-BRAKE CONTROL UNIT	32
42-641-1	ANTISKID/AUTOBRAKE CONTROL UNIT	32
42-641-2	ANTISKID/AUTOBRAKE CONTROL UNIT	32

4-273-02	TRANSFORMER-RECTIFIER	24
4-273-03	TRANSFORMER-RECTIFIER	24
42-757-1	ANTISKID/AUTOBRAKE CONTROL UNIT	32
42-767-1	ANTI-SKID/AUTO-BRAKE CONTROL UNIT	32
42-767-2	ANTI-SKID/AUTO-BRAKE CONTROL UNIT	32
42-807	PANEL AUTOBRAKE CONTROL SHIP IN ATA SPEC	32
42-809-3	COMPUTER AUTOBRAKE	32
42-831	PANEL AUTOBRAKE CONTROL SHIP IN ATA SPEC	32
42-877-1	ANTI-SKID/AUTO-BRAKE CONTROL UNIT	32
42-935-2	UNIT, ANTI-SKID CONTROL, BRAKES	32
42D109-1A	SWITCH OIL, Do not use per EA49-517127-14	79
42D115	SWITCH, ICE PROTECTION, DIFF PRESS	30
42D131-1	SWITCH ASSY - FUEL PRESSURE	28
42D185	TRNSMTTR ENGINE FUEL FLOW FURNISHED WITH	73
42D362	FUEL PUMP FILTER PRESSURE SWITCH - PW2000, PW40	73
42D395	FUEL PUMP FILTER PRESSURE SWITCH - PW2000, PW40	73
42G114-1	SWITCH, ICE PROTECTION, PRESS, TAIL	30
42G304	SWITCH, ICE PROTECTION, HIGH PRESS	30
43104-14	UNIT, POWER DRIVE, CARGO HANDLING - PRE	
43104-15	UNIT, POWER DRIVE, CARGO HANDLING - PRE	25
43104-20	UNIT, POWER DRIVE, CARGO HANDLING - PRE	25
43-1-1100	ACTUATOR, APU, AIR INLET	49
4311500-00	DUAL CAVITY OVEN	25
4311501-00	DUAL CAVITY OVEN	25
4312300-90	WARMER, BUN,	25
4313100-01	OVEN, CONVECTION, LH HINGED; HAL A330	25
4315000-00	OVEN, DF1575 CONVECTION OVEN	25
4315750-00	OVEN, DF1575 CONVECTION OVEN	25
4315751-00	OVEN, DF1575 CONVECTION OVEN	25
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	30
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	29
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	24

433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	21
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	31
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	26
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	26
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	26
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	24
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	36
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	36
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	34
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	24
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	36
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	32
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	33
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	21
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	29
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	73
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	34
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	24
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	21
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	34
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	34
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	21
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	27
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	27
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	24
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	24
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	24
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	30
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	30
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	36
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	36
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	32

433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	32
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	22
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	22
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	22
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	29
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	28
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	28
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	28
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	28
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	28
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	24
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	24
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	28
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	28
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	30
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	30
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	36
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	36
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	24
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	24
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	34
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	34
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	29
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	29
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	28
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	28
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	35
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	35
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	35
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	33
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	33
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	24

433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	24
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	24
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	24
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	21
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	21
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	31
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	31
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	26
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	26
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	26
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	26
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	26
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	24
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	24
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	36
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	36
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	36
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	34
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	34
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	24
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	24
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	28
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	28
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	32
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	33
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	33
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	21
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	21
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	29
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	29
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	73
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	73

433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	34
4336731004	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	24
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	24
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	21
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	34
433-673-10	LIGHTED PUSHBUTTON SWITCH INDICATOR ASSEMBLY	21
434-674-10	INCANDESCENT LAMP DIMMER	34
434-674-10	INCANDESCENT LAMP DIMMER	30
434-674-10	INCANDESCENT LAMP DIMMER	31
434-674-10	INCANDESCENT LAMP DIMMER	29
434-674-10	EQUIPMENT COOLING PANEL ASSEMBLY	30
434-674-10	INCANDESCENT LAMP DIMMER	31
434-674-10	INCANDESCENT LAMP DIMMER	31
434-674-10	INCANDESCENT LAMP DIMMER	33
4372-505	BOX GEAR, HORIZONTAL STABILIZER DRIVE RE	27
4372-507	BOX GEAR, HORIZONTAL STABILIZER DRIVE RE	27
4383100-01	CONTROL, OVEN MODULE	25
44933-1	IGNITION EXCITER	74
44A3-1A	SWITCH ANEROID, CABIN AIR CONDITIONING	21
44A3-5	SWITCH ALTERNATE MASK RELEASE ALT 44A3-5	35
45-0057-1	LIGHT, LANDING, RETRACTABLE; A319/A320	33
45-0057-11	LIGHT, LANDING, RETRACTABLE	34
45-0057-3	LIGHT, LANDING, RETRACTABLE; A319/A320	33
45-0057-9	LIGHT, LANDING, RETRACTABLE; A319/A320	33
45080-1	HYDRAULIC SOLENOID VALVE ASSEMBLY	27
4510-22UFC	DISPENSER, COFFEE MAKER	25
4510-25UFC	BEVERAGE MAKER	25
451T1003-3	TRAY ASSY, CONVEYOR, AFT CARGO HANDLING	25
451W1370-3	ROLLER GUIDE FWD CARGO COMPT CARGO HDLG	25
451W3220-3	TRAY ASSY, CONVEYOR, AFT CARGO HANDLING	25
451W4169-3	ROLLER GUIDE FWD CARGO COMPT CARGO HANDL	25
451W4169-3	STOP CARGO HANDLING, STOP AND LOCK ASSY,	25

4521-2222-	BOILER, WATER BOILER ENDURA, B/E	25
4527-1	RELIEF BALANCED OUTLET VALVE	27
452T1003-7	TRAY ASSY, CONVEYOR, AFT CARGO HANDLING	25
452T1016-2	LOCK, CARGO,HANDLING COMPT,USED ON A/C 1	25
452T1021-2	STOP PARTIAL LOAD, FWD CARGO COMPT, USED	25
452T1021-3	STOP ASSY, AFT COMPT CARGO LOAD HANDLING	25
452T1030-4	STOP, FWD CARGO HANDLING,USED ON A/C 116	25
452T1037-1	STOP LOAD, FWD AND AFT COMPT CARGO HANDL	25
452T1040-1	STOP PARTIAL LOAD, CARGO HANDLING	25
452T1053-1	LOCK, PARTIAL LOAD STOP,CARGO HANDLING	25
452T1104-1	STOP ASSY, AFT COMPT CARGO LOAD HANDLING	25
452T1104-1	STOP ASSY, AFT COMPT CARGO LOAD HANDLING	25
452T1104-7	LOCK CARGO HANDLING, FWD COMPT USED ON A	25
452T1104-8	STOP ASSY, AFT COMPT CARGO LOAD HANDLING	25
452T1141-3	LOCK, CARGO, HANDLING PALLET,USED ON A/C	25
452T1201-8	STOP CARGO HANDLING, STOP AND LOCK ASSY,	25
452T1202-8	STOP CARGO HANDLING, STOP AND LOCK ASSY,	25
452T1603-1	STOP, CARGO, INSOURCE CUSTOMER	25
452T1603-1	STOP, CARGO, INSOURCE CUSTOMER	
452T1603-1	STOP, CARGO, INSOURCE CUSTOMER	
452T1603-2	STOP, CARGO, INSOURCE CUSTOMER	25
452T1603-2	STOP, CARGO, INSOURCE CUSTOMER	25
452T1603-2	STOP, CARGO, INSOURCE CUSTOMER	25
452T1603-2	STOP, CARGO, INSOURCE CUSTOMER	25
452T1603-2	STOP, CARGO, INSOURCE CUSTOMER	25
452T1603-2	STOP, CARGO, INSOURCE CUSTOMER	25
452T1603-2	STOP, CARGO, INSOURCE CUSTOMER	25
452T1603-2	STOP, CARGO, INSOURCE CUSTOMER	25
452T1603-3	STOP, CARGO, INSOURCE CUSTOMER	25
452T1603-3	STOP, CARGO, INSOURCE CUSTOMER	25
452T1603-3	STOP, CARGO, INSOURCE CUSTOMER	25
452T1603-3	STOP, CARGO, INSOURCE CUSTOMER	25
452T2103-4	ROLLER GUIDE FWD CARGO COMPT CARGE HDLG	25
452T2103-8	ROLLER GUIDE FWD CARGO COMPT CARGE HDLG	25

452T2107-1	ROLLER GUIDE FWD CARGO COMPT CARGO HANDL	25
452T2301-1	GUIDE AUXILIARY CARGO HANDLING USED ON A	25
452T2301-1	GUIDE AUXILIARY CARGO HANDLING USED ON A	25
452T2301-1	GUIDE AUXILIARY CARGO HANDLING USED ON A	25
452T2301-1	GUIDE AUXILIARY CARGO HANDLING USED ON A	25
452T2301-1	GUIDE AUXILIARY CARGO HANDLING USED ON A	25
452T2633-1	GUIDE,EASY FWD CARGO,FOR HAWAIIAN AIR	25
452T2633-1	GUIDE,EASY FWD CARGO,FOR HAWAIIAN AIR	25
452T2633-1	GUIDE,EASY FWD CARGO,FOR HAWAIIAN AIR	25
452T2633-1	GUIDE,EASY FWD CARGO,FOR HAWAIIAN AIR	25
452T2633-1	GUIDE,EASY FWD CARGO,FOR HAWAIIAN AIR	25
452T2633-1	GUIDE,EASY FWD CARGO,FOR HAWAIIAN AIR	25
452T2633-2	GUIDE,EASY FWD CARGO,FOR HAWAIIAN AIR	25
452T2633-2	GUIDE,EASY FWD CARGO,FOR HAWAIIAN AIR	25
452T2633-2	GUIDE,EASY FWD CARGO,FOR HAWAIIAN AIR	25
452T2633-2	GUIDE,EASY FWD CARGO,FOR HAWAIIAN AIR	25
452T2633-2	GUIDE,EASY FWD CARGO,FOR HAWAIIAN AIR	25
452T2633-2	GUIDE,EASY FWD CARGO,FOR HAWAIIAN AIR	25
452T2633-2	GUIDE,EASY FWD CARGO,FOR HAWAIIAN AIR	25
452T2633-2	GUIDE,EASY FWD CARGO,FOR HAWAIIAN AIR	25
452T2633-3	GUIDE,EASY FWD CARGO,FOR HAWAIIAN AIR	25
452T2633-3	GUIDE,EASY FWD CARGO,FOR HAWAIIAN AIR	25
452T2633-3	GUIDE,EASY FWD CARGO,FOR HAWAIIAN AIR	25
452T2633-3	GUIDE,EASY FWD CARGO,FOR HAWAIIAN AIR	25
452T2633-3	GUIDE,EASY FWD CARGO,FOR HAWAIIAN AIR	25
452T2633-3	GUIDE,EASY FWD CARGO,FOR HAWAIIAN AIR	25
452T2633-3	GUIDE,EASY FWD CARGO,FOR HAWAIIAN AIR	25
452T2633-5	GUIDE,EASY FWD CARGO,FOR HAWAIIAN AIR	25
452T2633-7	GUIDE,EASY FWD CARGO,FOR HAWAIIAN AIR	25
452T3216-1	STRUT ASSY FWD, BULK BIN BARRIER	52
452T3216-1	STRUT ASSY FWD, BULK BIN BARRIER	52
453N1624-1	GRILLE, AFT CARGO COMPT BHD LINING	25
453N1624-1	GRILLE, AFT CARGO COMPT BHD LINING	25
453N1624-1	GRILLE, AFT CARGO COMPT BHD LINING	25
453N1624-1	GRILLE, AFT CARGO COMPT BHD LINING	25

453N1624-8	GRILLE, AFT CARGO COMPT BHD LINING	25
4550-01	DETECTOR, FIRE, APU	26
4550-01-48	DETECTOR, FIRE, APU	26
4567-2	BOARD ASSY, ELECTRONIC CONTROL (PCI)	25
45D16	SWITCH CLIMB PRESS....	21
45D16-1	SWITCH CLIMB PRESS....	21
4-60000H88	MAST, DRAIN; FWD/AFT.	38
4-60000H88	MAST, DRAIN; FWD/AFT.	38
4-60000H88	MAST, DRAIN; FWD/AFT.	38
4-60001H88	MAST, DRAIN; FWD/AFT.	38
46224-5	W1 AND W2 EEC HARNESS - PW4000	71
46228-5	W1 AND W2 EEC HARNESS - PW4000	73
46243-3	W1 AND W2 EEC HARNESS - PW4000	71
46244-3	W1 AND W2 EEC HARNESS - PW4000	71
4626-1	PRIORITY HYDRAULIC VALVE	27
46289-4	MOTOR DRIVEN FAN	21
46460-5	W1 AND W2 EEC HARNESS - PW4000	73
46461-3	W1 AND W2 EEC HARNESS - PW4000	71
46461-5	W1 AND W2 EEC HARNESS - PW4000	73
46462-5	W1 AND W2 EEC HARNESS - PW4000	73
46463-3	W1 AND W2 EEC HARNESS - PW4000	71
46465-1	W6 EEC HARNESS - PW4000	77
47215920B1	COMPUTER, PROBE HEAT, A319/A32	30
472266-01	CABIN SMOKE DETECTION SYSTEM KTA	26
472568-1	ENGINE FIRE AND OVERHEAT LOWER DETECTOR	26
472582-1	ENGINE FIRE AND OVERHEAT LOWER DETECTOR	26
472583-1	ENGINE FIRE AND OVERHEAT LOWER DETECTOR	26
472584-1	ENGINE FIRE AND OVERHEAT LOWER DETECTOR	26
473108-02	DUCTED SMOKE DETECTOR ASSEMBLY	26
473597-5	SMOKE DETECTOR ASSEMBLY	26
473957-1	FIRE EXTINGUISHER CONTAINERS	26
473957-2	FIRE EXTINGUISHER CONTAINERS	26

473957-4	FIRE EXTINGUISHER CONTAINERS	26
473957-5	FIRE EXTINGUISHER CONTAINERS	26
473957-6	FIRE EXTINGUISHER CONTAINERS	26
473957-7	FIRE EXTINGUISHER CONTAINERS	
47649-1	IGNITION EXCITER	74
47649-2	IGNITION EXCITER	74
47649-3	IGNITION EXCITER	74
476W2220-	ATTENDANT HANDSET CRADLE ASSY	23
476W2220-	ATTENDANT HANDSET CRADLE ASSY	23
476W2220-	ATTENDANT HANDSET CRADLE ASSY	23
476W2220-	ATTENDANT HANDSET CRADLE ASSY	23
4777667-55	CYLINDER RUDDER THROW LIMITER	27
478W1610-	WASTE WATER DRAIN MAST ASSEMBLY	38
478W1610-	WASTE WATER DRAIN MAST ASSEMBLY	38
478W1610-	MAST, DRAIN, ASSY	38
4891417-03	WHEELCHAIR,ON-BOARD;ALL A/C..	25
4891417-3	WHEELCHAIR,ON-BOARD;ALL A/C..	25
4910-200	RADOME FUSELAGE NOSE, WHITE...	34
49-117-10	COMPUTER, SLAT/FLAP CONTROL	27
4913176-1	BLOCK WING FLAP HYD ACTUATING MECHANISM	27
4913176-50	BLOCK WING FLAP HYD ACTUATING MECHANISM	27
4914173-1	TUBE-TORQUE DRIVE ACME SCREW	27
4914978-1	TUBE-TORQUE DRIVE ACME SCREW	27
4916349-50	TUBE PSGR DOOR HOOK ACTUATOR	52
49-170-07	COMPUTER, SLAT/FLAP CONTROL	27
49-170-11	COMPUTER, SLAT/FLAP CONTROL	27
4928806-50	TUBE PSGR DOOR HOOK ACTUATOR	52
4935-100V1	RADOME, NOSE; A319/A320.	53
4935-100V2	RADOME, NOSE; A319/A320.	53
4935-200	RADOME, NOSE; A319/A320.	53
4935-201R	RADOME, NOSE; A319/A320.	53
4937-100	RADOME ASSEMBLY	53

4937-300	RADOME ASSEMBLY	53
4937-400	RADOME ASSEMBLY	53
5000047-01	CONTROL BLEED VALVE BUILT INTO CONVENIEN	75
5006003B	PUMP, FUEL BOOST,.MAY NOT BE INSTALLED A	28
5006003C	PUMP, FUEL BOOST,.MAY NOT BE INSTALLED A	28
5006003D	PUMPING UNIT ASSEMBLY	28
5006286F	PUMPING UNIT ASSEMBLY	28
5006286G	PUMPING UNIT ASSEMBLY	28
5006397G	GEARED ROTARY ACTUATOR	27
5006397J	GEARED ROTARY ACTUATOR	27
5006397K	GEARED ROTARY ACTUATOR	27
5006397KD	GEARED ROTARY ACTUATOR	27
5006397L	GEARED ROTARY ACTUATOR	27
5006397M	GEARED ROTARY ACTUATOR	27
5006397N	GEARED ROTARY ACTUATOR	27
5006397P	GEARED ROTARY ACTUATOR	27
5006397R	GEARED ROTARY ACTUATOR	27
5006398G	GEARED ROTARY ACTUATOR	27
5006398H	GEARED ROTARY ACTUATOR	27
5006398J	GEARED ROTARY ACTUATOR	27
5006398K	GEARED ROTARY ACTUATOR	27
5006398L	GEARED ROTARY ACTUATOR	27
5006398M	GEARED ROTARY ACTUATOR	27
5006398N	GEARED ROTARY ACTUATOR	27
5006834M	FUEL PUMP - CF6-80C2	73
500720-02L	BI-FOLD DOOR LATCH	25
500720-1U	BI-FOLD DOOR LATCH	25
500720-2U	BI-FOLD DOOR LATCH	25
5007246A	FUEL PUMP	73
5007246B	FUEL PUMP	73
5007436C	LUBRICATION AND SCAVENGE OIL PUMP	79
5007436J	LUBRICATION AND SCAVENGE OIL PUMP	79

5007436K	LUBRICATION AND SCAVENGE OIL PUMP	79
5010224A	FUEL PUMP	73
501735-1	HARNESS, W5 CORE	73
501740-1	HARNESS, W5 CORE	73
501930-1U	BI-FOLD DOOR LATCH ASSEMBLY	25
50470-100	SEAT,COCKPIT OBSERVERS	25
50470-105	SEAT,COCKPIT OBSERVERS	25
5049-1	AUDIO SELECT PANEL	23
5050T37G0	ACTUATOR, VG	72
5050T37G0	ACTUATOR, VG	72
505863-1	T3 SENSOR	72
5059-4	VALVE HYD BRAKE SHUTTLE SHIP IN ATA SPEC	32
505P044-01	FUEL DISTRIBUTION VALVE - PW2000	73
505P044-02	FUEL DISTRIBUTION VALVE - PW2000	73
505P044-03	FUEL DISTRIBUTION VALVE - PW2000	73
50648-1	WATER QUANTITY TRANSMITTER	38
50648-27	WATER QUANTITY TRANSMITTER	38
5068D100-3	ELECTROMECHANICAL ROTARY ACTUATOR	52
5068D100-5	ELECTROMECHANICAL ROTARY ACTUATOR	52
5068D100-7	ELECTROMECHANICAL ROTARY ACTUATOR	52
50A776	PROBE, EEC SPEED TRANSDUCER	73
50T241	IGNITION EXCITERS	74
50U391	EEC FUEL/ OIL TEMP PROBE - PW4000	73
50U413	OIL FILTER DIFFERENTIAL PRESSURE SWITCH	79
50U413-001	OIL FILTER DIFFERENTIAL PRESSURE SWITCH	79
510-0030-1	CORE COMPARTMENT COOLING VALVE - CF6-80C2	
510-0030-2	CORE COMPARTMENT COOLING VALVE - CF6-80C2	
510-0031-1	CORE COMPARTMENT COOLING VALVE - CF6-80C2	75
5-1211	HALON FIRE EXTINGUISHER	26
5142-1	SPEAKER INTRPHN, CAPT AND F/O, USED ON B	23
5145-1-42	AUDIO CONTROL PANE	23
5145-1-60	AUDIO CONTROL PANE	23

5145-1-61	AUDIO CONTROL PANE	23
5145-1-64	AUDIO CONTROL PANE	23
5145-1-77	AUDIO CONTROL PANE	23
516534-2	MOTOR RAM AIR DOOR, USED ON B767 A/C 101	21
516P636-01	FUEL DISTRIBUTION VALVE - PW2000	73
516P636-02	FUEL DISTRIBUTION VALVE - PW2000	73
516P636-02	FUEL DISTRIBUTION VALVE - PW2000	
519858-1	APU STARTER MOTOR	49
519858-3	APU STARTER MOTOR	49
519858-4	APU STARTER MOTOR	49
519858-5	APU STARTER MOTOR	49
519858-6	APU STARTER MOTOR	49
519858-7	APU STARTER MOTOR	49
519858-8	APU STARTER MOTOR	49
519858-X	APU STARTER MOTOR	
51G160	AIR/OIL HEAT EXCHANGER SWITCH - PW4000	75
51U710	HOSE ASSY, MAIN OIL FILTER	79
51VM1-3	FLOW INDICATOR	21
52-0378-50	WIRE USED ON A/C 982 AND SUBS AND A/C MO	52
528-70	LIGHT, NAV, RH; DUAL;	33
528-80	LIGHT, NAV, RH; DUAL;	33
52G225	DUAL 3-WAY PNEUMATIC SOLENOID AIR VALVE - PW4000	75
52G435	PNEUMATIC RELAY VALVE - PW4000	75
52G436	PNEUMATIC RELAY VALVE - PW4000	75
5345-1	PANEL, PANEL AUDIO SELECT	23
5-361-49	VALVE STATIC SELECTOR	34
53H629	TURBINE BLADE/VANE COOLING VALVE	75
53T733	CONNECTR ASSY.,SUPPLEMENTAL CONTROL UNI	73
53T814-005	HARNESS, W5 CORE	73
540-0565-1	VALVE TCA (PACK 94 ENGINES ONLY) POST SB	75
540-0715-1	SHUTOFF VALVE - CF6-80C2	75
540-0715-3	SHUTOFF VALVE - CF6-80C2	75

540-0774-1	VALVE TCA (PACK 94 ENGINES ONLY) POST SB	75
541674-4	RAM AIR MODULATION LINEAR ELECTROMECHANICAL A	21
54182-1	SENSOR, PRESSURE FUELING SYSTEM	28
5421-10-93	DETECTOR, FIRE, FAN.	26
5421-14-93	DETECTOR, FIRE, FAN.	26
548376-6	CABIN TEMPERATURE CONTROLLER	21
5485-064	ACTUATOR ENG SYNCHRONIZATION SHIP IN ATA	76
54A400-400	COUPLING AIR COND PAK ASSY	21
54A400-400	COUPLING AIR COND PAK ASSY	21
54H488	Valve turbine Vane Cooling	75
54T101-01	TUBE OIL COOLER	24
5500300-11	OUTBD AILERON LOCKOUT ACTUATOR ASSEMBLY	27
5500300-13	OUTBD AILERON LOCKOUT ACTUATOR ASSEMBLY	27
5500300-15	OUTBD AILERON LOCKOUT ACTUATOR ASSEMBLY	27
5500300-17	OUTBD AILERON LOCKOUT ACTUATOR ASSEMBLY	27
5500300-17	OUTBD AILERON LOCKOUT ACTUATOR ASSEMBLY	27
5500300-19	OUTBD AILERON LOCKOUT ACTUATOR ASSEMBLY	27
5500300-3	OUTBD AILERON LOCKOUT ACTUATOR ASSEMBLY	27
5500300-7	OUTBD AILERON LOCKOUT ACTUATOR ASSEMBLY	27
5500A1ABF	PORTABLE CYLINDER ASSEMBLIES	35
5500A1ABF	PORTABLE CYLINDER ASSEMBLIES	35
5500A1TBF	PORTABLE CYLINDER ASSEMBLIES	35
5500A6ABF	PORTABLE CYLINDER ASSEMBLIES	35
5500B1ACF	PORTABLE CYLINDER ASSEMBLIES	35
5500B6ACF	PORTABLE CYLINDER ASSEMBLIES	35
5500C1ABF	PORTABLE CYLINDER ASSEMBLIES	35
5500C1TBF	PORTABLE CYLINDER ASSEMBLIES	35
5500C6ABF	PORTABLE CYLINDER ASSEMBLIES	35
5570-01	FIRE AND OVERHEAT DETECTION SYSTEM	26
55H304	DUAL 3-WAY PNEUMATIC SOLENOID AIR VALVE - PW4000	75
5613217-50	WINDOW,CO-PILOTS CLEAR VIEW, RH STORE I	56
5613217-50	WINDOW,CO-PILOTS CLEAR VIEW, RH STORE I	56

5613217-50	WINDOW,CO-PILOTS CLEAR VIEW, RH STORE I	56
5613217-50	WINDOW, PILOTS CLEAR VIEW,LH STORE IN A	56
5613217-50	WINDOW,CO-PILOTS CLEAR VIEW, RH STORE I	56
5613217-51	WINDOW,CO-PILOTS CLEAR VIEW, RH STORE I	56
5613217-51	WINDOW,CO-PILOTS CLEAR VIEW, RH STORE I	56
5613217-51	WINDOW,CO-PILOTS CLEAR VIEW, RH STORE I	56
5613217-51	WINDOW,CO-PILOTS CLEAR VIEW, RH STORE I	56
5613217-51	WINDOW,CO-PILOTS CLEAR VIEW, RH STORE I	56
5613217-51	WINDOW, PILOTS CLEAR VIEW,LH STORE IN A	56
5613217-52	WINDOW,CO-PILOTS CLEAR VIEW, RH STORE I	56
56H247	BLEED AIR VALVE	75
57-0466-1	WING LEADING EDGE SLAT NO. 1 & 10 ASSEMBLIES	27
57-0466-10	WING LEADING EDGE SLAT NO. 1 & 10 ASSEMBLIES	27
57-0466-10	WING LEADING EDGE SLAT NO. 1 & 10 ASSEMBLIES	27
57-0466-10	WING LEADING EDGE SLAT NO. 1 & 10 ASSEMBLIES	27
57-0466-11	WING LEADING EDGE SLAT NO. 1 & 10 ASSEMBLIES	27
57-0466-11	WING LEADING EDGE SLAT NO. 1 & 10 ASSEMBLIES	27
57-0466-11	WING LEADING EDGE SLAT NO. 1 & 10 ASSEMBLIES	27
57-0466-11	WING LEADING EDGE SLAT NO. 1 & 10 ASSEMBLIES	27
57-0466-11	WING LEADING EDGE SLAT NO. 1 & 10 ASSEMBLIES	27
57-0466-11	WING LEADING EDGE SLAT NO. 1 & 10 ASSEMBLIES	27
57-0466-11	WING LEADING EDGE SLAT NO. 1 & 10 ASSEMBLIES	27
57-0466-11	WING LEADING EDGE SLAT NO. 1 & 10 ASSEMBLIES	27
57-0466-11	WING LEADING EDGE SLAT NO. 1 & 10 ASSEMBLIES	27
57-0466-11	WING LEADING EDGE SLAT NO. 1 & 10 ASSEMBLIES	27
57-0466-11	WING LEADING EDGE SLAT NO. 1 & 10 ASSEMBLIES	27
57-0466-12	WING LEADING EDGE SLAT NO. 1 & 10 ASSEMBLIES	27
57-0466-12	WING LEADING EDGE SLAT NO. 1 & 10 ASSEMBLIES	27
57-0466-12	WING LEADING EDGE SLAT NO. 1 & 10 ASSEMBLIES	27
57-0466-12	WING LEADING EDGE SLAT NO. 1 & 10 ASSEMBLIES	27
57-0466-12	WING LEADING EDGE SLAT NO. 1 & 10 ASSEMBLIES	27
57-0466-12	WING LEADING EDGE SLAT NO. 1 & 10 ASSEMBLIES	27
57-0466-12	WING LEADING EDGE SLAT NO. 1 & 10 ASSEMBLIES	27
57-0466-12	WING LEADING EDGE SLAT NO. 1 & 10 ASSEMBLIES	27
57-0466-12	WING LEADING EDGE SLAT NO. 1 & 10 ASSEMBLIES	27

57-0470-52	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	27
57-0470-53	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	27
57-0470-54	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	27
57-0470-55	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	27
57-0470-56	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	27
57-0470-59	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	27
57-0470-60	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	27
57-0470-61	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	27
57-0470-62	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	27
57-0470-63	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	27
57-0470-64	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	27
57-0470-67	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	27
57-0470-68	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	27
57-0470-7	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	27
57-0470-73	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	27
57-0470-74	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	27
57-0470-75	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	27
57-0470-76	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	27
57-0470-77	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	27
57-0470-78	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	27
57-0470-79	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	27
57-0470-8	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	27
57-0470-80	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	27
57-0470-80	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	27
57-0470-85	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	27
57-0470-86	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	27
57-0470-95	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	27
57-0470-96	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	27
57-0470-97	NO.5 AND 6 WING INBOARD LEADING EDGE SLAT ASSEM	27
570-487	FREQUENCY INDICATOR	24
570-713-00	CABLE LAVATORY, AFT, TOILET DRAIN, PULL,	38
570-713-01	CABLE LAVATORY, AFT, TOILET DRAIN, PULL,	38

570-713-02	CABLE, ASSY; VALVE; LAV K	38
570-713-02	CABLE LAVATORY, AFT, TOILET DRAIN, PULL,	38
570-713-17	CABLE, ASSY; VALVE; LAV K	38
570-713-17	CABLE, ASSY; VALVE; LAV K	38
57186-07	PUMP MOTOR PACKAGE	29
57186-10	PUMP MOTOR PACKAGE	29
57186-11	PUMP MOTOR PACKAGE	29
575-206-02	CABLE, POTABLE WATER	38
575-206-02	CABLE, POTABLE WATER	38
5756000-15	SENSOR STABILIZER WARNING CABLE MOTION	27
5758405-1	SWITCH,THROTTLE.LIMIT,RH;DC9-10/-30/.	22
5758405-50	SWITCH,THROTTLE.LIMIT,RH;DC9-10/-30/.	22
5758405-50	SWITCH,THROTTLE.LIMIT,RH;DC9-10/-30/.	22
5758405-51	SWITCH,THROTTLE.LIMIT,RH;DC9-10/-30/.	22
5758405-51	SWITCH,THROTTLE.LIMIT,RH;DC9-10/-30/.	22
5758405-52	SWITCH,THROTTLE.LIMIT,RH;DC9-10/-30/.	22
5758405-53	SWITCH,THROTTLE.LIMIT,RH;DC9-10/-30/.	22
5758405-53	SWITCH,THROTTLE.LIMIT,RH;DC9-10/-30/.	22
5765017-11	DAMPER RUDDER ALT 5765017-503 V8120	27
580-299-10	CABLE THROTTLE CONTROL PUSH-PULL ENGINE	78
580-299-10	CABLE THROTTLE CONTROL PUSH-PULL ENGINE	76
58120-1	ACTUATOR,THRUST REVERSER DOOR LH AND RH	78
58120-2	ACTUATOR,THRUST REVERSER DOOR LH AND RH	78
5830201-10	TURBINE CASE COOLING AIR VALVE ACTUATOR	75
5830201-10	TURBINE CASE COOLING AIR VALVE ACTUATOR	75
5830201-10	TURBINE CASE COOLING AIR VALVE ACTUATOR	75
5830201-11	TURBINE CASE COOLING AIR VALVE ACTUATOR	75
5830201-11	TURBINE CASE COOLING AIR VALVE ACTUATOR	75
5830202-10	TURBINE CASE COOLING AIR VALVE	75
5830202-10	TURBINE CASE COOLING AIR VALVE	75
5830202-10	TURBINE CASE COOLING AIR VALVE	75
5830203-10	TURBINE CASE COOLING AIR VALVE	73

5830205-10	NACELLE VENTILATION SHUTOFF VALVE	75
5830205-10	NACELLE VENTILATION SHUTOFF VALVE	75
5830212-10	COMPRESSOR BLEED VALVE ASSEMBLY	75
5830212-10	COMPRESSOR BLEED VALVE ASSEMBLY	75
5830212-10	COMPRESSOR BLEED VALVE ASSEMBLY	75
5840207-10	COMPRESSOR BLEED VALVE ASSEMBLY	75
5840207-10	COMPRESSOR BLEED VALVE ASSEMBLY	75
5880357-10	ACTUATOR TURBINE COOLING VALVE (PACK 94	75
5880357-10	ACTUATOR TURBINE COOLING VALVE (PACK 94	75
5910040-50	VANE. FLAP, RH; AFT MOVEABLE;	27
5910040-50	VANE. FLAP, RH; AFT MOVEABLE;	27
5910040-50	VANE. FLAP, RH; AFT MOVEABLE;	27
5910040-50	VANE. FLAP, RH; AFT MOVEABLE;	27
5910040-50	VANE. FLAP, RH; AFT MOVEABLE;	27
5910040-50	VANE. FLAP, RH; AFT MOVEABLE;	27
5910040-50	VANE. FLAP, RH; AFT MOVEABLE;	27
5910040-50	VANE. FLAP, RH; AFT MOVEABLE;	27
5910040-51	VANE. FLAP, RH; AFT MOVEABLE;	27
5910040-51	VANE. FLAP, RH; AFT MOVEABLE;	27
5910040-51	VANE. FLAP, RH; AFT MOVEABLE;	27
5910040-51	VANE. FLAP, RH; AFT MOVEABLE;	27
5910040-51	VANE. FLAP, RH; AFT MOVEABLE;	27
5910040-51	VANE. FLAP, RH; AFT MOVEABLE;	27
5910040-51	VANE. FLAP, RH; AFT MOVEABLE;	27
5910040-51	VANE. FLAP, RH; AFT MOVEABLE;	27
5910040-52	VANE. FLAP, RH; AFT MOVEABLE;	27
5910041-50	VANE. FLAP, RH; AFT MOVEABLE;	27
5910041-50	VANE. FLAP, RH; AFT MOVEABLE;	27
5910041-50	VANE. FLAP, RH; AFT MOVEABLE;	27
5910041-51	VANE. FLAP, RH; AFT MOVEABLE;	27
5910041-51	VANE. FLAP, RH; AFT MOVEABLE;	57
5910041-51	VANE. FLAP, RH; AFT MOVEABLE;	27
5910042-50	VANE. FLAP, RH; AFT MOVEABLE;	27
5910042-50	VANE. FLAP, RH; AFT MOVEABLE;	27
5910042-50	VANE. FLAP, RH; AFT MOVEABLE;	27

5910042-50	VANE. FLAP, RH; AFT MOVEABLE;	27
5910042-50	VANE. FLAP, RH; AFT MOVEABLE;	27
5910042-50	VANE. FLAP, RH; AFT MOVEABLE;	27
5910042-50	VANE. FLAP, RH; AFT MOVEABLE;	27
5910042-50	VANE. FLAP, RH; AFT MOVEABLE;	27
5910042-51	VANE. FLAP, RH; AFT MOVEABLE;	27
5910042-51	VANE. FLAP, RH; AFT MOVEABLE;	27
5910042-51	VANE. FLAP, RH; AFT MOVEABLE;	27
5910042-51	VANE. FLAP, RH; AFT MOVEABLE;	27
5910042-51	VANE. FLAP, RH; AFT MOVEABLE;	27
5910043-50	VANE. FLAP, RH; AFT MOVEABLE;	27
5910043-50	VANE. FLAP, RH; AFT MOVEABLE;	27
5910043-50	VANE. FLAP, RH; AFT MOVEABLE;	27
5910043-50	VANE. FLAP, RH; AFT MOVEABLE;	27
5910043-50	VANE. FLAP, RH; AFT MOVEABLE;	27
5910043-50	VANE. FLAP, RH; AFT MOVEABLE;	27
5910043-50	VANE. FLAP, RH; AFT MOVEABLE;	27
5910043-50	VANE. FLAP, RH; AFT MOVEABLE;	27
5910043-51	VANE, OTBD, RH ASSY	27
5910043-51	VANE. FLAP, RH; AFT MOVEABLE;	27
5910043-51	VANE, OTBD, RH ASSY	27
5910047-2	TAB, AILERON, CONTROL; RT; ALL DC9 A/C	57
5910047-50	TAB, AILERON, CONTROL; RT; ALL DC9 A/C	57
5910055-1	SPOILER..FLIGHT, LH; DC9/MD80 (SEE /FOR	27
5910055-2	SPOILER..FLIGHT, LH; DC9/MD80 (SEE /FOR	27
5910055-50	SPOILER..FLIGHT, LH; DC9/MD80 (SEE /FOR	27
5910055-50	SPOILER..FLIGHT, LH; DC9/MD80 (SEE /FOR	27
5910055-50	SPOILER..FLIGHT, LH; DC9/MD80 (SEE /FOR	27
5910055-50	SPOILER..FLIGHT, LH; DC9/MD80 (SEE /FOR	27
5910055-50	SPOILER..FLIGHT, LH; DC9/MD80 (SEE /FOR	27
5910055-50	SPOILER..FLIGHT, LH; DC9/MD80 (SEE /FOR	27
5910055-50	SPOILER..FLIGHT, LH; DC9/MD80 (SEE /FOR	27
5910055-50	SPOILER..FLIGHT, LH; DC9/MD80 (SEE /FOR	27

5910081-17	DOOR ENTRANCE, FWD, LH EQUIV 5910081-167	
5910081-18	HINGE PASS ENTRANCE DOOR SHIP IN ATA SPE	52
5910083-57	DOOR, RADIO COMPARTMENT, ASSY	52
5910084-14	DOOR,R1	52
5910084-15	DOOR,R1	52
5910084-16	DOOR,R1	52
5910084-17	DOOR,R1	52
5910084-17	DOOR,R1	52
5910084-18	DOOR,R1	52
5910084-19	DOOR,R1	52
5910084-21	DOOR,R1	52
5910090-65	DUCT RAM AIR AFT FUSELAGE	21
5910091-13	RADOME,FUSELAGE NOSE, WHITE, USED ON A/C	53
5910091-19	RADOME,FUSELAGE NOSE, WHITE, USED ON A/C	34
5910091-21	RADOME,FUSELAGE NOSE, WHITE, USED ON A/C	53
5910091-25	RADOME,FUSELAGE NOSE, WHITE, USED ON A/C	53
5910091-27	RADOME,FUSELAGE NOSE, WHITE, USED ON A/C	53
5910091-29	RADOME,FUSELAGE NOSE, WHITE, USED ON A/C	53
5910091-3	RADOME,FUSELAGE NOSE, WHITE, USED ON A/C	53
5910091-35	RADOME,FUSELAGE NOSE, WHITE, USED ON A/C	53
5910141-10	DOOR, INSOURCE FOR NWA	52
5910141-12	DOOR, INSOURCE FOR NWA	52
5910141-12	DOOR, INSOURCE FOR NWA	52
5910141-63	DOOR, INSOURCE FOR NWA	52
5910141-93	DOOR, INSOURCE FOR NWA	52
5910157-10	HINGE AFT & FWD CARGO COMPT DOOR	52
5910231-10	DUCT,WATER SEPARATOR TO CK VLV; RH	30
5910244-12	DUCT,WATER SEPARATOR TO CK VLV; RH	21
5910244-35	DUCT,WATER SEPARATOR TO CK VLV; RH	21
5910244-36	DUCT,WATER SEPARATOR TO CK VLV; RH	21
5910244-65	DUCT,WATER SEPARATOR TO CK VLV; RH	21
5910244-65	DUCT,WATER SEPARATOR TO CK VLV; RH	21

5912171-47	VANE, OTBD, RH ASSY	57
5912171-48	VANE, OTBD, RH ASSY	57
5912171-50	VANE, OTBD, RH ASSY	27
5912171-50	VANE, OTBD, RH ASSY	27
5912175-51	FAIRING HORIZ STAB UPPER RH SEND TO SHOP	55
5912175-52	FAIRING HORIZ STAB UPPER RH SEND TO SHOP	55
5912176-2	FAIRING,LOWER RH;HORIZONTAL STABILIZER;	55
5912176-50	FAIRING,LOWER RH;HORIZONTAL STABILIZER;	55
5912176-50	FAIRING,LOWER RH;HORIZONTAL STABILIZER;	55
5912176-50	FAIRING,LOWER RH;HORIZONTAL STABILIZER;	55
5912176-51	FAIRING,LOWER RH;HORIZONTAL STABILIZER;	55
5912176-51	FAIRING,LOWER RH;HORIZONTAL STABILIZER;	55
5912176-51	FAIRING,LOWER RH;HORIZONTAL STABILIZER;	55
5912176-51	FAIRING,LOWER RH;HORIZONTAL STABILIZER;	55
5912176-51	FAIRING,LOWER RH;HORIZONTAL STABILIZER;	55
5912287-50	VALVE CHECK, WATER SEPARTOR	21
5912287-50	VALVE COOLING FAN CHECK FOR TRACKING PUR	21
5912287-51	VALVE COOLING FAN CHECK FOR TRACKING PUR	21
5912287-51	VALVE COOLING FAN CHECK FOR TRACKING PUR	21
5912287-51	VALVE COOLING FAN CHECK FOR TRACKING PUR	21
5912287-52	VALVE COOLING FAN CHECK FOR TRACKING PUR	21
5912396-5	WIPER WINDSHIELD, RH, 68 DEG.STROKE	30
5912396-6	WIPER WINDSHIELD, RH, 68 DEG.STROKE	30
5912909-1	VALVE RUDDER SHUT-OFF	27
5912909-50	VALVE RUDDER SHUT-OFF	27
5913367-1	TAIL CONE DOOR	53
5913528-50	SUPPORT FLAP HINGE IDLER R/H SHIP IN ATA	57
5913528-50	SUPPORT FLAP HINGE IDLER R/H SHIP IN ATA	57
5913900-55	ACTUATOR, FLT SPOILER, DC9-30/-40/-50/MD	27
5913900-55	ACTUATOR, FLT SPOILER, DC9-30/-40/-50/MD	27
5913900-55	ACTUATOR, FLT SPOILER, DC9-30/-40/-50/MD	27
5913900-55	ACTUATOR, FLT SPOILER, DC9-30/-40/-50/MD	27
5913900-55	ACTUATOR, FLT SPOILER, DC9-30/-40/-50/MD	27

5913900-55	ACTUATOR, FLT SPOILER, DC9-30/-40/-50/MD	27
5914066-55	SPRING ASSY, RUDDER LOAD FEEL AND TRIM	27
5914066-55	SPRING ASSY, RUDDER LOAD FEEL AND TRIM	27
5914066-55	SPRING ASSY, RUDDER LOAD FEEL AND TRIM	27
5914066-55	SPRING ASSY, RUDDER LOAD FEEL AND TRIM	27
5914168-50	TUBE-TORQUE DRIVE ACME SCREW	27
5914169-50	TUBE-TORQUE DRIVE ACME SCREW	27
5914169-51	BALLSCREW, ACTUATOR, STABILIZER	27
5914170-1	TUBE-TORQUE DRIVE ACME SCREW	27
5914170-50	TUBE-TORQUE DRIVE ACME SCREW	27
5914296-51	VALVE NLG STEERING DUAL CONTROL	
5914296-55	VALVE NLG STEERING DUAL CONTROL	32
5914387-51	MECHANISM, RUDDER LIMITER,USED ON A/C 926	27
5914387-51	MECHANISM, RUDDER LIMITER,USED ON A/C 926	27
5914387-52	MECHANISM, RUDDER LIMITER,USED ON A/C 926	27
5914387-52	MECHANISM, RUDDER LIMITER,USED ON A/C 926	27
5914387-52	MECHANISM, RUDDER LIMITER,USED ON A/C 926	27
5914405-50	TUBE-TORQUE DRIVE ACME SCREW	27
5914552-50	SEAT, OBSERVERS, ALL DC9;	25
5914552-50	SEAT, OBSERVERS, ALL DC9;	25
5914552-51	SEAT, OBSERVERS, ALL DC9;	25
5914552-51	SEAT, OBSERVERS, ALL DC9;	25
5914552-51	SEAT, OBSERVERS, ALL DC9;	25
5914613-25	SUPPORT, DETECTOR	26
5914613-25	SUPPORT, DETECTOR	26
5914613-45	SUPPORT, DETECTOR	26
5914613-5	SUPPORT, DETECTOR	26
5914613-5N	SUPPORT, DETECTOR	26
5914694-11	DOOR ASSY	52
5914694-11	DOOR ASSY	52
5914694-3	DOOR ASSY	52
5914694-95	DOOR ASSY	52

5914984-1	HINGE, FWD; AFT NOSE GEAR DOOR;	32
5914984-2	HINGE, FWD; AFT NOSE GEAR DOOR;	32
5914984-40	HINGE, FWD; AFT NOSE GEAR DOOR;	32
5914984-50	HINGE, FWD; AFT NOSE GEAR DOOR;	32
5914984-50	HINGE, FWD; AFT NOSE GEAR DOOR;	32
5914984-50	HINGE, FWD; AFT NOSE GEAR DOOR;	32
5914984-50	HINGE, FWD; AFT NOSE GEAR DOOR;	32
5914984-50	HINGE, FWD; AFT NOSE GEAR DOOR;	32
5914984-50	HINGE, FWD; AFT NOSE GEAR DOOR;	32
5914984-50	HINGE, FWD; AFT NOSE GEAR DOOR;	32
5914984-50	HINGE, FWD; AFT NOSE GEAR DOOR;	32
5914984-50	HINGE, FWD; AFT NOSE GEAR DOOR;	32
5914984-50	HINGE, FWD; AFT NOSE GEAR DOOR;	32
5914984-51	HINGE, FWD; AFT NOSE GEAR DOOR;	32
5914984-51	HINGE, FWD; AFT NOSE GEAR DOOR;	32
5914984-51	DOOR NLG RH FORWARD SND TO SHP 380 UPO..	32
5914984-51	HINGE, FWD; AFT NOSE GEAR DOOR;	32
5914985-41	DOOR NLG RH FORWARD SND TO SHP 380 UPO..	
5914985-50	HINGE, FWD; AFT NOSE GEAR DOOR;	32
5914985-50	HINGE, FWD; AFT NOSE GEAR DOOR;	32
5914985-51	HINGE, FWD; AFT NOSE GEAR DOOR;	32
5914985-51	HINGE, FWD; AFT NOSE GEAR DOOR;	32
5914985-51	HINGE, FWD; AFT NOSE GEAR DOOR;	32
5914985-51	HINGE, FWD; AFT NOSE GEAR DOOR;	32
5914985-51	HINGE, FWD; AFT NOSE GEAR DOOR;	32
5914985-51	HINGE, FWD; AFT NOSE GEAR DOOR;	32
5914985-52	DOOR NLG RH FORWARD SND TO SHP 380 UPO..	32
5914985-52	DOOR NLG RH FORWARD SND TO SHP 380 UPO..	
5914985-53	DOOR NLG RH FORWARD SND TO SHP 380 UPO..	
5914985-53	DOOR NLG RH FORWARD SND TO SHP 380 UPO..	32
5914985-53	DOOR NLG RH FORWARD SND TO SHP 380 UPO..	32
5914985-53	DOOR NLG RH FORWARD SND TO SHP 380 UPO..	32
5914985-53	DOOR NLG RH FORWARD SND TO SHP 380 UPO..	32
5914985-53	DOOR NLG RH FORWARD SND TO SHP 380 UPO..	32
5915081-21	DOOR APU LEFT SIDE SHIP IN ATA SPEC 300.	52

5915081-21	DOOR APU LEFT SIDE SHIP IN ATA SPEC 300.	52
5915081-7	DOOR APU LEFT SIDE SHIP IN ATA SPEC 300.	52
5915793-10	ELBOW APU EXHAUST SYSTEM	49
5915793-11	ELBOW APU EXHAUST SYSTEM	49
5915793-16	ELBOW APU EXHAUST SYSTEM	49
5915793-18	ELBOW APU EXHAUST SYSTEM	49
5915793-21	ELBOW APU EXHAUST SYSTEM	49
5915793-9	ELBOW APU EXHAUST SYSTEM	49
5916083-50	VANE ASSY, UPPER;APU AIR INLET DOOR PANE	49
5916083-50	VANE ASSY, UPPER;APU AIR INLET DOOR PANE	49
5916083-50	VANE ASSY, UPPER;APU AIR INLET DOOR PANE	49
5916083-50	VANE ASSY, UPPER;APU AIR INLET DOOR PANE	49
5916083-50	VANE ASSY, UPPER;APU AIR INLET DOOR PANE	49
5916083-51	VANE ASSY, UPPER;APU AIR INLET DOOR PANE	49
5916083-51	VANE ASSY, UPPER;APU AIR INLET DOOR PANE	49
5916083-51	VANE ASSY, UPPER;APU AIR INLET DOOR PANE	49
5916083-52	VANE ASSY, UPPER;APU AIR INLET DOOR PANE	49
5916083-52	VANE ASSY, UPPER;APU AIR INLET DOOR PANE	49
5916083-52	VANE ASSY, UPPER;APU AIR INLET DOOR PANE	49
5916083-53	VANE ASSY, UPPER;APU AIR INLET DOOR PANE	49
5916333-51	VANE ASSY, UPPER;APU AIR INLET DOOR PANE	49
5916458-1	VANE ASSY, UPPER;APU AIR INLET DOOR PANE	49
5916460-55	VALVE LANDING GEAR CONTROL	32
5916460-55	VALVE LANDING GEAR CONTROL	32
5916460-55	VALVE LANDING GEAR CONTROL	32
5916460-55	VALVE LANDING GEAR CONTROL	32
5916460-55	VALVE LANDING GEAR CONTROL	32
5916506-11	VANE ASSY, UPPER;APU AIR INLET DOOR PANE	49
5916506-50	SHAFT APU AIR INLET ACTUATOR PACKAGE 1EA	49
5917267-55	VALVE VENTRAL STAIR CONTROL	52
5918027-31	TAB, ELEVATOR, CONTROL; RT; DC9-10 ONLY	27
5918125-1	DAMPER AILERON AND ELEVATOR MODIFIED PER	

5920336-1	SKID TAIL, ASSY	32
5920413-50	PLATE STATIC PORT "RVSM CRITICAL"	34
5920890-1	VANE. FLAP, RH; AFT MOVEABLE;	27
5920890-1N	VANE. FLAP, RH; AFT MOVEABLE;	27
5922500-1	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922500-2	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922500-50	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922500-50	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922500-50	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922500-50	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922500-50	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922500-50	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922500-50	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922500-50	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922500-50	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922500-51	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922500-51	SLAT,NO.2 R/H DC9-30/-40/-50	57
5922500-51	SLAT,NO.2 R/H DC9-30/-40/-50	57
5922500-51	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922500-52	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922500-52	SLAT,NO.2 R/H DC9-30/-40/-50	57
5922532-2	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922532-50	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922532-50	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922532-50	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922532-50	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922532-50	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922532-50	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922532-51	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922532-51	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922533-1	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922533-50	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922533-50	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922533-50	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922533-50	SLAT,NO.2 R/H DC9-30/-40/-50	27

5922533-50	SLAT,NO.2 R/H DC9-30/-40/-50	57
5922533-50	SLAT,NO.2 R/H DC9-30/-40/-50	57
5922533-50	SLAT,NO.2 R/H DC9-30/-40/-50	57
5922534-50	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922534-50	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922534-50	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922534-50	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922534-50	SLAT,NO.2 R/H DC9-30/-40/-50	57
5922534-50	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922534-51	SLAT,NO.2 R/H DC9-30/-40/-50	57
5922534-51	SLAT,NO.2 R/H DC9-30/-40/-50	57
5922534-51	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922535-50	SLAT,NO.2 R/H DC9-30/-40/-50	27
5922535-50	SLAT,NO.2 R/H DC9-30/-40/-50	27
5923142-50	RESERVOR MLG TORQUE ARM HYD DAMPER	32
5924037-51	DUCT RAM AIR AFT FUSELAGE	21
5924225-1	TUBE-TORQUE DRIVE ACME SCREW	27
5926059-50	FITTING ASSY.,CTR HINGE INB SPOILER (RH)	57
5926411-26	VANE. FLAP, RH; AFT MOVEABLE;	27
5928777-50	DOOR ASSY EXTERNAL POWER ACCESS	53
5930476-50	VANE, OTBD, RH ASSY	57
5930476-51	VANE, OTBD, RH ASSY	57
5930479-51	VANE, OTBD, RH ASSY	27
5930479-51	VANE, OTBD, RH ASSY	27
5930479-51	VANE, OTBD, RH ASSY	57
5930479-51	VANE, OTBD, RH ASSY	57
5930480-51	VANE, OTBD, RH ASSY	27
5930480-52	VANE, OTBD, RH ASSY	27
5930480-52	VANE, OTBD, RH ASSY	27
5930480-52	VANE, OTBD, RH ASSY	27
5930480-52	VANE, OTBD, RH ASSY	57
5930494-1	VANE,LH IB FLAP ASSY	27

5930494-2	VANE,LH IB FLAP ASSY	27
5930494-50	VANE,LH IB FLAP ASSY	27
5930494-50	VANE,LH IB FLAP ASSY	27
5930494-50	VANE,LH IB FLAP ASSY	27
5930494-50	VANE,LH IB FLAP ASSY	27
5930495-50	VANE,LH IB FLAP ASSY	27
5930495-50	VANE,LH IB FLAP ASSY	27
5930495-50	VANE,LH IB FLAP ASSY	27
5930495-50	VANE,LH IB FLAP ASSY	27
5930495-51	VANE,LH IB FLAP ASSY	27
5930496-50	VANE, OTBD, RH ASSY	27
5930496-50	VANE, OTBD, RH ASSY	27
5930496-50	VANE, OTBD, RH ASSY	27
5930496-51	VANE, OTBD, RH ASSY	27
5930497-2	TAB, ELEVATOR ANTI FLOAT,RH MUST BE USAB	55
5930497-40	TAB, ELEVATOR ANTI FLOAT,RH MUST BE USAB	55
5930497-50	TAB, ELEVATOR ANTI FLOAT,RH MUST BE USAB	55
5930497-50	TAB, ELEVATOR ANTI FLOAT,RH MUST BE USAB	55
5930557-50	TAB, ELEVATOR, CONTROL; RT; DC9-10 ONLY	55
5930557-50	TAB, ELEVATOR, CONTROL; RT; DC9-10 ONLY	55
5930557-50	TAB, ELEVATOR, CONTROL; RT; DC9-10 ONLY	55
5930557-50	TAB, ELEVATOR, CONTROL; RT; DC9-10 ONLY	55
5930583-23	DOOR, MLG RH	32
5930583-23	DOOR, MLG RH	32
5930583-25	DOOR, MLG RH	32
5930583-26	DOOR, MLG RH	32
5930583-26	DOOR.MLG.FUSELAGE, RH EQUIV 5930583-4002	
5930583-27	DOOR.MLG.FUSELAGE, RH EQUIV 5930583-4002	32
5930583-27	DOOR.MLG.FUSELAGE, RH EQUIV 5930583-4002	32
5930583-28	DOOR, MLG RH	32
5930583-28	DOOR.MLG.FUSELAGE, RH EQUIV 5930583-4002	32
5930583-28	DOOR, MLG RH	32

5930583-28	DOOR.MLG.FUSELAGE, RH EQUIV 5930583-4002	32
5930583-28	DOOR.MLG.FUSELAGE, RH EQUIV 5930583-4002	32
5930583-29	DOOR.MLG.FUSELAGE, RH EQUIV 5930583-4002	32
5930583-29	DOOR.MLG.FUSELAGE, RH EQUIV 5930583-4002	32
5930583-29	DOOR.MLG.FUSELAGE, RH EQUIV 5930583-4002	32
5930583-29	DOOR, MLG RH	32
5930583-30	DOOR, MLG RH	32
5930583-30	DOOR, MLG RH	32
5930583-30	DOOR, MLG RH	32
5930583-30	DOOR, MLG RH	32
5930583-30	DOOR, MLG RH	32
5930583-30	DOOR, MLG RH	32
5930583-40	DOOR.MLG.FUSELAGE, RH EQUIV 5930583-4002	
5930639-51	DOOR OIL, SERVICING	71
5930639-52	DOOR OIL, SERVICING	71
5930639-52	DOOR OIL, SERVICING	71
5930639-53	DOOR OIL, SERVICING	71
5930640-50	DOOR.ENGINE, AFT LOWER, RH MODIFIED UPON	71
5930640-50	DOOR.ENGINE, AFT LOWER, RH MODIFIED UPON	71
5930640-50	DOOR.ENGINE, AFT LOWER, RH MODIFIED UPON	71
5930640-50	DOOR.ENGINE, AFT LOWER, RH MODIFIED UPON	71
5930645-1	COWL, NOSE, LT & RT; MD88; HAS	71
5930645-50	COWL, NOSE, LT & RT; MD88; HAS	71
5930645-50	COWL, NOSE, LT & RT; MD88; HAS	71
5930649-50	DOOR,ENGINE, UPPER, LH SHIP IN CATEGORY	71
5930649-50	DOOR,ENGINE, UPPER, LH SHIP IN CATEGORY	71
5930649-50	DOOR,ENGINE, UPPER, LH SHIP IN CATEGORY	71
5930649-50	DOOR,ENGINE, UPPER, LH SHIP IN CATEGORY	71
5930649-50	DOOR,ENGINE, UPPER, LH SHIP IN CATEGORY	71
5930649-50	DOOR,ENGINE, UPPER, LH SHIP IN CATEGORY	71
5930976-50	VALVE, FLIGHT SPOILER,PRESSURE REDUCER,W	27
5930976-50	VALVE, FLIGHT SPOILER,PRESSURE REDUCER,W	27
5930976-50	VALVE, FLIGHT SPOILER,PRESSURE REDUCER,W	27

5930976-50	VALVE, FLIGHT SPOILER,PRESSURE REDUCER,W	27
5930976-50	VALVE, FLIGHT SPOILER,PRESSURE REDUCER,W	27
5930976-50	VALVE, FLIGHT SPOILER,PRESSURE REDUCER,W	27
5930976-50	SPOILER NUMBER 7 RH UPON RECEIPT SENT TO	57
5930976-51	SPOILER NUMBER 7 RH UPON RECEIPT SENT TO	57
5930976-51	SPOILER NUMBER 7 RH UPON RECEIPT SENT TO	57
5930976-51	SPOILER NUMBER 7 RH UPON RECEIPT SENT TO	57
5930976-51	SPOILER NUMBER 7 RH UPON RECEIPT SENT TO	57
5934212-50	CYLINDER ELEVATOR POWER CONTROL	27
5934212-55	CYLINDER ELEVATOR POWER CONTROL	27
5934425-73	ANTENNA VOR/LOC UPPER AND LOWER RH	34
5934425-75	ANTENNA VOR/LOC UPPER AND LOWER RH	34
5935212-50	BOX AUTO SPOILER SWITCHING UNIT	27
5935910-50	LINK ASSY, WING FLAP FLEX JOINT LH	27
5935911-50	LINK ASSY, WING FLAP FLEX JOINT LH	27
5935928-50	VANE, OTBD, RH ASSY	57
5935928-50	VANE, OTBD, RH ASSY	57
5935928-50	VANE. FLAP, RH; AFT MOVEABLE;	57
5936674-1	STRUT VENTRAL STAIR DOOR ACTUATOR RIGHT	52
5936674-50	STRUT VENTRAL STAIR DOOR ACTUATOR RIGHT	52
5936680-50	STRUT VENTRAL STAIR DOOR ACTUATOR RIGHT	52
5936680-50	STRUT VENTRAL STAIR DOOR ACTUATOR RIGHT	52
5936791-50	DOOR WING MOUNTED MAIN LANDING GEAR LH	32
5936791-50	DOOR WING MOUNTED MAIN LANDING GEAR LH	32
5936801-50	PANEL, PANEL ASSY L/H	57
5936801-50	PANEL, PANEL ASSY L/H	57
5936802-50	PANEL, PANEL ASSY L/H	57
5936802-50	PANEL, PANEL ASSY L/H	57
5936919-50	MANIFOLD ELEVATOR BOOST SHIP IN ATA SPEC	27
5936956-50	VALVE HYD RESERVOIR RELIEF ISSUE TO SHOP	29
5936965-50	CYLINDER GROUND SPOILER.	27
5936965-55	CYLINDER GROUND SPOILER.	27

5936965-55	CYLINDER GROUND SPOILER.	27
5936971-55	VALVE SPOILER, GROUND	27
5936986-50	VALVE HYD RESERVOIR RELIEF ISSUE TO SHOP	29
5936986-55	VALVE HYD RESERVOIR RELIEF ISSUE TO SHOP	29
5937021-55	CYLINDER SLAT DRIVE ACTUATING	27
5937036-55	CYLINDER MLG RETRACT, LH AND RH EQUIV 59	32
5937036-55	CYLINDER MLG RETRACT, LH AND RH EQUIV 59	32
5937036-55	CYLINDER MLG RETRACT, LH AND RH EQUIV 59	32
5937036-55	CYLINDER MLG RETRACT, LH AND RH EQUIV 59	32
5937052-50	CYLINDER WING FLAP	27
5937415-50	SLAT,NO.2 R/H DC9-30/-40/-50	27
5937415-50	SLAT,NO.2 R/H DC9-30/-40/-50	27
5937415-50	SLAT,NO.2 R/H DC9-30/-40/-50	27
5937415-51	SLAT,NO.2 R/H DC9-30/-40/-50	27
5937415-51	SLAT,NO.2 R/H DC9-30/-40/-50	57
5937415-51	SLAT,NO.2 R/H DC9-30/-40/-50	57
5937415-51	SLAT,NO.2 R/H DC9-30/-40/-50	57
5937563-48	SLAT,NO.2 R/H DC9-30/-40/-50	
5937563-50	SLAT,NO.2 R/H DC9-30/-40/-50	27
5937563-50	SLAT,NO.2 R/H DC9-30/-40/-50	27
5937563-50	SLAT,NO.2 R/H DC9-30/-40/-50	57
5937563-50	SLAT,NO.2 R/H DC9-30/-40/-50	57
5937563-50	SLAT,NO.2 R/H DC9-30/-40/-50	57
5937563-50	SLAT,NO.2 R/H DC9-30/-40/-50	57
5937563-50	SLAT,NO.2 R/H DC9-30/-40/-50	57
5937563-50	SLAT,NO.2 R/H DC9-30/-40/-50	57
5937563-50	SLAT,NO.2 R/H DC9-30/-40/-50	57
5937601-51	DOOR SERVICE, LEFT AFT SHIP IN ATA SPEC	52
5937601-51	DOOR SERVICE, LEFT AFT SHIP IN ATA SPEC	52
5937760-1	DUCT,WATER SEPARATOR TO CK VLV; RH	30
5937760-2	DUCT,WATER SEPARATOR TO CK VLV; RH	30
5937763-1	DUCT,WATER SEPARATOR TO CK VLV; RH	30
5937764-50	DUCT,WATER SEPARATOR TO CK VLV; RH	30

5938076-3	DOOR OIL, SERVICING	71
5938090-21	DOOR OIL, SERVICING	71
5938155-50	HINGE, APRON, UPPER COWL DOOR, LH	71
5938157-1	HINGE, APRON, UPPER COWL DOOR, LH	71
5938159-1	HINGE, APRON, UPPER COWL DOOR, LH	71
5938161-1	HINGE, APRON, UPPER COWL DOOR, LH	71
5938163-50	HINGE, APRON, UPPER COWL DOOR, LH	71
5938164-1	HINGE, APRON, UPPER COWL DOOR, LH	71
5938165-1	HINGE, APRON, UPPER COWL DOOR, LH	71
5938165-2	HINGE, APRON, UPPER COWL DOOR, LH	71
5938167-50	HINGE, APRON, UPPER COWL DOOR, LH	71
5938189-50	HINGE, APRON, UPPER COWL DOOR, LH	71
5938189-50	HINGE, APRON, UPPER COWL DOOR, LH	71
5938252-1	DUCT,WATER SEPARATOR TO CK VLV; RH	36
5938253-1	DUCT,WATER SEPARATOR TO CK VLV; RH	80
5938254-1	DUCT,WATER SEPARATOR TO CK VLV; RH	80
5938255-50	DUCT,WATER SEPARATOR TO CK VLV; RH	80
5938308-50	HARNESS THRUST REVERSER SHIP IN ATA SPEC	78
5938323-50	DETECTOR FIRE, ENGINE SHIP IN CATAGORY 2	26
5938323-50	DETECTOR FIRE, ENGINE SHIP IN CATAGORY 2	26
5938323-50	DETECTOR FIRE, ENGINE SHIP IN CATAGORY 2	26
5938323-50	DETECTOR FIRE, ENGINE SHIP IN CATAGORY 2	26
5938323-50	DETECTOR FIRE, ENGINE SHIP IN CATAGORY 2	26
5938323-50	DETECTOR FIRE, ENGINE SHIP IN CATAGORY 2	26
5938323-50	DETECTOR FIRE, ENGINE SHIP IN CATAGORY 2	26
5938325-50	BARRIER ENG TO PYLON	71
5938349-1	HARNESS, AD; GENERATOR POWER; -217 QEC;	71
5938351-1	HARNESS, AD;GENERATOR CONTROL; -217 QEC;	71
5938354-51	HARNESS,INSOURCE ILFC PART TRKING ONLY	71
5938354-52	HARNESS,INSOURCE ILFC PART TRKING ONLY	71
5938355-50	DUCT,WATER SEPARATOR TO CK VLV; RH	36
5938355-50	DUCT,WATER SEPARATOR TO CK VLV; RH	36
5938725-50	VALVE ELEVATOR POWER BOOST CONTROL.	27

5938801-50	MECHANISM SLAT DRIVE, PRE EO 9-63341-6AD	27
5938801-50	MECHANISM SLAT DRIVE, PRE EO 9-63341-6AD	27
5939074-55	CYLINDER MLG DOOR LH AND RH	32
5940489-50	TAB ELEVATOR GEARED, RH MUST BE USABLE	55
5940489-50	TAB ELEVATOR GEARED, RH MUST BE USABLE	55
5940491-50	TAB ELEVATOR GEARED, RH MUST BE USABLE	55
5940491-50	TAB ELEVATOR GEARED, RH MUST BE USABLE	55
5940560-3	TUBE-TORQUE DRIVE ACME SCREW	27
5940560-5	TUBE-TORQUE DRIVE ACME SCREW	27
5940670-50	TAB ELEVATOR GEARED, RH MUST BE USABLE	55
5940670-50	TAB ELEVATOR GEARED, RH MUST BE USABLE	55
5940671-1	TAB, ELEVATOR, CONTROL; RT; DC9-10 ONLY	55
5940671-2	TAB, ELEVATOR, CONTROL; RT; DC9-10 ONLY	55
5940671-40	TAB ELEVATOR GEARED, RH MUST BE USABLE	55
5940671-40	TAB ELEVATOR GEARED, RH MUST BE USABLE	55
5940672-50	TAB, ELEVATOR ANTI FLOAT,RH MUST BE USAB	55
5940672-50	TAB, ELEVATOR ANTI FLOAT,RH MUST BE USAB	55
5951609-1	DIODE TRANSFORMER RESISTOR BLOCKING	24
5951609-50	DIODE TRANSFORMER RESISTOR BLOCKING	24
5953623-50	DUCT,WATER SEPARATOR TO CK VLV; RH	21
5953624-50	DUCT,WATER SEPARATOR TO CK VLV; RH	21
5953624-50	DUCT,WATER SEPARATOR TO CK VLV; RH	21
5953624-51	DUCT,WATER SEPARATOR TO CK VLV; RH	21
5953625-51	DUCT,WATER SEPARATOR TO CK VLV; RH	21
5953625-51	DUCT,WATER SEPARATOR TO CK VLV; RH	21
5953625-52	DUCT,WATER SEPARATOR TO CK VLV; RH	21
5953625-52	DUCT,WATER SEPARATOR TO CK VLV; RH	21
5954612-1	SEAT, FORWARD CABIN, ATTENDANT	25
5954612-50	SEAT, FORWARD CABIN, ATTENDANT	25
5954612-50	SEAT, FORWARD CABIN, ATTENDANT	25
5955323-50	ROD SLAT ANTI-ICING PACKAGE 1EA PER PACK	30
5955323-50	ROD SLAT ANTI-ICING PACKAGE 1EA PER PACK	30

5955401-50	TAB, AILERON CONTROL,RH	27
5955401-50	TAB, AILERON CONTROL,RH	27
5955401-50	TAB, AILERON CONTROL,RH	27
5955401-50	TAB, AILERON CONTROL,RH	27
5955401-50	TAB, AILERON CONTROL,RH	27
5955401-50	TAB, AILERON CONTROL,RH	27
5955401-51	TAB, AILERON CONTROL,RH	27
5955416-1	TAB, AILERON CONTROL,RH	27
5955416-2	TAB, AILERON CONTROL,RH	27
5955419-1	ROD,MLG OUTBOARD DOOR MECHANISM	27
5955419-2	ROD,MLG OUTBOARD DOOR MECHANISM	27
5955439-50	TAB, AILERON CONTROL,RH	27
5955439-50	TAB, AILERON CONTROL,RH	27
5955455-50	TAB, AILERON CONTROL,RH	27
5955455-50	TAB, AILERON CONTROL,RH	27
5955455-50	TAB, AILERON CONTROL,RH	27
5955455-50	TAB, AILERON CONTROL,RH	27
5955455-50	TAB, AILERON CONTROL,RH	27
5955455-50	TAB, AILERON CONTROL,RH	27
5955455-50	TAB, AILERON CONTROL,RH	27
5955455-50	TAB, AILERON CONTROL,RH	27
5955455-50	TAB, AILERON CONTROL,RH	27
5955470-50	TAB, AILERON CONTROL,RH	27
5955470-50	TAB, AILERON CONTROL,RH	27
5955470-50	TAB, AILERON CONTROL,RH	27
5955470-50	TAB, AILERON CONTROL,RH	27
5955470-50	TAB, AILERON CONTROL,RH	27
5955501-1	TAB RUDDER W/CAD PLATED BALANCE WEIGHTS	55
5955501-50	TAB RUDDER W/CAD PLATED BALANCE WEIGHTS	55
5955501-50	TAB RUDDER W/CAD PLATED BALANCE WEIGHTS	55
5955501-51	TAB RUDDER W/CAD PLATED BALANCE WEIGHTS	55
5955501-51	TAB RUDDER W/CAD PLATED BALANCE WEIGHTS	55
5955545-1	TAB RUDDER W/CAD PLATED BALANCE WEIGHTS	27
5955545-50	TAB RUDDER W/CAD PLATED BALANCE WEIGHTS	55

5955545-50	TAB RUDDER W/CAD PLATED BALANCE WEIGHTS	55
5956186-50	BOX, AUTO THROTTLE GEAR,ASSY SHIP IN ATA	22
5956253-50	VANE, OTBD, RH ASSY	57
5956253-50	VANE, OTBD, RH ASSY	57
5956253-50	VANE, OTBD, RH ASSY	57
5956404-17	WIRE USED ON A/C 982 AND SUBS AND A/C MO	49
5956712-1C	SEAT ATTENDANT, AFT, BOTTOM FURNISH SEAT	25
5956743-55	CYLINDER,MLG,DOOR ACTUATOR	32
5956888-50	CONTROL CENTER INSTRUMENT PANEL AND PEDE	33
5956888-51	CONTROL CENTER INSTRUMENT PANEL AND PEDE	33
5956889-51	CONTROL COCKPIT OVERHEAD PANEL LIGHTING	33
5956890-1	PANEL,CONTROL,ASSY;INSTRUMENT.	24
5956890-1C	PANEL,CONTROL,ASSY;INSTRUMENT.	24
5956890-1C	PANEL,CONTROL,ASSY;INSTRUMENT.	24
5956890-1S	PANEL,CONTROL,ASSY;INSTRUMENT.	24
5956890-51	PANEL,CONTROL,ASSY;INSTRUMENT.	33
5956890-51	PANEL,CONTROL,ASSY;INSTRUMENT.	33
5958570-1	SUPPORT ENGINE FIRE DETECTR ELEMENT	26
5958694-50	DUCT,WATER SEPARATOR TO CK VLV; RH	36
5958696-50	DUCT,WATER SEPARATOR TO CK VLV; RH	36
5958697-1	DUCT,WATER SEPARATOR TO CK VLV; RH	71
5958765-50	DUCT,WATER SEPARATOR TO CK VLV; RH	36
5958878-1	DUCT,WATER SEPARATOR TO CK VLV; RH	71
59600-5007	HYDRAULIC SOLENOID VALVE ASSEMBLY	27
59600-5009	HYDRAULIC SOLENOID VALVE ASSEMBLY	
59600-5011	HYDRAULIC SOLENOID VALVE ASSEMBLY	27
5961526-51	DUCT,WATER SEPARATOR TO CK VLV; RH	21
5961568-50	CAM TAILCONE RELEASE	53
5961892-50	CYLINDER VENTRAL STAIR	52
5963913-1	DUCT AUXILIARY POWER UNIT EXHAUST NOZZLE	49
5964420-1	WINDOW, PILOTS CLEAR VIEW,LH STORE IN A	56
5964420-2	WINDOW, PILOTS CLEAR VIEW,LH STORE IN A	56

5964420-50	WINDOW, PILOTS CLEAR VIEW,LH STORE IN A	56
5964420-50	WINDOW, PILOTS CLEAR VIEW,LH STORE IN A	56
5964420-50	WINDOW, PILOTS CLEAR VIEW,LH STORE IN A	56
5964420-50	WINDOW, PILOTS CLEAR VIEW,LH STORE IN A	56
5964420-50	WINDOW, PILOTS CLEAR VIEW,LH STORE IN A	56
5964420-50	WINDOW, PILOTS CLEAR VIEW,LH STORE IN A	56
5964420-50	WINDOW, PILOTS CLEAR VIEW,LH STORE IN A	56
5964420-50	WINDOW, PILOTS CLEAR VIEW,LH STORE IN A	56
5964420-50	WINDOW, PILOTS CLEAR VIEW,LH STORE IN A	56
5964420-50	WINDOW, PILOTS CLEAR VIEW,LH STORE IN A	56
5965440-55	VALVE,HYDRAULIC, RESERVOIR BLEED,POST EO	29
5965440-55	VALVE,HYDRAULIC, RESERVOIR BLEED,POST EO	29
5965903-55	ACTUATOR HYD PYLON FLAP MUST BE USABLE O	27
5965942-1	FLAP, ASSY, R/H	54
5965942-2	FLAP, ASSY, R/H	54
5966027-1	VANE ASSY, UPPER;APU AIR INLET DOOR PANE	49
5966028-1	VANE ASSY, UPPER;APU AIR INLET DOOR PANE	49
5966294-50	VANE, OTBD, RH ASSY	57
5966392-1	PILOTS CHART HOLDER ASSY	25
59T865-01	MANIFOLD LOW PRESSURE TURBINE PACKAGE 1	72
5U0030	THERMCPL OIL TEMP MUST BE USABLE ON	79
600-0108-1	CONTROLLR, OVEN, HIGH TEMP	25
600-0108-5	CONTROLLR, OVEN, HIGH TEMP	25
600-0108-9	CONTROLLR, OVEN, HIGH TEMP	25
6002089-1	MONITOR, BRAKE TEMP,.STATIC.SENSITIVE	32
60-0304-31	PWRSPPLY RECHARGEABLE POWER FAILURE CABI	33
60-0304-51	PWRSPPLY RECHARGEABLE POWER FAILURE CABI	33
600380-1	FAUCET AND DRAIN VALVE	38
600380-2	FAUCET AND DRAIN VALVE	38
600480-3	VALVE DRAIN	38
6006079-2	MANIFOLD HYD, ANTI-SKID BRAKING CONTROL,	32
6006081-2	TRANSDCR MLG WHEEL SPEED	32
600611-00-	CONTROLLER, AIR, HEAT; CURE	21

600611-00-	CONTROLLER, AIR, HEAT; CURE	21
600611-00-	CONTROLLER, AIR, HEAT; CURE	21
600622-00-	JOYSTICK, A330	25
600622-00-	JOYSTICK, A330	25
600622-00-	JOYSTICK, A330	25
6010N0001-	ACTUATOR SLAT.SEQUENCE MECHANISM EQUIV 6	27
6010N0001-	ACTUATOR SLAT.SEQUENCE MECHANISM EQUIV 6	27
6010N0001-	ACTUATOR SLAT.SEQUENCE MECHANISM EQUIV 6	27
601116-301	CREWREST, AD, LOWER DECK MOBILE; A330	25
601117-1	STAIRHOUSE, AD, LOWER DECK CREW REST; A3	25
60-1177-3	RACK,BATTERY,EMERGENCY LIGHTING, LESS BA	33
60-1177-5	RACK,BATTERY,EMERGENCY LIGHTING, LESS BA	33
60-1177-7	RACK,BATTERY,EMERGENCY LIGHTING, LESS BA	33
60-1177-9	RACK,BATTERY,EMERGENCY LIGHTING, LESS BA	33
60-1211-1R	POWER.SUPPLY, FLOOR PROX EMER LIGHT	24
60-1211-3R	POWER.SUPPLY, FLOOR PROX EMER LIGHT	33
60128-301	KIT, SURVIVAL; A320	25
601322-00	LOWER EGT THERMOCOUPLE HARNESS	77
601322-06	LOWER EGT THERMOCOUPLE HARNESS	77
601322HAS	LOWER EGT THERMOCOUPLE HARNESS	77
601323-06	LOWER EGT THERMOCOUPLE HARNESS	77
601323HAS	LOWER EGT THERMOCOUPLE HARNESS	77
601323-09	LOWER EGT THERMOCOUPLE HARNESS	77
601324-00	LOWER EGT THERMOCOUPLE HARNESS	77
6020-00	HARNESS, FAN CASE,..	72
6023100-1	ACTUATOR ASSEMBLY SPOILER OVERRIDE	
6023100-2	ACTUATOR ASSEMBLY SPOILER OVERRIDE	27
602-3373	MICROPHONE, PUBLIC ADDRESS; A/C 2761-277	23
602-4182	MICROPHONE, PUBLIC ADDRESS; A/C 2761-277	23
602TR	MICROPHONE, PUBLIC ADDRESS; A/C 2761-277	23
602TR4183	MICROPHONE, PUBLIC ADDRESS; A/C 2761-277	23
603-2342	MICROPHONE, PUBLIC ADDRESS; A/C 2761-277	23

60-3368-5	STROBE LIGHT POWER SUPPLY	33
60-3368-7	STROBE LIGHT POWER SUPPLY	33
60-3368-7M	STROBE LIGHT POWER SUPPLY	33
60-3368-9	STROBE LIGHT POWER SUPPLY	33
60-4411-1	BATTERY, EMERGENCY POWER,LIGHTS LESS PAC	33
60-4411-3	BATTERY, EMERGENCY POWER,LIGHTS LESS PAC	33
60-4411-5	BATTERY, EMERGENCY POWER,LIGHTS LESS PAC	33
60-4983-3	STROBE POWER SUPPLY	33
605138-6	MOTOR DRIVEN CENTRIFUGAL FAN	21
60-5206-1	AIRCRAFT POSITION AND ANTICOLLISION LIGHT ASSEMBLY	33
60-5206-2	AIRCRAFT POSITION AND ANTICOLLISION LIGHT ASSEMBLY	33
605290-4-1	HOUSING MACHINED, EXHAUST FAN	21
605290-4-2	HOUSING MACHINED, EXHAUST FAN	21
605457-1-1	MOTOR DRIVEN CENTRIFUGAL FAN	21
605457-3	MOTOR DRIVEN CENTRIFUGAL FAN	21
605457-7	MOTOR DRIVEN CENTRIFUGAL FAN	21
605457-8	MOTOR DRIVEN CENTRIFUGAL FAN	21
606173-01	THERMOCOUPLE CABLES AND JUNCTION BOXES	72
606622-1	CABIN AIR RECIRCULATION FAN	21
606622-2	CABIN AIR RECIRCULATION FAN	21
606622-3	CABIN AIR RECIRCULATION FAN	21
606622-4	CABIN AIR RECIRCULATION FAN	21
606634-1	CABIN AIR RECIRCULATION FAN	21
606634-2	CABIN AIR RECIRCULATION FAN	21
606707-1	MOTOR DRIVEN FAN	21
606709-1	MOTOR DRIVEN FAN	21
606714-1	MOTOR DRIVEN FAN	21
606752-00	HARNESS, ASSY; VIBRATION SENSOR;	72
606752-01	HARNESS, ASSY; VIBRATION SENSOR;	72
606772-1	CABIN AIR RECIRCULATION FAN	21
606772-2	CABIN AIR RECIRCULATION FAN	21
606772-3	CABIN AIR RECIRCULATION FAN	21

606772-6	CABIN AIR RECIRCULATION FAN	21
606772-7	CABIN AIR RECIRCULATION FAN	21
606802-2	WASTE SYSTEM VACUUM BLOWER	38
606832-12	CABIN PRESSURE OUTFLOW VALVE	21
606832-14	CABIN PRESSURE OUTFLOW VALVE	21
606832-15	CABIN PRESSURE OUTFLOW VALVE	21
606832-16	CABIN PRESSURE OUTFLOW VALVE	21
606832-18	CABIN PRESSURE OUTFLOW VALVE	21
606832-21	CABIN PRESSURE OUTFLOW VALVE	21
607146-1-1	CONTROL TEMPERATURE, CABIN AND COCKPIT	21
607146-2-1	CONTROL TEMPERATURE, CABIN AND COCKPIT	21
607146-2-2	CONTROL TEMPERATURE, CABIN AND COCKPIT	21
607152-1-1	SWITCH CABIN TEMPERATURE	21
607400-1-1	SELECTOR, CABIN TEMPERATURE,USED ON B737 A	21
607510-2	CONTROL 35 DEGREE F	21
607510-3	CONTROL 35 DEGREE F	21
607518-2	TEMPERATURE CONTROL	21
60-75501	FUEL BOOST PUMP MOTOR-IMPELLER SUBASSEMBLY	28
60-75503	FUEL BOOST PUMP MOTOR-IMPELLER SUBASSEMBLY	28
60-75504	FUEL BOOST PUMP MOTOR-IMPELLER SUBASSEMBLY	28
60-755100	FUEL BOOST PUMP MOTOR-IMPELLER SUBASSEMBLY	28
60-755100-	FUEL BOOST PUMP MOTOR-IMPELLER SUBASSEMBLY	28
60-755100-	FUEL BOOST PUMP MOTOR-IMPELLER SUBASSEMBLY	28
60-755100-	FUEL BOOST PUMP MOTOR-IMPELLER SUBASSEMBLY	28
6078T09P0	CABLE, ASSY W3 WHITE	74
6078T39P0	PUMP, FUEL, SET UP FOR TRACKING PURP	73
6078T39P0	PUMP, FUEL, SET UP FOR TRACKING PURP	73
6078T39P0	PUMP, FUEL, SET UP FOR TRACKING PURP	73
6078T55P1	CONTROL, MAIN FUEL	73
6078T55P1	CONTROL, MAIN FUEL	72
6078T55P2	CONTROL, MAIN FUEL	73
6078T55P2	CONTROL, MAIN FUEL	72

6078T55P2	CONTROL, MAIN FUEL	72
6078T55P2	CONTROL, MAIN FUEL	72
6078T55P2	CONTROL, MAIN FUEL	72
607976-01	THERMOCOUPLE CABLES AND JUNCTION BOXES	77
607999-00	THERMOCOUPLE CABLES AND JUNCTION BOXES	77
6087T04P0	PUMP ASSY, LUBE AND SCAVENGE*TRACKING ON	79
6087T04P0	PUMP ASSY, LUBE AND SCAVENGE*TRACKING ON	79
6087T04P0	PUMP ASSY, LUBE AND SCAVENGE*TRACKING ON	79
6087T04P0	PUMP ASSY, LUBE AND SCAVENGE*TRACKING ON	79
6087T04P0	PUMP ASSY, LUBE AND SCAVENGE*TRACKING ON	79
6087T04P0	PUMP ASSY, LUBE AND SCAVENGE*TRACKING ON	79
6087T04P0	PUMP ASSY, LUBE AND SCAVENGE*TRACKING ON	79
6087T04P1	PUMP ASSY, LUBE AND SCAVENGE*TRACKING ON	79
60897-2	ACCUMULATOR ASSEMBLY	32
60946-5	ACCUMULATOR ASSEMBLY	32
60-98908	PUMP. FUEL BOOST CENTER WING RESTRICTED	28
60-989100-	PUMP. FUEL BOOST CENTER WING RESTRICTED	28
60-989100-	PUMP. FUEL BOOST CENTER WING RESTRICTED	28
60B00200-5	PUMP HYD. ENGINE AND AIR DRIVEN NOT MODI	29
60B00216-4	VALVE ASSEMBLY, LANDING GEAR SELECTOR	
60B00216-5	VALVE ASSEMBLY, LANDING GEAR SELECTOR	32
60B00216-8	VALVE ASSEMBLY, LANDING GEAR SELECTOR	32
60B00220-1	VALVE NLG OPERATED SEQUENCE ASSY	32
60B00220-2	VALVE NLG OPERATED SEQUENCE ASSY	32
60B00226-4	MODULAR ASSEMBLY RESERVOIR PRESSURIZATION	29
60B00226-6	MODULAR ASSEMBLY RESERVOIR PRESSURIZATION	29
60B00226-7	MODULAR ASSEMBLY RESERVOIR PRESSURIZATION	29
60B00238-1	RAPID RESPONSE RELIEF VALVE ASSEMBLY	32
60B00238-1	FUSE SELF RESETTING VALVE ASSEMBLY	32
60B00238-1	RAPID RESPONSE RELIEF VALVE ASSEMBLY	32
60B00238-5	RAPID RESPONSE RELIEF VALVE ASSEMBLY	32
60B00252-2	MLG DOWNLOCK OPERATED DOOR SEQUENCE VALVE A	32
60B00253-4	MLG UPLOCK OPERATED SEQUENCE VALVE ASSEMBLY	32

60B00258-5	MOTOR OPERATED SHUTOFF VALVE	78
60B00273-1	TRANSFER CYLINDER / ACCUMULATOR	32
60B00273-1	MLG UPLOCK OPERATED SEQUENCE VALVE ASSEMBLY	32
60B00273-1	ACCUMLTR, PARKING BRAKE	32
60B00273-3	ALTERNATE BRAKE ACCUMULATOR ISOLATION VALVE AS	32
60B00273-6	ACCUMLTR PARKING BRAKE	32
60B10003-1	EMERGENCY POWER RESERVOIR	52
60B10003-1	EMERGENCY POWER RESERVOIR	52
60B10003-1	EMERGENCY POWER RESERVOIR	52
60B10006-3	SNUBBER ENTRY DOOR RIGHT SIDE SHIP IN AT	52
60B10006-3	SNUBBER ENTRY DOOR RIGHT SIDE SHIP IN AT	52
60B10006-3	SNUBBER ENTRY DOOR RIGHT SIDE SHIP IN AT	52
60B10006-3	SNUBBER ENTRY DOOR RIGHT SIDE SHIP IN AT	52
60B40042-3	VALVE HYDRAULIC SOLENOID GROUND SPOILER	27
60B50012-6	POTABLE WATER SYSTEM COMPRESSOR ASSEMBLY	38
60B50012-8	POTABLE WATER SYSTEM COMPRESSOR ASSEMBLY	38
60B50012-9	POTABLE WATER SYSTEM COMPRESSOR ASSEMBLY	38
60B50027-2	FAUCET LAVATORY SINK, USED ON A/C 225, 3	38
60B50341-2	VALVE, LAV WASTE DRAIN,A/C 629 AND SUBS	38
60B50341-4	PRECHARGE SHUTOFF VALVE ASSEMBLY	38
60B92404-3	PUMP, FUEL, BOOST; LOW CAPACITY; HAS INS	28
60B92404-4	PUMP, FUEL, BOOST; LOW CAPACITY; HAS INS	28
60B92404-5	PUMP, FUEL, BOOST; LOW CAPACITY; HAS INS	28
60B92404-6	PUMP, FUEL, BOOST; LOW CAPACITY; HAS INS	28
60B92404-7	PUMP, FUEL, BOOST; LOW CAPACITY; HAS INS	28
60B92404-8	PUMP, FUEL, BOOST; LOW CAPACITY; HAS INS	28
61-1675-11	DISPENSER, COFFEE, WORLD AIRWAYS PART	25
61-1675-3	FRESH BREW COFFEEMAKER	25
61260-102	EVACUATION SLIDE SURVIVAL KIT	25
61473-104	757 DOOR 2 DUAL LANE EVAC SLIDE/RAFT SYSTEM	25
617-1	WINDOW HEAT CONTROL	30
617-2	WINDOW HEAT CONTROL	30

617-6	WINDOW HEAT CONTROL	30
617-7	WINDOW HEAT CONTROL	30
6197-1	INDICATR TAXI-SPEED, USED ON B767 A/C 10	32
62197-001-	DISPENSER, COFFEE, WORLD AIRWAYS PART	25
62222-101	ENCLOSURE, AD, OFF-WING; R/H; A319/A320;	25
62222-102	ENCLOSURE, AD, OFF-WING; R/H; A319/A320;	25
62222-103	ENCLOSURE, AD, OFF-WING; R/H; A319/A320;	25
62222-104	ENCLOSURE, AD, OFF-WING; R/H; A319/A320;	25
6222M53	NUMBER 1 BEARING ACCELEROMETER	77
6222SM8	ACCLRMTR ENGINE VIBRATION MUST BE USABLE	77
622-3890-0	TRANSCVR, RADIO ALTIMETER	34
622-3890-0	TRANSCVR, RADIO ALTIMETER	34
622-4096-0	AMPLIFIR P.A 70 VOLTS OUTPUT UPON RECEIP	23
622-4096-0	AMPLIFIR P.A 70 VOLTS OUTPUT UPON RECEIP	23
622-4540-0	DME-700 DISTANCE MEASURING EQUIPMENT	34
622-4540-0	DME-700 DISTANCE MEASURING EQUIPMENT	34
622-4542-0	TRANSCEIVER, ALTIMETER, RADIO	34
622-4542-1	LRA-700 RADIO ALTIMETER	34
622-4542-1	LRA-700 RADIO ALTIMETER	34
622-4542-1	LRA-700 RADIO ALTIMETER	32
622-4591-5	FCC-701 FLIGHT CONTROL COMPUTER	22
622-4591-5	FCC-701 FLIGHT CONTROL COMPUTER	22
622-4591-5	FCC-701 FLIGHT CONTROL COMPUTER	22
622-4591-5	FCC-701 FLIGHT CONTROL COMPUTER	22
622-4591-5	FCC-701 FLIGHT CONTROL COMPUTER	22
622-4593-5	MAINTENANCE CONTROL DISPLAY PANEL	22
622-4593-5	MAINTENANCE CONTROL DISPLAY PANEL	22
622-4593-5	MAINTENANCE CONTROL DISPLAY PANEL	22
622-4593-5	MAINTENANCE CONTROL DISPLAY PANEL	22
622-4593-5	MAINTENANCE CONTROL DISPLAY PANEL	22
622-4593-5	MAINTENANCE CONTROL DISPLAY PANEL	22
622-4598-5	MAINTENANCE CONTROL DISPLAY PANEL	

622-4598-5	MAINTENANCE CONTROL DISPLAY PANEL	
622-4598-5	MAINTENANCE CONTROL DISPLAY PANEL	
622-4598-5	MAINTENANCE CONTROL DISPLAY PANEL	
622-4717-0	MCP-701/702 MODE CONTROL PANELS	22
622-4717-0	MCP-701/702 MODE CONTROL PANELS	22
622-5001-1	RADIO DISTANCE MAGNETIC INDICATOR	34
622-5001-6	RADIO DISTANCE MAGNETIC INDICATOR	34
622-5002-2	RMI-733 RADIO MAGNETIC INDICATOR	34
622-5002-2	RMI-733 RADIO MAGNETIC INDICATOR	34
622-5045-2	GENERATR. EFIS.SYMBOL. STATIC SENSITVE..	31
622-5045-2	GENERATR. EFIS.SYMBOL. STATIC SENSITVE..	31
622-5046-1	ELECTRONIC DISPLAY UNIT AND RLS-701 REMOTE LIGHT	34
622-5046-1	ELECTRONIC DISPLAY UNIT AND RLS-701 REMOTE LIGHT	31
622-5047-1	ELECTRONIC DISPLAY UNIT AND RLS-701 REMOTE LIGHT	31
622-5047-1	ELECTRONIC DISPLAY UNIT AND RLS-701 REMOTE LIGHT	31
622-5047-5	ELECTRONIC DISPLAY UNIT AND RLS-701 REMOTE LIGHT SEN	
622-5048-1	EFIC-701 ELECTRONIC FLIGHT INSTRUMENT CONTROL	31
622-5048-1	EFIC-701 ELECTRONIC FLIGHT INSTRUMENT CONTROL	34
622-5048-3	EFIC-701 ELECTRONIC FLIGHT INSTRUMENT CONTROL	31
622-5048-3	EFIC-701 ELECTRONIC FLIGHT INSTRUMENT CONTROL	31
622-5048-3	EFIC-701 ELECTRONIC FLIGHT INSTRUMENT CONTROL	34
622-5129-1	PANEL, WEATHER RADAR 9217-9219	34
622-5129-1	WCP-701/702 CONTROL PANEL	34
622-5129-2	WCP-701/702 CONTROL PANEL	34
622-5129-2	WCP-701/702 CONTROL PANEL	34
622-5129-2	PANEL, WEATHER RADAR 9217-9219	34
622-5129-8	WCP-701/702 CONTROL PANEL	34
622-5130-0	PANEL, WEATHER RADAR 9217-9219	34
622-5130-2	PANEL, WEATHER RADAR 9217-9219	34
622-5130-8	PANEL, WEATHER RADAR DUAL CONTROL	34
622-5130-8	PANEL, WEATHER RADAR DUAL CONTROL	34
622-5132-1	TRANSCEIVER, WEATHER RADAR, A330 VOL III	34

622-5132-1	TRANSCEIVER, WEATHER RADAR, A330 VOL III	34
622-5132-6	TRANSCEIVER, WEATHER RADAR, A330 VOL III	34
622-5132-6	TRANSCEIVER, WEATHER RADAR, A330 VOL III	34
622-5132-6	TRANSCEIVER, WEATHER RADAR, A330 VOL III	34
622-5133-0	WMT-701X/702X RT MOUNT	34
622-5135-0	WMA-701X/702X ANTENNA PEDESTAL AND WFA-701X AN	34
622-5135-2	WMA-701X/702X ANTENNA PEDESTAL AND WFA-701X AN	34
622-5135-2	WMA-701X/702X ANTENNA PEDESTAL AND WFA-701X AN	34
622-5135-8	WMA-701X/702X ANTENNA PEDESTAL AND WFA-701X AN	34
622-5136-0	WMA-701X/702X ANTENNA PEDESTAL AND WFA-701X AN	34
622-5136-2	WMA-701X/702X ANTENNA PEDESTAL AND WFA-701X AN	34
622-5136-2	WMA-701X/702X ANTENNA PEDESTAL AND WFA-701X AN	34
622-5136-8	WEATHER RADAR ANTENNA PEDESTAL	34
622-5136-8	WEATHER RADAR ANTENNA PEDESTAL	34
622-5219-0	VHF-700 COMMUNICATIONS TRANSCEIVER	23
622-5219-0	VHF-700 COMMUNICATIONS TRANSCEIVER	23
622-5219-0	VHF-700 COMMUNICATIONS TRANSCEIVER	23
622-5219-0	VHF-700 COMMUNICATIONS TRANSCEIVER	23
622-5219-0	VHF-700 COMMUNICATIONS TRANSCEIVER	23
622-5220-0	VOR-70	34
622-5220-1	VOR-70	34
622-5220-1	VOR-70	34
622-5221-1	ILS-700/700A ILS RECEIVER	34
622-5221-1	ILS-700/700A ILS RECEIVER	34
622-5222-0	ADF-700 ADF RECEIVER	34
622-5222-1	ADF-700 ADF RECEIVER	34
622-5272-0	HF RECEIVER TRANSMITTER	23
622-5272-0	HF RECEIVER TRANSMITTER	23
622-5272-1	HF RECEIVER TRANSMITTER	23
622-5342-0	PASSENGER ADDRESS UNIT PAU-700	23
622-5342-1	PASSENGER ADDRESS UNIT PAU-700	23
622-5374-0	AUTOLAND STATUS ANNUNCIATOR	22

622-5389-0	FREQUENCY PANEL	34
622-5432-0	HF COMM FREQUENCY PANEL	23
622-6089-1	DSP-701A DISPLAY SELECT PANEL	31
622-6089-1	DSP-701A DISPLAY SELECT PANEL	31
622-6827-0	COLLINS HFP-712 HF COMM FREQUENCY PANEL	23
622-6827-0	COLLINS HFP-712 HF COMM FREQUENCY PANEL	23
622-6827-0	COLLINS HFP-712 HF COMM FREQUENCY PANEL	23
622-6829-0	FREQUENCY PANEL	34
622-6830-0	DFP-713/713A ADF FREQUENCY PANEL	34
622-6831-0	COLLINS VFP-712 VHF COMM FREQUENCY PANEL	23
622-6831-0	COLLINS VFP-712 VHF COMM FREQUENCY PANEL	23
622-6831-0	COLLINS VFP-712 VHF COMM FREQUENCY PANEL	23
622-7878-1	TPR-720 ATC/MODE S TRANSPONDER	34
622-7878-2	TPR-720 ATC/MODE S TRANSPONDER	34
622-7998-0	EDU-766D/776D ELECTRONIC DISPLAY UNIT AND RLS-70	31
622-7998-0	EDU-766D/776D ELECTRONIC DISPLAY UNIT AND RLS-70	31
622-7998-0	EDU-766D/776D ELECTRONIC DISPLAY UNIT AND RLS-70	34
622-7999-0	EDU-766D/776D ELECTRONIC DISPLAY UNIT AND RLS-70	31
622-7999-0	EDU-766D/776D ELECTRONIC DISPLAY UNIT AND RLS-70	31
622-7999-0	EDU-766D/776D ELECTRONIC DISPLAY UNIT AND RLS-70	34
622-8000-0	EFIP-701D ELECTRONIC FLIGHT INSTRUMENT PROCESS	31
622-8000-0	EFIP-701D ELECTRONIC FLIGHT INSTRUMENT PROCESS	31
622-8000-0	EFIP-701D ELECTRONIC FLIGHT INSTRUMENT PROCESS	31
622-8000-0	EFIP-701D ELECTRONIC FLIGHT INSTRUMENT PROCESS	31
622814-4	PACK/ZONE TEMPERATURE CONTROLLER	21
622814-5	PACK/ZONE TEMPERATURE CONTROLLER	21
622-8587-2	DATA LINK CONTROL	23
622-8587-5	DATA LINK CONTROL	
622-8587-5	DATA LINK CONTROL	23
622-8587-5	DATA LINK CONTROL	23
622-8590-1	PANEL EFIS DISPLAY CONTROL	34
622-8590-1	PANEL EFIS DISPLAY CONTROL	31

622-8757-1	FLIGHT CONTROL COMPUTER	22
622-8757-1	FLIGHT CONTROL COMPUTER	22
622-8757-1	FLIGHT CONTROL COMPUTER	22
622-8974-3	TTC-920 TCAS TRANSPONDER CONTROL	34
622-8974-3	TTC-920 TCAS TRANSPONDER CONTROL	34
622-9436-1	EFIP-701E ELECTRONIC FLIGHT INSTRUMENT PROCESS	31
622-9436-1	EFIP-701E ELECTRONIC FLIGHT INSTRUMENT PROCESS	31
622-9676-2	DATA LINK MANAGEMENT UNIT	23
622-9676-3	DATA LINK MANAGEMENT UNIT	23
622-9676-4	DATA LINK MANAGEMENT UNIT	23
622-9676-4	DATA LINK MANAGEMENT UNIT	23
622-9676-5	DATA LINK MANAGEMENT UNIT	23
622-9676-6	DATA LINK MANAGEMENT UNIT	23
62364-101	KIT, SURVIVAL; A320	25
62364-105	KIT, SURVIVAL; A320	25
62364-301	KIT, SURVIVAL; A320	25
62364-305	KIT, SURVIVAL; A320	25
62369-101	KIT, SURVIVAL; A320	25
62369-305	KIT, SURVIVAL; A320	25
6237M117A	NO. 1 BEARING ACCELEROMETER	77
6237M118A	FAN FRAME COMPRESSOR CASE VIBRATION SENSOR	77
624066-2	WINDOW HEAT CONTROL	30
624066-3	WINDOW HEAT CONTROL	30
624066-4	WINDOW HEAT CONTROL	30
624066-5	WINDOW HEAT CONTROL	30
624284-1	PACK STANDBY CONTROLLER	21
62449-101	COVER, SLIDE RAFT, EVAC, FWD; NO LATCHES	25
62450-101	KIT, SURVIVAL; A320	25
624958-2	CABIN ZONE TEMPERATURE CONTROLLER	
624958-3	CABIN ZONE TEMPERATURE CONTROLLER	21
624958-4	CABIN ZONE TEMPERATURE CONTROLLER	21
625868-1	CABIN ZONE TEMPERATURE SELECTOR	21

625878-1	ALTITUDE SWITCH	21
625934-4	CABIN ZONE TEMPERATURE CONTROLLER	21
625934-5	CABIN ZONE TEMPERATURE CONTROLLER	21
625934-6	CABIN ZONE TEMPERATURE CONTROLLER	21
625946-10	PACK TEMPERATURE CONTROLLER	21
625946-5	PACK TEMPERATURE CONTROLLER	
625946-6	PACK TEMPERATURE CONTROLLER	21
625946-7	PACK TEMPERATURE CONTROLLER	21
625946-8	PACK TEMPERATURE CONTROLLER	21
625946-9	PACK TEMPERATURE CONTROLLER	21
62630-1	RAPID RESPONSE RELIEF VALVE ASSEMBLY	32
6268-10	FLAP SHUT-OFF VALVE	27
6268-12	FLAP SHUT-OFF VALVE	27
63292146-1	SENSOR, PNEUMATIC SYSTEM,HIGH STAGE PRES	36
63396754-1	VALVE, PACK FLOW CONTROL	21
63396754-2	VALVE, PACK FLOW CONTROL	21
6350A25CC	OXYGEN BOTTLE...	35
6350A25EE	OXYGEN BOTTLE...	35
6350A33CC	OXYGEN BOTTLE...	35
6350A33SS	OXYGEN BOTTLE...	35
6350A34CC	PORTABLE CYLINDER ASSEMBLIES	35
6350A34CC	OXYGEN BOTTLE...	35
6373-1	REGULATOR	29
6373-2	REGULATOR	32
63999-003	MODEL 38T MICROPHONE	23
63999-004	MODEL 38T MICROPHONE	23
64141-580-	IND, ALTIMETER, STANDBY; A319/A320;	34
64141-590-	IND, ALTIMETER, STANDBY; A319/A320;	34
642-2000-2	MOUNT, FWD ENGINE	71
642-5855-5	CORE FIRE LOOP	26
642W9818-	HARNESS, ASSY; VIBRATION SENSOR;	72
642W9955-	FIRE DETECTOR HARNESS	71

642W9956-	FIRE DETECTOR HARNESS	71
642W9957-	FIRE DETECTOR HARNESS	71
642W9958-	FIRE DETECTOR HARNESS	71
6445-01	FIRE/OVERHEAT DETECTION SYS CONTROL CARD	26
645252-2	FAN, VARIABLE SPEED,CONSTANT FREQUENCY,C	21
645405-1	CABIN AIR RECIRCULATION FAN	21
645405-2	CABIN AIR RECIRCULATION FAN	21
645507-2	MIXED FLOW FAN	21
645670-1	FAN RADIO RACK EXHAUST AND CARGO HEATING	21
645705-1	FAN ELECTRONIC COMPARTMENT	21
645705-2	FAN ELECTRONIC COMPARTMENT	21
645705-3	FAN ELECTRONIC COMPARTMENT	21
645705-4	FAN ELECTRONIC COMPARTMENT	21
64753-001-	AD, 2001-10-13, DO NOT STOCK, WATER HEAT	25
64769-001-	DISPENSER, COFFEE, WORLD AIRWAYS PART	25
6489-01	DETECTOR	26
6491-01	DETECTOR	26
6493-01	DETECTOR	26
6493-02	DETECTOR	26
6495-01	DETECTOR	26
6497-01	DETECTOR	26
65-0294-21	INDICATOR LIGHT ASSEMBLY	33
65-0294-23	INDICATOR LIGHT ASSEMBLY	33
65-0294-3	INDICATOR LIGHT ASSEMBLY	33
65-0294-7	INDICATOR LIGHT ASSEMBLY	33
65-17821-2	HYDRAULIC SYSTEM A AND B PRESSURE MODULAR AS	29
65-17821-2	PACKAGE, HYD PRESSURE, 737-9	29
65-2863-8	WINDOW OBSERVATION	56
65-44503-1	FEEL ACTUATOR CYLINDER ASSEMBLY	27
65-44503-5	FEEL ACTUATOR CYLINDER ASSEMBLY	22
65-44503-7	FEEL ACTUATOR CYLINDER ASSEMBLY	27
65-44503-8	FEEL ACTUATOR CYLINDER ASSEMBLY	27

65-44681-1	STANDBY SYSTEM MODULAR PACKAGE ASSEMBLY	29
65-44681-1	STANDBY SYSTEM MODULAR PACKAGE ASSEMBLY	29
65-44681-1	STANDBY SYSTEM MODULAR PACKAGE ASSEMBLY	29
65-44751-2	TAB LOCK ACTUATOR ASSEMBLY	27
65-44751-3	TAB LOCK ACTUATOR ASSEMBLY	27
65-44761-1	AILERON AND ELEVATOR POWER CONTROL UNIT ASSEMBLY	
65-44761-1	AILERON AND ELEVATOR POWER CONTROL UNIT ASSEMBLY	
65-44761-1	AILERON AND ELEVATOR POWER CONTROL UNIT ASSEMBLY	
65-44761-1	AILERON AND ELEVATOR POWER CONTROL UNIT ASSEMBLY	27
65-44761-1	AILERON AND ELEVATOR POWER CONTROL UNIT ASSEMBLY	27
65-44761-1	AILERON AND ELEVATOR POWER CONTROL UNIT ASSEMBLY	27
65-44761-2	AILERON AND ELEVATOR POWER CONTROL UNIT ASSEMBLY	27
65-44761-2	AILERON AND ELEVATOR POWER CONTROL UNIT ASSEMBLY	27
65-44891-1	FLIGHT CONTROL MODULAR PACKAGE ASSEMBLY	27
65-44891-3	FLIGHT CONTROL MODULAR PACKAGE ASSEMBLY	27
65-44891-4	FLIGHT CONTROL MODULAR PACKAGE ASSEMBLY	27
65-44891-5	FLIGHT CONTROL MODULAR PACKAGE ASSEMBLY	27
65-44891-7	FLIGHT CONTROL MODULAR PACKAGE ASSEMBLY	27
65-44891-8	FLIGHT CONTROL MODULAR PACKAGE ASSEMBLY	27
65-46370-1	RATIO CHANGER ASSEMBLY	27
65-46370-2	RATIO CHANGER ASSEMBLY	27
65-46370-2	RATIO CHANGER ASSEMBLY	27
65-46370-2	RATIO CHANGER ASSEMBLY	27
654T0387-2	OUTBOARD LEADING EDGE SLAT DRIVE OFFSET GEARBOX	27
654T0387-2	OUTBOARD LEADING EDGE SLAT DRIVE OFFSET GEARBOX	27
654T0387-2	OUTBOARD LEADING EDGE SLAT DRIVE OFFSET GEARBOX AS	
654T0387-2	OUTBOARD LEADING EDGE SLAT DRIVE OFFSET GEARBOX	27
654T0387-2	OUTBOARD LEADING EDGE SLAT DRIVE OFFSET GEARBOX	25
654T0387-2	OUTBOARD LEADING EDGE SLAT DRIVE OFFSET GEARBOX	27
65-50555-1	AILERON CENTERING MECHANISM ASSEMBLY	27
65-52810-1	AIR CONDITIONING ACCESSORY UNIT ASSEMBLY M324	
65-52810-2	AIR CONDITIONING ACCESSORY UNIT ASSEMBLY M324	21

65-52810-4	AIR CONDITIONING ACCESSORY UNIT ASSEMBLY M324	21
65-52810-5	AIR CONDITIONING ACCESSORY UNIT ASSEMBLY M324	21
65-52810-6	AIR CONDITIONING ACCESSORY UNIT ASSEMBLY M324	21
65-52854-7	GALLEY/SERVICE DOOR GUIDE ARM ASSEMBLY	52
65806-002-	ELECTRONIC CLOCK	31
65-84209-2	AUTO SPEED BRAKE CONTROL ACCESSORY UNIT ASSY	27
658D100-1	RUDDER TRIM ACTUATOR	27
658D100-3	RUDDER TRIM ACTUATOR	27
658D100-5	RUDDER TRIM ACTUATOR	27
65B15178-1	FLAP, L/E, VARIABLE CAMBER; POS 1-5&22-2	57
65B15178-3	FLAP, L/E, VARIABLE CAMBER; POS 1-5&22-2	57
65B15178-3	FLAP, L/E, VARIABLE CAMBER; POS 1-5&22-2	57
65B63104-5	RESTRANT WITH CASTER, L/H FWD CARGO COMP	25
65C25465-2	UNIT, FEEL AND CENTERING	27
65C26864-2	OUTBOARD GROUND SPOILER ACTUATOR ASSY	27
65C26864-3	OUTBOARD GROUND SPOILER ACTUATOR ASSY	27
65C26869-2	AUTO SLAT CONTROL VALVE ASSEMBLY	27
65C33409-1	DIMMING RELAY MODULE ASSEMBLY	33
65C33409-3	DIMMING RELAY MODULE ASSEMBLY	33
66068-05	VARIABLE DELIVERY HYDRAULIC PUMP	29
66068-06	VARIABLE DELIVERY HYDRAULIC PUMP	29
66068-08	VARIABLE DELIVERY HYDRAULIC PUMP	29
664D100-5	CARGO DOOR LIFT AND LATCH LINEAR ACTUATOR	52
664D100-7	CARGO DOOR LIFT AND LATCH LINEAR ACTUATOR	52
6664287-0	COMPUTER, WINDOW HEAT, CURE; H...	30
66760-1	FLAP & SLAT HYDRAULIC DEPRESSURIZATION MODULE	27
66760-2	FLAP & SLAT HYDRAULIC DEPRESSURIZATION MODULE	27
66760-3	FLAP & SLAT HYDRAULIC DEPRESSURIZATION MODULE	27
66760-4	FLAP & SLAT HYDRAULIC DEPRESSURIZATION MODULE	27
66760-5	FLAP & SLAT HYDRAULIC DEPRESSURIZATION MODULE	27
66790-1	HYDRAULIC FLAP & SLAT CONTROL VALVE ASSEMBLY	27
66940-3	3-WAY NORMALLY CLOSED SOLENOID VALVE	78

6713D080000		
6714D070000		
6733A03000	VALVE, FAN AIR, A330	36
6740B02	VALVE, PNEUMATIC, OVERPRESSURE	36
6740B03	VALVE, PNEUMATIC, OVERPRESSURE	36
6740B04	VALVE, PNEUMATIC, OVERPRESSURE	36
6740B05000	VALVE, PNEUMATIC, OVERPRESSURE	36
6740E01000	VALVE, PNEUMATIC, OVERPRESSURE	36
6740F01000	VALVE, PNEUMATIC, OVERPRESSURE	36
6743A01000	OVERPRESSURE VALVE	36
6763D080000		
6763D090000		
6764B030000		
6764B060000		
6773B030000		
6773E01000	HIGH PRESSURE BLEED VALVE	36
6773F010000		
6774E010000		
6774G010000		
680640-3	AIR CYCLE MACHINE	21
680640-4	AIR CYCLE MACHINE	21
684-17-29	THERMCPL T7	77
684D100-1	AUTOMATIC GROUND SPEED BRAKE LINEAR ACTUATOR	27
684D100-11	AUTOMATIC GROUND SPEED BRAKE LINEAR ACTUATOR	27
684D100-13	AUTOMATIC GROUND SPEED BRAKE LINEAR ACTUATOR	27
684D100-15	AUTOMATIC GROUND SPEED BRAKE LINEAR ACTUATOR	27
684D100-17	AUTOMATIC GROUND SPEED BRAKE LINEAR ACTUATOR	27
684D100-3	AUTOMATIC GROUND SPEED BRAKE LINEAR ACTUATOR	27
684D100-5	AUTOMATIC GROUND SPEED BRAKE LINEAR ACTUATOR	27
684D100-7	AUTOMATIC GROUND SPEED BRAKE LINEAR ACTUATOR	27
684D100-9	AUTOMATIC GROUND SPEED BRAKE LINEAR ACTUATOR	27
686-1000-0	HANDSET ATTENDANT	23

686-2000-0	HANDSET ATTENDANT	23
686-2000-0	HANDSET ATTENDANT	23
686-3000-0	UNIT, ELECTRONIC SWITCHING; 717	23
686-3000-0	UNIT, ELECTRONIC SWITCHING; 717	23
686-3000-0	UNIT, ELECTRONIC SWITCHING; 717	23
686-3000-0	UNIT, ELECTRONIC SWITCHING; 717	23
68770-1	VALVE HYD RELIEF ALT S271N202-2	29
69000940-1	COMPUTER, ENHANCED GROUND PROXIMITY	34
69-20321-3	GALLEY/SERVICE DOOR GUIDE ARM ASSEMBLY	52
69-2914-15	GROUND SERVICE SWING CHECK VALVE ASSEMBLY	21
69-2914-25	GROUND SERVICE SWING CHECK VALVE ASSEMBLY	21
69-37307-1	ENGINE AND APU FIRE CONTROL MODULE ASSEMBLY P	26
69-37307-1	ENGINE AND APU FIRE CONTROL MODULE ASSEMBLY P	26
69-37307-1	ENGINE AND APU FIRE CONTROL MODULE ASSEMBLY P	26
69-37307-1	ENGINE AND APU FIRE CONTROL MODULE ASSEMBLY P	26
69-37307-1	ENGINE AND APU FIRE CONTROL MODULE ASSEMBLY P	26
69-37307-1	ENGINE AND APU FIRE CONTROL MODULE ASSEMBLY P	26
69-37307-1	ENGINE AND APU FIRE CONTROL MODULE ASSEMBLY P	26
69-37307-3	ENGINE AND APU FIRE CONTROL MODULE ASSEMBLY P	26
69-37313-1	MODULE, FLIGHT CONTROLS, P5-3, (NOT MOD)	31
69-37313-1	MODULE, FLIGHT CONTROLS, P5-3, (NOT MOD)	31
69-37313-4	MODULE, FLIGHT CONTROLS, P5-3, (NOT MOD)	31
69-37317-1	HYDRAULIC PUMPS MODULE ASSEMBLY P5-8	31
69-37317-3	HYDRAULIC PUMPS MODULE ASSEMBLY P5-8	29
69-37317-5	HYDRAULIC PUMPS MODULE ASSEMBLY P5-8	31
69-37317-6	HYDRAULIC PUMPS MODULE ASSEMBLY P5-8	29
69-37317-8	HYDRAULIC PUMPS MODULE ASSEMBLY P5-8	29
69-37319-3	AIR CONDITIONING MODULE ASSEMBLY, P5-10	21
69-37320-1	ENGINE AND WING ANTI-ICE MODULE	30
69-37320-1	ENGINE AND WING ANTI-ICE MODULE	30
69-37320-1	ENGINE AND WING ANTI-ICE MODULE	30
69-37320-3	ENGINE AND WING ANTI-ICE MODULE	30
69-37324-1	CABIN TEMPERATURE MODULE ASSEMBLY, P5-17	21

69-37324-3	MODULE, CABIN TEMPERATURE	21
69-37324-7	CABIN TEMPERATURE MODULE ASSEMBLY, P5-17	21
69-37334-1	MODULE, CABIN ALTIMETER, P5-16 AND RATE	21
69-37334-3	MODULE, CABIN ALTIMETER, P5-16 AND RATE	21
6949-4	AIR CHILLER	25
6954-3	AIR CHILLER	25
69-54784-1	HYDRAULIC SWIVEL ASSEMBLY	32
69-55179-7	INDICATOR LIGHT DIMMING MODULE ASSEMBLY, M469	33
69-60764-1	CARD PRINTED MASTER DIM SHIP IN ATA SPEC	23
69-60764-3	CARD PRINTED MASTER DIM SHIP IN ATA SPEC	33
696233A	TRNSMSSN CSD BUILT INTO CONVENIENCE	24
696233B	TRNSMSSN CSD BUILT INTO CONVENIENCE	24
69-73713-1	IRS MODE SELECTOR MODULE ASSEMBLY	31
69-73713-1	IRS MODE SELECTOR MODULE ASSEMBLY	31
69-73713-1	IRS MODE SELECTOR MODULE ASSEMBLY	34
69-73713-2	IRS MODE SELECTOR MODULE ASSEMBLY	34
69-73713-3	IRS MODE SELECTOR MODULE ASSEMBLY	23
69-73713-5	IRS MODE SELECTOR MODULE ASSEMBLY	31
69-73713-8	IRS MODE SELECTOR MODULE ASSEMBLY	31
69-76436-9	STAB TRIM AND CAB DOOR MODULE ASSEMBLY, P8-47	52
697729C	TRNSMSSN CSD BUILT INTO CONVENIENCE	24
69-78214-3	AURAL WARNING MODULE ASSEMBLY	31
69-78214-4	AURAL WARNING MODULE ASSEMBLY	31
69-78809-3	UNIVERSAL MASTER CAUTION PRINTED CIRCUIT ASSY	31
69-78809-4	UNIVERSAL MASTER CAUTION PRINTED CIRCUIT ASSY	31
69-78809-5	UNIVERSAL MASTER CAUTION PRINTED CIRCUIT ASSY	31
69-78809-6	UNIVERSAL MASTER CAUTION PRINTED CIRCUIT ASSY	31
699739A	BLOCK CSD CYLINDER	24
699739B	BLOCK CSD CYLINDER	24
6A5732	HARNESS, FAN CASE,..	71
6A6440	HARNESS, FAN CASE,..	71
6RW176YN	TRNSFRMR RECTIFIER	24

700-2061-0	MONITOR 8.6 INCH LCD, USED ON A/C 1401 A	23
700-2061-0	MONITOR 8.6 INCH LCD, USED ON A/C 1401 A	25
7002-2B	WHEELCHR, ON BOARD	25
7002-3	WHEELCHR, ON BOARD	25
70-030-000	WIDE CARRIAGE INTELLIGENT PRINTER	23
700750-117	THERMAL PRINTER	23
700750-181	THERMAL PRINTER	23
70205-1	MOTOR OPERATED 4 WAY VALVE	32
702537-1	LIGHT, WING TIP, STROBE;AFT	33
702537-2	LIGHT, WING TIP, STROBE;AFT	33
70269-1	TAIL SKID CONTROL MODULE	32
70507-2	VALVE DUAL BRAKE METERING	32
70507-3	VALVE DUAL BRAKE METERING	32
70577-42	SNUBBER ENTRY DOOR RIGHT SIDE SHIP IN AT	52
70577-43	SNUBBER ENTRY DOOR RIGHT SIDE SHIP IN AT	52
70577-44	SNUBBER ENTRY DOOR RIGHT SIDE SHIP IN AT	52
70577-45	SNUBBER ENTRY DOOR RIGHT SIDE SHIP IN AT	52
7069M94G0	ALTITUDE SENSOR - CF6-80A	77
7069M94G0	ALTITUDE SENSOR - CF6-80A	77
707258A	TRNSMSSN CSD BUILT INTO CONVENIENCE	24
7075M51G0	OIL TANK	79
7075M51G0	OIL TANK	79
7075M51G0	OIL TANK	79
7075M51G0	OIL TANK	79
7075M51G1	OIL TANK	79
707760-2	1 KVA INVERTER	24
707760-3	1 KVA INVERTER	24
707760-4	1 KVA INVERTER	24
707792A	HARNESS, WIRING, CSD;	71
708200-2	LAMP DIMMER ASSEMBLY	33
708200-3	LAMP DIMMER ASSEMBLY	33
7082M59G0	STATOR, ECU ALTERNATOR, CFM56-5	74

7082M60G0	STATOR, ECU ALTERNATOR, CFM56-5	73
7082M60G0	STATOR, ECU ALTERNATOR, CFM56-5	73
7082M61G0	STATOR, ECU ALTERNATOR, CFM56-5	74
7087M94G0	VALVE ACTIVE, CLEAR	75
70N105-807	COWL NOSE, ENGINE INTAKE; A330	71
70N106-801	COWL NOSE, ENGINE INTAKE; A330	71
7101-01	SENSOR, AFT FIRE DETECTION;	26
7101-02	SENSOR, AFT FIRE DETECTION;	26
7101-04	SENSOR, AFT FIRE DETECTION;	26
7101-05	SENSOR, AFT FIRE DETECTION;	72
7101-05-10	SENSOR, AFT FIRE DETECTION	26
7101-12	SENSOR, AFT FIRE DETECTION;	26
7101-129	SENSOR, AFT FIRE DETECTION;	26
7101-13	SENSOR, AFT FIRE DETECTION;	26
7101-19	SENSOR, AFT FIRE DETECTION;	26
7101-20	SENSOR, AFT FIRE DETECTION;	26
7101-21	SENSOR, AFT FIRE DETECTION;	26
7101-22	SENSOR, AFT FIRE DETECTION;	26
7101-23	SENSOR, AFT FIRE DETECTION;	26
7101-236	SENSOR, AFT FIRE DETECTION;	26
7101-24	SENSOR, AFT FIRE DETECTION;	26
71-0146-50	HARNESS,INSOURCE ILFC PART TRKING ONLY	71
7107M48G0	ALTITUDE SENSOR - CF6-80A	77
7107M48G0	ALTITUDE SENSOR - CF6-80A	77
7108M19P0	NBR 1 BEARING VIBRATION SENSOR ACCELEROMETER	77
711002-3	PANEL SELECTOR-FLIGHT CONTROL PRESS	21
711002-4	PANEL SELECTOR-FLIGHT CONTROL PRESS	21
711002-5	PANEL SELECTOR-FLIGHT CONTROL PRESS	21
7120M32P0	ENGINE BLEED AIR THERMOCOUPLE PROBE	77
7120M99P0	ACCELEROMETER	77
7120M99P0	ACCELEROMETER	77
7121-19971	PRESSURE CONTROLLER	21

7121-19971	PRESSURE CONTROLLER	21
7123-19973	PRESSURE SELECTOR PANEL PSL105-1	21
7123-19973	PRESSURE SELECTOR PANEL PSL105-1	21
7123-19973	PRESSURE SELECTOR PANEL PSL105-1	21
712334-1	FILTER.MAIN.FUEL RESTRICTED AIR SHIPMENT	73
71404-1	DUAL BRAKE METERING VALVE	32
71404-2	DUAL BRAKE METERING VALVE	32
714900-4	MAIN FUEL PUMP (POST-SB 73-A0062)	73
715-3010-5	COWL, INLET	71
7156M94G0	RATING	72
7157M57G0	STATOR, ECU ALTERNATOR, CFM56-5	73
7161M98G0	CONNECTOR PLUG	72
7161M98G6	CONNECTOR PLUG	72
717-2500-2	DRIVE CARGO POWER.USED WITH ADAPTER PN 1	25
72120-807	DUCT FAN TURB POST EO 49-64241-3AD	
72-130001-	DETECTOR SMOKE, LAVATORY USED ON A/C 201	26
72-130001-	DETECTOR SMOKE, LAVATORY USED ON A/C 201	26
72-130001-	DETECTOR SMOKE, LAVATORY USED ON A/C 201	26
72-130002-	DETECTOR SMOKE, LAVATORY USED ON A/C 201	26
72184003B	WHEELCHR, ON BOARD	25
725941DL	WOBBLER, VARIABLE, TIN COATED	24
727792L	INTEGRATED DRIVE GENERATOR	24
727810B	AUXILIARY GENERATOR	24
728825B	TRNSMSSN IDG-BUILT INTO CONV ASSY BY SHO	24
728843D	ROTOR,IDG TRANSMISSION, FOR TRACKING PUR	24
728843E	ROTOR,IDG TRANSMISSION, FOR TRACKING PUR	24
728843F	ROTOR,IDG TRANSMISSION, FOR TRACKING PUR	24
728843G	ROTOR,IDG TRANSMISSION, FOR TRACKING PUR	24
728843H	ROTOR,IDG TRANSMISSION, FOR TRACKING PUR	24
729355B	ROTOR,IDG TRANSMISSION, FOR TRACKING PUR	24
729355D	ROTOR,IDG TRANSMISSION, FOR TRACKING PUR	24
729355E	ROTOR,IDG TRANSMISSION, FOR TRACKING PUR	24

729355F	ROTOR,IDG TRANSMISSION, FOR TRACKING PUR	24
729355G	ROTOR,IDG TRANSMISSION, FOR TRACKING PUR	24
729550A	RAM AIR TURBINE GROUND CHECKOUT MODULE	29
729550C	RAM AIR TURBINE GROUND CHECKOUT MODULE	29
729550D	RAM AIR TURBINE GROUND CHECKOUT MODULE	29
729552A	TACHOMETER INDICATOR	29
729638A	HOUSING, SUPPORT-MATCHED SET SETUP FOR	24
729638B	HOUSING, SUPPORT-MATCHED SET SETUP FOR	24
729638C	HOUSING, SUPPORT-MATCHED SET SETUP FOR	24
729638E	HOUSING, SUPPORT-MATCHED SET SETUP FOR	24
729825B	INTEGRATED DRIVE GENERATOR	24
729825C	INTEGRATED DRIVE GENERATOR	24
729825D	INTEGRATED DRIVE GENERATOR	24
729825E	INTEGRATED DRIVE GENERATOR	24
729825F	INTEGRATED DRIVE GENERATOR	24
729825G	INTEGRATED DRIVE GENERATOR	24
729825H	INTEGRATED DRIVE GENERATOR	24
729825J	INTEGRATED DRIVE GENERATOR	24
729825K	INTEGRATED DRIVE GENERATOR	24
729825L	INTEGRATED DRIVE GENERATOR	24
729825M	INTEGRATED DRIVE GENERATOR	24
72A000-701	FAIRING ASSY,PYLON LOWER AFT; A330;	
72A100-701	FAIRING ASSY;PYLON LWR AFT;A330	54
72A100-703	FAIRING ASSY;PYLON LWR AFT;A330	54
72A100-705	FAIRING ASSY;PYLON LWR AFT;A330	54
72N140-351	COWL, FAN ASSY, FWD LH; A330	71
72N140-353	COWL, FAN ASSY, FWD LH; A330	71
72N160-351	COWL, FAN ASSY, FWD RH; A330	71
72N160-353	COWL, FAN ASSY, FWD RH; A330	71
72N160-807	COWL, FAN ASSY, FWD RH; A330	71
72N640-807	COWL, FAN ASSY, AFT RH; A330	71
72N640-809	COWL, FAN ASSY, AFT RH; A330	71

730844B	QUICK ATTACH-DETACH ADAPTER	24
731376A	AXIAL FLOW FAN ASSEMBLY	21
731378A	AXIAL FLOW FAN	21
732-11240-	MODULATOR ASSY, RESERVOIR PRESSURIZATION	29
732-11240-	MODULATOR ASSY, RESERVOIR PRESSURIZATION	29
732-11240-	MODULATOR ASSY, RESERVOIR PRESSURIZATION	29
732-11240-	MODULATOR ASSY, RESERVOIR PRESSURIZATION	29
732-11240-	MODULATOR ASSY, RESERVOIR PRESSURIZATION	29
732-11240-	MODULATOR ASSY, RESERVOIR PRESSURIZATION	29
732-11610-	RESERVOIR PRESSURIZATION MODULAR ASSEMBLY	29
732-11610-	RESERVOIR PRESSURIZATION MODULAR ASSEMBLY	29
732-11750-	ISOLATION BYPASS CHECK VALVE	36
732-11750-	ISOLATION BYPASS CHECK VALVE	36
732-11750-	ISOLATION BYPASS CHECK VALVE	36
732-13300-	ENGINE CONDITION CONTROL MOTOR ACTUATOR - CF6	76
732-13870-	ACTUATOR ASSY APU AIR INTAKE	49
732-13870-	ACTUATOR ASSY APU AIR INTAKE	49
732-13870-	ACTUATOR ASSY APU AIR INTAKE	49
732-13870-	ACTUATOR ASSY APU AIR INTAKE	49
732-13870-	ACTUATOR ASSY APU AIR INTAKE	49
732-13870-	ACTUATOR ASSY APU AIR INTAKE	49
732-13870-	ACTUATOR ASSY APU AIR INTAKE	49
732-13870-	ACTUATOR ASSY APU AIR INTAKE	49
732-13870-	ACTUATOR ASSY APU AIR INTAKE	49
732-13870-	ACTUATOR ASSY APU AIR INTAKE	49
732-13870-	ACTUATOR ASSY APU AIR INTAKE	49
732-13870-	ACTUATOR ASSY APU AIR INTAKE	49
732-13870-	ACTUATOR ASSY APU AIR INTAKE	49
732-13870-	ACTUATOR ASSY APU AIR INTAKE	49
732-18550-	MODULE, PDU (RB 271080130/271003252 PCD)	27
732-18550-	MODULE, PDU (RB 271080130/271003252 PCD)	27
732-18550-	MODULE, PDU (RB 271080130/271003252 PCD)	27
732-18550-	CONTROL VALVE MODULE, T.E. FLAP	27
732-18550-	CONTROL VALVE MODULE, T.E. FLAP	27
732-18550-	CONTROL VALVE MODULE, T.E. FLAP	27

732-18550-	CONTROL VALVE MODULE, T.E. FLAP	27
732-18550-	CONTROL VALVE MODULE, T.E. FLAP	27
732-18550-	CONTROL VALVE MODULE, T.E. FLAP	27
732-18550-	CONTROL VALVE MODULE, T.E. FLAP	27
732-18560-	LEADING EDGE OUTBOARD CONTROL VALVE MODULE	27
732-18560-	LEADING EDGE OUTBOARD CONTROL VALVE MODULE	27
732-18560-	LEADING EDGE OUTBOARD CONTROL VALVE MODULE	27
732-18560-	LEADING EDGE OUTBOARD CONTROL VALVE MODULE	27
732-18560-	LEADING EDGE OUTBOARD CONTROL VALVE MODULE	27
732-18570-	LEADING EDGE INBOARD CONTROL VALVE MODULE	27
732-18570-	LEADING EDGE INBOARD CONTROL VALVE MODULE	27
732-18570-	LEADING EDGE INBOARD CONTROL VALVE MODULE	27
732-18600-	MOTOR OPERATED BYPASS VALVE	27
732-18600-	MOTOR OPERATED BYPASS VALVE	27
732-18610-	MOTOR OPERATED BYPASS VALVE	27
732-18700-	HYDRAULIC SHUT-OFF VALVE MODULE, FLAP AND SLAT	27
732-18700-	HYDRAULIC SHUT-OFF VALVE MODULE, FLAP AND SLAT	27
732-18700-	HYDRAULIC SHUT-OFF VALVE MODULE, FLAP AND SLAT	27
732-18700-	HYDRAULIC SHUT-OFF VALVE MODULE, FLAP AND SLAT	27
732-18700-	HYDRAULIC SHUT-OFF VALVE MODULE, FLAP AND SLAT	27
732-18700-	HYDRAULIC SHUT-OFF VALVE MODULE, FLAP AND SLAT	27
732-18700-	HYDRAULIC SHUT-OFF VALVE MODULE, FLAP AND SLAT	27
732-18700-	HYDRAULIC SHUT-OFF VALVE MODULE, FLAP AND SLAT	27
732591A	ROTOR, HOUSING, ELECTRONIC FWD COMPT..	21
732591B	ROTOR, HOUSING, ELECTRONIC FWD COMPT..	21
732591C	ROTOR, HOUSING, ELECTRONIC FWD COMPT..	21
732591D	ROTOR, HOUSING, ELECTRONIC FWD COMPT..	21
732591E	ROTOR, HOUSING, ELECTRONIC FWD COMPT..	21
732591F	ROTOR, HOUSING, ELECTRONIC FWD COMPT..	21
732591G	ROTOR, HOUSING, ELECTRONIC FWD COMPT..	21
733756A	WOBBLER, VARIABLE, TIN COATED	24
734284A	GENERATOR CONTROL UNIT	24

734284C	GENERATOR CONTROL UNIT	24
734284D	GENERATOR CONTROL UNIT	24
734284E	GENERATOR CONTROL UNIT	24
734284F	GENERATOR CONTROL UNIT	24
734285C	BUS POWER CONTROL UNIT	24
734285D	BUS POWER CONTROL UNIT	24
734285E	BUS POWER CONTROL UNIT	24
734285F	BUS POWER CONTROL UNIT	
734817-1	ROTOR, HOUSING, ELECTRONIC FWD COMPT..	21
734933A	GROUND CHECKOUT MODULE	29
734933B	GROUND CHECKOUT MODULE	29
734933C	GROUND CHECKOUT MODULE	29
735462-1	ROTOR, HOUSING, ELECTRONIC FWD COMPT..	21
736938-1	ROTOR, HOUSING, ELECTRONIC FWD COMPT..	21
737-0010-1	WINGLET, RH, SPLIT SCIMITAR; WINGLET ASY	57
737-0010-1	WINGLET, RH, SPLIT SCIMITAR; WINGLET ASY	57
737-0010-3	WINGLET, RH, SPLIT SCIMITAR; WINGLET ASY	57
737-0010-3	WINGLET, RH, SPLIT SCIMITAR; WINGLET ASY	57
739515A	INTEGRATED DRIVE GENERATOR	24
739515B	INTEGRATED DRIVE GENERATOR	24
739515C	INTEGRATED DRIVE GENERATOR	24
739515D	INTEGRATED DRIVE GENERATOR	24
740120A	CONTROL UNIT, GEN, A319/A320;	24
740120B	CONTROL UNIT, GEN, A319/A320;	24
740120C	CONTROL UNIT, GEN, A319/A320;	24
740121A	CONTROL UNIT, GROUND POWER	24
740121B	CONTROL UNIT, GROUND POWER	24
743309A	ROTOR, HOUSING, ELECTRONIC FWD COMPT..	21
743496-8	VALVE SOLENOID, IDLE.	73
743496-9	VALVE SOLENOID, IDLE.	73
7-44017-10	CABLE DRAIN, REMOTE CONTROL VALVE ACTUAT	38
7-44017-10	CABLE DRAIN, REMOTE CONTROL VALVE ACTUAT	38

7-44017-20	CABLE DRAIN, REMOTE CONTROL VALVE ACTUAT	38
7-44017-23	CABLE DRAIN, REMOTE CONTROL VALVE ACTUAT	38
7-44017-7	CABLE DRAIN, REMOTE CONTROL VALVE ACTUAT	38
744041A	INTEGRATED DRIVE GENERATOR	24
744041B	INTEGRATED DRIVE GENERATOR	24
7-44758-11	CONTROL FLUSH CABLE, VACUUM WASTE SYSTEM	38
7-44758-12	CONTROL FLUSH CABLE, VACUUM WASTE SYSTEM	38
7-44758-5	CONTROL FLUSH CABLE, VACUUM WASTE SYSTEM	38
7-44758-6	CONTROL FLUSH CABLE, VACUUM WASTE SYSTEM	38
745329A	INTEGRATED DRIVE GENERATOR	24
745329B	INTEGRATED DRIVE GENERATOR	24
745329C	INTEGRATED DRIVE GENERATOR	24
745329D	INTEGRATED DRIVE GENERATOR	24
745329E	INTEGRATED DRIVE GENERATOR	24
745329F	INTEGRATED DRIVE GENERATOR	24
747101D	HOUSING, SUPPORT-MATCHED SET SETUP FOR	24
747768C	ROTOR,IDG TRANSMISSION, FOR TRACKING PUR	24
747768D	ROTOR,IDG TRANSMISSION, FOR TRACKING PUR	24
749895A	HOUSING ASSY, STATOR EXCITER ASSY	24
749895B	HOUSING ASSY, STATOR EXCITER ASSY	24
749A0000-C	PLENUM, CHAMBER, AIR-COND; A319/A320;	21
749A0000-C	PLENUM, CHAMBER, AIR-COND; A319/A320;	21
74M200-079	DOOR,.BLOCKER, ASSY; THRUST REVERSER;	78
74M200S07	DOOR,.BLOCKER, ASSY; THRUST REVERSER;	78
7517900-10	TCAS COMPUTER, VOL. 1	34
7517900-10	TCAS COMPUTER, VOL. 1	34
751A0000-C	VALVE, AIR, FLOW CONTROL; A/C 3201-3259	21
751A0000-C	VALVE, AIR, FLOW CONTROL; A/C 3201-3259	21
751A0000-C	VALVE, AIR, FLOW CONTROL; A/C 3201-3259	21
751A0000-C	VALVE, AIR, FLOW CONTROL; A/C 3201-3259	21
751F0000-C	VALVE, AIR, FLOW CONTROL; A/C 3201-3259	21
752497A	HOUSING, END CAP, GENERATOR ASSY.	24

754-0355-0	EFIC-701 ELECTRONIC FLIGHT INSTRUMENT CONTROL	34
754-0505-0	MCP-701/702 MODE CONTROL PANELS	22
754-0529-0	EFIC-701 ELECTRONIC FLIGHT INSTRUMENT CONTROL	34
754-0529-0	EFIC-701 ELECTRONIC FLIGHT INSTRUMENT CONTROL	34
755299A	GEARED ROTARY ACTUATOR	27
755299C	GEARED ROTARY ACTUATOR	27
755299D	GEARED ROTARY ACTUATOR	27
755300A	GEARED ROTARY ACTUATOR	27
755300D	GEARED ROTARY ACTUATOR	27
755359A	INTEGRATED DRIVE GENERATOR	24
755359B	INTEGRATED DRIVE GENERATOR	24
755359C	INTEGRATED DRIVE GENERATOR	24
756605A	HOUSING, SUPPORT-MATCHED SET SETUP FOR	24
7588587-10	PRESSURE AND CASE DRAIN FILTER MODULE	29
7588587-10	PRESSURE AND CASE DRAIN FILTER MODULE	29
75D106	SWITCH DIFF SENSOR FWD E/E COMPT PACKAGE	21
75D30-1	SWITCH, DIFFERENTIAL PRESS,FWD CARGO COM	21
760SUE2-4	AUTOTHROTTLE COMPUTER	22
760SUE2-5	AUTOTHROTTLE COMPUTER	22
761574B	INTEGRATED DRIVE GENERATOR	24
761A0000-0	ACTUATOR-OUTLET	21
761A0000-0	ACTUATOR-OUTLET	21
761B0000-0	ACTUATOR-OUTLET	21
762068-02	HOUSING, INPUT B737NG IDG	24
762068-04	HOUSING, INPUT B737NG IDG	24
762068-05	HOUSING, INPUT B737NG IDG	24
762068-06	HOUSING, INPUT B737NG IDG	24
762068-08	HOUSING, INPUT B737NG IDG	24
762068-09	HOUSING, INPUT B737NG IDG	24
762185E	GENERATOR CONTROL UNIT	24
762185F	GENERATOR CONTROL UNIT	24
762185G	GENERATOR CONTROL UNIT	24

762185H	GENERATOR CONTROL UNIT	24
762185J	GENERATOR CONTROL UNIT	24
762187E	BUS POWER CONTROL UNIT	24
762187F	BUS POWER CONTROL UNIT	24
762187G	BUS POWER CONTROL UNIT	24
762359A	ROTOR,HOUSING, B737NG IDG	24
762359D	ROTOR,HOUSING, B737NG IDG	24
762359F	ROTOR,HOUSING, B737NG IDG	24
762A0000-0	ACTUATOR-OUTLET	21
762A0000-0	ACTUATOR-OUTLET	21
764224A	LUBRICATION AND SCAVENGE OIL PUMP ASSY	79
764855WE	WOBBLER, VARIABLE, TIN COATED	24
764939B	BLOCK CSD CYLINDER	24
766088A	INTEGRATED DRIVE GENERATOR	24
766088B	INTEGRATED DRIVE GENERATOR	24
766298A	INTEGRATED DRIVE GENERATOR	24
767-3600-3	SLAT, #1-BLENDED WINGLET MOD APB767-3601	57
767-3600-6	SLAT, #1-BLENDED WINGLET MOD APB767-3601	57
767-3601-2	SLAT, VORTILON, SLAT #2	27
767-3601-2	SLAT, VORTILON, SLAT #2	27
767-3601-4	SLAT, VORTILON, SLAT #2	27
767-3650-4	ASSEMBLY, OUTBOARD AILERON	27
767584J	CONTROL UNIT, GENERATOR, GCU; A330	24
767584K	CONTROL UNIT, GENERATOR, GCU; A330	24
769606-11	CONTROL, FUEL, ENGINE WITHOUT SBCV,	73
769606-12	CONTROL, FUEL, ENGINE WITHOUT SBCV,	73
769606-13	CONTROL, FUEL, ENGINE WITHOUT SBCV,	73
769606-14	CONTROL, FUEL, ENGINE WITHOUT SBCV,	73
769606-15	CONTROL, FUEL, ENGINE WITHOUT SBCV,	73
77-109-10	ENGINE OIL TRANSMITTER	79
77-109-10A	ENGINE OIL TRANSMITTER	79
77-109-11	ENGINE OIL TRANSMITTER	

77-109-12	ENGINE OIL TRANSMITTER	79
77-109-13	ENGINE OIL TRANSMITTER	79
77-109-14	ENGINE OIL TRANSMITTER	79
77-109-15	ENGINE OIL TRANSMITTER	79
77-109-21	ENGINE OIL TRANSMITTER	79
77-109-8	ENGINE OIL TRANSMITTER	
77-109-9	ENGINE OIL TRANSMITTER	79
77-139-1	TRANSCEIVER, WEATHER RADAR, A330 VOL III	
77-139-2	TRANSCEIVER, WEATHER RADAR, A330 VOL III	
77-139-3	TRANSCEIVER, WEATHER RADAR, A330 VOL III	79
773245-2	FUEL CONTROL UNIT	73
773284-4	FAN AIR TEMPERATURE SENSOR	36
773284-5	FAN AIR TEMPERATURE SENSOR	36
773284-6	FAN AIR TEMPERATURE SENSOR	36
773284-7	FAN AIR TEMPERATURE SENSOR	36
773288-10	PRESSURE REGULATING AND SHUTOFF VALVE	36
773288-6	PRESSURE REGULATING AND SHUTOFF VALVE	36
773288-7	PRESSURE REGULATING AND SHUTOFF VALVE	36
773288-7-8	PRESSURE REGULATING AND SHUTOFF VALVE	36
773288-7-8	PRESSURE REGULATING AND SHUTOFF VALVE	36
773288-8	PRESSURE REGULATING AND SHUTOFF VALVE	36
773288-9	PRESSURE REGULATING AND SHUTOFF VALVE	36
773289-11	HIGH PRESSURE CONTROLLER	36
773289-13	HIGH PRESSURE CONTROLLER	36
773289-14	HIGH PRESSURE CONTROLLER	36
773289-15	HIGH PRESSURE CONTROLLER	36
773289-16	HIGH PRESSURE CONTROLLER	36
773289-18	HIGH PRESSURE CONTROLLER	36
773289-3	HIGH PRESSURE CONTROLLER	36
773289-5	HIGH PRESSURE CONTROLLER	36
773289-7	HIGH PRESSURE CONTROLLER	36
773289-9	HIGH PRESSURE CONTROLLER	36

773855-3	FAN AIR MODULATING VALVE	36
773855-4	FAN AIR MODULATING VALVE	36
773855-5	FAN AIR MODULATING VALVE	36
773855-6	FAN AIR MODULATING VALVE	36
773855-7	FAN AIR MODULATING VALVE	36
773855-8	FAN AIR MODULATING VALVE	36
773857-10	HIGH PRESSURE SHUTOFF VALVE	36
773857-11	HIGH PRESSURE SHUTOFF VALVE	36
773857-12	HIGH PRESSURE SHUTOFF VALVE	36
773857-13	HIGH PRESSURE SHUTOFF VALVE	36
773857-18	HIGH PRESSURE SHUTOFF VALVE	36
773857-19	HIGH PRESSURE SHUTOFF VALVE	36
773857-20	HIGH PRESSURE SHUTOFF VALVE	36
773857-21	HIGH PRESSURE SHUTOFF VALVE	36
773857-4	HIGH PRESSURE SHUTOFF VALVE	36
773857-5	HIGH PRESSURE SHUTOFF VALVE	36
773857-6	HIGH PRESSURE SHUTOFF VALVE	36
773857-6-1	HIGH PRESSURE SHUTOFF VALVE	36
773857-7	HIGH PRESSURE SHUTOFF VALVE	36
773857-7-1	HIGH PRESSURE SHUTOFF VALVE	36
773857-8	HIGH PRESSURE SHUTOFF VALVE	36
773857-9	HIGH PRESSURE SHUTOFF VALVE	36
773857-9-1	HIGH PRESSURE SHUTOFF VALVE	36
774860A1	PNEUMATIC STARTER	80
774860A10	PNEUMATIC STARTER	80
774860A2	PNEUMATIC STARTER	80
774860A3	PNEUMATIC STARTER	80
774860A4	PNEUMATIC STARTER	80
774860A5	PNEUMATIC STARTER	80
774860A6	PNEUMATIC STARTER	80
774860A8	PNEUMATIC STARTER	80
774860A9	PNEUMATIC STARTER	80

775538-1	PNEUMATIC STARTER VALVE	80
775538-6	PNEUMATIC STARTER VALVE	80
775538-7	PNEUMATIC STARTER VALVE	80
775550-2	PNEUMATIC STARTER	80
775550-3	PNEUMATIC STARTER	80
775550-6	PNEUMATIC STARTER	80
775550-7	PNEUMATIC STARTER	80
775550A2	PNEUMATIC STARTER	80
775550A3	PNEUMATIC STARTER	80
775550A5	PNEUMATIC STARTER	80
775550A7	PNEUMATIC STARTER	80
776443HAS	THERMCPL ASSY, BOX AND CABLE	77
776950-1	FUEL METERING UNIT BYPASS VALVE	73
779100-10	FUEL CONTROL UNIT	73
779100-4	FUEL CONTROL UNIT	73
779100-5	FUEL CONTROL UNIT	73
779100-9	FUEL CONTROL UNIT	73
7800001-00	VALVE RINSE PACKAGE 1EA PER PACK USED ON	38
7800028-00	VALVE ASSY, TOILET PKG, 1EA PER PK,ID PA	38
7800028-00	VALVE ASSY, TOILET PKG, 1EA PER PK,ID PA	38
7800029-00	VALVE TOILET, RINSE WATER	38
7800084-00	FLUSH CONTROL UNIT	38
7800084-00	FLUSH CONTROL UNIT	38
78-0170-50	PANEL, BIFURCATION, R/H LOWER	78
781169-5	TRANSDCR PRESSURE, 450 PSI STATIC SENSIT	73
783600-13-	CONTROL, ELECTRICAL ENGINE, EEC 104	73
783600-13-	CONTROL, ELECTRICAL ENGINE, EEC 104	73
783600-13-	CONTROL, ELECTRICAL ENGINE, EEC 104	73
783600-13-	CONTROL, ELECTRICAL ENGINE, EEC 104	73
783600-13-	CONTROL, ELECTRICAL ENGINE, EEC 104	73
783600-14-	CONTROL, ELECTRICAL ENGINE, EEC 104	73
783600-17-	CONTROL, ELECTRICAL ENGINE, EEC 104	73

783600-17-	CONTROL, ELECTRICAL ENGINE, EEC 104	73
783600-17-	CONTROL, ELECTRICAL ENGINE, EEC 104	73
783600-17-	CONTROL, ELECTRICAL ENGINE, EEC 104	73
783600-18-	CONTROL, ELECTRICAL ENGINE, EEC 104	73
783600-18-	CONTROL, ELECTRICAL ENGINE, EEC 104	73
783600-18-	CONTROL, ELECTRICAL ENGINE, EEC 104	73
783600-18-	CONTROL, ELECTRICAL ENGINE, EEC 104	73
784750A2	PNEUMATIC STARTER	80
784750A3	PNEUMATIC STARTER	80
784750A4	PNEUMATIC STARTER	80
784750A5	PNEUMATIC STARTER	80
784750A6	PNEUMATIC STARTER	80
785-002-61	COMPUTER, BLEED.MOTOR	36
785-002-7	COMPUTER, BLEED.MOTOR	36
787A0000-0	VALVE BLOCK, PCU; FLAP/SLAT; A320	27
788366-1	FUEL DISTRIBUTION VALVE	73
788366-2	FUEL DISTRIBUTION VALVE	73
788366-3	FUEL DISTRIBUTION VALVE	73
788399-3	AIR/OIL HEAT EXCHANGER VALVE	79
788399-4	AIR/OIL HEAT EXCHANGER VALVE	79
788399-5	AIR/OIL HEAT EXCHANGER VALVE	79
788399-6	AIR/OIL HEAT EXCHANGER VALVE	79
79-0051-50	PLUG -MAGNETIC ASSY.(USE ON DELTA EQUIP)	79
79-0051-50	ELECTRONIC CHIP DETECTOR	79
790270-1	HIGH PRESSURE SHUTOFF VALVE	36
790270-13	HIGH PRESSURE SHUTOFF VALVE	36
790270-14	HIGH PRESSURE SHUTOFF VALVE	36
790270-15	HIGH PRESSURE SHUTOFF VALVE	36
790270-2	HIGH PRESSURE SHUTOFF VALVE	36
790270-3	HIGH PRESSURE SHUTOFF VALVE	36
790270-4	HIGH PRESSURE SHUTOFF VALVE	36
790270-4-1	HIGH PRESSURE SHUTOFF VALVE	36

790270-5	HIGH PRESSURE SHUTOFF VALVE	36
790270-6	HIGH PRESSURE SHUTOFF VALVE	36
790270-7	HIGH PRESSURE SHUTOFF VALVE	36
790270-8	HIGH PRESSURE SHUTOFF VALVE	36
790270-9	HIGH PRESSURE SHUTOFF VALVE	36
790312-001	CONTROL, 6TH STAGE PRESSURE RATIO	75
790424-4	VALVE ENGINE STARTER MUST BE USABLE ON	80
7907939407	HARNESS WIRE ASSEMBLY.	49
791100-4-1	CONTROL, EEC - EA 51-476152-03	73
791100-4-1	CONTROL, EEC - EA 51-476152-03	73
791303-01	BULKHEAD, AFT MOVEABLE, USED ON A/C 685	25
7913861-55	VALVE, FLIGHT SPOILER,PRESSURE REDUCER,W	27
7920956-55	VALVE BRAKE CONTROL BUILT INTO CONVENIEN	32
792187-01	BULKHEAD, FORWARD MOVEABLE,USED ON A/C 6	25
792-6140-0	ANTENNA COUPLER	23
792755-11	PRESSURE CONTROLLER	36
792755-12	PRESSURE CONTROLLER	36
792755-13	PRESSURE CONTROLLER	36
792755-14	PRESSURE CONTROLLER	36
792755-15	PRESSURE CONTROLLER	36
792755-16	PRESSURE CONTROLLER	36
792755-4	PRESSURE CONTROLLER	36
792755-5	PRESSURE CONTROLLER	36
792755-6	PRESSURE CONTROLLER	36
792755-8	PRESSURE CONTROLLER	36
793261-001	DUCT FAN TURB POST EO 49-64241-3AD	72
793809-1	SENSOR ASSEMBLY, PRESSURE SET	73
793810-2	SENSOR ASSEMBLY, PRESSURE SET	73
7939410-50	WIRE USED ON A/C 982 AND SUBS AND A/C MO	49
7939415-50	WIRE USED ON A/C 982 AND SUBS AND A/C MO	49
793999-2	AIR/OIL HEAT EXCHANGER VALVE	24
793999-3	AIR/OIL HEAT EXCHANGER VALVE	24

7951209-50	SWITCH FLAP.HANDLE POSITION PURCHASE PN	27
7956753-55	VALVE, HYD MANUAL,3-POSITION 3-PORT,FUSE	32
7957134-50	INDICATR TEMPERATURE CONTROL VALVE POSIT	21
7958518-52	DUCT,WATER SEPARATOR TO CK VLV; RH	36
7958518-52	DUCT,WATER SEPARATOR TO CK VLV; RH	36
7958518-53	DUCT,WATER SEPARATOR TO CK VLV; RH	36
7958518-53	DUCT,WATER SEPARATOR TO CK VLV; RH	36
7958518-53	DUCT,WATER SEPARATOR TO CK VLV; RH	36
7958520-50	TRNSMTTR OIL QUANTITY FURNISHED WITH SEL	79
7958591-50	DUCT,WATER SEPARATOR TO CK VLV; RH	71
7958591-50	DUCT ANTI-ICE ALT 7958591-505 V8827	75
798750-1	AIR/OIL HEAT EXCHANGER VALVE	75
798750-2	AIR/OIL HEAT EXCHANGER VALVE	75
798850-1	AIR/OIL HEAT EXCHANGER VALVE	24
798850-2	AIR/OIL HEAT EXCHANGER VALVE	24
799643-3	PRESSURE CONTROLLER	36
799801-1	PRESSURE REGULATING AND SHUTOFF VALVE	36
799801-2	PRESSURE REGULATING AND SHUTOFF VALVE	36
799801-3	PRESSURE REGULATING AND SHUTOFF VALVE	36
799801-4	PRESSURE REGULATING AND SHUTOFF VALVE	36
7YE4000A7	WARMER, BUN,POST EO 01-453745-03	25
80000000-0	STABILIZER TRIM LIMIT SWITCH AND POSITION TRANSM	27
80000000-0	STABILIZER TRIM LIMIT SWITCH AND POSITION TRANSM	27
80000000-0	STABILIZER TRIM LIMIT SWITCH AND POSITION TRANSM	27
80000000-1	STABILIZER TRIM LIMIT SWITCH AND POSITION TRANSM	27
80000000-1	STABILIZER TRIM LIMIT SWITCH AND POSITION TRANSM	27
80000000-1	STABILIZER TRIM LIMIT SWITCH AND POSITION TRANSM	27
80000000-1	STABILIZER TRIM LIMIT SWITCH AND POSITION TRANSM	27
80000000-1	STABILIZER TRIM LIMIT SWITCH AND POSITION TRANSM	27
80000000-1	STABILIZER TRIM LIMIT SWITCH AND POSITION TRANSM	27
80000000-1	STABILIZER TRIM LIMIT SWITCH AND POSITION TRANSM	27
800100-1	EXTINGUISHER, FIRE; LAVATORY D AND S; 75	26
800100-3	EXTINGUISHER, FIRE; LAVATORY D AND S; 75	26

800100-5	EXTINGUISHER, FIRE; LAVATORY D AND S; 75	26
8002-3	WHEELCHR, ON BOARD	25
801000-3	FUEL METERING VALVE PW4000	73
801000-4	FUEL METERING VALVE PW4000	73
801307-00	STATIONARY CYLINDER & VALVE ASSEMBLY	35
801307-01	OXY, ASSY;VLV 9.00DIA;CREW/PSG HAS INSP	35
801307-02	OXYGEN BOTTLE	35
801307-03	OXYGEN BOTTLE	35
801307-04	STATIONARY CYLINDER & VALVE ASSEMBLY	35
801307-06	STATIONARY CYLINDER & VALVE ASSEMBLY	35
801307-07	OXYGEN BOTTLE	35
801307-08	OXYGEN BOTTLE	35
801307-09	OXYGEN BOTTLE	35
801307-10	OXYGEN BOTTLE	35
801307-11	OXYGEN BOTTLE	35
801307-20	OXYGEN BOTTLE	35
801307-22	STATIONARY CYLINDER & VALVE ASSEMBLY	35
801307-23	OXYGEN BOTTLE	35
801307-24	OXYGEN BOTTLE	35
802157-1	HIGH PRESSURE SHUTOFF VALVE	36
802157-1-7	HIGH PRESSURE SHUTOFF VALVE	36
802157-2	HIGH PRESSURE SHUTOFF VALVE	36
802157-3	HIGH PRESSURE SHUTOFF VALVE	36
802157-8	HIGH PRESSURE SHUTOFF VALVE	36
802170-1	HIGH PRESSURE SHUTOFF VALVE	36
802170-10	HIGH PRESSURE SHUTOFF VALVE	36
802170-11	HIGH PRESSURE SHUTOFF VALVE	36
802170-12	HIGH PRESSURE SHUTOFF VALVE	36
802170-2	HIGH PRESSURE SHUTOFF VALVE	36
802170-3	HIGH PRESSURE SHUTOFF VALVE	36
802170-4	HIGH PRESSURE SHUTOFF VALVE	36
802170-5	HIGH PRESSURE SHUTOFF VALVE	36

802170-9	HIGH PRESSURE SHUTOFF VALVE	36
803300-31	EMERGENCY POWER RESERVOIR	52
803300-33	EMERGENCY POWER RESERVOIR	52
803300-34	EMERGENCY POWER RESERVOIR	52
803300-35	EMERGENCY POWER RESERVOIR	52
803300-35A	EMERGENCY POWER RESERVOIR	52
803300-37	SNUBBER ENTRY DOOR RIGHT SIDE SHIP IN AT	52
803900-1	PWRSPPLY RECHARGEABLE POWER FAILURE CABI	33
804-0001	RECORDER, RECMARK II MINI QAR, USED ON	31
804-0002	RECORDER, RECMARK II MINI QAR, USED ON	31
804-0011	RECORDER, RECMARK II MINI QAR, USED ON	31
804044-15	BOTTLE, CYLINDER, OXY; ASSY	35
8055683-45	UNIT DATA ACQUISITION STATIC SENSITIVE	23
8061-638	UNIT FUEL METERING FURNISHED W/ATTACHING	73
806808-1	VSV ACTUATOR	75
806808-2	VSV ACTUATOR	75
806808-3	VSV ACTUATOR	75
806835-01	BOTTLE, CYLINDER, OXY; ASSY	35
807983-1	SENSOR ASSEMBLY, PRESSURE SET	73
808050-4-0	SENSOR ASSEMBLY, PRESSURE SET	73
808050-4-0	SENSOR ASSEMBLY, PRESSURE SET	73
808050-4-0	SENSOR ASSEMBLY, PRESSURE SET	73
808050-4-0	SENSOR ASSEMBLY, PRESSURE SET	73
808050-5-0	SENSOR ASSEMBLY, PRESSURE SET	73
808050-5-0	SENSOR ASSEMBLY, PRESSURE SET	73
808077-3	SENSOR ASSEMBLY, PRESSURE SET	73
808077-4	SENSOR ASSEMBLY, PRESSURE SET	73
808118-4	ELECTRONIC ENGINE CONTROL IPC	73
808556-1	INTERMEDIATE PRESSURE CHECK VALVE	36
808726-1	2.5 BLEED VALVE ACTUATOR - PW4000	75
808726-2	2.5 BLEED VALVE ACTUATOR - PW4000	75
808737-619	SEAT CO-PILOT MODIFIED PER EO 4-43451-3	25

81000-1500	LOGO LIGHT ASSEMBLY	33
81000-1500	LOGO LIGHT ASSEMBLY	33
81000-1500	LOGO LIGHT ASSEMBLY	33
81000-1500	LOGO LIGHT ASSEMBLY	33
81000-1500	LOGO LIGHT ASSEMBLY	33
81000-1500	LOGO LIGHT ASSEMBLY	33
81000-1500	LOGO LIGHT ASSEMBLY	33
81000-1500	LOGO LIGHT ASSEMBLY	33
81000-1500	LOGO LIGHT ASSEMBLY	33
81000-1721	LOGO LIGHT ASSEMBLY	33
81000-1721	LOGO LIGHT ASSEMBLY	33
81000-1750	FLIGHT COMPARTMENT INSTRUMENT PANEL FLOODLIGHT	33
81000-3760	LOGO LIGHT ASSEMBLY	33
81000-3760	LOGO LIGHT ASSEMBLY	33
81000-3770	LOGO LIGHT ASSEMBLY	33
81000-3770	LOGO LIGHT ASSEMBLY	33
81000-3770	LOGO LIGHT ASSEMBLY	33
81000-3770	LOGO LIGHT ASSEMBLY	33
81000-3780	SIGN EMER EXT DOOR LH SIGN	33
81000-3780	SIGN EMER EXT DOOR LH SIGN	33
81000-3790	LOGO LIGHT ASSEMBLY	33
81001-1500	LOGO LIGHT ASSEMBLY	33
81001-1500	LOGO LIGHT ASSEMBLY	33
810957-1	FUEL CONTROL UNIT	73
810A0000-0	SERVOCONTROL, RUDDER, A319/A320	27
810A0000-0	SERVOCONTROL, RUDDER, A319/A320	27
810A0000-0	SERVOCONTROL, RUDDER, A319/A320	27
811150-415	COFFEE MAKER	25
811150-417	COFFEE MAKER	25
811390-1	STARTER AIR VALVE - CF6-80C2	80
811390-3	STARTER AIR VALVE - CF6-80C2	80
813500-411	ACTUATOR ASSEMBLY	25

813520-1	FUEL METERING UNIT BYPASS VALVE	73
813664-1	VSV ACTUATOR	75
813664-2	VSV ACTUATOR	75
814392-2-0	PANEL CABIN PRESSURE CONTROL SELECTOR	21
814890-1	2.5 BLEED VALVE ACTUATOR - PW4000	75
814890-2	2.5 BLEED VALVE ACTUATOR - PW4000	75
815770-2-0	ELECTRONIC ENGINE CONTROL IPC	73
815770-2-0	ELECTRONIC ENGINE CONTROL IPC	73
815770-2-0	ELECTRONIC ENGINE CONTROL IPC	73
815770-2-0	ELECTRONIC ENGINE CONTROL IPC	73
815770-2-0	ELECTRONIC ENGINE CONTROL IPC	73
819779-1	VSV ACTUATOR	75
819802-1	VSV ACTUATOR	75
819810-1	VSV ACTUATOR	75
82000-4870	SIGN LAV OCCUPIED ALT 82000-49001ATS V	33
82000-4900	SIGN LAV OCCUPIED ALT 82000-49001ATS V	33
8201-11-00	OVEN, OVEN ASSY	25
8201-11-00	OVEN, SELL-BRITAX OVEN, ESD SENSITIVE	25
8201-17-00	OVEN, OVEN ASSY	25
8203-11-00	OVEN, SELL-BRITAX OVEN, ESD SENSITIVE	25
8203-11-00	OVEN, SELL-BRITAX OVEN, ESD SENSITIVE	25
822-0282-1	ILS-700/700A ILS RECEIVER	34
822-0297-0	VOR/MB NAVIGATION RECEIVER	34
822-0297-0	RECEIVER, VOR/ILS,ARINC 547,STATIC SENSI	34
822-0298-0	RECEIVER, ILS RECEIVER STATIC SENSITIVE	34
822-0299-0	ADF-900 ADF RECEIVER	34
822-0299-0	RECEIVER, ADF	34
822-0323-0	VHF-700 COMMUNICATIONS TRANSCEIVER	23
822-0323-0	VHF-900 COMMUNICATIONS TRANSCEIVER	23
822-0329-0	DISTANCE MEASURING EQUIPMENT	34
822-0329-0	TRANSCVR, DME	34
822-0330-0	HF900 HF RECEIVER-TRANSMITTER	23

822-0330-0	HFSM900 HF RECEIVER-TRANSMITTER	23
822-0334-0	LRA-900 RADIO ALTIMETER AND RAA-700 RADIO ALTIME	34
822-0334-0	LRA-900 RADIO ALTIMETER AND RAA-700 RADIO ALTIME	34
822-0334-0	LRA-900 RADIO ALTIMETER AND RAA-700 RADIO ALTIME	34
822-0336-0	TRNSPNDR ATC MODE S, USED ON 1801-1816 A	34
822-0693-0	VHF-700 COMMUNICATIONS TRANSCEIVER	23
822-0693-0	VHF-700 COMMUNICATIONS TRANSCEIVER	23
822-0693-0	VHF-700 COMMUNICATIONS TRANSCEIVER	23
822-0726-1	VOR-70	34
822-0761-1	RECEIVER VOR/ILS NAV	34
822-0987-0	COUPLER HF ANTENNA	23
822-0987-0	CPL-920D HF ANTENNA COUPLER	23
822-0987-0	CPL-920D HF ANTENNA COUPLER	23
822-0989-0	TRANSCEIVER, HF, 747-400;757-3	23
822-0990-0	HFSM900 HF RECEIVER-TRANSMITTER	23
822-0990-0	HFSM900 HF RECEIVER-TRANSMITTER	23
822-0990-0	HFSM900 HF RECEIVER-TRANSMITTER	23
822-0990-0	HFSM900 HF RECEIVER-TRANSMITTER	23
822-1033-1	ENGINE AND ALERT PROCESSOR	31
822-1044-0	VHF-700 COMMUNICATIONS TRANSCEIVER	23
822-1044-0	VHF-700 COMMUNICATIONS TRANSCEIVER	23
822-1047-0	VHF-900 COMMUNICATIONS TRANSCEIVER	23
822-1047-0	VHF-900 COMMUNICATIONS TRANSCEIVER	23
822-1047-0	VHF-900 COMMUNICATIONS TRANSCEIVER	23
822-1047-2	VHF-900 COMMUNICATIONS TRANSCEIVER	23
822-1178-1	DU-9801 DISPLAY UNIT	31
822-1178-1	DU-9801 DISPLAY UNIT	31
822-1239-1	CMU-900 COMMUNICATIONS MANAGMENT UNIT	23
822-1239-1	CMU-900 COMMUNICATIONS MANAGMENT UNIT	23
822-1250-0	VHF-920 VHF TRANSCEIVER	23
822-1261-1	FCC-703 FLIGHT CONTROL COMPUTER	22
822-1261-1	FCC-703 FLIGHT CONTROL COMPUTER	22

822-1287-1	VHF-210	23
822-1287-1	VHF-210	23
822-1293-0	TTR-921 TCAS TRANSMITTER-RECEIVER & TRE-920	34
822-1293-0	TTR-921 TCAS TRANSMITTER-RECEIVER & TRE-920	34
822-1338-0	TPR-901 ATC/MODE S TRANSPONDER	34
822-1338-0	TPR-901 ATC/MODE S TRANSPONDER	34
822-1338-0	TPR-901 ATC/MODE S TRANSPONDER	34
822-1338-0	TPR-901 ATC/MODE S TRANSPONDER	34
822-1379-1	DSP-9800 DISPLAY SELECT PANEL	31
822-1381-1	DISPLAY PROCESSING COMPUTER	31
822-1382-1	DCC-9800 DATA CONCENTRATOR COMPUTER	31
822-1567-1	MCP-730 MODE CONTROL PANEL	22
822-1567-1	MCP-730 MODE CONTROL PANEL	22
822-1604-1	FCC-730 FLIGHT CONTROL COMPUTER	22
822-1604-1	FCC-730 FLIGHT CONTROL COMPUTER	22
822-1710-0	WRT-2100 Receiver	34
822-1710-0	WRT-2100 Receiver	34
822-1710-2	WRT-2100 Receiver	34
822-1710-2	WRT-2100 Receiver	34
822-1821-0	GLU-925 GLOBAL LANDING UNIT	34
822-1821-3	GLU-925 GLOBAL LANDING UNIT	34
822-1821-3	GLU-925 GLOBAL LANDING UNIT	34
823742-1	2.5 BLEED VALVE ACTUATOR - PW4000	75
8241-01	FIRE DETECTOR ASSEMBLIES	26
824250-610	ELECTRICALLY-POWERED CAPTAIN AND FIRST OFFICER	25
824250-611	ELECTRICALLY-POWERED CAPTAIN AND FIRST OFFICER	25
824251-608	ELECTRICALLY-POWERED CAPTAIN AND FIRST OFFICER	25
824251-611	ELECTRICALLY-POWERED CAPTAIN AND FIRST OFFICER	25
824251-615	ELECTRICALLY-POWERED CAPTAIN AND FIRST OFFICER	25
824252-612	FLIGHT ENGINEER SEAT	25
825204-1	FLOW CONTROL AND SHUTOFF VALVE	21
825230-1	FLOW SENSING VENTURI	21

825301-1	HIGH PRESSURE SHUTOFF/PRESSURE REGULATING VAL	36
825303-2	PRESSURE REGULATING SHUTOFF VALVE	36
825305-2	FAN AIR MODULATING VALVE	36
825501-10	PW4000 FUEL PUMP	73
825501-11	PW4000 FUEL PUMP	73
825501-12	PW4000 FUEL PUMP	73
825501-8	PW4000 FUEL PUMP	73
825501-9	PW4000 FUEL PUMP	73
8256M4	COMPRSSR AIR, POTABLE WATER AUXILIARY AI	38
826300-601	SEAT OBSERVER SHIP IN ATA SPEC 300	25
826300-603	SEAT OBSERVER SHIP IN ATA SPEC 300	25
826301-603	SEAT, OBSERVERS, ALL DC9;	25
8270016-3	CONTAINR AFT INFLATABLE SLIDE	25
8270016-5	CONTAINR AFT INFLATABLE SLIDE	25
827104-1	FUEL CONTROL	73
827262-401	ELECTRICALLY-POWERED CAPTAIN AND FIRST OFFICER	25
827262-402	SEAT OBSERVER SHIP IN ATA SPEC 300	25
828300-3	FUEL PUMP	73
828300-4	FUEL PUMP	73
828300-5	FUEL PUMP	73
828450-405	OVEN ASSEMBLIES	25
828450-407	OVEN ASSEMBLIES	25
828450-407	OVEN ASSEMBLIES	25
828450-409	OVEN ASSEMBLIES	25
828490-401	BUN WARMER	25
83000-0560	WINDOW HEAT CONTROL	30
83000-0560	WINDOW HEAT CONTROL	30
83000-0560	WINDOW HEAT CONTROL	30
83000-2790	MODULE, WINDOW HEAT CONTROL	30
831610-401	OVEN, Double, Less Racks, G2C, G2D & G4B	25
831610-401	OVEN, Double, Less Racks, G2C, G2D & G4B	25
831610-403	OVEN, Double, Less Racks, G2C, G2D & G4B	25

831610-403	OVEN, Double, Less Racks, G2C, G2D & G4B	25
831610-405	OVEN, Double, Less Racks, G2C, G2D & G4B	25
831620-401	OVEN, Double, Less Racks, G2C, G2D & G4B	25
831620-401	OVEN, Double, Less Racks, G2C, G2D & G4B	25
831620-403	OVEN, Double, Less Racks, G2C, G2D & G4B	11
831620-403	OVEN, Double, Less Racks, G2C, G2D & G4B	25
831620-405	OVEN, Double, Less Racks, G2C, G2D & G4B	25
832200-602	ELECTRICALLY-POWERED CAPTAIN AND FIRST OFFICER	25
832200-603	ELECTRICALLY-POWERED CAPTAIN AND FIRST OFFICER	25
832260-401	ELECTRICALLY-POWERED CAPTAIN AND FIRST OFFICER	25
832260-402	ELECTRICALLY-POWERED CAPTAIN AND FIRST OFFICER	25
8-336-04	BOX PROXIMITY, LANDING GEAR SWITCH..	32
8-336-05	BOX PROXIMITY, LANDING GEAR SWITCH..	32
8-336-05M0	BOX PROXIMITY, LANDING GEAR SWITCH..	51
834002-403	PUMP, WATER, WASTE FLUSH,WITH MOTOR,"FUR	38
835880-404	TOILET, LAV-AFT R/H	
835880-405	TOILET, LAV-AFT R/H	38
835881-405	TOILET, LAV-AFT R/H	38
836SD6-20	INDICATR TAXI-SPEED, USED ON B767 A/C 10	32
8378M12	COMPRESSOR, WATER, AIR	38
839513-401	WARMER, BUN	25
839513-403	WARMER, BUN	25
8-416-01	PROXIMITY SWITCH ELECTRONICS UNIT	32
8-416-02	PROXIMITY SWITCH ELECTRONICS UNIT	32
84333-00-0	COMPUTER, SLAT/FLAP CONTROL, SFCC; A330	27
84333-00-0	COMPUTER, SLAT/FLAP CONTROL, SFCC; A330	27
8-497-03	UNIT PROXIMITY SWITCH ELECTRONIC STATIC	32
8-497-04	UNIT PROXIMITY SWITCH ELECTRONIC STATIC	32
861CAB	ANGLE OF ATTACK SENSOR	34
861CABM0	ANGLE OF ATTACK SENSOR	34
86-20A	TRNSFRMR BALLAST, PEDESTAL AND CONSOLE L	33
870600-100	VALVE IN LINE HYD,PRESSURE BULKHEAD TO L	29

87093732V0	OBRM, Z1, SOFTWARE FOR FCDC (-04M02);	27
871BN3-2	ICE DETECTOR	30
871BN3-4	ICE DETECTOR	30
88267-2	DUCT ASSY.,LH ENGINE STARTER	80
88269-2	DUCT ASSY.,LH ENGINE STARTER	80
8-887-02	SENSOR BATTERY PACKAGE 1EA PER PACK,	24
8-887-03	SENSOR BATTERY PACKAGE 1EA PER PACK,	24
89-01-0700	HANDSET,CABIN; A319	23
89-01-0704	HANDSET,CABIN; A319	23
89-01-0707	HANDSET,CABIN; A319	23
89-01-0712	HANDSET,CABIN; A319	23
89-01-0715	HANDSET,CABIN; A319	23
8901-254	TEMPERATURE SENSOR ASSEMBLY - CF6	73
8901-318	TEMPERATURE SENSOR ASSEMBLY - CF6	
891511-14	OXY, ASSY;VLV 9.00DIA;CREW/PSG HAS INSP	35
8-930-03	BATTERY CHARGER	24
8960-02-00	HARNESS, MW0326; FIRE DETECTION;	26
898150-1	CONTAINR, FIRE EXTNGSHR,S/L 60 MOS BUILT	26
898150-3	CONTAINR, FIRE EXTNGSHR,S/L 60 MOS BUILT	26
898732-02	CONTROL CARD, ENGINE OVERHEAT AND SHORT DISCR	26
898737-1	FIRE DECTECTOR ASSEMBLY	26
898738-1	FIRE DECTECTOR ASSEMBLY	26
899-0850-0	PANEL, RADIO MANAGEMENT, RMP; SEE IGK; A	23
899-0850-0	PANEL, RADIO MANAGEMENT, RMP; SEE IGK; A	23
899-0850-0	PANEL, RADIO MANAGEMENT, RMP; SEE IGK; A	23
899-0850-0	PANEL, RADIO MANAGEMENT, RMP; SEE IGK; A	23
8A1248	DUCT ASSY, COOLING AIR SHIP IN ATA SPEC	75
8A1249	DUCT ASSY, COOLING AIR SHIP IN ATA SPEC	72
8A1874	DUCT ASSY, COOLING AIR SHIP IN ATA SPEC	75
8A1878	DUCT ASSY, COOLING AIR SHIP IN ATA SPEC	75
8D1494	GAGE PRESSURE SWITCH	79
8D1496	GAGE PRESSURE SWITCH	79

8DJ339WAI	STANDBY ENGINE INDICATOR	77
8DJ339WAI	STANDBY ENGINE INDICATOR	77
8ES005304	POWER SUPPLY, A319/A320/A330.	33
8ES005309	POWER SUPPLY, STROBE, A319/A320/A330	33
8ES403703	TRANSFORMER, REAR NAV LIGHT; D.	33
8ES455012	POWER SUPPLY, A319/A320/A330.	33
8ES455438	POWER SUPPLY, STROBE, A319/A320/A330	33
8ES455438	POWER SUPPLY, STROBE, A319/A320/A330	33
8ES455440	POWER SUPPLY, A319/A320/A330	33
8G1270	GAGE PRESSURE SWITCH	21
8TC19AAH1	HPTCC THERMOCOUPLE PROBE	73
8TC19AAN1	T3 SENSOR	72
8TC34ABF1	ENGINE BLEED AIR THERMOCOUPLE PROBE	72
8TC34ABF2	PROBE, EGT THERMACOUPLE	72
8TC34ABF4	PROBE, EGT THERMACOUPLE	72
8TC34ABH8	EGT THERMOCOUPLE PROBE	77
8TC34ABW	EGT THERMOCOUPLE PROBE	77
8TJ124GGA	FUEL FLOW TRANSMITTER	73
8TJ124GGM	FUEL FLOW TRANSMITTER	73
8TJ124GGN	FUEL FLOW TRANSMITTER	73
8TJ124GGN	FUEL FLOW TRANSMITTER	73
8TJ124GGT	FUEL FLOW TRANSMITTER	73
8TJ138AAA	FAN SPEED SENSOR	77
8TJ138AAA	FAN SPEED SENSOR	77
8TJ146AAP	TRNSMTTR OIL QUANTITY FURNISHED WITH SEL	79
8TJ146AAY	TRNSMTTR OIL QTY, ENGINE	79
8TJ146CFA	OIL LEVEL SENSOR	79
8TJ85GCG2	TRNSMTTR ENGINE FUEL FLOW FURNISHED WITH	73
8TJ88GAN1	PWRSPPLY FUEL FLOW	73
8TJ88GAN3	PWRSPPLY FUEL FLOW	73
8TJ88GAN4	PWRSPPLY FUEL FLOW	73
8TJ99GGE1	LIQUID LEVEL TRANSMITTER	49

90-0215-1	WINDSHIELD WIPER GEARCASE ASSEMBLY	30
90-0215-2	WINDSHIELD WIPER GEARCASE ASSEMBLY	30
90-0215-3	WINDSHIELD WIPER GEARCASE ASSEMBLY	30
90-0215-4	WINDSHIELD WIPER GEARCASE ASSEMBLY	30
9002D14-1	TRNSFRMR AC POWER DIFFERENTIAL CURRENT P	24
90042-411	SPIGOT GALLEY WATER ALT 821765-403	38
9008D09-1	RELAY, AC POWER, IMPROVED	24
9008D09-2	RELAY, AC POWER, IMPROVED	24
9008D09-3	RELAY, AC POWER, IMPROVED	24
900974-03	DETECTOR, DETECTION, SYSTEM FIRE; LH;	26
902013-01	MODEL 801-DRSS FIRE/OVERHEAT DETECTOR ASSEMBL	26
902014-01	MODEL 801-DRSS FIRE/OVERHEAT DETECTOR ASSEMBL	26
902016-01	FIRE/OVERHEAT DETECTOR ASSEMBLY	26
902018-01	FIRE/OVERHEAT DETECTOR ASSEMBLY	26
902020-01	MODEL 801-DRSS FIRE/OVERHEAT DETECTOR ASSEMBL	26
902862-01	FIRE/OVERHEAT DETECTOR ASSEMBLY	26
903-1341	MICROPHONE	23
903-1342	MICROPHONE	23
90-42603-1	STOP, CARGO, INSOURCE CUSTOMER	25
9045000-1	EXCITER ENG IGNITION ALT 49988	74
9045330-2	EXCITER IGNITION MUST BE USABLE ON	74
9049300-2	UNIT,APU IGNITION	49
9052304-1	HARNESS EEC WIRING SHIP IN CATEGORY 2 CO	73
9101M52P0	EXCITER, ENG IGNITION	74
9101M52P1	EXCITER, ENG IGNITION	74
9101M52P1	EXCITER, ENG IGNITION	74
9101M52P1	EXCITER, ENG IGNITION	74
9101M52P1	EXCITER, ENG IGNITION	74
9101M52P1	EXCITER, ENG IGNITION	74
9101M52P1	EXCITER, ENG IGNITION	74
9131-8506	RELAY MISC ELECTRONIC PANELS ALT BH31	24
91465-117	SEAT.. F/A, SINGLE, WALL MOUNTED; 3L;	25
91465-211	SEAT.. F/A, SINGLE, WALL MOUNTED; 3L;	25

91465-217	SEAT.. F/A, SINGLE, WALL MOUNTED; 3L;	25
91466-211	SEAT, F/A, DOUBLE, WALL MOUNTED; 5635-56	25
91466-511	SEAT, F/A, DOUBLE, WALL MOUNTED; 5635-56	25
91466-611	SEAT, F/A, DOUBLE, WALL MOUNTED; 5635-56	25
914F565-4	PANEL BUS, AC CONTROL	24
92001-10-1	DRIVE, CARGO LOADING PDU POST ERA 414354	25
920129-100	MOTOR OPERATED CARTRIDGE SELECTOR VALVE	27
920129-200	MOTOR OPERATED CARTRIDGE SELECTOR VALVE	27
920129-300	MOTOR OPERATED CARTRIDGE SELECTOR VALVE	27
9221M80P0	FAN SPEED SENSOR	77
9238M66P0	IGNITION EXCITERS	74
9238M66P0	IGNITION EXCITERS	74
9238M66P1	IGNITION EXCITERS	74
924D100-1	ACTUATOR LINEAR, SPEED BRAKE LEVER SHIP	27
9257M34P0	ACCLRMTR,NBR 1 BGR, INTERNALLY MOUNTED	77
9257M34P0	ACCLRMTR,NBR 1 BGR, INTERNALLY MOUNTED	77
9269-10117	RELAY WARNING LIGHT DIMMING	33
9280-14	MAIN FUEL PUMP	
9280-14A1	MAIN FUEL PUMP	73
9280-15A1	MAIN FUEL PUMP	73
9280-16A1	MAIN FUEL PUMP	73
9280-16A2	MAIN FUEL PUMP	
9280-16A3	MAIN FUEL PUMP	
9280-17A3	MAIN FUEL PUMP	73
9280-17A4	MAIN FUEL PUMP	73
9280-17A5	MAIN FUEL PUMP	73
9280-18	MAIN FUEL PUMP	73
9280-18A2	MAIN FUEL PUMP	
9280-18A3	MAIN FUEL PUMP	73
9280-18A6	MAIN FUEL PUMP	73
9281M10P0	ACCELEROMETER	77
9281M10P0	ACCELEROMETER	77

9284M71P0	ACCLRMTR BEARING EXTERNAL VIBRATION MONI	77
9285M98G0	TUBE OIL B SUMP SUPPLY LT SIDE	72
9288M10G0	TUBE OIL B SUMP SUPPLY LT SIDE	72
9292M68G0	TUBE OIL B SUMP SUPPLY LT SIDE	72
9292M94G0	TUBE OIL B SUMP SUPPLY LT SIDE	72
9297M86G0	MANIFOLD LOW PRESSURE TURBINE PACKAGE 1	73
9297M86G0	MANIFOLD LOW PRESSURE TURBINE PACKAGE 1	73
9297M86G0	MANIFOLD LOW PRESSURE TURBINE PACKAGE 1	73
9297M86G0	MANIFOLD LOW PRESSURE TURBINE PACKAGE 1	73
9352124-50	WARMER, BUN, UPPER DECK GALLEY	25
9354M30G0	TUBE OIL B SUMP SUPPLY LT SIDE	72
9354M43G0	MANIFOLD LOW PRESSURE TURBINE PACKAGE 1	72
9354M43G0	MANIFOLD LOW PRESSURE TURBINE PACKAGE 1	72
9354M87G0	TUBE OIL B SUMP SUPPLY LT SIDE	72
9355M33P1	FUEL PUMP - CF6-80C2	73
93560-07	AUXILIARY POWER UNIT VIBRATION ISOLATION	49
93560-08	AUXILIARY POWER UNIT VIBRATION ISOLATION	49
93560-09	AUXILIARY POWER UNIT VIBRATION ISOLATION	49
93560-10	AUXILIARY POWER UNIT VIBRATION ISOLATION	49
93560-11	AUXILIARY POWER UNIT VIBRATION ISOLATION	49
9361M72G0	MANIFOLD LOW PRESSURE TURBINE PACKAGE 1	72
9361M72G0	MANIFOLD LOW PRESSURE TURBINE PACKAGE 1	72
9367M18P0	ENGINE BLEED AIR THERMOCOUPLE PROBE	72
9373M91P0	PROBE, EGT THERMOCOUPLE CF680C2/80E1	77
9377M60P0	DIFFERENTIAL PRESSURE SWITCH	79
9377M61P0	FUEL FLOW TRANSMITTER	73
937E205G3	THRUST MANAGEMENT COMPUTER	22
937E305G2	THRUST MANAGEMENT COMPUTER	22
9387M17P0	STATOR, ECU ALTERNATOR, CFM56-5	73
93A152-00	COCKPIT VOICE RECORDER	23
93A152-20	COCKPIT VOICE RECORDER	23
93A152-25	PANEL, CONTROL , VOICE RECORDER.	23

93A152-30	COCKPIT VOICE RECORDER	23
93A152-50	PANEL, CONTROL , VOICE RECORDER.	23
93A152-70	PANEL, CONTROL , VOICE RECORDER.	23
940D046-1	STATOR AC GENERATOR NO AIRCRAFT SHIPPING	24
940D531-4	STATOR AC GENERATOR NO AIRCRAFT SHIPPING	24
946F979-1	STATOR AC GENERATOR NO AIRCRAFT SHIPPING	24
947F945-3	PANEL GENERATOR CONTROL	24
947F946-1	PANEL BUS, AC CONTROL AD 90-03-17	24
947F946-2	PANEL BUS, AC CONTROL AD 90-03-17	24
947F946-3	PANEL BUS, AC CONTROL AD 90-03-17	24
948E308G2	THRUST MANAGEMENT COMPUTER	22
948E309G3	THRUST MANAGEMENT COMPUTER	22
948E310G1	THRUST MANAGEMENT COMPUTER	22
948E310G2	THRUST MANAGEMENT COMPUTER	22
948E410G2	COMPUTER, THRUST MANAGEMENT	22
948E414G2	THRUST MANAGEMENT COMPUTER	22
948E416G1	THRUST MANAGEMENT COMPUTER	22
948E501G3	THRUST MANAGEMENT COMPUTER	22
948E502G3	THRUST MANAGEMENT COMPUTER	22
948E503G2	THRUST MANAGEMENT COMPUTER	22
94FS481420	VALVE LAV DRAIN USED ON AC 9015 AND SUB	30
9590-1	ACTUATOR HORIZONTAL STABILIZER PRIMARY.T	27
9590-5	ACTUATOR HORIZONTAL STABILIZER PRIMARY.T	27
9590-6	ACTUATOR HORIZONTAL STABILIZER PRIMARY.T	27
96043-01	ISOLATOR, VIBRATION,FWD RH,APU INITIAL P	49
96043-03	ISOLATOR, VIBRATION,FWD RH,APU INITIAL P	49
9632501-20	CABLE,CONTROL,POTABLE WATER	38
965-0449-0	COMPUTER STALL WARNING STATIC SENSITIVE	34
965-0976-0	MKV ENHANCED GROUND PROXIMITY WARNING SYSTEM	34
965-0976-0	MKV ENHANCED GROUND PROXIMITY WARNING SYSTEM	34
965-0976-0	MKV ENHANCED GROUND PROXIMITY WARNING SYSTEM	34
965-0976-0	MKV ENHANCED GROUND PROXIMITY WARNING SYSTEM	34

965-0976-0	MKV ENHANCED GROUND PROXIMITY WARNING SYSTEM	34
965-0976-0	MKV ENHANCED GROUND PROXIMITY WARNING SYSTEM	34
965-0976-0	MKV ENHANCED GROUND PROXIMITY WARNING SYSTEM	34
965-0976-0	MKV ENHANCED GROUND PROXIMITY WARNING SYSTEM	34
965-0976-0	MKV ENHANCED GROUND PROXIMITY WARNING SYSTEM	34
965-0976-0	MKV ENHANCED GROUND PROXIMITY WARNING SYSTEM	34
965-0976-0	MKV ENHANCED GROUND PROXIMITY WARNING SYSTEM	34
965-0976-0	MKV ENHANCED GROUND PROXIMITY WARNING SYSTEM	34
965-0976-0	MKV ENHANCED GROUND PROXIMITY WARNING SYSTEM	34
965-0976-0	MKV ENHANCED GROUND PROXIMITY WARNING SYSTEM	34
965-1676-0	MKV ENHANCED GROUND PROXIMITY WARNING SYSTEM	34
965-1690-0	MKV ENHANCED GROUND PROXIMITY WARNING SYSTEM	34
965-1690-0	MKV ENHANCED GROUND PROXIMITY WARNING SYSTEM	34
965-1690-0	MKV ENHANCED GROUND PROXIMITY WARNING SYSTEM	34
9693-13-1	SPIGOT ASSEMBLY	38
9693-13-3	SPIGOT ASSEMBLY	38
9700A1ABF	PORTABLE CYLINDER ASSEMBLIES	35
9700C1ABF	PORTABLE CYLINDER ASSEMBLIES	35
9700C1ABF	PORTABLE CYLINDER ASSEMBLIES	35
9700C2CF2	PORTABLE CYLINDER ASSEMBLIES	35
9700C3CBF	PORTABLE CYLINDER ASSEMBLIES	35
974B0000-0	PLENUM	21
9750B0818	BATTERY MAIN DC POWER SHELF LIFE 3 MONTH	24
976J252-3	STATOR AC GENERATOR NO AIRCRAFT SHIPPING	24
976J252-6	GENERATR AC, 40 KVA, ENG DRIVEN, MOD DWG	24
976J252-8	GENERATR AC, 40 KVA, ENG DRIVEN, MOD DWG	24
978C0000-0	CONTROLLER, ZONE TEMPERATURE - A330	21
978C0000-0	CONTROLLER, ZONE TEMPERATURE - A330	21
978C0000-0	CONTROLLER, ZONE TEMPERATURE - A330	21
978C0000-0	CONTROLLER, ZONE TEMPERATURE - A330	21
979410-4	VALVE ENGINE STARTER CONTROL USED ON JT8	80
979410-5	VALVE ENGINE STARTER CONTROL USED ON JT8	80

979410-6	VALVE ENGINE STARTER CONTROL USED ON JT8	80
979680-1-1	VALVE TEMP CONTROL, WATER SEPARATOR	21
979806-10	SURGE CONTROL VALVE	49
979806-11	SURGE CONTROL VALVE	49
979806-12	SURGE CONTROL VALVE	49
979806-5	SURGE CONTROL VALVE	49
979806-6	SURGE CONTROL VALVE	49
979806-7	SURGE CONTROL VALVE	49
979806-8	SURGE CONTROL VALVE	49
979806-9	SURGE CONTROL VALVE	49
980-4700-0	FLIGHT DATA RECORDER	31
980-4700-0	FLIGHT DATA RECORDER	31
980-4700-0	FLIGHT DATA RECORDER	31
980-4700-0	FLIGHT DATA RECORDER	31
980-6022-0	COCKPIT VOICE RECORDER	23
9810-5	MECHANICALLY TIMED FAUCET ASSY	38
9834-100	FAUCET LAVATORY PACKAGE 1EA PER PACK,	38
9915570-50	STRUT VENTRAL STAIR DOOR ACTUATOR RIGHT	52
9934502-52	PLATE WING AND NOSE LANDING GEAR LIGHT	33
9934504-52	PLATE, LIGHTPLATE ASSY, PEDESTAL	33
999-2010-5	DOOR ASSEMBLY, FAN COWL	71
9994-1	HINGE, CABIN,OVERHEAD,STORAGE COMPT RH,U	25
999D5053-5	SWITCH, PDOS	78
999D5056-5	ROD, T/R HOLD OPEN	78
9BG408324	UNIT, CONTROL, CHART HOLDER RH.	33
9EL455890-	LENS, WING TIP, RH	33
9EL455890-	LENS, WING TIP, LH	33
9EL455891-	LENS, LANDING TAXI LIGHT, RH	33
9EL455891-	LENS, LANDING TAXI LIGHT, LH	33
A2350-0048	ACTUATOR ACTUATOR, VALVE SELECTOR EQUIV	38
A257728500	GUIDE, -Y;	78
A28320-1	AUTOPILOT SERVO ASSEMBLY	22

A28320-10	AUTOPILOT SERVO ASSEMBLY	22
A28320-11	AUTOPILOT SERVO ASSEMBLY	22
A28320-12	AUTOPILOT SERVO ASSEMBLY	22
A28320-13	AUTOPILOT SERVO ASSEMBLY	22
A28320-15	AUTOPILOT SERVO ASSEMBLY	22
A28320-2	AUTOPILOT SERVO ASSEMBLY	22
A28320-3	AUTOPILOT SERVO ASSEMBLY	22
A28320-4	AUTOPILOT SERVO ASSEMBLY	22
A28320-5	AUTOPILOT SERVO ASSEMBLY	22
A28320-6	AUTOPILOT SERVO ASSEMBLY	22
A28320-7	AUTOPILOT SERVO ASSEMBLY	22
A28320-8	AUTOPILOT SERVO ASSEMBLY	22
A28320-9	AUTOPILOT SERVO ASSEMBLY	22
A28321-10	ELEVATOR AUTOPILOT SERVO ASSEMBLY	22
A28321-11	ELEVATOR AUTOPILOT SERVO ASSEMBLY	22
A28321-12	ELEVATOR AUTOPILOT SERVO ASSEMBLY	22
A28321-13	ELEVATOR AUTOPILOT SERVO ASSEMBLY	22
A28321-14	ELEVATOR AUTOPILOT SERVO ASSEMBLY	22
A28321-15	ELEVATOR AUTOPILOT SERVO ASSEMBLY	22
A28321-16	ELEVATOR AUTOPILOT SERVO ASSEMBLY	22
A28321-18	ELEVATOR AUTOPILOT SERVO ASSEMBLY	22
A28321-2	ELEVATOR AUTOPILOT SERVO ASSEMBLY	22
A28321-2M	ELEVATOR AUTOPILOT SERVO ASSEMBLY	22
A28321-3	ELEVATOR AUTOPILOT SERVO ASSEMBLY	22
A28321-3M	ELEVATOR AUTOPILOT SERVO ASSEMBLY	22
A28321-4	ELEVATOR AUTOPILOT SERVO ASSEMBLY	22
A28321-5	ELEVATOR AUTOPILOT SERVO ASSEMBLY	22
A28321-6	ELEVATOR AUTOPILOT SERVO ASSEMBLY	22
A28321-7	ELEVATOR AUTOPILOT SERVO ASSEMBLY	22
A28321-8	ELEVATOR AUTOPILOT SERVO ASSEMBLY	22
A28321-9	ELEVATOR AUTOPILOT SERVO ASSEMBLY	22
A28640-10	LATERAL CENTRAL CONROL ACTUATOR	27

A28640-12	LATERAL CENTRAL CONROL ACTUATOR	27
A28640-2	LATERAL CENTRAL CONROL ACTUATOR	27
A28640-3	LATERAL CENTRAL CONROL ACTUATOR	
A28640-4	LATERAL CENTRAL CONROL ACTUATOR	27
A28640-5	LATERAL CENTRAL CONROL ACTUATOR	27
A28640-6	LATERAL CENTRAL CONROL ACTUATOR	27
A28640-7	LATERAL CENTRAL CONROL ACTUATOR	27
A28640-8	LATERAL CENTRAL CONROL ACTUATOR	27
A28640-9	LATERAL CENTRAL CONROL ACTUATOR	27
A3-254-000	MIRROR, LAV E & F, CABINET; W/LIGHT;	25
A36157100	STANDBY AIRSPEED INDICATOR	34
A400G2	RELAY AUXILIARY.POWER.UNIT (APU) STARTER	49
A46197100	STANDBY ALTIMETER	34
A703CD	GTCP331-200 APU WIRE HARNESS	49
A800100-1	EXTINGUISHER, FIRE; LAVATORY D AND S; 75	26
A800100-3	EXTINGUISHER, FIRE; LAVATORY D AND S; 75	26
A825100-3	EXTINGUISHER, FIRE; LAVATORY D AND S; 75	26
A825100-4	EXTINGUISHER, FIRE; LAVATORY D AND S; 75	26
AC2A	AUTO THROTTLE SERVO MOTOR	22
AC30-0003	SWITCH, ROTARY, AUTO BRAKE	32
AC30-0003	SWITCH, ROTARY, AUTO BRAKE	32
AC30-0003	SWITCH, ROTARY, AUTO BRAKE	32
AC30-0003	SWITCH, ROTARY, AUTO BRAKE	32
AC30-0004	SWITCH STARTER ASSEMBLY	31
AC30-0004	SWITCH STARTER ASSEMBLY	31
ACP2788A	CONTROL PANEL, AUDIO, ACP;A319	23
ACP2788AE	CONTROL PANEL, AUDIO, ACP;A319	23
ACP2788AE	CONTROL PANEL, AUDIO, ACP;A319	23
ADP1664-1	TANK POTABLE WATER ALT S417N201-1	38
AG7000-01	VIDEO CASSETTE PLAYER	25
AIR91728	TRANSFER CYLINDER / ACCUMULATOR	32
AIR91728-1	TRANSFER CYLINDER / ACCUMULATOR	28

AIR91740	ACCUMULATOR	32
AIR91740-0	ACCUMULATOR	32
AIR91740-1	ACCUMULATOR	32
AJH7011-50	PUSHROD ELEVATOR ANTI-FLOAT TAB CONTROL	27
AMI395455	LINK, FLT SPOILER ACTUATING MECH DRIVE	27
AR9012-3D	FAUCET ASSEMBLY	38
AR9030-1D	FAUCET,LAV SINK, USED ON B757 A/C MODIF	38
AR9030-3D	FAUCET,LAV SINK, USED ON B757 A/C MODIF	38
AR9030-3D	FAUCET,LAV SINK, USED ON B757 A/C MODIF	38
AR9030-3D	FAUCET,LAV SINK, USED ON B757 A/C MODIF	38
AR9042-11	HEATER, WATER; LAVATORY	38
ASH734-1	INVERTER STATIC EMERGENCY A/C POWER OPEN	24
ASP4550	SWITCH, APU OIL PRESSURE, LOW	49
AV13J5144	SELECTOR VALVES	29
AV13J5147	SELECTOR VALVES	27
AV13J5158	MOTOR OPERATED CARTRIDGE SELECTOR VALVE	27
AV16A1275	VALVE DEFUEL SHUTOFF RESTRICTED AIR SHIP	28
AV16B1736	VALVE, FUEL FILL, RESTRICTED AIR SHIPMEN	28
AV16B1965	VALVE,GATE SHUTOFF,See Basic Data Text	29
AV16B2100	VALVE,GATE SHUTOFF,See Basic Data Text	29
AV16E1305	MOTOR OPERATED SHUTOFF VALVE	78
AV16E3261	VALVE POTABLE WATER SYSTEM SHUT-OFF	38
AV24A1166	VALVE HYD FIRE SHUT-OFF LH AND RH	29
AV31	ACTUATOR	28
AV31-1	ACTUATOR	28
AV32	FUEL SHUTOFF VALVE	28
AW2835AB	CABIN ALTITUDE & DIFFERENTIAL PRESSURE INDICATOR	21
AW2835AB	CABIN ALTITUDE & DIFFERENTIAL PRESSURE INDICATOR	21
AYG7422-50	ACTUATOR MLG BRAKE VALVE SHIP IN CATEGOR	32
B17CA1042	VALVE, AIR, CARGO CMPT HOT AIR PRESS REG	21
B18834B	BALLSCREW, ACTUATOR, STABILIZER	27
B188MA1	MONITOR EXTERNAL POWER	24

B227002-50	CONTROL PANEL, COCKPIT DOOR	52
B237002-50	RIGHT LIGHTING CONTROL PANEL ASSEMBLY M10057	31
B237002-50	RIGHT LIGHTING CONTROL PANEL ASSEMBLY M10057	31
B372BAM0	UNIT, POWER SUPPLY, (ESDS)	27
B397BAM0	COMPUTER, FLIGHT AUGMENTATION,	22
B397BAM0	COMPUTER, FLIGHT AUGMENTATION,	22
B397CAM0	COMPUTER, FLIGHT AUGMENTATION,	22
B42365-1	STATIONARY CYLINDER & VALVE ASSEMBLY	35
B429	3PST NORMALLY OPEN	24
B429-1	3PST NORMALLY OPEN	24
B430	3PST MAGNETIC LATCH	24
B430-1	3PST MAGNETIC LATCH	24
BA06-01	NICKEL CADMIUM BATTERY	24
BA27-01	BATTERY MAIN DC POWER SHELF LIFE 3 MONTH	24
BDC5	INCANDESCENT LAMP DIMMER	33
BLG7000-5	VALVE SPOILER, GROUND	27
BPS7-3	BATTERY POWER SUPPLY	33
BRH18579	HARNESS, EEC TO FANCASE, LANE A 1C	71
BRH18670	HARNESS, EEC TO FIXED COWL, LANE A 1G	71
BRH18671	HARNESS, EEC TO FIXED COWL, LANE B 1H	71
BRH20538	HARNESS, HARNESS, EXTERNAL NL SPEED	71
C01607002	TRACK ASSY, FLAP, STN 1 LH	57
C01607002	TRACK ASSY, FLAP, STN 1 RH	57
C01607002	TRACK, ASSY, FLAP; STN 1 LH	57
C01607002	TRACK, ASSY, FLAP; STN 1 RH	57
C01607006	CARRIAGE, ASSY, FLAP; STN 1 LH	57
C01607006	CARRIAGE ASSY, STN 1 RH	57
C01607007	LINK ASSY, REAR; STN 1 LH	57
C01607007	LINK ASSY, REAR; STN 1 RH	57
C01612521	PINION, SLAT 1	27
C01613007	SPOILER, GROUND GA	57
C01617001	TRACK, FLAP, 2L	57

C01617001	TRACK, FLAP, 2R	57
C01617002	TRACK, FLAP, 3L	57
C01617002	TRACK, FLAP, 3R	57
C01617003	TRACK, FLAP, 4L	57
C01617003	TRACK, FLAP, 4R	57
C01617007	BEAM, FLAP, 2L	57
C01617007	BEAM, FLAP, 2R	57
C01617009	BEAM, FLAP, 3L	57
C01617009	BEAM, FLAP, 3L	57
C01617011	BEAM, FLAP, 4R	57
C01617011	BEAM, FLAP, 4R	57
C01617014	FAIRING ASSY, AFT; FTF 2; LH	57
C01617014	FAIRING ASSY, AFT; FTF 2; RH	57
C01617016	FAIRING ASSY, AFT; FTF 3; LH	57
C01617018	FAIRING ASSY, AFT; FTF 4; LH	57
C01617018	FAIRING ASSY, AFT; FTF 4; RH	57
C01618120	EDGE, LEADING LOWER, WINGLET	57
C01618120	EDGE, LEADING LOWER, WINGLET	57
C01618121	EDGE, LEADING UPPER, WINGLET	57
C01618121	EDGE, LEADING UPPER, WINGLET	57
C01637433	PIN, FUSE, DISTRIBUTION PLATE	57
C01637679	BEARING ASSY, AFT TRUNNION (LH)	57
C01637679	BEARING ASSY, AFT TRUNNION (RH)	57
C01637681	BEARING ASSY, OUTBD BEAM	57
C01637767	PIN ASSY, ATTACH LINK; MLG BEAM	57
C01637768	PIN ASSY, ATTACH LINK; MLG BEAM	57
C01637953	BEAM ASSY, MLG	57
C01637953	BEAM ASSY, MLG	57
C01637953	BEAM, ASSY, MLG (LH)	57
C01637953	BEAM, ASSY, MLG (RH)	57
C01981100	FAIRING ASSY, VS DORSAL	55
C02000000	HSTAB TOP, INSTALL	55

C02031000	ELEVATOR, ASSY, HS ELEV	27
C02031000	ELEVATOR, ASSY, HS ELEV	27
C02031000	ELEVATOR, ASSY, LH	27
C02031000	ELEVATOR, ASSY, RH	27
C02093111	FAIRING, HS TIP	55
C02093111	FAIRING, HS TIP	55
C05500008	CONTROL, ALTERNATE FLIGHT CONTROL UNIT	27
C05500013	CONTROL, MOTOR, ELECTRONICS; HSTA	27
C07202-2	CONTROL SHAKER ASSEMBLY	27
C07202-2M	CONTROL SHAKER ASSEMBLY	27
C07202-3	CONTROL SHAKER ASSEMBLY	27
C12848AA0	PANEL, RADIO MANAGEMENT,	23
C12848CA0	PANEL, RADIO MANAGEMENT,	23
C12848CB0	PANEL, RADIO MANAGEMENT,	23
C12849AA0	UNIT, FLIGHT CONTROL	22
C12849AB0	UNIT, FLIGHT CONTROL	22
C12849AB0	UNIT, FLIGHT CONTROL	22
C12850AA0	UNIT, FLIGHT CONTROL, A319/A320	22
C12850AB0	UNIT, FLIGHT CONTROL, A319/A320	22
C12850AC0	UNIT, FLIGHT CONTROL, A319/A320	22
C12850AC0	UNIT, FLIGHT CONTROL, A319/A320	22
C12858CA0	COMPUTER, FMGEC, A330; HAS INSP	22
C12860AA0	UNIT, CFDIU, CENTRALIZED FAULT DISPLAY	31
C12860AA0	UNIT, CFDIU, CENTRALIZED FAULT DISPLAY	31
C13043AA0	COMPUTER, FMGC, FMS2; IGK 22-84-0005	22
C13164GA0	FLIGHT MANAGEMENT GUIDANCE COMPUTER	22
C13164HA0	COMPUTER, FMGEC	22
C19266AA0	MULTIPURPOSE CONTROL AND DISPLAY UNIT	22
C19298AF0	UNIT, DISPLAY, DU; A330	31
C2029339C	CONTROL UNIT, BRAKING & STEERING;BSCU;A3	32
C24750000	UNIT, HYDRAULIC CONTROL, THRUST REVER...	78
C24837101	MANIFOLD-NORMAL ASSY, BRAKE, MLG;A319/32	32

C24837101	MANIFOLD-NORMAL ASSY, BRAKE, MLG;A319/32	32
C24837101	MANIFOLD-NORMAL ASSY, BRAKE, MLG;A319/32	32
C24837101	MANIFOLD-NORMAL ASSY, BRAKE, MLG;A319/32	32
C24837101	MANIFOLD-NORMAL ASSY, BRAKE, MLG;A319/32	32
C24839010	MANIFOLD, BRAKE, PLUMBING; RH	32
C24840010	MANIFOLD, BRAKE, PLUMBING; RH	32
C48902-001	DIFFERENTIAL PRESSURE SENSOR ASSEMBLY	27
C48902-002	DIFFERENTIAL PRESSURE SENSOR ASSEMBLY	27
C51LM0020	VALVE, FILL,	29
C5487ABBI	UNIT, PCB, CPU, SPOILER/ELEVATOR (ESDS)	27
C5487ABBI	UNIT, PCB, CPU, SPOILER/ELEVATOR (ESDS)	27
C5487ABDI	UNIT, PCB, CPU, SPOILER/ELEVATOR (ESDS)	27
C5487ABDI	UNIT, PCB, CPU, SPOILER/ELEVATOR (ESDS)	27
C5488ABBI	UNIT, PCB, CPU, SPOILER/ELEVATOR (ESDS)	27
CA119M1-0	ACCLRMTR BEARING EXTERNAL VIBRATION MONI	77
CA127M1-0	NBR 1 BEARING VIBRATION SENSOR ACCELEROMETER	77
CA150-00	T495 THERMOCOUPLE WIRIING HARNESS	77
CA151-01	T495 THERMOCOUPLE WIRIING HARNESS	77
CA151-02	T495 THERMOCOUPLE WIRIING HARNESS	77
CA151M1-0	NBR 1 BEARING VIBRATION SENSOR ACCELEROMETER	71
CA152-01	T495 THERMOCOUPLE WIRIING HARNESS	77
CA152-04	T495 THERMOCOUPLE WIRIING HARNESS	77
CA155M1-0	ACCELEROMETER	77
CA170-00	EGT WIRING HARNESS	77
CA172-02	EGT WIRING HARNESS	77
CA27977-00	ELEVATOR FEEL SHIFT MODULE	27
CA27977-00	ELEVATOR FEEL SHIFT MODULE	27
CA955M6-0	ACCELEROMETER	77
CA955M6-0	ACCELEROMETER	77
CA955M70	ACCELEROMETER	77
CA955M7-0	ACCELEROMETER	77
CD00384-1		21

CE00310-3		21
CE00310-4		21
CE1909AA1	FAN, EXTRACTION; A330	21
CG1093AC0	INERTIAL REFERENCE MODE PANEL	34
CG1093AD0	INERTIAL REFERENCE MODE PANEL	34
CG1093AD0	INERTIAL REFERENCE MODE PANEL	34
CG1093AD0	INERTIAL REFERENCE MODE PANEL	34
CG1093AD0	INERTIAL REFERENCE MODE PANEL	34
CG1093AD0	INERTIAL REFERENCE MODE PANEL	34
CG1135AC0	INERTIAL SYSTEM DISPLAY UNIT	34
CG1135AC0	INERTIAL SYSTEM DISPLAY UNIT	34
CG1135AC0	INERTIAL SYSTEM DISPLAY UNIT	34
CG1151AC0	CONTROL PANEL, IRS, AIR DATA;A319/A320;	34
CG1237BD0	PANEL, INERTIAL REFERENCE CONTROL	34
CG1244AC0	PANEL, INERTIAL REFERENCE CONTROL	34
CG1244AD0	PANEL, INERTIAL REFERENCE CONTROL	34
D01000	VALVE, LAV WASTE DRAIN,A/C 629 AND SUBS	38
D13626-101	EVACUATION SLIDE SURVIVAL KIT	25
D15360-101	KIT, SURVIVAL; A320	25
D15360-103	KIT, SURVIVAL; A320	25
D1775-1	MOTOR HORIZONTAL STABILIZER CONTROL	27
D212101920	TUBE, ASSY;	21
D212101920	TUBE, ASSY;	21
D212102180	DUCT, AVIONICS COOLING	21
D212103640	DUCT, AVIONICS COOLING	21
D212115560	TUBE, ASSY;	21
D212725150	TUBE, ASSY;	21
D212740300	DUCT,WATER SEPARATOR TO CK VLV; RH	21
D212775430	TUBE, ASSY;	21
D212781990	TUBE, ASSY;	21
D215710000	OUTLET,ASSY;RAM AIR;RH;A/C 3249-3278	21
D215710010	TUBE, ASSY;	21
D215710010	TUBE, ASSY;	21

D215710300	OUTLET,ASSY;RAM AIR;RH;A/C 3249-3278	21
D215710300	FLAP, RAM AIR OUTLET;3249-3259	21
D215710800	OUTLET,ASSY;RAM AIR;RH;A/C 3249-3278	21
D215710800	OUTLET,ASSY;RAM AIR;RH;A/C 3249-3278	21
D230900000	HANDWIND THRUST REVERSER MANUAL DRIVE	78
D23119000	BOX, ELECTRIC, NLG TOWING;	32
D23119500	BOX, ELECTRIC, NLG TOWING, A-3.	32
D23119500	BOX, ELECTRIC, NLG TOWING, A-3.	32
D23119750	BOX, ELECTRIC, NLG TOWING, A-3.	32
D23119750	BOX, ELECTRIC, NLG TOWING;	32
D23119751	BOX, ELECTRIC, NLG TOWING;	32
D23119760	BOX, ELECTRIC, NLG TOWING;	32
D23119770	BOX, ELECTRIC, NLG TOWING;	32
D23119770	BOX, ELECTRIC, NLG TOWING, A-3.	32
D251116850	FOOTREST, SLIDING TBLE	25
D251122580	FOOTREST, SLIDING TBLE	25
D251141180	FOOTREST, SLIDING TBLE	25
D252700040	LINING, SUPPORT ARM	25
D252700140	LINING, SUPPORT ARM	25
D252700140	LINING, SUPPORT ARM	25
D252701200	LINING, FROONT; AFT LWR	25
D252701200	LINING, FROONT; AFT LWR	25
D252701210	LINING, FROONT; AFT LWR	25
D252701210	LINING, FROONT; AFT LWR	25
D252701220	LINING, FROONT; AFT LWR	25
D252701230	LINING, FROONT; AFT LWR	25
D252701230	LINING, FROONT; AFT LWR	25
D252701240	LINING, FROONT; AFT LWR	25
D252701250	LINING, FROONT; AFT LWR	25
D252701260	LINING, FROONT; AFT LWR	25
D252701260	LINING, FROONT; AFT LWR	25
D252701540	LINING, FROONT; AFT LWR	25

D252701660	LINING, FRONT; AFT LWR	52
D252701660	LINING, FRONT; UPR CTR	52
D252701680	LINING, FRONT; UPR CTR	52
D252701760	LINING, FRONT; UPR CTR	52
D252702420	LINING, FRONT; UPR CTR	25
D252702420	LINING, FRONT; UPR CTR	25
D252702430	LINING, FRONT; UPR CTR	25
D252702430	LINING, FRONT; UPR CTR	25
D252702450	LINING, FRONT; UPR CTR	25
D252702450	LINING, FRONT; UPR CTR	25
D252702470	LINING, FRONT; UPR CTR	25
D252702480	LINING, FRONT; UPR CTR	25
D252702500	LINING, FRONT; UPR CTR	25
D252702540	LINING, FRONT; UPR CTR	25
D252705330	LINING, FRONT; UPR CTR	25
D252705330	LINING, FRONT; UPR CTR	25
D252705330	LINING, FRONT; UPR CTR	25
D252705400	PANEL, SIDEWALL, ASSY;	25
D252710140	PANEL, SIDEWALL, ASSY;	25
D252711390	PANEL, ASSY COVE LIGHT; LH	25
D252720060	PANEL, SIDEWALL, ASSY;	25
D252720060	PANEL, SIDEWALL, ASSY;	25
D252748000	DOOR, COCKPIT, A320	25
D252775270	PANEL, SIDEWALL, ASSY;	25
D252897330	PANEL, SIDEWALL, ASSY;	25
D252897330	PANEL, SIDEWALL, ASSY;	25
D252897430	PANEL, SIDEWALL, ASSY;	25
D252897600	FAIRING, ASSY; WINDOW	25
D254702440	TABLE, BABY CHANGE, F/C LAV;	21
D254703180	DOOR, FWD LAV ENTRY	52
D254711900	TABLE, BABY CHANGE, F/C LAV;	25
D254712000	TABLE, BABY CHANGE, F/C LAV;	25

D25571314	PANEL, ASSY;CEILING;AFT CARGO;(3251-3270	25
D25571530	PANEL, AFT CARGO, CEILING;	25
D25571530	PANEL, AFT CARGO, CEILING;	25
D25571734	PANEL, ASSY;CEILING;AFT CARGO;(3251-3270	21
D25571734	PANEL, ASSY;CEILING;AFT CARGO;(3251-3270	21
D25571742	PANEL, ASSY;CEILING;AFT CARGO;(3251-3270	25
D25571742	PANEL, ASSY;CEILING;AFT CARGO;(3251-3270	21
D25571742	PANEL, ASSY;CEILING;AFT CARGO;(3251-3270	25
D25571742	PANEL, ASSY;CEILING;AFT CARGO;(3251-3270	25
D25585011	PANEL, AFT CARGO, CEILING;	25
D25585054	PANEL, AFT CARGO, CEILING;	25
D25670446	COVER, SLIDE RAFT, EVAC, FWD; W/LATCHES;	25
D25670446	COVER, SLIDE RAFT, EVAC, FWD; W/LATCHES;	25
D25670446	COVER, SLIDE RAFT, EVAC, FWD; W/LATCHES;	25
D25670446	COVER, SLIDE RAFT, EVAC, FWD; W/LATCHES;	25
D25670456	COVER, SLIDE RAFT, EVAC, FWD; W/LATCHES;	25
D25670456	COVER, SLIDE RAFT, EVAC, FWD; W/LATCHES;	25
D25671716	COVER, SLIDE RAFT, EVAC, FWD; W/LATCHES;	25
D25671716	COVER, SLIDE, NO. 3L & 3R DOOR; A330;	25
D25671716	COVER, SLIDE, NO. 3L & 3R DOOR; A330;	25
D25671716	COVER, SLIDE, NO. 3L & 3R DOOR; A330;	25
D25BD	CONTACTR RELAY 3 PDT 28 VDC	24
D27210033	COVER, SLIDE, NO. 3L & 3R DOOR; A330;	27
D29070190	MANIFOLD, HYDRAULIC POWER,	29
D29070197	LEFT SYSTEM HYDRAULIC RESERVOIR ASSEMBLY	29
D31BAA	RELAY,BATTERY CHARGER and TRNSFR PACKAGE	24
D31C	3PDT CENTER OFF CONTRACTOR	24
D455-07-00	ENGINE FIRE SHUTOFF SWITCH	26
D455-08-00	ENGINE FIRE SHUTOFF SWITCH	26
D455-24-00	ENGINE FIRE SHUT-OFF SWITCH	26
D455-25-00	ENGINE FIRE SHUT-OFF SWITCH	26
D49185014	ELBOW, APU DUCT	49

D523711070	COVER, ACCESS; CARGO COMPT	52
D523711070	COVER, ACCESS; CARGO COMPT	52
D523717350	DOOR ASSY; FWD CARGO; 737 A/C 3709-3771	52
D524700050	LENS, GLAZING ASSY; WING TIP; LT WING; A	52
D524854000	LENS, GLAZING ASSY; WING TIP; LT WING; A	52
D524854000	LENS, GLAZING ASSY; WING TIP; LT WING; A	52
D524854000	DOOR, NLG, FWD; RH	52
D528100890	DOOR, NLG, FWD; RH	52
D528100890	DOOR, NLG, FWD; RH	52
D528100890	DOOR, NLG, FWD; RH	52
D528100890	DOOR, NLG, FWD; RH	52
D528100890	DOOR, NLG, FWD; RH	52
D528100890	DOOR, NLG, FWD; RH	52
D528100890	DOOR, NLG, FWD; RH	52
D528100890	DOOR, NLG, AFT; RIGHT SIDE; A320	52
D528100890	DOOR, NLG, AFT; RIGHT SIDE; A320	52
D528101080	DOOR, NLG, FWD; RH	52
D528101080	DOOR, NLG, FWD; RH	52
D528101080	DOOR, NLG, FWD; RH	52
D528101080	DOOR, NLG, FWD; RH	52
D528101080	DOOR, NLG, FWD; RH	52
D528101080	DOOR, NLG, FWD; RH	52
D528101080	DOOR, NLG, FWD; RH	52
D528101080	DOOR, NLG, FWD; RH	52
D528101100	DOOR, NLG, FWD; RH	32
D528101100	DOOR, NLG, FWD; RH	32
D528101100	DOOR, NLG, FWD; RH	32
D528101100	DOOR, NLG, FWD; RH	32
D528101100	DOOR, NLG, FWD; RH	32
D528101100	DOOR, NLG, FWD; RH	32
D528101100	DOOR, NLG, FWD; RH	32
D528101100	DOOR, NLG, FWD; RH	32
D528101100	DOOR, NLG, FWD; RH	32
D528101420	DOOR, NLG, FWD; RH	32
D528101420	DOOR, NLG, FWD; RH	32
D528101660	DOOR, NLG, FWD; RH	32

D528101660	DOOR, NLG, FWD; RH	52
D528101660	DOOR, NLG, FWD; RH	32
D528101660	DOOR, SERVICE PANEL; ASSEMBLY;	52
D528400000	FAIRING, LEG; MLG; RH	32
D528400000	FAIRING, LEG; MLG; RH	32
D528400080	DOOR, ASSY, HINGED FAIRING MLG (RH)	52
D528400080	DOOR, MLG, RH; POST MOD EO 3241-01045	52
D528400080	DOOR, MLG, RH; POST MOD EO 3241-01045	52
D528587520	DOOR, ASSY, HINGED FAIRING MLG (RH)	52
D528800080	DOOR, MLG, RH; POST MOD EO 3241-01045	32
D528800080	DOOR, MLG, RH; POST MOD EO 3241-01045	32
D528800080	DOOR, MLG, RH; POST MOD EO 3241-01045	32
D528800080	DOOR, MLG, RH; POST MOD EO 3241-01045	32
D528800080	DOOR, MLG, RH; POST MOD EO 3241-01045	32
D528800080	DOOR, MLG, RH; POST MOD EO 3241-01045	32
D528801650	DOOR, MLG, RH; POST MOD EO 3241-01045	32
D528801650	MLG DOOR	32
D528801650	DOOR, MLG, RH; POST MOD EO 3241-01045	32
D528801650	MLG DOOR	32
D528801650	MLG DOOR	32
D528801650	MLG DOOR	32
D528801650	MLG DOOR	32
D528801650	DOOR, NLG, FWD; RH	32
D528801650	DOOR, MLG, RH; POST MOD EO 3241-01045	32
D528801650	DOOR, NLG, FWD; RH	32
D528801650	MLG DOOR	32
D531104770	RADOME, NOSE; A319/A320	53
D531104770	RADOME, NOSE; A319/A320	53
D531104770	RADOME, NOSE; A319/A320	53
D531104770	RADOME, NOSE; A319/A320	53
D531104770	RADOME, NOSE; A319/A320	53
D531104770	RADOME, NOSE; A319/A320	53
D531104770	RADOME, NOSE; A319/A320	53

D531104770	RADOME, NOSE; A319/A320	53
D531320100	RADOME, NOSE; A319/A320	53
D532302950	PANEL, SIDEWALL, ASSY;	53
D532318580	PANEL, SIDEWALL, ASSY;	53
D533-04-00	SWITCH ENGINE FIRE SHUT-OFF SHIP IN ATA	26
D533100710	DOOR, GRD AIR ACCESS	52
D533101460	DOOR, GRD AIR ACCESS	52
D533102260	DOOR, GRD AIR ACCESS	52
D533103230	FAIRING, WING TO FUSELAGE, RH	53
D533103230	FAIRING, WING TO FUSELAGE, RH	53
D533110110	DOOR, GRD AIR ACCESS	52
D533110180	DOOR, GRD AIR ACCESS	53
D533110180	DOOR, GRD AIR ACCESS	53
D533717000	FAIRING, PANEL; WING TO FAIRING;	53
D533717000	FAIRING, PANEL; WING TO FAIRING;	53
D533717000	FAIRING, PANEL; WING TO FAIRING;	53
D533717170	DOOR, HYD ACCESS WING TO FUSELAGE FAIRIN	53
D533717170	DOOR, HYD ACCESS WING TO FUSELAGE FAIRIN	53
D533717170	DOOR, HYD ACCESS WING TO FUSELAGE FAIRIN	53
D533717170	DOOR, HYD ACCESS WING TO FUSELAGE FAIRIN	53
D533717170	DOOR, HYD ACCESS WING TO FUSELAGE FAIRIN	53
D533717170	DOOR, HYD ACCESS WING TO FUSELAGE FAIRIN	53
D533717170	DOOR, HYD ACCESS WING TO FUSELAGE FAIRIN	53
D533717300	FAIRING, WING TO FUSELAGE, RH	53
D533717300	FAIRING, WING TO FUSELAGE, RH	53
D533754490	FAIRING ASSEMBLY	53
D534750100	FAIRING, WING TO FUSELAGE, PANEL 197BB;	53
D534750100	FAIRING, WING TO FUSELAGE, PANEL 197BB;	53
D534750100	FAIRING, WING TO FUSELAGE, PANEL 197BB;	53
D534750100	FAIRING, WING TO FUSELAGE, PANEL 197BB;	53
D534750100	FAIRING, WING TO FUSELAGE, PANEL 197BB;	53
D534750140	FAIRING, WING TO FUSELAGE, PANEL 197BB;	53
D534750140	FAIRING, WING TO FUSELAGE, PANEL 197BB;	53

D534750140	FAIRING, WING TO FUSELAGE, PANEL 197BB;	53
D534750140	FAIRING, WING TO FUSELAGE, PANEL 197BB;	53
D534750140	FAIRING, WING TO FUSELAGE, PANEL 197BB;	53
D534750140	FAIRING, WING TO FUSELAGE, PANEL 198BB;	53
D534750140	FAIRING, WING TO FUSELAGE, PANEL 198BB;	53
D534750140	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D534750140	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D534750140	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D534750140	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D534750140	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D534750140	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D534750140	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D534750140	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D534750140	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D534750140	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D534750140	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D534750140	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D534750140	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D534750140	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D534750140	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D534750200	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D534750200	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D534750200	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D534750300	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D534750300	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D534750400	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D534750400	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D534750400	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D534750400	PANEL, ASSY;CEILING;AFT CARGO;(3251-3270	53
D534750400	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D534750500	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D534750500	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53

D53475050	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D53475050	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D53475050	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D53475050	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D53475050	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D53475050	PANEL, ASSY;CEILING;AFT CARGO;(3251-3270	53
D53475050	FAIRING, WING TO FUSELAGE, PANEL 198GB;	53
D53475060	PANEL, 197CB DOOR	25
D53475060	PANEL, 197CB DOOR	25
D53475060	PANEL, 197CB DOOR	25
D53475060	PANEL, 197CB DOOR	25
D53480056	DOOR, SERVICE PANEL; ASSEMBLY;	52
D53480207	DOOR, SERVICE PANEL; ASSEMBLY;	52
D53480236	DOOR, SERVICE PANEL; ASSEMBLY;	52
D53610125	PANEL, CABIN FLOOR-A320	53
D53610403	PANEL, FLOORBOARD, 232FF;	53
D53610560	PANEL, FLOORBOARD, 232FF;	53
D53610560	PANEL, FLOORBOARD, 232FF;	53
D53610632	PANEL, FLOORBOARD, 232FF;	53
D53610650	PANEL, FLOORBOARD, 232FF;	53
D53610813	PANEL, CABIN FLOOR-A320	53
D53610813	PANEL, CABIN FLOOR-A320	53
D53610813	PANEL, CABIN FLOOR-A320	53
D53912685	TUBE, ASSY;	21
D53912685	TUBE, ASSY;	21
D54510070	TAILCONE, ASSY; MOVABLE FAIRING ASSY;	54
D54510090	TAILCONE, ASSY; MOVABLE FAIRING ASSY;	54
D54530233	TAILCONE, ASSY; MOVABLE FAIRING ASSY;	54
D54530238	TAILCONE, ASSY; MOVABLE FAIRING ASSY;	54
D55183400	EDGE, HORIZ LE; OB; ASSY;	55
D55280001	A320 ELEVATOR ASSEMBLY	55
D55280001	A320 ELEVATOR ASSEMBLY	55

D552800010	A320 ELEVATOR ASSEMBLY	55
D552800010	A320 ELEVATOR ASSEMBLY	55
D552800010	A320 ELEVATOR ASSEMBLY	55
D552800010	A320 ELEVATOR ASSEMBLY	55
D552800010	A320 ELEVATOR ASSEMBLY	55
D552800010	A320 ELEVATOR ASSEMBLY	55
D552800010	A320 ELEVATOR ASSEMBLY	55
D552800010	A320 ELEVATOR ASSEMBLY	55
D552800010	A320 ELEVATOR ASSEMBLY	55
D552800010	A320 ELEVATOR ASSEMBLY	55
D552800010	A320 ELEVATOR ASSEMBLY	55
D552800010	A320 ELEVATOR ASSEMBLY	55
D552800010	A320 ELEVATOR ASSEMBLY	55
D552800010	A320 ELEVATOR ASSEMBLY	55
D552800010	A320 ELEVATOR ASSEMBLY	55
D552800010	A320 ELEVATOR ASSEMBLY	55
D552800010	A320 ELEVATOR ASSEMBLY	55
D552800010	A320 ELEVATOR ASSEMBLY	55
D552800010	A320 ELEVATOR ASSEMBLY	55
D552800010	A320 ELEVATOR ASSEMBLY	55
D552800010	A320 ELEVATOR ASSEMBLY	55
D552800010	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800010	A320 ELEVATOR ASSEMBLY	55
D552800010	A320 ELEVATOR ASSEMBLY	55
D552800010	A320 ELEVATOR ASSEMBLY	55
D552800010	A320 ELEVATOR ASSEMBLY	55
D552800010	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800010	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800010	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800010	A320 ELEVATOR ASSEMBLY	55
D552800010	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800010	A320 ELEVATOR ASSEMBLY	55
D552800010	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800010	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800010	A320 ELEVATOR ASSEMBLY	55

D552800010	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800010	A320 ELEVATOR ASSEMBLY	55
D552800020	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800020	A320 ELEVATOR ASSEMBLY	55
D552800020	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800020	A320 ELEVATOR ASSEMBLY	55
D552800020	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800020	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	A320 ELEVATOR ASSEMBLY	55
D552800030	A320 ELEVATOR ASSEMBLY	55
D552800030	A320 ELEVATOR ASSEMBLY	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	A320 ELEVATOR ASSEMBLY	55
D552800030	ELEVATOR, ASSY; RH; A330, AD RELATED	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	A320 ELEVATOR ASSEMBLY	55
D552800030	A320 ELEVATOR ASSEMBLY	55
D552800030	A320 ELEVATOR ASSEMBLY	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	A320 ELEVATOR ASSEMBLY	55
D552800030	A320 ELEVATOR ASSEMBLY	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55

D552800030	A320 ELEVATOR ASSEMBLY	55
D552800030	A320 ELEVATOR ASSEMBLY	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552800030	ELEVATOR, ASSY; RH; A320; HAS INSP	55
D552829100	TIP, ELEVATOR LH	55
D552829100	TIP, ELEVATOR LH	55
D552829100	TIP, ELEVATOR LH	55
D553712530	PANEL, VERTICAL STABILIZER; 325 EL	55
D553712600	SUPPORT	55
D554710000	RUDDER, A320	55
D554710000	RUDDER, A320	55
D554710000	TIP,RUDDER,RU001K	55
D554710000	TIP,RUDDER,RU001K	55
D554710000	TIP,RUDDER,RU001K	55
D554710000	TIP,RUDDER,RU001K	55

D55471000	TIP,RUDDER,RU001K	55
D55471000	TIP,RUDDER,RU001K	55
D55471000	RUDDER, A320	55
D55471000	TIP,RUDDER,RU001K	55
D55471000	TIP,RUDDER,RU001K	55
D55471000	TIP,RUDDER,RU001K	55
D55471000	TIP,RUDDER,RU001K	55
D55471000	TIP,RUDDER,RU001K	55
D55471001	TIP,RUDDER,RU001K	55
D55471002	TIP,RUDDER,RU001K	55
D55471003	RUDDER, A320	55
D55471004	TIP,RUDDER,RU001K	55
D55471006	TIP,RUDDER,RU001K	55
D55471180	TIP,RUDDER,RU001K	55
D57350071	LENS, GLAZING ASSY;WINGTIP;RT;A320.	57
D57350071	FENCE, RH WING TIP	57
D57350071	FENCE, RH WING TIP	57
D57351050	LENS, GLAZING ASSY;WINGTIP;RTW; A320	57
D57351050	LENS, GLAZING ASSY;WINGTIP;RTW; A320	57
D57351050	LENS, GLAZING ASSY;WINGTIP;RTW; A320	57
D57351050	LENS, GLAZING ASSY;WINGTIP;RTW; A320	57
D57351050	LENS, GLAZING ASSY;WINGTIP;RTW; A320	57
D57351050	LENS, GLAZING ASSY;WINGTIP;RTW; A320	57
D57351050	LENS, GLAZING ASSY;WINGTIP;RTW; A320	57
D57351050	LENS, GLAZING ASSY;WINGTIP;RTW; A320	57
D57351050	LENS, GLAZING ASSY;WINGTIP;RTW; A320	57
D57351200	FENCE, RH WING TIP	57
D57351200	FENCE, RH WING TIP	57
D57351200	FENCE, RH WING TIP	57
D57351271	LENS, GLAZING ASSY;WINGTIP;RTW; A320	57
D57351271	LENS, GLAZING ASSY;WINGTIP;RTW; A320	57
D57351271	LENS, GLAZING ASSY;WINGTIP;RTW; A320	57
D57351271	LENS, GLAZING ASSY;WINGTIP;RTW; A320	57

D573512760	LENS, GLAZING ASSY;WINGTIP;RTW; A320	57
D573512760	LENS, GLAZING ASSY;WINGTIP;RTW; A320	57
D573512760	LENS, GLAZING ASSY;WINGTIP;RT;A320.	57
D573512760	LENS, GLAZING ASSY;WINGTIP;RTW; A320	57
D573512760	LENS, GLAZING ASSY;WINGTIP;RTW; A320	57
D573512760	LENS, GLAZING ASSY;WINGTIP;RT;A320.	57
D573512760	LENS, GLAZING ASSY;WINGTIP;RTW; A320	57
D573512760	LENS, GLAZING ASSY;WINGTIP;RTW; A320	57
D574601000	SLAT,ASSY; #5 RT.	57
D574601000	SLAT,ASSY; #5 RT.	57
D574601000	SLAT,ASSY; #5 RT.	57
D574601000	SLAT,ASSY; #5 RT.	57
D574601000	SLAT,ASSY; #5 RT.	57
D574601000	SLAT,ASSY; #5 RT.	57
D574601000	SLAT, SLAT ASSY, #1,L/H	57
D574601680	SLAT,ASSY; #5 RT.	57
D574601680	SLAT,ASSY; #5 RT.	57
D574601680	SLAT,ASSY; #5 RT.	57
D574601680	SLAT,ASSY; #5 RT.	57
D574601680	SLAT,ASSY; #5 RT.	57
D574601680	SLAT,ASSY; #5 RT.	57
D574601680	SLAT,ASSY; #5 RT.	57
D574601680	SLAT,ASSY; #5 RT.	57
D574601980	SLAT,ASSY; #5 RT.	57
D574601980	SLAT,ASSY; #5 RT.	57
D574601980	SLAT,ASSY; #5 RT.	57
D574601980	SLAT,ASSY; #5 RT.	57
D574601980	SLAT,ASSY; #5 RT.	57
D574601980	SLAT,ASSY; #5 RT.	57
D574601980	SLAT,ASSY; #5 RT.	57
D574602000	SLAT, ASSY; #3; LT	57
D574602000	SLAT, ASSY; #3; LT	57
D574602000	SLAT, ASSY; #3; LT	57
D574602000	SLAT, ASSY; #3; LT	57

D57460200	SLAT, ASSY; #3; LT	57
D57460200	SLAT, ASSY; #3; LT	57
D57460200	SLAT, ASSY; #3; LT	57
D57460200	SLAT, SLAT ASSY, #1,L/H	57
D57460200	SLAT, ASSY; #3; LT	57
D57460277	SLAT, ASSY; #3; LT	57
D57460277	SLAT, ASSY; #3; LT	57
D57460277	SLAT, ASSY; #3; LT	57
D57460278	SLAT, ASSY; #3; LT	57
D57460300	SLAT, ASSY; #3; LT	27
D57460300	SLAT, ASSY; #3; RT	57
D57460300	SLAT, ASSY; #3; RT	57
D57460300	SLAT, ASSY; #3; RT	57
D57460377	SLAT, ASSY; #3; RT	57
D57460377	SLAT, ASSY; #3; RT	27
D57460377	SLAT, ASSY; #3; RT	57
D57460377	SLAT, ASSY; #3; RT	27
D57460378	SLAT, ASSY; #3; RT	57
D57460378	SLAT, ASSY; #3; RT	27
D57460378	SLAT, ASSY; #3; RT	57
D57460398	SLAT, ASSY; #3; RT	57
D57460400	SLAT,ASSY; #5 RT	57
D57460400	SLAT,ASSY; #5 RT	57
D57460400	SLAT,ASSY; #5 RT	57
D57460400	SLAT,ASSY; #5 RT	57
D57460400	SLAT,ASSY; #5 RT	57
D57460400	SLAT,ASSY; #5 RT	57
D57460477	SLAT,ASSY; #5 RT	57
D57460477	SLAT,ASSY; #5 RT	57
D57460478	SLAT,ASSY; #5 RT	57
D57460478	SLAT,ASSY; #5 RT	57
D57460478	SLAT,ASSY; #5 RT	57

D57460500	SLAT,ASSY; #5 RT.	57
D57460500	SLAT,ASSY; #5 RT.	57
D57460500	SLAT,ASSY; #5 RT.	57
D57460500	SLAT,ASSY; #5 RT.	57
D57460500	SLAT,ASSY; #5 RT.	57
D57460500	SLAT,ASSY; #5 RT	57
D57460577	SLAT,ASSY; #5 RT.	57
D57460577	SLAT,ASSY; #5 RT	57
D57460577	SLAT,ASSY; #5 RT.	57
D57460598	SLAT,ASSY; #5 RT.	57
D57460600	SLAT,ASSY; #5 RT.	57
D57460600	SLAT,ASSY; #5 RT.	57
D57460600	SLAT,ASSY; #5 RT.	57
D57460677	SLAT,ASSY; #5 RT.	57
D57460677	SLAT,ASSY; #5 RT.	57
D57460677	SLAT,ASSY; #5 RT.	57
D57460677	SLAT,ASSY; #5 RT.	57
D57460677	SLAT,ASSY; #5 RT.	57
D57460677	SLAT,ASSY; #5 RT.	57
D57460910	SLAT,ASSY; #5 RT.	57
D57460910	SLAT,ASSY; #5 RT.	57
D57460920	SLAT, ASSY; #3; LT	57
D57460930	SLAT, ASSY; #3; RT	27
D57540501	FLAP, L/E, VARIABLE CAMBER; POS 1-5&22-2	57
D57540501	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
D57540501	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
D57540501	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
D57540501	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
D57540501	FLAP, L/E, VARIABLE CAMBER; POS 1-5&22-2	57
D57540501	FLAP, L/E, VARIABLE CAMBER; POS 1-5&22-2	57
D57540501	FAIRING, FWD, FIXED; FLAP TRACK #2; RH;	57
D57540504	FLAP, L/E, VARIABLE CAMBER; POS 1-5&22-2	57
D57540504	FENCE, RH WING TIP	57

D575405100	FLAP, L/E, VARIABLE CAMBER; POS 1-5&22-2	57
D575405100	FLAP, L/E, VARIABLE CAMBER; POS 1-5&22-2	57
D575406010	FLAP, L/E, VARIABLE CAMBER; POS 1-5&22-2	57
D575406010	FLAP, L/E, VARIABLE CAMBER; POS 1-5&22-2	57
D575406010	FAIRING, FWD, FIXED, FLAP TRACK 3; LH	57
D575406010	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
D575406010	FAIRING, FWD, FIXED; FLAP TRACK #2; RH;	57
D575406010	FAIRING, FWD, FIXED, FLAP TRACK 3; LH	57
D575406010	FAIRING, FWD, FIXED, FLAP TRACK 3; LH	57
D575406010	FAIRING, FWD, FIXED; FLAP TRACK #2; RH;	57
D575406010	FAIRING, FWD, FIXED; FLAP TRACK #2; RH;	57
D575406010	FAIRING, FWD, FIXED; FLAP TRACK #2; RH;	57
D575406010	FAIRING, FWD, FIXED; FLAP TRACK #2; RH;	57
D575406010	FAIRING, FWD, FIXED; FLAP TRACK #2; RH;	57
D575406010	FAIRING, FWD, FIXED; FLAP TRACK #2; RH;	57
D575406010	FAIRING, FWD, FIXED; FLAP TRACK #2; RH;	57
D575406020	FLAP, L/E, VARIABLE CAMBER; POS 1-5&22-2	57
D575406020	FAIRING, FWD, FIXED, FLAP TRACK 3; LH	57
D575407010	FAIRING, FLAP TRACK NO. 4; LH	57
D575407010	FAIRING, FLAP TRACK NO. 4; LH	57
D575407010	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
D575407010	FLAP, L/E, VARIABLE CAMBER; POS 1-5&22-2	57
D575407010	FAIRING, WING TO FUSELAGE, PANEL 198GB;	57
D575407010	FAIRING, FLAP TRACK NO. 4; LH	57
D575407010	FAIRING, FLAP TRACK NO. 4; LH	57
D575407010	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
D575407010	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
D575407010	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
D575407010	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
D575407010	FAIRING, FLAP TRACK NO. 4; LH	57
D575407020	FLAP, L/E, VARIABLE CAMBER; POS 1-5&22-2	57
D575407020	FAIRING, FLAP TRACK NO. 4; LH	57

D575407020	FAIRING, FLAP TRACK NO. 4; LH	57
D575460140	PANEL, ASSY; RH	57
D575460140	PANEL, ASSY; RH	57
D575460140	PANEL, ASSY; RH	57
D575700500	FLAP ASSY, INBOARD;RH;A/C 3160-3171;3277	57
D575700500	FLAP ASSY, INBOARD;RH;A/C 3160-3171;3277	57
D575703050	STRUT, INTERCONNECT; FLAP.	27
D575703050	STRUT, INTERCONNECT; FLAP.	27
D575703220	STRUT, INTERCONNECT; FLAP.	27
D575703220	STRUT, INTERCONNECT; FLAP.	27
D575703220	STRUT, INTERCONNECT; FLAP.	27
D575706500	FLAP ASSY, INBOARD;RH;A/C 3160-3171;3277	57
D575706500	FLAP ASSY, INBOARD;RH;A/C 3160-3171;3277	57
D575706500	FLAP ASSY, INBOARD;RH;A/C 3160-3171;3277	57
D575706500	FLAP ASSY, INBOARD;RH;A/C 3160-3171;3277	57
D575710050	FLAP ASSY, OUTBOARD, RH; A/C 3201-3206	57
D575710050	FLAP ASSY, OUTBOARD, RH; A/C 3201-3206	57
D575710050	FLAP, ASSY; OUTBOARD LH	57
D575710050	FLAP ASSY, OUTBOARD, RH; A/C 3201-3206	57
D575710050	FLAP ASSY, OUTBOARD, RH; A/C 3201-3206	57
D575710050	FLAP ASSY, OUTBOARD, RH; A/C 3201-3206	57
D575710050	FLAP, ASSY; OUTBOARD LH	57
D575710050	FLAP ASSY, OUTBOARD, RH; A/C 3201-3206	57
D575710050	FLAP, ASSY; OUTBOARD LH	57
D575710050	FLAP, ASSY; OUTBOARD LH	57
D575710050	FLAP ASSY, OUTBOARD, RH; A/C 3201-3206	57
D575710050	PANEL, ASSY COVE LIGHT; LH	57
D575710050	PANEL, ASSY COVE LIGHT; LH	57
D575710060	PANEL, ASSY COVE LIGHT; LH	57
D575710060	FLAP, ASSY; OUTBOARD LH	57
D575710060	PANEL, ASSY COVE LIGHT; LH	57
D575710060	FLAP, ASSY; OUTBOARD LH	57

DSY2058-5	IN-PLANE BAGGAGE SYSTEM	25
DSY2059-5	IN-PLANE BAGGAGE SYSTEM	25
DSY2068-5	IN-PLANE BAGGAGE SYSTEM	25
E13017AA0	UNIT, PCB, CPU, SPOILER/ELEVATOR (ESDS)	27
E13589AA0	UNIT, CFDIU, CENTRALIZED FAULT DISPLAY	22
E13589AA0	UNIT, CFDIU, CENTRALIZED FAULT DISPLAY	22
E21327006	BSCU, EMM L4.9B; A320; CU.....	32
E21327106	BSCU, EMM L4.9B; A320; CU.....	32
E21327107	OBRM, BSCU, EMM; STD L4.9B; A319/A320;	32
E21337006	OBRM, BSCU, EMM; STD L4.9B; A319/A320;	32
E709-01-00	CEILING LIGHT	33
E709-03-00	CEILING LIGHT	33
E709-04-00	CEILING LIGHT	33
ED43A1D5	**NOT 145 APPROVED - FLIGHT DATA INTERFACE UNIT	31
ED43A1D6	**NOT 145 APPROVED - FLIGHT DATA INTERFACE UNIT	31
ED44A210	UNIT, DATA MAN, DMU; HAS	31
EM2144-01	PANEL, ASSY;CEILING;AFT CARGO;(3251-3270	25
EM56-20-1	MOTOR OPERATED GATE SHUTOFF VALVE	29
EM56-20-3	MOTOR OPERATED GATE SHUTOFF VALVE	29
EM56-20-4	MOTOR OPERATED GATE SHUTOFF VALVE	29
EM56-20-5	MOTOR OPERATED GATE SHUTOFF VALVE	29
EM91-79-1	2-WAY 2-POSITION SHUTOFF BALL VALVE	29
EM91-79-3	2-WAY 2-POSITION SHUTOFF BALL VALVE	29
EM91-79-4	2-WAY 2-POSITION SHUTOFF BALL VALVE	29
EM91-79-5	2-WAY 2-POSITION SHUTOFF BALL VALVE	29
EM91-80	VALVE, ISOLATED A/C PUMP,SHUT-OFF,REF...	29
EM91-80-1	VALVE, ISOLATED A/C PUMP,SHUT-OFF,REF...	29
EM91-80-3	VALVE, ISOLATED A/C PUMP,SHUT-OFF,REF...	29
EM91-80-4	VALVE, ISOLATED A/C PUMP,SHUT-OFF,REF...	29
EM91-80-5	VALVE, ISOLATED A/C PUMP,SHUT-OFF,REF...	29
EVT3454C	FAN, AVIONICS EQUIPMENT, BLOWE	21
EVT3454D	FAN, AVIONICS EQUIPMENT, BLOWE	21

F523705501	DOOR, FWD, CARGO COMPARTMENT; AD RELATED	52
F523705501	DOOR, FWD, CARGO COMPARTMENT; AD RELATED	52
F523705501	DOOR, FWD, CARGO COMPARTMENT; AD RELATED	52
F523705501	DOOR, FWD, CARGO COMPARTMENT; AD RELATED	52
F523707300	DOOR, FWD, CARGO COMPARTMENT; AD RELATED	52
F523707300	DOOR, AFT, CARGO COMPARTMENT; ASSY	52
F523709000	DOOR, FWD, CARGO COMPARTMENT; AD RELATED	52
F523709000	DOOR, FWD, CARGO COMPARTMENT; AD RELATED	52
F523710000	DOOR, AFT CARGO COMPARTMENT; A330	52
F523710000	DOOR, AFT CARGO COMPARTMENT; A330	52
F523712000	DOOR, AFT, CARGO COMPARTMENT; ASSY	52
F523723000	DOOR, AFT, CARGO COMPARTMENT; ASSY	52
F523723000	DOOR, AFT, CARGO COMPARTMENT; ASSY	52
F523723000	DOOR, AFT, CARGO COMPARTMENT; ASSY	52
F523723000	DOOR, AFT, CARGO COMPARTMENT; ASSY	52
F523723000	DOOR, AFT, CARGO COMPARTMENT; ASSY	52
F523723001	DOOR, AFT CARGO COMPARTMENT; A330	52
F523723001	DOOR, AFT, CARGO COMPARTMENT; ASSY	52
F523723001	DOOR, AFT, CARGO COMPARTMENT; ASSY	52
F523723001	DOOR, AFT, CARGO COMPARTMENT; ASSY	52
F523723001	DOOR, AFT, CARGO COMPARTMENT; ASSY	52
F523723150	DOOR, AFT, CARGO COMPARTMENT; ASSY	52
F523723150	DOOR, AFT, CARGO COMPARTMENT; ASSY	52
F523723150	DOOR, AFT, CARGO COMPARTMENT; ASSY	52
F523723150	DOOR, AFT, CARGO COMPARTMENT; ASSY	52
F524712250	DOOR, MLG, ASSY; LH; A330	52
F524716210	DOOR, MLG, ASSY; LH; A330	52
F528105010	DOOR, MLG, ASSY; LH; A330	32
F528105010	DOOR, MLG, ASSY; LH; A330	32
F528105010	DOOR, MLG, ASSY; LH; A330	32
F528105011	DOOR, MLG, ASSY; LH; A330	32
F551838500	MOTOR HORIZONTAL STABILIZER CONTROL	55
F551838500	MOTOR HORIZONTAL STABILIZER CONTROL	55

F552800000	ELEVATOR, ASSY; RH;.A330, AD RELATED	55
F552800000	ELEVATOR, ASSY; RH; A330, AD RELATED	55
F552800000	ELEVATOR, ASSY; RH; A330, AD RELATED	55
F552800000	ELEVATOR, ASSY; RH; A330, AD RELATED	55
F552800000	ELEVATOR, ASSY; RH; A330, AD RELATED	55
F552800000	ELEVATOR, ASSY; RH;.A330, AD RELATED	55
F552800000	ELEVATOR, ASSY; RH;.A330, AD RELATED	55
F552800000	ELEVATOR, ASSY; RH;.A330, AD RELATED	55
F552800000	ELEVATOR, ASSY; RH;.A330, AD RELATED	55
F552800000	ELEVATOR, ASSY; RH; A330, AD RELATED	55
F552800000	ELEVATOR, ASSY; RH;.A330, AD RELATED	55
F552800000	ELEVATOR, ASSY; RH;.A330, AD RELATED	55
F552800000	ELEVATOR, ASSY; RH;.A330, AD RELATED	55
F552800000	ELEVATOR, ASSY; RH;.A330, AD RELATED	55
F552800000	ELEVATOR, ASSY; RH;.A330, AD RELATED	55
F552800000	ELEVATOR, ASSY; RH;.A330, AD RELATED	55
F552800020	ELEVATOR, ASSY; RH;.A330, AD RELATED	55
F552800020	ELEVATOR, ASSY; RH;.A330, AD RELATED	55
F552800020	ELEVATOR, ASSY; RH;.A330, AD RELATED	55
F552800020	ELEVATOR, ASSY; RH;.A330, AD RELATED	55
F552800050	ELEVATOR, ASSY; RH;.A330, AD RELATED	55
F552800050	ELEVATOR, ASSY; RH;.A330, AD RELATED	55
F552800050	ELEVATOR, ASSY; RH;.A330, AD RELATED	55
F552800050	ELEVATOR, ASSY; RH;.A330, AD RELATED	55
F552800050	ELEVATOR, ASSY; RH;.A330, AD RELATED	55
F552800050	ELEVATOR, ASSY; RH;.A330, AD RELATED	55
F552800050	ELEVATOR, ASSY; RH;.A330, AD RELATED	55
F552800050	ELEVATOR, ASSY; RH;.A330, AD RELATED	55
F552800050	ELEVATOR, ASSY; RH;.A330, AD RELATED	55
F552800050	ELEVATOR, ASSY; RH;.A330, AD RELATED	55
F573534900	WINGLET, ASSY; RH	57
F573534900	WINGLET, ASSY; RH	57

F573534900	WINGLET, ASSY; RH	57
F573534900	WINGLET, ASSY; RH	57
F573534900	WINGLET, ASSY; RH	57
F573534900	WINGLET, ASSY; RH	57
F573534900	WINGLET, ASSY; RH	57
F573534900	WINGLET, ASSY; RH	57
F574621880	SLAT, SLAT ASSY, #1,L/H	57
F574621980	SLAT, SLAT ASSY, #1,L/H	57
F575741120	FAIRING, ASSY, MOVABLE; #5R;	57
F575741120	FAIRING, ASSY, MOVABLE; #5R;	57
F575741120	FAIRING, ASSY, MOVABLE; #5R;	57
F575741120	FAIRING, ASSY, MOVABLE; #5R;	57
F575741120	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
F575741120	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
F575741120	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
F575741120	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
F575741120	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
F575741120	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
F575741120	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
F575741120	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
F575741120	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
F575741130	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
F575741130	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
F575741130	FAIRING, ASSY, MOVABLE; #5R;	57
F575741130	FAIRING, ASSY, MOVABLE; #5R;	57
F575741130	FAIRING, ASSY, MOVABLE; #5R;	57
F575741130	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
F575741130	FAIRING, ASSY, MOVABLE; #5R;	57
F575741130	FAIRING, ASSY, MOVABLE; #5R;	57
F575741130	FAIRING, ASSY, MOVABLE; #5R;	57
F575741130	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
F575741130	FAIRING, ASSY, MOVABLE; #5R;	57
F575741130	FAIRING, WING TO FUSELAGE, PANEL 198GB;	57

F575741130	FAIRING, ASSY, MOVABLE; #5R;	57
F575741130	FAIRING, ASSY; WINDOW	57
F575741130	FAIRING, ASSY, MOVABLE; #5R;	57
F575741130	FAIRING, ASSY; WINDOW	57
F575741130	FAIRING, ASSY, MOVABLE; #5R;	57
F575741130	FAIRING, ASSY; WINDOW	57
F575741130	FAIRING, ASSY, MOVABLE; #5R;	57
F575741130	FAIRING, ASSY; WINDOW	57
F575741130	FAIRING, ASSY, MOVABLE; #5R;	57
F575741130	FAIRING, ASSY; WINDOW	57
F575741130	FAIRING, ASSY, MOVABLE; #5R;	57
F575741130	FAIRING, ASSY; WINDOW	57
F575741130	FAIRING, ASSY, MOVABLE; #5R;	57
F575741130	FAIRING, ASSY; WINDOW	57
F575741130	FAIRING, ASSY, MOVABLE; #5R;	57
F575741130	FAIRING, ASSY; WINDOW	57
F575741130	FAIRING, ASSY, MOVABLE; #5R;	57
F575741130	FAIRING, ASSY; WINDOW	57
F575741130	FAIRING, ASSY, MOVABLE; #5R;	57
F575741130	FAIRING, ASSY; WINDOW	57
F575741130	FAIRING, ASSY, MOVABLE; #5R;	57
F575741130	FAIRING, ASSY; WINDOW	57
F575741130	FAIRING, ASSY, MOVABLE; #5R;	57
F575741130	FAIRING, ASSY, MOVABLE; #3R; POST-MOD;	57
F575741130	FAIRING, ASSY, MOVABLE; #5R;	57
F575741130	FAIRING, ASSY, MOVABLE; #3R; POST-MOD;	57
F575741130	FAIRING, ASSY, MOVABLE; #5R;	57
F575741130	FAIRING, ASSY, MOVABLE; #5R;	57
F575741130	FAIRING, ASSY, MOVABLE; #3R; POST-MOD;	57
F575741130	FAIRING, ASSY, MOVABLE; #3R; POST-MOD;	57

F575741130	FAIRING, ASSY, MOVABLE; #3R; POST-MOD;	57
F575741130	FAIRING, ASSY, MOVABLE; #3R; POST-MOD;	57
F575741130	FAIRING, ASSY, MOVABLE; #3R; POST-MOD;	57
F575741130	FAIRING, ASSY, MOVABLE; #3R; POST-MOD;	57
F575741130	FAIRING, ASSY, MOVABLE; #3R; POST-MOD;	57
F575741130	FAIRING, ASSY, MOVABLE; #3R; POST-MOD;	57
F575741140	FAIRING, ASSY, MOVABLE; #4R;	57
F575741140	FAIRING, ASSY, MOVABLE; #4R;	57
F575741140	FAIRING, WING TO FUSELAGE, PANEL 198BB;	57
F575741140	FAIRING, WING TO FUSELAGE, PANEL 198BB;	57
F575741140	FAIRING, WING TO FUSELAGE, PANEL 198BB;	57
F575741140	FAIRING, WING TO FUSELAGE, PANEL 198BB;	57
F575741150	FAIRING, ASSY, MOVABLE; #5R;	57
F575741150	FAIRING, WING TO FUSELAGE, PANEL 198BB;	57
F575741150	FAIRING, WING TO FUSELAGE, PANEL 198BB;	57
F575741150	FAIRING, WING TO FUSELAGE, PANEL 198BB;	57
F575741150	FAIRING, WING TO FUSELAGE, PANEL 198BB;	57
F575741150	FAIRING, WING TO FUSELAGE, PANEL 198GB;	57
F575741150	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
F575741150	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
F575741150	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
F575741150	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
F575741150	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
F575741150	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
F575741150	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
F575741150	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
F575741150	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
F575741150	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
F575741150	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
F575741150	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
F575741160	FAIRING, ASSY, MOVABLE; #4R;	57
F575741160	FAIRING, ASSY, MOVABLE; #4R;	57

F575741160	FAIRING, ASSY, MOVABLE; #4R;	57
F575741160	FAIRING, ASSY, MOVABLE; #4R;	57
F575741160	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
F575741160	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
F575741160	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
F575741160	FAIRING, FWD, FIXED; FLAP TRACK 4; RH	57
F576105070	AILERON ASSY, OUTER RH	57
F577700000	SPOILER, ASSY #5 (RH) POSITION	57
F577700000	SPOILER, ASSY #5 (RH) POSITION	57
F577700010	SPOILER, ASSY #5 (RH) POSITION	57
F577700010	SPOILER, ASSY #5 (RH) POSITION	57
F577700020	SPOILER, ASSY #6 (RH) POSITION	57
F577700020	SPOILER, ASSY #6 (RH) POSITION	57
F577710010	SPOILER, ASSY #6 (RH) POSITION	57
F577710010	SPOILER, ASSY #6 (RH) POSITION	57
F577710020	SPOILER, ASSY #6 (RH) POSITION	57
F577710020	SPOILER, ASSY #6 (RH) POSITION	57
F577721000	SPOILER, ASSY #6 (RH) POSITION	57
F577721000	SPOILER, ASSY #1 (LH) POS; 3312-3321 & 3	57
F577721000	SPOILER, ASSY #6 (RH) POSITION	57
F577721000	SPOILER, ASSY #6 (RH) POSITION	57
F577722000	SPOILER, ASSY #6 (RH) POSITION	57
F577722000	SPOILER, ASSY #6 (RH) POSITION	57
F577722000	SPOILER, ASSY #6 (RH) POSITION	57
F577722000	SPOILER, ASSY #6 (RH) POSITION	57
F577722000	SPOILER, ASSY #6 (RH) POSITION	57
F577722000	SPOILER, ASSY #6 (RH) POSITION	57
F577722000	SPOILER, ASSY #6 (RH) POSITION	57
F577722000	SPOILER, ASSY #6 (RH) POSITION	57
F577722000	SPOILER, ASSY #6 (RH) POSITION	57
F577722000	SPOILER, ASSY #6 (RH) POSITION	57
F577726000	SPOILER, ASSY #6 (RH) POSITION	57
F577726000	SPOILER, ASSY #6 (RH) POSITION	57
F577726000	SPOILER, ASSY #6 (RH) POSITION	57

FG1006AA5	FUEL QUANTITY TANK UNIT ASSEMBLY	28
FG1006AA5	FUEL QUANTITY TANK UNIT ASSEMBLY	28
FG1006AA5	FUEL QUANTITY TANK UNIT ASSEMBLY	28
FG1006AA6	FUEL QUANTITY TANK UNIT ASSEMBLY	28
FG1006AA6	FUEL QUANTITY TANK UNIT ASSEMBLY	28
FG1006AA6	FUEL QUANTITY TANK UNIT ASSEMBLY	28
FG1006AA6	FUEL QUANTITY TANK UNIT ASSEMBLY	28
FG1007AA0	FUEL QUANTITY COMPENSATOR ASSEMBLY	28
FG1007AA0	FUEL QUANTITY COMPENSATOR ASSEMBLY	28
FR5	HALON FIRE EXTINGUISHER	26
G25274007	TABLE, BABY CHANGE, F/C LAV;	25
G3122B	AMPLIFIR INTERPHONE	23
G5515	SPEAKER TCAS RESTRICTED AIR SHIPMENT	23
G5515R	SPEAKER TCAS RESTRICTED AIR SHIPMENT	23
G5515V1	SPEAKER TCAS RESTRICTED AIR SHIPMENT	34
G5730-03	PANEL INSTRUMENT SWITCHING STATIC SENSIT	34
G57772300	SPOILER, ASSY #4 (RH) POSITION	57
G57772300	SPOILER, ASSY #4 (RH) POSITION	57
G57772300	SPOILER, ASSY #4 (RH) POSITION	57
G57772300	SPOILER, ASSY #4 (RH) POSITION	57
G57772300	SPOILER, ASSY #4 (RH) POSITION	57
G57772300	SPOILER, ASSY #4 (RH) POSITION	57
G57772300	SPOILER, ASSY #4 (RH) POSITION	57
G57772300	SPOILER, ASSY #4 (RH) POSITION	57
G57772300	SPOILER, ASSY #4 (RH) POSITION	57
G57772300	SPOILER, ASSY #4 (RH) POSITION	57
G57772300	SPOILER, ASSY #4 (RH) POSITION	57
G57772300	SPOILER, ASSY #4 (RH) POSITION	57
G57772300	SPOILER, ASSY #4 (RH) POSITION	57
G57772300	SPOILER, ASSY #4 (RH) POSITION	57
G57772300	SPOILER, ASSY #4 (RH) POSITION	57
G57772400	SPOILER, ASSY #4 (RH) POSITION	57
G57772400	SPOILER, ASSY #4 (RH) POSITION	57

G6225-04	PANEL ADF CONTROL ARINC 712 STATIC SENSI	34
G6773	PANEL, VHF NAV CONTROL,NBR 1 & 2 USED ON	34
G6773-02	PANEL, VHF NAV CONTROL,NBR 1 & 2 USED ON	34
G6773-03	PANEL, VHF NAV CONTROL,NBR 1 & 2 USED ON	34
G6773-04	PANEL, VHF NAV CONTROL,NBR 1 & 2 USED ON	34
G6959-01	PANEL, VHF COMMUNICATION CONTROL	23
G6990-09	PANEL, CONTROL; TRANSPONDER	34
G6992-02	ATC/TCAS CONTROL PANEL	34
G6992-03	ATC/TCAS CONTROL PANEL	34
G6992-08	ATC/TCAS CONTROL PANEL	34
G6992-10	PANEL, CONTROL; TRANSPONDER	34
G6992-12	PANEL, CONTROL; TRANSPONDER	34
G6992-40	ATC/TCAS CONTROL PANEL	34
G6992-42	ATC/TCAS CONTROL PANEL	34
G7119-02	PANEL INTERPHONE SWITCH USED ON A/C 9201	23
G7120-01	SPEAKER PUBLIC ADDRESS USED ON MD90 A/C	23
G7164-03	ANNUNCIATOR, HF/SAT	23
G7400-01	VHF COMM CONTROL PANEL	23
G7400-227	VHF COMM CONTROL PANEL	23
G7400-27	VHF COMM CONTROL PANEL	23
G7400-31	VHF COMM CONTROL PANEL	23
G7400-32	PANEL, VHF COMMUNICATION CONTROL	23
G7401-03	HF COMMUNICATION CONTROL PANEL	23
G7402-04	ADF CONTROL PANEL	34
G7402-05	ADF CONTROL PANEL	34
G7403-03	ADF CONTROL PANEL	34
G7404-01	RADIO TUNING PANELS	23
G7404-03	RADIO TUNING PANELS	23
G7404-04	RADIO TUNING PANELS	23
G7404-121	RADIO TUNING PANELS	23
G7404-123	RADIO TUNING PANELS	23
G7404-124	RADIO TUNING PANELS	23

G7404-125	RADIO TUNING PANELS	23
G7404-23	RADIO TUNING PANELS	23
G7404-24	RADIO TUNING PANELS	23
G7490-42	PANEL, ATC CONTROL, USED ON AC 6801-6813	34
G7500-03	NAV CONTROL PANEL	34
G7501-01	NAV CONTROL PANEL	34
GE16720-0	LIGHT AFT ANTICOLLISION POSITION	
GE16720-0	LIGHT, WING TIP, STROBE;AFT	33
GE16720-0	LIGHT AFT ANTICOLLISION POSITION	33
GE16720-0	LIGHT, WING TIP, STROBE;AFT	33
GE16720-0	LIGHT AFT ANTICOLLISION POSITION	33
GM6937-5	ROTARY TRANSDUCER	27
GMT4200	PILOT AND CO-PILOT ELECTRONIC CLOCK	31
GMT4200-1	PILOT AND CO-PILOT ELECTRONIC CLOCK	31
H05A0035-	UNIT CENTER AURAL WARNING STATIC SENSITI	31
H05A0035-	UNIT CENTER AURAL WARNING STATIC SENSITI	31
H150AKM	STANDBY ATTITUDE INDICATOR	34
H150AKM1	STANDBY ATTITUDE INDICATOR	34
H321BHM1	IND, STANDBY HORIZON, A320; A340	34
H341BWM	GYROSCOPIC HORIZON/STANDBY ATTITUDE INDICATOR	34
H341CBM	GYROSCOPIC HORIZON/STANDBY ATTITUDE INDICATOR	34
H3855-8	LATCH, AFT LOAD SHARE; T/R;...	78
H414-15	LATCH FLUSH, AFT CARGO DOOR SHIP IN ATA	52
H414-23	LATCH FLUSH, AFT CARGO DOOR SHIP IN ATA	52
H414-29	LATCH FLUSH, AFT CARGO DOOR SHIP IN ATA	52
H414-31	LATCH FLUSH, AFT CARGO DOOR SHIP IN ATA	52
H414-35	LATCH FLUSH, AFT CARGO DOOR SHIP IN ATA	52
H414-37	LATCH FLUSH, AFT CARGO DOOR SHIP IN ATA	52
H504B	CONTROL SURFACE POSITION TRANSMITTER	27
H504C	CONTROL SURFACE POSITION TRANSMITTER	27
H505A	CONTROL SURFACE POSITION TRANSMITTER	27
H505B	TRANSMITTER	27

H509B	CONTROL SURFACE POSITION TRANSMITTER	27
H61C0552M	VALVE HYD CHECK SYS A UPON RECEIPT SEND	29
HA247-5	LATCH EQUIPMENT ACCESS DOOR	52
HA247-9	LATCH EQUIPMENT ACCESS DOOR	52
HAC19460	IMMERSION THERMOCOUPLE	75
HAC19822	EEC FUEL/ OIL TEMP PROBE - PW4000	73
HAC19822A	EEC FUEL/ OIL TEMP PROBE - PW4000	73
HAC20461	EGT THERMOCOUPLE CABLES & JUNCTION BOXES	77
HAD18269	EGT THERMOCOUPLE PROBE	77
HAD18286	OIL TEMP PROBE - PW4000	73
HAD18540	EGT THERMOCOUPLE PROBE	77
HAD18600	HARNESS, FAN CASE,..	77
HAD18700	EEC FUEL TEMPERATURE PROBE	73
HAD18927	EGT THERMOCOUPLE CABLE AND BOX ASSEMBLY	77
HAD18928	EGT THERMOCOUPLE CABLES	77
HAD18929	EGT THERMOCOUPLE CABLES	77
HAD18952	EEC THERMOCOUPLE	73
HAD18952A	EEC THERMOCOUPLE	73
HAD19412	EGT THERMOCOUPLE CABLE AND BOX ASSEMBLY	77
HAD19490	EGT THERMOCOUPLE CABLES & JUNCTION BOXES	77
HAD19795	THERMCPL OPTION, EGT IMMERSION MUST BE U	77
HAD20458	EGT THERMOCOUPLE CABLES & JUNCTION BOXES	77
HAD20459	EGT THERMOCOUPLE CABLES & JUNCTION BOXES	77
HAD20460	EGT THERMOCOUPLE CABLES & JUNCTION BOXES	77
HAD20594	HARNESS EGT, T/C 1 & 2	77
HAD20759	HARNESS EGT, T/C 1 & 2	77
HC1750	VALVE, ANTI-ICE, WING; A319/A320	30
HC1750A	VALVE, ANTI-ICE, WING; A319/A320	30
HC1751	VALVE, ANTI-ICE, WING; A319/A320	30
HC1752	VALVE, ANTI-ICE, WING; A319/A320	30
HC1755	VALVE, ANTI-ICE, WING; A319/A320	30
HC1756	VALVE, ANTI-ICE, WING; A319/A320	30

HC1757	VALVE, ANTI-ICE, WING; A319/A320	30
HC1758	VALVE, ANTI-ICE, WING; A319/A320	30
HG1057AA0	DIGITAL FUEL GUAGE PROCESSOR	28
HG1057AA0	DIGITAL FUEL GUAGE PROCESSOR	28
HG1057AA0	DIGITAL FUEL GUAGE PROCESSOR	28
HG1057LR0	FUEL QUANTITY PROCESSOR	28
HG1057LR0	FUEL QUANTITY PROCESSOR	28
HG1064AA0	DIGITAL FUEL GAUGE PROCESSOR	28
HG1064AA0	DIGITAL FUEL GAUGE PROCESSOR	28
HG1103BA0	UNIT, INERTIAL REFERENCE,USED ON A/C 986	34
HG2030AD1	AIR DATA INERTIAL REFERENCE UNIT	34
HG2030AE2	AIR DATA INERTIAL REFERENCE UNIT	34
HG2030AE2	AIR DATA INERTIAL REFERENCE UNIT	34
HG2030AE2	AIR DATA INERTIAL REFERENCE UNIT	34
HG2050AC0	AIR DATA INERTIAL REFERENCE UNIT	34
HG2050AC0	AIR DATA INERTIAL REFERENCE UNIT	34
HG2050AC0	AIR DATA INERTIAL REFERENCE UNIT	34
HG2050AC0	AIR DATA INERTIAL REFERENCE UNIT	34
HG280D80	DIGITAL AIR DATA COMPUTER	34
HP1368100	THRUST REVERSER ISOLATION VALVE MODULE	78
HP1368100	THRUST REVERSER ISOLATION VALVE MODULE	78
HP1368100	THRUST REVERSER ISOLATION VALVE MODULE	78
HP1368100	THRUST REVERSER ISOLATION VALVE MODULE	78
HP1368100	THRUST REVERSER ISOLATION VALVE MODULE	78
HP1368100	THRUST REVERSER ISOLATION VALVE MODULE	78
HP1373100	RESERVOIR FILL SELECTOR VALVE ASSEMBLY	29
HP1373100	RESERVOIR FILL SELECTOR VALVE ASSEMBLY	29
HTE200002	ACTUATOR, FUEL VALVE; SINGLE.MOTOR	28
HTE200002	ACTUATOR, FUEL VALVE; SINGLE.MOTOR	28
JG1208AA0	INDICATOR	28
JG1208CA0	INDICATOR	28
JMS2001-5	LATCH ASSY, FWD LAV RH DOOR, AFT LAV RH	25

JMS2001-5	LATCH ASSY, FWD LAV RH DOOR, AFT LAV RH	25
JMS2001-5	LATCH ASSY, FWD LAV RH DOOR, AFT LAV RH	25
K217ABM1	UNIT, NWA INSOURCE PART...	22
K282AAM0	PRINTER, A330	45
K282AAM0	PRINTER, A330	45
L0060001	GLARESHEILD FLOODLIGHT	33
L0060002	GLARESHEILD FLOODLIGHT	33
L14500	ANNUNCTR CABIN ATTENDANT CALL PACKAGE 1E	33
LA2B00300	COMPUTER, FLT CONTROL, FCSC, A330	27
LA2E20202	COMPUTER, FLT WARNING	31
LA2E90606	CONTROL PANEL, ECAM, A330	31
LA2H60300	MONITOR, BRAKE, TEMPERATURE.	32
LA2K2B100	COMPUTER, FLT CTL, PRIM; FCPC; A330	27
LA2T0G205	ATSU, AIR TRAFFIC, SERVICES UNIT	23
LA2T0G205	ATSU, AIR TRAFFIC, SERVICES UNIT	23
LA2T0G207	ATSU, AIR TRAFFIC, SERVICES UNIT	46
LG80E1	ENGINE SPEED PRINTED WIRING ASSEMBLY	77
LK35-2	STANDBY ALTIMETER	34
LM433SA17	AFT VIBRATION ISOLATOR	71
LM433SA33	AFT VIBRATION ISOLATOR	71
LM433SA37	AFT VIBRATION ISOLATOR	71
M4100952	SWITCH PACK SHUTDOWN SHIP IN ATA SPEC 30	21
M4809A111	TABLE, GALLEY, FOLDING, FWD GALLEY	25
M4809A141	TABLE, GALLEY, FOLDING, FWD GALLEY	25
M4809A142	TABLE, GALLEY, FOLDING; AFT GALLEY; LH	25
M4809A155	TABLE, GALLEY, FOLDING; AFT GALLEY; LH	25
M4809A303	TABLE, GALLEY, FOLDING, FWD GALLEY	25
M4811A111	TABLE, GALLEY, FOLDING; AFT GALLEY; LH	25
M4811A113	TABLE, GALLEY, FOLDING; AFT GALLEY; LH	25
M4811A114	DOOR, ROLLER, ASSY; GALLEY COMPT 5-3/4 &	25
M4811A141	TABLE, GALLEY, FOLDING, FWD GALLEY	25
M4811A275	TABLE, GALLEY, FOLDING; AFT GALLEY; LH	25

M6562-1	DOOR, ASSY; STOWABLE;	25
M6563-1	DOOR, ASSY; STOWABLE;	25
M6565-141	DOOR, ASSY; STOWABLE;	25
M6962-1	DIVIDER, CLASS, RH; A319/A320'	25
M6963-1	DIVIDER, CLASS, RH; A319/A320'	25
M732591AF	ROTOR, HOUSING, ELECTRONIC FWD COMPT..	21
M732591BF	ROTOR, HOUSING, ELECTRONIC FWD COMPT..	21
M732591DF	ROTOR, HOUSING, ELECTRONIC FWD COMPT..	21
M732591EF	ROTOR, HOUSING, ELECTRONIC FWD COMPT..	21
M734284AF	GENERATOR CONTROL UNIT	24
M734284DF	GENERATOR CONTROL UNIT	24
M734284F	GENERATOR CONTROL UNIT	24
M892480	Fire Extinguisher	26
MA11A1265	MOTOR ACTUATOR ASSEMBLY	28
MA11A1265	MOTOR ACTUATOR ASSEMBLY	28
MA11A1267	MOTOR ACTUATOR ASSEMBLY	28
MC10-25-1	CREW OXYGEN MASK REGULATOR	35
MC10-25-1	CREW OXYGEN MASK REGULATOR	35
MC10-25-1	CREW OXYGEN MASK REGULATOR	35
MC10-25-1	CREW OXYGEN MASK REGULATOR	35
MC10-25-1	CREW OXYGEN MASK REGULATOR	
MC10-25-1	CREW OXYGEN MASK REGULATOR	35
MC10-25-1	CREW OXYGEN MASK REGULATOR	35
MF10-02-1	FULL FACE QUICK DONNING MASK REGULATOR	35
MF40-40-00	MASK, CREW OXYGEN, B737-900	35
MXP106-02	BOX, OXYGEN MASK STOWAGE	35
MXP 146.00	BOX, OXYGEN MASK STOWAGE	35
MXP146-1	BOX, OXYGEN MASK STOWAGE	35
MXP 147.00	FLIGHT CREW MASK STOWAGE	35
MXP147-1	BOX, OXYGEN MASK STOWAGE	35
MXP147-2	FLIGHT CREW MASK STOWAGE	35
MXP147-3	FLIGHT CREW MASK STOWAGE	35

MXP147-5	FLIGHT CREW MASK STOWAGE	35
N57351276	LENS, GLAZING ASSY; WING TIP; LT WING; A	57
N57351276	LENS, GLAZING ASSY;WINGTIP;RTWINGA320	57
N57351276	LENS, GLAZING ASSY;WINGTIP;RTWINGA320	57
N57351276	LENS, GLAZING ASSY;WINGTIP;RTWINGA320	57
N57351276	LENS, GLAZING ASSY;WINGTIP;RTWINGA320	57
NA138-714	SELCAL DECODER	23
NA138-714	SELCAL DECODER	23
NA138-714	SELCAL DECODER	23
NW26592-1	KIT, SURVIVAL; A320	25
NW26592-1	KIT SURVIVAL, SLIDE RAFT; 757	25
NW26592-5	KIT, SURVIVAL; A320	25
NW26592-6	KIT, SURVIVAL; A320	25
NW3C71-37	HARNESS, FAN CASE, RH;	71
NW5A71-41	HARNESS, FAN CASE,..	71
NW5B21-42	AIR CONDITIONING CONTROL PANEL ASSEMBLY, M1019	21
NW5B34-39	EFIC-701 ELECTRONIC FLIGHT INSTRUMENT CONTROL	34
NW5B34-39	PANEL EFIS NWA INSOURCE	31
NW6B31-41	CARD, MEMORY, ASSY HONEYWELL F.	31
NWSA7121	AFT MOUNT ASSEMBLY - PW4000	71
NWSA7121	AFT ENGINE MOUNT - PW2000	71
NWSA7121	AFT ENGINE MOUNT - PW2000	71
P183-395-1	WATER QUANTITY INDICATOR	38
P56C	RVDT POSITION TRANSDUCER - CF6-80A, CF6-80C2 PMO	76
P76200A	AUTO THROTTLE SERVO MOTOR	22
PC01801	TRANSFORMER, CURRENT	24
PC01801-0	TRANSFORMER, CURRENT	24
PG1152AC	MODULE, AIR DATA, A319/A320; R.	34
PU90-429W	DETECTOR LAVATORY SMOKE	26
PV3-160-4E	VARIABLE DISPLACEMENT HYDRAULIC PUMP ASSEMBLY	29
R21275	TAB, AILERON CONTROL,RH	27
R21A	TRNSFRMR ROTATING VARIABLE LESS CONNECTO	27

R22A	TRNSFRMR, ROTATING VARIABLE,LESS CONNECT	27
R574581030	PANEL, ACCESS, NO. 4; RIGHT WING	57
R574581030	PANEL, ACCESS, NO. 4; RIGHT WING	57
R6357-501A	CONTROL, MASTER CAUTION, WARNING; ALL DC	33
R6357-505A	CONTROL, MASTER CAUTION, WARNING; ALL DC	33
R6357-550	CONTRLLR MASTER WARNING AND CAUTION SYST	33
R93036	AIRCRAFT FIRE EXTINGUISHERS, LIQUID TYPE	26
R99285	PORTABLE CYLINDER ASSEMBLIES	35
RDAA90212	VIDEO MODULE/PSU PANEL ASSEMBLY	23
RDAA90212	VIDEO MODULE/PSU PANEL ASSEMBLY	23
RDAA90212	VIDEO MODULE/PSU PANEL ASSEMBLY	23
RDAA90212	VIDEO MODULE/PSU PANEL ASSEMBLY	23
RDAA90212	VIDEO MODULE/PSU PANEL ASSEMBLY	23
RDAA90212	VIDEO MODULE/PSU PANEL ASSEMBLY	23
RDAA90212	VIDEO MODULE/PSU PANEL ASSEMBLY	23
RDAA90212	VIDEO MODULE/PSU PANEL ASSEMBLY	23
RDAM8303	SPEAKER, AURAL WARNING,COCKPIT,USED ON A	23
RDAM8303	SPEAKER, AURAL WARNING,COCKPIT,USED ON A	23
RDAM8304	SPEAKER, AURAL WARNING,COCKPIT,USED ON A	23
RG1017AA0	LOAD SELECT CONTROL ASSEMBLY	28
RG150-1	BATTERY, INERTIAL REFERENCE, UNIT	34
RL22FYB3Y	SEAT, FLT ATTENDANT, SWIVEL; A319/A320	25
RL27FYB31	SEAT, FLT ATTENDANT, SWIVEL; A319/A320	25
RL27FYB3Y	SEAT, FLT ATTENDANT, SWIVEL; A319/A320	25
RL27FYF31	SEAT, FLT ATTENDANT, SWIVEL; A319/A320	25
RL27FYU31	SEAT, FLT ATTENDANT, SWIVEL; A319/A320	25
RL27FYU3Y	SEAT, FLT ATTENDANT, SWIVEL; A319/A320	25
RPS1	PWRSPPLY EMERGENCY LIGHTING LESS BATTERY	33
RPS1B	PWRSPPLY EMERGENCY LIGHTING LESS BATTERY	33
RR12551A	PUMP FUEL, ENGINE START RESTRICTED AIR S	28
RR34150L	LUBE AND SCAVENGE PUMP	79
RR37100	LUBE AND SCAVENGE PUMP	79
RR37100B	LUBE AND SCAVENGE PUMP	79

RR37100D	LUBE AND SCAVENGE PUMP	79
RS19210-2	IN-PLANE BAGGAGE SYSTEM	25
S152-0020-	PANEL, TEST MIC/MONITOR,VOICE RECORDER,U	23
S152-0020-	PANEL, TEST MIC/MONITOR,VOICE RECORDER,U	23
S152-0040-	PANEL, TEST MIC/MONITOR,VOICE RECORDER,U	23
S200-0003-	SOLID STATE VOICE RECORDER	23
S210T120-1	HIGH PRESSURE SHUTOFF VALVE	36
S210T120-1	FAN AIR MODULATING VALVE	36
S210T120-1	HIGH PRESSURE SHUTOFF VALVE	36
S210T120-1	FAN AIR MODULATING VALVE	36
S210T120-1	HIGH PRESSURE SHUTOFF VALVE	36
S210T120-1	HIGH PRESSURE SHUTOFF VALVE	36
S210T120-1	HIGH PRESSURE SHUTOFF VALVE	36
S210T120-1	PRESSURE CONTROLLER	36
S210T120-1	FAN AIR MODULATING VALVE	36
S210T120-1	PRESSURE CONTROLLER	36
S210T120-1	PRESSURE CONTROLLER	36
S210T120-2	HIGH PRESSURE CONTROLLER	36
S210T120-2	HIGH PRESSURE CONTROLLER	36
S210T120-2	PRESSURE CONTROLLER	36
S210T120-2	PRESSURE CONTROLLER	36
S210T120-3	HIGH PRESSURE CONTROLLER	36
S210T120-4	HIGH PRESSURE SHUTOFF VALVE	36
S210T120-5	HIGH PRESSURE SHUTOFF VALVE	36
S210T120-5	PRESSURE REGULATING AND SHUTOFF VALVE	36
S210T120-6	PRESSURE CONTROLLER	36
S210T120-6	PRESSURE REGULATING AND SHUTOFF VALVE	36
S210T120-7	HIGH PRESSURE SHUTOFF VALVE	36
S210T120-7	PRESSURE REGULATING AND SHUTOFF VALVE	36
S210T120-8	PRESSURE REGULATING AND SHUTOFF VALVE	36
S212N102-	DUAL PURPOSE VALVE	36
S212N102-	DUAL PURPOSE VALVE	36

S212N102-1	DUAL PURPOSE VALVE	36
S212N102-1	DUAL PURPOSE VALVE	36
S212N102-1	DUAL PURPOSE VALVE	36
S212N102-1	DUAL PURPOSE VALVE	36
S212N102-2	DUAL PURPOSE VALVE	36
S212N102-2	DUAL PURPOSE VALVE	36
S212N102-2	DUAL PURPOSE VALVE	36
S212N102-2	DUAL PURPOSE VALVE	36
S212N102-3	DUAL PURPOSE VALVE	36
S212N102-3	DUAL PURPOSE VALVE	36
S212N102-3	DUAL PURPOSE VALVE	36
S212N102-7	DUAL PURPOSE VALVE	36
S212N102-9	DUAL PURPOSE VALVE	36
S218W401-1	HARNES, FAN CASE,..	26
S231N212-8	VALVE POSITION INDICATOR	21
S231T102-1	MODEL VS-800 VERTICAL SPEEN INDICATOR	34
S231T120-1	ELECTRONIC CLOCK	31
S231T240-1	VALVE POSITION INDICATOR	21
S231T240-2	VALVE POSITION INDICATOR	21
S231T240-3	VALVE POSITION INDICATOR	21
S231T330-1	ICE DETECTOR	30
S231T330-2	ICE DETECTOR	30
S231T330-5	ICE DETECTOR	30
S231T330-5	ICE DETECTOR	30
S232A312-1	SEAT FIRST OBSERVER SHIP IN ATA SPEC 300	25
S232T311-3	CREW SEAT	25
S233T100-0	PLATE AY, LIGHTED LFT INST SOURCE SELECT	31
S233T100-0	PLATE,WING & ANTI-ICE,LIGHTPLATE USED ON	31
S233T100-0	PLATE, AUTO BRAKE-LIGHT	31
S233T100-0	PLATE, AUTO BRAKE-LIGHT	31
S233T100-1	PLATE, LIGHT; LEFT LIGHTING	31
S233T100-1	PLATE,WING & ANTI-ICE,LIGHTPLATE USED ON	31

S233T100-1	PLATE,WING & ANTI-ICE,LIGHTPLATE USED ON	31
S233T100-1	WINDSHIELD CLEARANCE PANEL ASSEMBLY M10023	31
S233T100-1	PLATE,WING & ANTI-ICE,LIGHTPLATE USED ON	31
S233T100-1	PLATE,WING & ANTI-ICE,LIGHTPLATE USED ON	31
S233T100-1	PLATE,WING & ANTI-ICE,LIGHTPLATE USED ON	33
S233T100-1	PLATE,WING & ANTI-ICE,LIGHTPLATE USED ON	31
S233T100-1	PLATE, LIGHT; LEFT LIGHTING	31
S233T100-1	PLATE, LIGHT; LEFT LIGHTING	33
S233T100-1	WING AND ENGINE ANTI-ICE CONTROL PANEL ASSEMBL	33
S233T100-1	PLATE,WING & ANTI-ICE,LIGHTPLATE USED ON	33
S233T100-1	PLATE,WING & ANTI-ICE,LIGHTPLATE USED ON	30
S233T100-1	PLATE, LIGHT; LEFT LIGHTING	28
S233T100-2	PLATE,WING & ANTI-ICE,LIGHTPLATE USED ON	33
S233T100-4	PLATE,WING & ANTI-ICE,LIGHTPLATE USED ON	31
S233T100-5	PLATE, AUTO BRAKE-LIGHT	31
S233T100-5	PLATE,WING & ANTI-ICE,LIGHTPLATE USED ON	33
S233T100-5	PLATE,WING & ANTI-ICE,LIGHTPLATE USED ON	33
S233T100-5	PLATE,WING & ANTI-ICE,LIGHTPLATE USED ON	33
S233T100-5	PLATE ASSY, AUDIO SELECTOR,PANEL USED	31
S233T100-5	PLATE,WING & ANTI-ICE,LIGHTPLATE USED ON	33
S233T100-5	PLATE, LIGHT; LEFT LIGHTING	31
S233T100-5	PLATE WING AND NOSE LANDING GEAR LIGHT	33
S233T100-5	PLATE, LIGHT; LEFT LIGHTING	33
S233T100-6	PLATE,WING & ANTI-ICE,LIGHTPLATE USED ON	31
S233T100-6	PLATE, LIGHT; LEFT LIGHTING	31
S233T100-6	PLATE,WING & ANTI-ICE,LIGHTPLATE USED ON	33
S233T100-6	PLATE, LIGHT; LEFT LIGHTING	31
S233T100-6	PLATE, LIGHT; LEFT LIGHTING	33
S233T100-6	RIGHT LIGHTING CONTROL PANEL ASSEMBLY M10057	33
S233T100-6	PLATE,WING & ANTI-ICE,LIGHTPLATE USED ON	31
S233T100-6	PLATE, LIGHT; LEFT LIGHTING	31
S233T100-6	PLATE,WING & ANTI-ICE,LIGHTPLATE USED ON	31

S233T100-6	PLATE,WING & ANTI-ICE,LIGHTPLATE USED ON	29
S233T100-6	RIGHT LIGHTING CONTROL PANEL ASSEMBLY M10057	33
S233T100-8	PLATE,WING & ANTI-ICE,LIGHTPLATE USED ON	76
S23995-003	SEAT, PAN ASSEMBLY.	25
S23995-004	SEAT, PAN ASSEMBLY.	25
S23995-004	SEAT, PAN ASSEMBLY.	25
S241T100-2	MCP-701/702 MODE CONTROL PANELS	22
S242A801-1	DISPLAY ELECTRONICS UNIT DIGITAL COMPUTER	31
S242A801-2	DISPLAY ELECTRONICS UNIT DIGITAL COMPUTER	34
S242N701-1	ENGINE AND ALERT PROCESSOR	31
S242N701-2	ENGINE AND ALERT PROCESSOR	31
S242N701-2	ENGINE AND ALERT PROCESSOR	31
S242T101-2	INERTIAL REFERENCE MODE PANEL	34
S242T101-2	INERTIAL REFERENCE MODE PANEL	34
S242T101-2	INERTIAL REFERENCE MODE PANEL	34
S242T101-2	INERTIAL REFERENCE MODE PANEL	34
S242T102-1	MULTIPURPOSE CONTROL DISPLAY UNIT	34
S242T102-1	MULTIPURPOSE CONTROL DISPLAY UNIT	34
S242T102--	MULTIPURPOSE CONTROL DISPLAY UNIT	
S242T102--	MULTIPURPOSE CONTROL DISPLAY UNIT	
S242T102--	MULTIPURPOSE CONTROL DISPLAY UNIT	
S242T102-1	MULTIPURPOSE CONTROL DISPLAY UNIT	34
S242T102--	MULTIPURPOSE CONTROL DISPLAY UNIT	
S242T404-3	EFIC-701 ELECTRONIC FLIGHT INSTRUMENT CONTROL	31
S242T404-4	EFIP-701D ELECTRONIC FLIGHT INSTRUMENT PROCESS	31
S242T404-4	EFIP-701D ELECTRONIC FLIGHT INSTRUMENT PROCESS	31
S242T404-4	EFIP-701D ELECTRONIC FLIGHT INSTRUMENT PROCESS	31
S242T404-4	EFIP-701D ELECTRONIC FLIGHT INSTRUMENT PROCESS	31
S242T404-4	EFIP-701D ELECTRONIC FLIGHT INSTRUMENT PROCESS	31
S242T404-5	ELECTRONIC DISPLAY UNIT AND RLS-701 REMOTE LIGHT	31
S242T404-5	ELECTRONIC DISPLAY UNIT AND RLS-701 REMOTE LIGHT	31
S242T404-5	EDU-766D/776D ELECTRONIC DISPLAY UNIT AND RLS-70	31

S242T404-5	EDU-766D/776D ELECTRONIC DISPLAY UNIT AND RLS-70	31
S242T404-6	ELECTRONIC DISPLAY UNIT AND RLS-701 REMOTE LIGHT	31
S242T404-6	EDU-766D/776D ELECTRONIC DISPLAY UNIT AND RLS-70	31
S251A200-1	ACTUATOR ASSEMBLY, INBOARD GROUND SPOILER	27
S251N111-1	FLIGHT SPOILER POWER CONTROL UNIT	27
S251N111-1	FLIGHT SPOILER POWER CONTROL UNIT	27
S251N111-1	FLIGHT SPOILER POWER CONTROL UNIT	
S251N111-1	FLIGHT SPOILER POWER CONTROL UNIT	27
S251N111-1	FLIGHT SPOILER POWER CONTROL UNIT	27
S251N111-4	FLIGHT SPOILER POWER CONTROL UNIT	27
S251N111-5	FLIGHT SPOILER POWER CONTROL UNIT	27
S251N111-6	FLIGHT SPOILER POWER CONTROL UNIT	27
S251N111-6	FLIGHT SPOILER POWER CONTROL UNIT	27
S251N111-7	FLIGHT SPOILER POWER CONTROL UNIT	27
S251N111-8	FLIGHT SPOILER POWER CONTROL UNIT	
S251N111-8	FLIGHT SPOILER POWER CONTROL UNIT	27
S251N111-9	FLIGHT SPOILER POWER CONTROL UNIT	27
S251N114-2	AILERON POWER CONTROL UNIT ASSEMBLY	27
S251N114-3	POWER CONTROL UNIT - AILERON	27
S251N114-4	AILERON POWER CONTROL UNIT ASSEMBLY	27
S251N114-5	AILERON POWER CONTROL UNIT ASSEMBLY	27
S251N115-3	LATERAL CONTROL AUTOPILOT SERVO ASSEMBLY	22
S251N115-4	LATERAL CONTROL AUTOPILOT SERVO ASSEMBLY	22
S251N115-6	LATERAL CONTROL AUTOPILOT SERVO ASSEMBLY	22
S251N117-5	ROTARY TRANSDUCER	27
S251N118-1	FLIGHT SPOILER POWER CONTROL UNIT	27
S251N118-5	FLIGHT SPOILER POWER CONTROL UNIT	27
S251N118-5	FLIGHT SPOILER POWER CONTROL UNIT	27
S251N118-6	FLIGHT SPOILER POWER CONTROL UNIT	
S251N118-6	FLIGHT SPOILER POWER CONTROL UNIT	27
S251N118-7	FLIGHT SPOILER POWER CONTROL UNIT	27
S251N118-8	FLIGHT SPOILER POWER CONTROL UNIT	

S251N118-8	FLIGHT SPOILER POWER CONTROL UNIT	27
S251N118-9	FLIGHT SPOILER POWER CONTROL UNIT	
S251N118-9	FLIGHT SPOILER POWER CONTROL UNIT	27
S251N211-1	ELEVATOR POWER CONTROL UNIT ASSY	27
S251N211-1	ELEVATOR POWER CONTROL UNIT ASSY	27
S251N211-1	ELEVATOR POWER CONTROL UNIT ASSY	27
S251N211-7	ELEVATOR POWER CONTROL UNIT ASSY	
S251N211-8	ELEVATOR POWER CONTROL UNIT ASSY	
S251N211-9	ELEVATOR POWER CONTROL UNIT ASSY	27
S251N212-2	PITCH CONTROL AUTOPILOT	22
S251N212-3	PITCH CONTROL AUTOPILOT	22
S251N212-4	PITCH CONTROL AUTOPILOT	22
S251N212-6	PITCH CONTROL AUTOPILOT	22
S251N233-3	DIFFERENTIAL PRESSURE SENSOR ASSEMBLY	27
S251N276	STABILIZER CONTROL BRAKE ASSEMBLY	27
S251N276-1	STABILIZER CONTROL BRAKE ASSEMBLY	27
S251N276-2	STABILIZER CONTROL BRAKE ASSEMBLY	27
S251N311-4	RUDDER POWER CONTROL UNIT ASSEMBLY	27
S251N311-5	RUDDER POWER CONTROL UNIT ASSEMBLY	27
S251N311-6	RUDDER POWER CONTROL UNIT ASSEMBLY	27
S251N311-8	RUDDER POWER CONTROL UNIT ASSEMBLY	27
S251N312-1	ROLLOUT GUIDANCE AUTOPILOT SERVO ASSEMBLY	22
S251N312-2	ROLLOUT GUIDANCE AUTOPILOT SERVO ASSEMBLY	22
S251N312-3	ROLLOUT GUIDANCE AUTOPILOT SERVO ASSEMBLY	22
S251N312-4	ROLLOUT GUIDANCE AUTOPILOT SERVO ASSEMBLY	22
S251N313-1	YAW DAMPER SERVO	27
S251N401-1	SCREW BALL, T/E FLAP, PRE SB 757-27A0139	27
S251N401-1	SCREW BALL, T/E FLAP, PRE SB 757-27A0139	27
S251N401-1	SCREW BALL, T/E FLAP, PRE SB 757-27A0139	27
S251N401-1	SCREW, BALL SCREW ASSY	27
S251N401-2	SCREW, BALL SCREW ASSY	27
S251N401-5	SCREW BALL, T/E FLAP, PRE SB 757-27A0139	27

S251N401-9	SCREW BALL, T/E FLAP, PRE SB 757-27A0139	27
S251N404-2	HYDRAULIC FLAP & SLAT CONTROL VALVE ASSEMBLY	27
S251T220-1	ELEVATOR FEEL SYSTEM COMPUTER ASSEMBLY	27
S251T220-3	ELEVATOR FEEL SYSTEM COMPUTER ASSEMBLY	27
S251T220-3	ELEVATOR FEEL SYSTEM COMPUTER ASSEMBLY	27
S251T220-4	ELEVATOR FEEL SYSTEM COMPUTER ASSEMBLY	
S251T220-5	ELEVATOR FEEL SYSTEM COMPUTER ASSEMBLY	27
S251T220-6	ELEVATOR FEEL SYSTEM COMPUTER ASSEMBLY	27
S251T220-8	ELEVATOR FEEL SYSTEM COMPUTER ASSEMBLY	27
S251T320-2	RUDDER TRIM ACTUATOR	27
S251T360-5	ACTUATOR SERVO RATIO CHANGER	27
S252T101-5	INBOARD AILERON POWER CONTROL ACTUATOR	27
S252T102-3	OUTBD AILERON LOCKOUT ACTUATOR ASSEMBLY	27
S252T102-4	OUTBD AILERON LOCKOUT ACTUATOR ASSEMBLY	27
S252T303-1	INBOARD SPOILER POWER CONTROL ACTUATOR ASSEM	27
S252T701-4	RUDDER POWER CONTROL ACTUATOR	27
S252T701-6	RUDDER POWER CONTROL ACTUATOR	27
S252T703-2	AUTOPILOT SERVO ASSEMBLY	22
S252T703-3	AUTOPILOT SERVO ASSEMBLY	22
S252T703-4	AUTOPILOT SERVO ASSEMBLY	22
S252T703-5	AUTOPILOT SERVO ASSEMBLY	22
S252T704-1	YAW DAMPER SERVO	22
S252T704-1	YAW DAMPER SERVO	22
S252T704-1	YAW DAMPER SERVO	22
S252T704-1	YAW DAMPER SERVO	22
S252T704-1	YAW DAMPER SERVO	22
S252T704-1	YAW DAMPER SERVO	22
S252T704-1	YAW DAMPER SERVO	22
S252T704-1	YAW DAMPER SERVO	22
S252T704-1	YAW DAMPER SERVO	22
S252T704-1	YAW DAMPER SERVO	22
S252T801-3	ELEVATOR POWER CONTROL ACTUATOR	27
S252T801-4	ELEVATOR POWER CONTROL ACTUATOR	27
S256A225-1	LEADING EDGE SLAT ACTUATOR ASSEMBLY	27

S256T006-1	MODULE FLAP AND SLAT HYD SHUT OFF VALVE	27
S256T006-1	MODULE FLAP AND SLAT HYD SHUT OFF VALVE	27
S256T007-1	SENSOR FLAP POSITION, USED ON B767 A/C 1	27
S270T002-3	MOTOR ACTUATED ROTARY SELECTOR VALVE	29
S270T201-6	PUMP, HYD ELEC DRIVEN (RB 291001935 PCG)	29
S270T242-1	NOSE GEAR STEERING CHECK VALVE MODULAR ASSEM	29
S271N101-6	POWER TRANSFER HYDRAULIC MOTORPUMP	29
S271N203-5	PRESSURE AND CASE DRAIN FILTER MODULE	29
S271N203-6	PRESSURE AND CASE DRAIN FILTER MODULE	29
S271N501-1	2-WAY 2-POSITION SHUTOFF BALL VALVE	29
S271N501-2	2-WAY 2-POSITION SHUTOFF BALL VALVE	29
S271T462-3	RESERVOIR FILL SELECTOR VALVE ASSEMBLY	29
S271T527-1	THRUST REVERSER INTERLOCK ACTUATOR	78
S271T527-4	THRUST REVERSER INTERLOCK ACTUATOR	78
S271T527-5	THRUST REVERSER INTERLOCK ACTUATOR	78
S271T527-6	THRUST REVERSER INTERLOCK ACTUATOR	78
S271T527-7	THRUST REVERSER INTERLOCK ACTUATOR	78
S272U860-5	FLOW RATE FUSE ASSEMBLY	29
S272U860-6	FLOW RATE FUSE ASSEMBLY	29
S272U860-7	FLOW RATE FUSE ASSEMBLY	29
S273N201-5	ACTUATOR ASSEMBLY, MAIN LANDING GEAR DOOR	32
S273N201-6	ACTUATOR ASSEMBLY, MAIN LANDING GEAR DOOR	32
S273N201-7	ACTUATOR ASSEMBLY, MAIN LANDING GEAR DOOR	32
S273N201-8	ACTUATOR ASSEMBLY, MAIN LANDING GEAR DOOR	32
S273N201-9	ACTUATOR ASSEMBLY, MAIN LANDING GEAR DOOR	32
S273N203-2	MODULE, LANDING GEAR CONTROL.....	32
S273N203-4	FUSE ASSEMBLY, QUANTITY MEASURING	32
S273T461-1	MOTOR OPERATED 4 WAY VALVE	32
S274A100-1	FUSE ASSEMBLY, QUANTITY MEASURING	29
S274A100-2	FUSE ASSEMBLY, QUANTITY MEASURING	29
S274A100-3	FUSE ASSEMBLY, QUANTITY MEASURING	29
S274A100-5	FUSE ASSEMBLY, QUANTITY MEASURING	32

S274A100-6	FUSE ASSEMBLY, QUANTITY MEASURING	32
S274A101-1	VALVE BRAKE METERING-STEEL DISC ALT 60B0	32
S274A101-2	ACCUMULATOR ASSEMBLY	32
S274A101-3	ACCUMULATOR HYDRAULIC ASSEMBLY	32
S274T111-2	VALVE ASSEMBLY-FUSE SELF RESETTING	32
S274T120-1	AUTOBRAKE SELECTOR SWITCH ASSEMBLY	32
S274T120-1	AUTO-BRAKE SHUTTLE VALVE MODULE	32
S274T120-1	VALVE MODULE, ANTI-SKID SHUTTLE	32
S274T120-3	AUTO-BRAKE SHUTTLE VALVE MODULE	32
S274T120-3	AUTO-BRAKE SHUTTLE VALVE MODULE	32
S274T120-6	AUTOBRAKE SELECTOR SWITCH ASSEMBLY	32
S274T120-7	AUTO-BRAKE SHUTTLE VALVE MODULE	32
S274T120-8	AUTOBRAKE SELECTOR SWITCH ASSEMBLY	32
S274T120-9	AUTO-BRAKE SHUTTLE VALVE MODULE	32
S274T402-1	VALVE DUAL BRAKE METERING	32
S274T402-2	DUAL BRAKE METERING VALVE	32
S274T402-3	VALVE DUAL BRAKE METERING	32
S274T402-3	DUAL BRAKE METERING VALVE	32
S274T402-5	VALVE DUAL BRAKE METERING	32
S275A210-3	STEERING VALVE ASSEMBLY	32
S275T412-3	VALVE HYD, NLG PRIORITY ALT S275T412-4	32
S275T412-5	VALVE HYD, NLG PRIORITY ALT S275T412-4	32
S281W501-	BATTERY MAIN DC POWER SHELF LIFE 3 MONTH	24
S282T002-1	NICKEL CADMIUM BATTERY	24
S283A301-4	UNIT, ANTI-SKID CONTROL,BRAKES	32
S283N202-2	WASTE TANK OVERFILL DETECTOR	38
S283T001-1	ANTISKID/AUTOBRAKE CONTROL UNIT	32
S283T001-1	ANTISKID/AUTOBRAKE CONTROL UNIT	32
S283T001-1	ANTISKID/AUTOBRAKE CONTROL UNIT	32
S283T001-1	ANTISKID/AUTOBRAKE CONTROL UNIT	32
S283T001-1	ANTISKID/AUTOBRAKE CONTROL UNIT	32
S283T001-1	ANTISKID/AUTOBRAKE CONTROL UNIT	32

S283T001-1	ANTISKID/AUTOBRAKE CONTROL UNIT	32
S283T001-2	VALVE, ANTI-SKID NORTHWEST PART...	32
S283T001-2	ANTISKID/AUTOBRAKE CONTROL UNIT	32
S283T001-2	ANTISKID/AUTOBRAKE CONTROL UNIT	32
S283T001-2	ANTISKID/AUTOBRAKE CONTROL UNIT	32
S283T001-3	ANTISKID/AUTOBRAKE CONTROL UNIT	32
S283T001-8	ANTISKID/AUTOBRAKE CONTROL UNIT	32
S283T001-9	ANTISKID/AUTOBRAKE CONTROL UNIT	32
S283T012-1	LIGHT ANTI-COLLISION, WHITE, RH	33
S283T012-1	LIGHT ANTI-COLLISION, WHITE, RH	33
S283T012-2	STROBE LIGHT POWER SUPPLY	33
S283T012-2	STROBE LIGHT POWER SUPPLY	33
S283T012-2	STROBE LIGHT POWER SUPPLY	33
S283T012-3	LIGHT ANTI-COLLISION, WHITE, RH	33
S283T012-3	LIGHT ANTI-COLLISION, WHITE, RH	33
S283T012-8	LIGHT ANTI-COLLISION, WHITE, RH	33
S315A103-5	THRUST REVERSER COWL OPENING ACTUATOR	71
S315A103-6	THRUST REVERSER COWL OPENING ACTUATOR	71
S315A103-7	COWL OPENING HYDRAULIC POWER UNIT ASSEMBLY	78
S315N370-1	SYNCHRO-SHAFT LOCK	78
S315N370-2	SYNCHRO-SHAFT LOCK	78
S315N370-3	SYNCHRO-SHAFT LOCK	78
S315T360-1	DIRECTIONAL CONTROL VALVE ASSEMBLY	78
S315T360-3	COWL OPENING HYDRAULIC POWER UNIT ASSEMBLY	78
S315T360-3	COWL OPENING HYDRAULIC POWER UNIT ASSEMBLY	78
S315T360-3	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	78
S315T360-3	COWL OPENING HYDRAULIC POWER UNIT ASSEMBLY	78
S315T360-4	COWL OPENING HYDRAULIC POWER UNIT ASSEMBLY	78
S315T360-4	COWL OPENING HYDRAULIC POWER UNIT ASSEMBLY	78
S315T360-4	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	78
S315T360-4	COWL OPENING HYDRAULIC POWER UNIT ASSEMBLY	78
S315T360-4	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	78

S315T360-4	COWL OPENING HYDRAULIC POWER UNIT ASSEMBLY	78
S315T360-5	COWL OPENING HYDRAULIC POWER UNIT ASSEMBLY	78
S315T360-5	COWL OPENING HYDRAULIC POWER UNIT ASSEMBLY	78
S315T363-4	COWL OPENING HYDRAULIC POWER UNIT ASSEMBLY	78
S315T363-6	THRUST REVERSER LOCKING ACTUATOR ASSEMBLY	78
S332A002-2	THREE INCH DIAMETER STARTER CONTROL VALVE	
S332N303-1	DUCT ANTI-ICE ALT S332N303-13 V8120	30
S332N303-1	DUCT PWA4060 QEC MUST BE USABLE ON DELTA	71
S332N303-8	HARNESS, FAN CASE,..	36
S332T004-1	GAGE PRESSURE SWITCH	79
S332T004-1	GAGE PRESSURE SWITCH	79
S332T004-2	GAGE PRESSURE SWITCH	79
S332T004-2	GAGE PRESSURE SWITCH	73
S332T004-2	GAGE PRESSURE SWITCH	79
S332T004-2	GAGE PRESSURE SWITCH	79
S332T004-3	GAGE PRESSURE SWITCH	73
S332T004-3	GAGE PRESSURE SWITCH	79
S332T004-3	GAGE PRESSURE SWITCH	79
S332T004-3	GAGE PRESSURE SWITCH	79
S332T004-5	GAGE PRESSURE SWITCH	79
S332T004-7	GAGE PRESSURE SWITCH	28
S332T004-9	GAGE PRESSURE SWITCH	79
S332T006-1	ENGINE OIL TRANSMITTER	79
S332T006-1	ENGINE OIL TRANSMITTER	79
S332T006-1	ENGINE OIL TRANSMITTER	79
S332T006-1	ENGINE OIL TRANSMITTER	79
S332T006-5	ENGINE OIL TRANSMITTER	79
S332T006-7	ENGINE OIL TRANSMITTER	79
S332T006-9	ENGINE OIL TRANSMITTER	79
S332T011-1	FIRE EXTINGUISHER CONTAINER	26
S332T011-2	FIRE EXTINGUISHER CONTAINER	26
S332T011-2	FIRE EXTINGUISHER CONTAINER	26

S332T011-2	FIRE EXTINGUISHER CONTAINER	26
S332T011-4	FIRE EXTINGUISHER CONTAINER	26
S332T011-5	FIRE EXTINGUISHER CONTAINER	26
S332T011-7	FIRE EXTINGUISHER CONTAINER	26
S332T100-1	FIRE DETECTOR ASSEMBLIES	26
S332T100-3	FIRE/OVERHEAT DETECTOR ASSEMBLY	26
S332T100-4	FIRE/OVERHEAT DETECTOR ASSEMBLY	26
S332T101-2	ENGINE FIRE AND OVERHEAT LOWER DETECTOR	26
S332T301-6	DETECTOR	26
S332T304-1	NBR 1 BEARING VIBRATION SENSOR ACCELEROMETER	71
S332T304-1	ACCELEROMETER	77
S332T305-2	NBR 4 BEARING OIL PRESSURE TRANSMITTER	79
S332T305-3	DIFFERENTIAL OIL PRESSURE TRANSMITTER	79
S332T305-5	NBR 4 BEARING OIL PRESSURE TRANSMITTER	79
S332T305-8	NBR 4 BEARING OIL PRESSURE TRANSMITTER	79
S34006-100	SEAT, PAN ASSEMBLY.	25
S34006-100	SEAT, PAN ASSEMBLY.	25
S34006-100	SEAT, PAN ASSEMBLY.	25
S34006-100	SEAT, PAN ASSEMBLY.	25
S34006-100	SEAT, PAN ASSEMBLY.	25
S34006-100	SEAT, PAN ASSEMBLY.	25
S343T003-1	ACTUATOR	28
S343T003-1	ACTUATOR	28
S343T003-2	FUEL SHUTOFF VALVE	28
S344N001-3	FUEL PRESENCE SENSOR SYSTEM CARD	28
S345N011-4	FUEL QUANTITY INDICATOR	28
S345N011-8	FUEL QUANTITY INDICATOR	28
S345T001-2	FUEL MEASURING STICK FLEXI-STICK ASSEMBLY	28
S416T208-1	ACTUATOR ASSEMBLY SPOILER OVERRIDE	25
S416T208-1	ACTUATOR ASSEMBLY SPOILER OVERRIDE	25
S416T208-1	ACTUATOR ASSEMBLY SPOILER OVERRIDE	25
S417N201-1	TANK POTABLE WATER ALT S417N201-1	38

S417T105-1	VALVE WASTE TANK DRAIN INITIAL PURCHASE	38
S417T105-1	VALVE WASTE TANK DRAIN INITIAL PURCHASE	38
S417T105-2	VALVE WASTE TANK DRAIN INITIAL PURCHASE	38
S417T105-7	VALVE WASTE TANK DRAIN INITIAL PURCHASE	38
S417T105-8	VALVE WASTE TANK DRAIN INITIAL PURCHASE	38
S453T201-1	BOTTLE FIRE, FWD CARGO FWD BOTTLE 800 CU	26
S453T201-1	BOTTLE FIRE, FWD CARGO FWD BOTTLE 800 CU	26
S453T201-1	BOTTLE FIRE, FWD CARGO FWD BOTTLE 800 CU	26
S453T201-2	BOTTLE FIRE, FWD CARGO FWD BOTTLE 800 CU	
S453T201-4	BOTTLE FIRE, FWD CARGO FWD BOTTLE 800 CU	26
S702Y0202	DETECTOR, FIRE, FAN.	26
S800-2000-	FLIGHT DATA RECORDER	31
S800-3000-	FLIGHT DATA RECORDER	31
SA3445-010	PRINTED CIRCUIT ASSEMBLY	31
SAS911-001	VALVE, ANTI-ICE, WING; A319/A320	30
SAS911-002	VALVE, ANTI-ICE, WING; A319/A320	30
SAS912-001	VALVE, ANTI-ICE, WING; A319/A320	30
SAS912-002	VALVE, ANTI-ICE, WING; A319/A320	30
SB0927030	SPRING ASSY, RUDDER LOAD FEEL AND TRIM	27
SB0927030	SPRING ASSY, RUDDER LOAD FEEL AND TRIM	27
SB209L1A1	ACCUMULATOR, LAF; A320;	29
SC4700-3	SERVOACTUATOR, FLIGHT, YAW DAMPNER	27
SC4700-4	SERVOACTUATOR, FLIGHT, YAW DAMPNER	27
SC4700-5	SERVOACTUATOR, FLIGHT, YAW DAMPNER	27
SE0932000	ROD,MLG OUTBOARD DOOR MECHANISM	32
SEDL0C9A	DUAL DUCT PRESSURE INDICATOR	36
SEDL0C9B	DUAL DUCT PRESSURE INDICATOR	36
SEDL0C9C	DUAL DUCT PRESSURE INDICATOR	21
SETL0C420	CABIN PRESSURIZATION INDICATOR	21
SR0927800	SPRING ASSY, RUDDER LOAD FEEL AND TRIM	27
SR0932005	RESERVOR MLG TORGUE ARM HYD DAMPER	32
SR0932006	CYLINDER MLG RETRACT, LH AND RH EQUIV 59	32

SR0932006	CYLINDER MLG RETRACT, LH AND RH EQUIV 59	32
SR0932006	CYLINDER MLG RETRACT, LH AND RH EQUIV 59	32
SR0936002	DUCT,WATER SEPARATOR TO CK VLV; RH	21
SR9029000	VALVE,HYDRAULIC, RESERVOIR BLEED,POST EO	29
SRDL0C12I	FLAP POSITION INDICATOR	27
SRL92F	INDICATR PNEUMATIC PRESSURE	36
ST12AE	TRNSMTTR HYD QTY	29
ST12BH	TRNSMTTR FLAP POSITION INDICATING	27
ST12S	TRNSMTTR, POSITION	29
ST3100-23-	HANDSET WITH SUPPORT BRACKET	23
ST3100-33-	HANDSET WITH SUPPORT BRACKET	23
SYLG51153	ACTUATOR, CARGO HANDLING,STOP LOCK FWD A	25
SYLZ52876	THERMSTT, PNEUMATIC DUCT, HIGH TEMP	30
SYLZ9885	VALVE,ANTI-ICING; DC9-50 ONLY	30
TAAI2-33CE	SEAT,CREW,PILOT,ELECT;HAS INSP	25
TAAI2-33CE	SEAT,CREW,PILOT,ELECT;HAS INSP	25
TAAI2-33CE	SEAT,CREW,PILOT,ELECT;HAS INSP	25
TAAI2-33PE	SEAT,CREW,PILOT,ELECT;HAS INSP	25
TAAI2-33PE	SEAT,CREW,PILOT,ELECT;HAS INSP	25
TAAI3-03CE	SEAT,CREW,PILOT,ELECT;HAS INSP	25
TAAI3-03CE	SEAT,CREW,PILOT,ELECT;HAS INSP	25
TAAI3-03CE	SEAT,CREW,PILOT,ELECT;HAS INSP	25
TAAI3-03PE	SEAT,CREW,PILOT,ELECT;HAS INSP	25
TAAI3-03PE	SEAT,CREW,PILOT,ELECT;HAS INSP	25
TAAI3-03PE	SEAT,CREW,PILOT,ELECT;HAS INSP	25
TAE0328-2	LIGHT, WING TIP, STROBE;AFT	33
TC174-00	T495 THERMOCOUPLE WIRIING HARNESS	77
TC174-01	T495 THERMOCOUPLE WIRIING HARNESS	77
TC174-02	T495 THERMOCOUPLE WIRIING HARNESS	77
TC200-00	T495 THERMOCOUPLE WIRIING HARNESS	77
TC200-01	T495 THERMOCOUPLE WIRIING HARNESS	77

TC200-02	T495 THERMOCOUPLE WIRIING HARNESS	77
TC254-01	EGT WIRING HARNESS	72
TC254-02	EGT WIRING HARNESS	72
TC255-01	EGT WIRING HARNESS	72
TC255-02	EGT WIRING HARNESS	72
TC255-03	EGT WIRING HARNESS	72
TC255-04	EGT WIRING HARNESS	72
TC296-02	PROBE T49.5	77
TC296-03	PROBE T49.5	77
TC296-04	PROBE T49.5	77
TD1702-100	TOILET TIMER SWITCH	38
TD1715-100	TOILET TIMER SWITCH	38
TY1801-03	ACTUATOR NON-LOCKING, LWR L/H REVERSER &	78
TY1801-03A	ACTUATOR NON-LOCKING, LWR L/H REVERSER &	78
TY1801-50	ACTUATOR NON-LOCKING, LWR L/H REVERSER &	78
TY1801-50A	ACTUATOR NON-LOCKING, LWR L/H REVERSER &	78
TY1802-04	ACTUATOR LOCKING, LOWER L/H & R/H REVERS	78
TY1802-50	ACTUATOR LOCKING, LOWER L/H & R/H REVERS	78
TY1878-20	SYNCHRO-SHAFT LOCK	78
TY1878-20A	SYNCHRO-SHAFT LOCK	78
TY1878-20B	SYNCHRO-SHAFT LOCK	78
TY1878-21	SYNCHRO-SHAFT LOCK	78
TY1878-21A	SYNCHRO-SHAFT LOCK	78
TY1878-21B	SYNCHRO-SHAFT LOCK	78
TY1878-21C	SYNCHRO-SHAFT LOCK	78
TY1878-22	SYNCHRO-SHAFT LOCK	78
TY1878-22A	SYNCHRO-SHAFT LOCK	78
TY1914-02	HANDWIND THRUST REVERSER MANUAL DRIVE	78
TY3515-01	TRAY, SFECU ARINC MOUNTING	27
TY3515-02	TRAY, SFECU ARINC MOUNTING	27
TY3530-02	SENSOR, FLAP SKEW, TRK 1	27
U431BAM0	UNIT, POWER SUPPLY, (ESDS)	27

U83B	THRUST REVERSER INTERLOCK ACTUATOR	22
V1-4360	VALVE ASSEMBLY FUSE SELF RESETTING	32
V1-4360-1	FUSE SELF RESETTING VALVE ASSEMBLY	32
V1-4360-2	FUSE SELF RESETTING VALVE ASSEMBLY	32
V2-4360	VALVE ASSEMBLY FUSE SELF RESETTING	32
V2-4360-1	VALVE ASSEMBLY FUSE SELF RESETTING	32
V2-4360-2	VALVE ASSEMBLY FUSE SELF RESETTING	32
V3400-283	VALVE SOLENOID, IDLE.	73
V3400-2830	VALVE SOLENOID, IDLE.	73
V3400-292	VALVE SOLENOID, IDLE.	73
V6-4360	VALVE ASSEMBLY-FUSE SELF RESETTING	32
V6-4360-1	VALVE ASSEMBLY-FUSE SELF RESETTING	32
V6-4360-2	VALVE ASSEMBLY-FUSE SELF RESETTING	32
VA4110	FAN, RECIRCULATION, CARGO COMPARTMENT;A3	21
VD3810	FAN, AIR, CARGO COMPT VENTILATION; A319/	21
VD3810-10	FAN, AIR, CARGO COMPT VENTILATION; A319/	21
VD3901-00	FAN, RECIRCULATION, LAV/GALLEY	21
VD3909-00	FAN, AIR, CARGO COMPT VENTILATION; A319/	21
WA03BYU3	SEAT, FLT ATTENDANT, DR2L; A319	25
WA16BYT3	SEAT, FLT ATTENDANT, DR2L; A319	25
WA46BYT3	SEAT, FLT ATTENDANT, DR2L; A319	25
WA46BYU3	SEAT, FLT ATTENDANT, DR2L; A319	25
WA54BYU3	SEAT, FLT ATTENDANT, DR2L; A319	25
WA76BYT3	SEAT, FLT ATTENDANT, DR2L; A319	25
WA93BYF3	SEAT, FLT ATTENDANT, DR2L; A319	25
WA93BYU3	SEAT, FLT ATTENDANT, DR2L; A319	25
WCS2056-1	EIGHT DIRECTION SWITCH ASSEMBLY	25
WL101AMS	INDICATR STANDBY ALTIMETR AND AIRSPEED	34
WL102AMS	ALTIMETER / AIRSPEED INDICATOR	34
WL102AMS	ALTIMETER / AIRSPEED INDICATOR	34
WL501RC1	CABIN RATE OF CLIMB INDICATOR	21
XW21090	MOTOR WINDSHIELD WIPER	30

Y35A	TRNSFRMR ROTATING VARIABLE LESS CONNECTO	27
Z220H0002	CONTROL UNIT, DRAIN MAST, A319	30
ZCDA2X02	RELAY,BATTERY CHARGER and TRNSFR PACKAGE	24
39-353	VALVE, ANTI-SKID BRAKE CONTROL	32
D434-56-00	ANNUNCTR, AUTO FLIGHT STATUS	22
113A4300-1	SPOILER ASSY; #3 FLT; LH WING	27
113A4300-2	SPOILER ASSY; #3 FLT; LH WING	27
113A4400-1	SPOILER ASSY; #4 FLT; LH WING	27
113A4400-2	SPOILER ASSY; #4 FLT; LH WING	27
152LMA23	INDICATR APU-EGT	49
LA2E20202	COMPUTER, FLT WARNING	31
LA2E20202	COMPUTER, FLT WARNING	31
LA2E20202	COMPUTER, FLT WARNING	31
LA2E20202	COMPUTER, FLT WARNING	31
LA2E20202	COMPUTER, FLT WARNING	31
LA2E20202	COMPUTER, FLT WARNING	31
LA2E20202	COMPUTER, FLT WARNING	31
LA2E20202	COMPUTER, FLT WARNING	31
LA2E20202	COMPUTER, FLT WARNING	31
LA2E20202	COMPUTER, FLT WARNING	31
LA2E20202	COMPUTER, FLT WARNING	31
LA2E20202	COMPUTER, FLT WARNING	31